

# CubeSuite+ V2.00.00

Integrated Development Environment

User's Manual: V850 Debug

Target Device

V850 Family

All information contained in these materials, including products and product specifications, represents information on the product at the time of publication and is subject to change by Renesas Electronics Corp. without notice. Please review the latest information published by Renesas Electronics Corp. through various means, including the Renesas Electronics Corp. website (<http://www.renesas.com>).

## Notice

1. Descriptions of circuits, software and other related information in this document are provided only to illustrate the operation of semiconductor products and application examples. You are fully responsible for the incorporation of these circuits, software, and information in the design of your equipment. Renesas Electronics assumes no responsibility for any losses incurred by you or third parties arising from the use of these circuits, software, or information.
2. Renesas Electronics has used reasonable care in preparing the information included in this document, but Renesas Electronics does not warrant that such information is error free. Renesas Electronics assumes no liability whatsoever for any damages incurred by you resulting from errors in or omissions from the information included herein.
3. Renesas Electronics does not assume any liability for infringement of patents, copyrights, or other intellectual property rights of third parties by or arising from the use of Renesas Electronics products or technical information described in this document. No license, express, implied or otherwise, is granted hereby under any patents, copyrights or other intellectual property rights of Renesas Electronics or others.
4. You should not alter, modify, copy, or otherwise misappropriate any Renesas Electronics product, whether in whole or in part. Renesas Electronics assumes no responsibility for any losses incurred by you or third parties arising from such alteration, modification, copy or otherwise misappropriation of Renesas Electronics product.
5. Renesas Electronics products are classified according to the following two quality grades: "Standard" and "High Quality". The recommended applications for each Renesas Electronics product depends on the product's quality grade, as indicated below.

"Standard": Computers; office equipment; communications equipment; test and measurement equipment; audio and visual equipment; home electronic appliances; machine tools; personal electronic equipment; and industrial robots etc.

"High Quality": Transportation equipment (automobiles, trains, ships, etc.); traffic control systems; anti-disaster systems; anti-crime systems; and safety equipment etc.

Renesas Electronics products are neither intended nor authorized for use in products or systems that may pose a direct threat to human life or bodily injury (artificial life support devices or systems, surgical implantations etc.), or may cause serious property damages (nuclear reactor control systems, military equipment etc.). You must check the quality grade of each Renesas Electronics product before using it in a particular application. You may not use any Renesas Electronics product for any application for which it is not intended. Renesas Electronics shall not be in any way liable for any damages or losses incurred by you or third parties arising from the use of any Renesas Electronics product for which the product is not intended by Renesas Electronics.
6. You should use the Renesas Electronics products described in this document within the range specified by Renesas Electronics, especially with respect to the maximum rating, operating supply voltage range, movement power voltage range, heat radiation characteristics, installation and other product characteristics. Renesas Electronics shall have no liability for malfunctions or damages arising out of the use of Renesas Electronics products beyond such specified ranges.
7. Although Renesas Electronics endeavors to improve the quality and reliability of its products, semiconductor products have specific characteristics such as the occurrence of failure at a certain rate and malfunctions under certain use conditions. Further, Renesas Electronics products are not subject to radiation resistance design. Please be sure to implement safety measures to guard them against the possibility of physical injury, and injury or damage caused by fire in the event of the failure of a Renesas Electronics product, such as safety design for hardware and software including but not limited to redundancy, fire control and malfunction prevention, appropriate treatment for aging degradation or any other appropriate measures. Because the evaluation of microcomputer software alone is very difficult, please evaluate the safety of the final products or systems manufactured by you.
8. Please contact a Renesas Electronics sales office for details as to environmental matters such as the environmental compatibility of each Renesas Electronics product. Please use Renesas Electronics products in compliance with all applicable laws and regulations that regulate the inclusion or use of controlled substances, including without limitation, the EU RoHS Directive. Renesas Electronics assumes no liability for damages or losses occurring as a result of your noncompliance with applicable laws and regulations.
9. Renesas Electronics products and technology may not be used for or incorporated into any products or systems whose manufacture, use, or sale is prohibited under any applicable domestic or foreign laws or regulations. You should not use Renesas Electronics products or technology described in this document for any purpose relating to military applications or use by the military, including but not limited to the development of weapons of mass destruction. When exporting the Renesas Electronics products or technology described in this document, you should comply with the applicable export control laws and regulations and follow the procedures required by such laws and regulations.
10. It is the responsibility of the buyer or distributor of Renesas Electronics products, who distributes, disposes of, or otherwise places the product with a third party, to notify such third party in advance of the contents and conditions set forth in this document, Renesas Electronics assumes no responsibility for any losses incurred by you or third parties as a result of unauthorized use of Renesas Electronics products.
11. This document may not be reproduced or duplicated in any form, in whole or in part, without prior written consent of Renesas Electronics.
12. Please contact a Renesas Electronics sales office if you have any questions regarding the information contained in this document or Renesas Electronics products, or if you have any other inquiries.

(Note 1) "Renesas Electronics" as used in this document means Renesas Electronics Corporation and also includes its majority-owned subsidiaries.

(Note 2) "Renesas Electronics product(s)" means any product developed or manufactured by or for Renesas Electronics.

# How to Use This Manual

This manual describes the role of the CubeSuite+ integrated development environment for developing applications and systems for V850 family, and provides an outline of its features.

CubeSuite+ is an integrated development environment (IDE) for V850 family, integrating the necessary tools for the development phase of software (e.g. design, implementation, and debugging) into a single platform.

By providing an integrated environment, it is possible to perform all development using just this product, without the need to use many different tools separately.

<b>Readers</b>	This manual is intended for users who wish to understand the functions of the CubeSuite+ and design software and hardware application systems.												
<b>Purpose</b>	This manual is intended to give users an understanding of the functions of the CubeSuite+ to use for reference in developing the hardware or software of systems using these devices.												
<b>Organization</b>	This manual can be broadly divided into the following units.												
	<b>CHAPTER 1 GENERAL</b> <b>CHAPTER 2 FUNCTIONS</b> <b>APPENDIX A WINDOW REFERENCE</b> <b>APPENDIX B USER OPEN INTERFACE</b> <b>APPENDIX C INDEX</b>												
<b>How to Read This Manual</b>	It is assumed that the readers of this manual have general knowledge of electricity, logic circuits, and microcontrollers.												
<b>Conventions</b>	<table><tr><td>Data significance:</td><td>Higher digits on the left and lower digits on the right</td></tr><tr><td>Active low representation:</td><td>XXX (overscore over pin or signal name)</td></tr><tr><td>Note:</td><td>Footnote for item marked with Note in the text</td></tr><tr><td>Caution:</td><td>Information requiring particular attention</td></tr><tr><td>Remark:</td><td>Supplementary information</td></tr><tr><td>Numeric representation:</td><td>Decimal ... XXXX Hexadecimal ... 0xFFFF</td></tr></table>	Data significance:	Higher digits on the left and lower digits on the right	Active low representation:	XXX (overscore over pin or signal name)	Note:	Footnote for item marked with Note in the text	Caution:	Information requiring particular attention	Remark:	Supplementary information	Numeric representation:	Decimal ... XXXX Hexadecimal ... 0xFFFF
Data significance:	Higher digits on the left and lower digits on the right												
Active low representation:	XXX (overscore over pin or signal name)												
Note:	Footnote for item marked with Note in the text												
Caution:	Information requiring particular attention												
Remark:	Supplementary information												
Numeric representation:	Decimal ... XXXX Hexadecimal ... 0xFFFF												

## Related Documents

The related documents indicated in this publication may include preliminary versions. However, preliminary versions are not marked as such.

Document Name	Document No.
CubeSuite+ Integrated Development Environment User's Manual	Start
	R20UT2444E
	V850 Design
	R20UT2134E
	R8C Design
	R20UT2135E
	RL78 Design
	R20UT2136E
	78K0R Design
	R20UT2137E
	78K0 Design
	R20UT2138E
	RX Coding
	R20UT2470E
	V850 Coding
	R20UT0553E
	Coding for CX Compiler
	R20UT2139E
	R8C Coding
	R20UT0576E
	RL78, 78K0R Coding
	R20UT2140E
	78K0 Coding
	R20UT2141E
	RX Build
	R20UT2472E
	V850 Build
	R20UT0557E
	Build for CX Compiler
	R20UT2142E
	R8C Build
	R20UT0575E
	RL78, 78K0R Build
	R20UT2143E
	78K0 Build
	R20UT0783E
	RX Debug
	R20UT2350E
	V850 Debug
	This manual
	R8C Debug
	R20UT0770E
	RL78 Debug
	R20UT2445E
	78K0R Debug
	R20UT0732E
	78K0 Debug
	R20UT0731E
	Analysis
	R20UT2447E
	Message
	R20UT2448E

**Caution** The related documents listed above are subject to change without notice. Be sure to use the latest edition of each document when designing.

# TABLE OF CONTENTS

## CHAPTER 1 GENERAL ... 8

- 1.1 Summary ... 8
- 1.2 Features ... 8

## CHAPTER 2 FUNCTIONS ... 10

- 2.1 Overview ... 10
- 2.2 Preparation before Debugging ... 13
  - 2.2.1 Confirm the connection to a host machine ... 13
- 2.3 Configuration of Operating Environment of the Debug Tool ... 17
  - 2.3.1 Select the debug tool to use ... 17
  - 2.3.2 [IECUBE]/[IECUBE2] ... 18
  - 2.3.3 [MINICUBE]/[MINICUBE2] ... 35
  - 2.3.4 [E1] ... 48
  - 2.3.5 [E20] ... 61
  - 2.3.6 [EZ Emulator] ... 74
  - 2.3.7 [Simulator] ... 81
- 2.4 Connect to/Disconnect from the Debug Tool ... 89
  - 2.4.1 Connect to the debug tool ... 89
  - 2.4.2 Disconnect from the debug tool ... 89
  - 2.4.3 Connect to the debug tool using hot plug-in [E1/E20(LPD)/(JTAG)[V850E2]] ... 90
- 2.5 Download/Upload Programs ... 92
  - 2.5.1 Execute downloading ... 92
  - 2.5.2 Advanced downloading ... 95
  - 2.5.3 Execute uploading ... 103
- 2.6 Display/Change Programs ... 105
  - 2.6.1 Display source files ... 105
  - 2.6.2 Display the result of disassembling ... 113
  - 2.6.3 Run a build in parallel with other operations ... 116
  - 2.6.4 Perform line assembly ... 117
- 2.7 Execute Programs ... 120
  - 2.7.1 Reset microcontroller (CPU) ... 121
  - 2.7.2 Execute programs ... 121
  - 2.7.3 Execute programs in steps ... 122
- 2.8 Stop Programs (Break) ... 125
  - 2.8.1 Stop the program manually ... 125
  - 2.8.2 Stop the program at the arbitrary position (breakpoint) ... 125
  - 2.8.3 Stop the program at the arbitrary position (break event) ... 128
  - 2.8.4 Stop the program with the access to variables/I/O registers ... 130
  - 2.8.5 Stop the program when an invalid execution is detected [IECUBE] ... 133
  - 2.8.6 Other break causes ... 134

2.9	Display/Change the Memory, Register and Variable ...	135
2.9.1	Display/change the memory ...	135
2.9.2	Display/change the CPU register ...	148
2.9.3	Display/change the I/O register ...	150
2.9.4	Display/change global variables/static variables ...	153
2.9.5	Display/change local variables ...	153
2.9.6	Display/change watch-expressions ...	155
2.10	Display Information on Function Call from Stack ...	162
2.10.1	Display call stack information ...	162
2.11	Collect Execution History of Programs [IECUBE][IECUBE2][Simulator] ...	164
2.11.1	Configure the trace operation ...	164
2.11.2	Collect execution history until stop of the execution ...	171
2.11.3	Collect execution history in the arbitrary section ...	171
2.11.4	Collect execution history only when the condition is met ...	173
2.11.5	Stop/restart collection of execution history ...	176
2.11.6	Display the collected execution history ...	176
2.11.7	Clear the trace memory ...	178
2.11.8	Search the trace data ...	178
2.11.9	Save the contents of execution history ...	183
2.12	Measure Execution Time of Programs ...	185
2.12.1	Measure execution time until stop of the execution ...	185
2.12.2	Measure execution time in the arbitrary section ...	186
2.12.3	Measurable time ranges ...	188
2.13	Measure Coverage [IECUBE][IECUBE2][Simulator] ...	190
2.13.1	Configure the coverage measurement ...	190
2.13.2	Display the coverage measurement result ...	193
2.14	Set an Action into Programs ...	195
2.14.1	Inset printf ...	195
2.15	Manage Events ...	198
2.15.1	Change the state of set events (valid/invalid) ...	198
2.15.2	Display only particular event types ...	199
2.15.3	Jump to the event address ...	199
2.15.4	Delete events ...	200
2.15.5	Write comment to events ...	200
2.15.6	Notes for setting events ...	200
2.16	Use Hook Function ...	206
2.17	Use the Simulator GUI [Simulator] ...	208
2.17.1	Check the I/O waveform of the microcontroller ...	209
2.17.2	Input signals to the pins ...	209
2.17.3	Perform serial communication ...	210
2.17.4	Use buttons, LEDs, level gauges, and other components ...	210
2.18	About Input Value ...	211
2.18.1	Input rule ...	211
2.18.2	Symbol name completion function ...	212
2.18.3	Icons for invalid input ...	212

## **APPENDIX A WINDOW REFERENCE ... 213**

**A.1 Description ... 213**

## **APPENDIX B USER OPEN INTERFACE ... 541**

**B.1 Overview ... 541**

**B.1.1 Types of interface functions ... 542**

**B.1.2 Interface methods ... 542**

**B.1.3 Development environment ... 543**

**B.2 Creating User Model ... 544**

**B.2.1 Program configuration ... 544**

**B.2.2 Outline of programming ... 545**

**B.2.3 Example of program file (UserModel.c) ... 547**

**B.2.4 Compilation and linking ... 548**

**B.3 Embedding User Model ... 549**

**B.3.1 Description in simulator configuration file ... 549**

**B.3.2 Example of simulator configuration file ... 551**

**B.4 Supplied Interface Functions ... 553**

**B.4.1 Overview ... 553**

**B.4.2 Basic interface functions ... 555**

**B.4.3 Time interface functions ... 559**

**B.4.4 Pin interface functions ... 566**

**B.4.5 External bus interface functions ... 575**

**B.4.6 Serial interface functions ... 582**

**B.4.7 Signal output unit interface functions ... 601**

**B.4.8 Error numbers ... 607**

**B.5 User-Defined Functions ... 608**

**B.6 Sample Program (Timer Model) ... 622**

**B.6.1 Overview ... 622**

**B.6.2 Configuration ... 622**

**B.6.3 Operation ... 622**

**B.6.4 Project file ... 622**

**B.6.5 Details of program ... 623**

## **APPENDIX C INDEX ... 627**

## CHAPTER 1 GENERAL

CubeSuite+ is a platform of an integrated developing environment for RX family, V850 family, R8C family ([Localised support](#)), RL78 family, 78K0R microcontrollers, 78K0 microcontrollers.

CubeSuite+ can run all the operations needed for developing the programs such as designing, coding, building, debugging, and flash programming.

In this manual, the debugging is explained out of those operations needed for the program development.

In this chapter, an overview of debugging products that CubeSuite+ provides is explained.

**Remark** Localised support

"Localised support " refers to specific regions support only.

CubeSuite+ for R8C (including NC30) is shipped and supported to the following regions only.

- Renesas Electronics Hong Kong Limited
- Renesas Electronics (China) Co., Ltd.
- Renesas Electronics (Shanghai) Co., Ltd.

### 1.1 Summary

You can effectively debug/simulate the program developed for the V850 family, using the debugger which CubeSuite+ provides.

### 1.2 Features

The following are the features of the debugger provided by CubeSuite+.

- Connecting to the various debug tools

A pleasant debugging environment for target systems is provided by connecting to Full-spec Emulators (IECUBE/IECUBE2), On-chip Debugging Emulators (MINICUBE/MINICUBE2/E1/E20/EZ Emulator) and Simulator.

- C source text and disassembled text are shown mixed

The C source text and the disassembled text are shown mixed on the same panel.

- Source level debugging and instruction level debugging

The source level debugging and the instruction level debugging for a C source program can be done.

- Support of flash self programming emulation (Code flash)

**[V850E1][V850ES]**

Flash self programming emulation can be performed with IECUBE.

**[V850E2]**

Flash self programming emulation (including settings of option bytes) can be performed with all of the connectable debug tools.

- Data flash memory writing function

When the selected microcontroller incorporates the data flash memory, the contents of data flash memory (including ID tag) can be displayed and modified by the same access method as an ordinary memory operation (except for Simulator).

- Real-time display update function

The contents of memory, registers and variables are automatically updated not only when the program execution is stopped, but also in execution.

- Save/restore the debugging environment

The debugging environment such as breakpoints, event configuration information, file download information, display condition/position of the panel, etc. can be saved.

## CHAPTER 2 FUNCTIONS

This chapter describes a debugging process of CubeSuite+ and main functions for debugging.

### 2.1 Overview

The basic debugging sequence for programs using CubeSuite+ is as follows:

#### (1) Start CubeSuite+

Launch CubeSuite+ from the [Start] menu of Windows.

**Remark** For details on "Start CubeSuite+", see "CubeSuite+ Integrated Development Environment User's Manual: Start".

#### (2) Set a project

Create a new project, or load an existing one.

**Remark** For details on "Set a project", see "CubeSuite+ Integrated Development Environment User's Manual: Start".

#### (3) Create a load module

Create a load module by running a build after setting of the active project and the build tool to be used.

**Remark** For details on "Create a load module" with CA850/CX, see "CubeSuite+ Integrated Development Environment User's Manual: Build".

#### (4) Confirm the connection to a host machine

Connect the debug tool (IECUBE, IECUBE2, MINICUBE, MINICUBE2, E1, E20, EZ Emulator or Simulator) to be used to a host machine.

#### (5) Select the debug tool to use

Select the debug tool to be used in a project.

**Remark** The selectable debug tool differs depending on the microcontroller type to be used in a project.

#### (6) Configure operating environment of the debug tool

Configure the operating environment of the debug tool selected in steps (5).

- [\[IECUBE\]/\[IECUBE2\]](#)
- [\[MINICUBE\]/\[MINICUBE2\]](#)
- [\[E1\]](#)
- [\[E20\]](#)
- [\[EZ Emulator\]](#)
- [\[Simulator\]](#)

#### (7) Connect to the debug tool

Connect the debug tool to CubeSuite+ to start communication.

#### (8) Execute downloading

Download the load module created in steps (3) to the debug tool.

**(9) Display source files**

Display the contents of the downloaded load module (source files) on the [Editor panel](#) or [Disassemble panel](#).

**(10) Execute programs**

Execute the program by using the operation method corresponding to a purpose.

If you wish to stop the program at the arbitrary position, set a breakpoint/break event<sup>Note</sup> before executing the program (see "[2.8.2 Stop the program at the arbitrary position \(breakpoint\)](#)", "[2.8.3 Stop the program at the arbitrary position \(break event\)](#)", or "[2.8.4 Stop the program with the access to variables/I/O registers](#)").

**Note** These functions are implemented by setting events to the debug tool used.

See "[2.15.6 Notes for setting events](#)", when you use events.

**Remark [V850E2]**

When the selected microcontroller version supports multi-core, select a core ( $PE_n$ ) to be debugged on the [Debug Manager panel \[V850E2\]](#) before executing the program.

**(11) Stop the program manually**

Stop the program currently being executed.

Note that if a breakpoint or a break event has been set in steps [\(10\)](#), the program execution will be stopped automatically when the set break condition is met.

**(12) Check the result of the program execution**

Check the following information that the debug tool acquired by the program execution.

- [Display/Change the Memory, Register and Variable](#)
- [Display Information on Function Call from Stack](#)
- [Collect Execution History of Programs \[IECUBE\]\[IECUBE2\]\[Simulator\]](#)<sup>Note</sup>
- [Measure Execution Time of Programs](#)<sup>Note</sup>
- [Measure Coverage \[IECUBE\]\[IECUBE2\]\[Simulator\]](#)

**Note** These functions are implemented by setting events to the debug tool used.

See "[2.15.6 Notes for setting events](#)", when you use events.

Debug the program, repeating steps [\(9\)](#) to [\(12\)](#) as required.

Note that if the program is modified during debugging, steps [\(3\)](#) and [\(8\)](#) also should be repeated.

**Remarks 1.** Other than the above, you can also check the result of the program execution by using the following functions.

- [Set an Action into Programs](#)
  - [Use Hook Function](#)
  - [Use the Simulator GUI \[Simulator\]](#)
- 2.** The acquired information can be saved to a file.
- [Save the disassembled text contents](#)
  - [Save the memory contents](#)
  - [Save the CPU register contents](#)
  - [Save the I/O register contents](#)
  - [Save the contents of local variables](#)
  - [Save the contents of watch-expressions](#)
  - [Save the contents of call stack information](#)
  - [Save the contents of execution history](#)

**(13) Execute uploading**

Save the program (the memory contents) to a file in the arbitrary format (e.g. Intel hex format, binary data format, and etc.), as required.

**(14) Disconnect from the debug tool**

Disconnect the debug tool from CubeSuite+ to terminate communication.

**(15) Save the project file**

Save the setting information of the project to the project file.

**Remark** For details on "Save the project file", see "CubeSuite+ Integrated Development Environment User's Manual: Start".

## 2.2 Preparation before Debugging

This section describes the preparation to start debugging the created program.

### 2.2.1 Confirm the connection to a host machine

Connection examples for each debug tool are shown.

Note that the relationship between the microcontroller selected in the project and the connectable debug tools is as the following table.

**Remark** "(Serial)", "(LPD)" or "(JTAG)" in the table below means that E1/E20 is used with serial communications, LPD communications or JTAG communications.

**Table 2-1. Relationship between Types of Microcontroller and Connectable Debug Tools**

Type of Microcontroller	Debug Tool						
	IECUBE	IECUBE2	MINICUBE E1/E20(JTAG)	MINICUBE2 E1/E20(Serial)	E1/E20(LPD)	Simulator	EZ Emulator
V850E1	✓	-	✓	✓	-	✓	✓
V850ES	✓	-	✓	✓	-	✓	✓
V850E2 (Single-core)	-	✓ Note	✓	✓ Note	✓ Note	✓	-
V850E2 (Multi-core)	-	-	✓	-	-	-	-

#### Note [V850E2]

Depending on the type of the microcontroller to be selected, this debug tool may not be supported.


- (1) [IECUBE]
- (2) [IECUBE2]
- (3) [MINICUBE]
- (4) [MINICUBE2]
- (5) [E1]
- (6) [E20]
- (7) [EZ Emulator]
- (8) [Simulator]

#### (1) [IECUBE]

Connect a host machine and IECUBE. If required, connect a target board, too.

See IECUBE User's Manual for details on the connection method.

**Figure 2-1. Connection Example [IECUBE]**




**(2) [IECUBE2]**

Connect a host machine and IECUBE2. If required, connect a target board, too.

See IECUBE2 User's Manual for details on the connection method.


Figure 2-2. Connection Example [IECUBE2]

**(3) [MINICUBE]**

Connect a host machine and MINICUBE. If required, connect a target board, too.

See MINICUBE User's Manual for details on the connection method.


Figure 2-3. Connection Example [MINICUBE]

**(4) [MINICUBE2]**

Connect a host machine and MINICUBE2. If required, connect a target board, too.

See MINICUBE2 User's Manual for details on the connection method.

Figure 2-4. Connection Example [MINICUBE2]




## (5) [E1]

Connect a host machine and E1. If required, connect a target board, too.

See E1 User's Manual for details on the connection method.

**Figure 2-5. Connection Example [E1]**




**Remark** You can make a choice among serial communications [**E1(Serial)**], LPD communications [**E1(LPD)**] and JTAG communications [**E1(JTAG)**] as the communication method to the target board (see "[2.3.1 Select the debug tool to use](#)").

## (6) [E20]

Connect a host machine and E20. If required, connect a target board, too.

See E20 User's Manual for details on the connection method.

**Figure 2-6. Connection Example [E20]**




**Remark** You can make a choice among serial communications [**E1(Serial)**], LPD communications [**E1(LPD)**] and JTAG communications [**E1(JTAG)**] as the communication method to the target board (see "[2.3.1 Select the debug tool to use](#)").

## (7) [EZ Emulator]

Connect a host machine and an evaluation kit

See EZ Emulator User's Manual for details on the connection method.


**Figure 2-7. Connection Example [EZ Emulator]**



**(8) [Simulator]**

A host machine is only needed for debugging (emulators are not needed).

**Figure 2-8. Connection Example [Simulator]**



### 2.3 Configuration of Operating Environment of the Debug Tool

This section describes the configuration of the operating environment for each debug tool.


#### 2.3.1 Select the debug tool to use

You can configure the operating environment in the [Property panel](#) corresponding to the debug tool to use.

Therefore, first, select the debug tool to be used in a project (the debug tool to be used can be specified in the individual projects).

To select or switch the debug tool, use the context menu shown by right clicking on the [*Microcontroller type Debug tool name (Debug Tool)*] node on the [Project Tree panel](#).

**Figure 2-9. Select/Switch Debug Tool to Use**



**Caution** The context menu items displayed differ depending on the microcontroller selected in the project (see "[Table 2-1. Relationship between Types of Microcontroller and Connectable Debug Tools](#)").

**Remark [E1][E20]**

- Select [*Microcontroller type E1(Serial)*]/[*Microcontroller type E20(Serial)*] to use E1/E20 in the serial communication mode.
- Select [*Microcontroller type E1(LPD)*]/[*Microcontroller type E20(LPD)*] to use E1/E20 in the LPD communication mode.
- Select [*Microcontroller type E1(JTAG)*]/[*Microcontroller type E20(JTAG)*] to use E1/E20 in the JTAG communication mode.


If the [Property panel](#) is already open, click the [*Microcontroller type Debug tool name (Debug Tool)*] node again. The view switches to the Property panel of the selected debug tool.

If the Property panel is not open, double-click the above mentioned node to open the corresponding Property panel.


### 2.3.2 [IECUBE]/[IECUBE2]

Configure the operating environment on the [Property panel](#) below when using IECUBE/IECUBE2.

**Figure 2-10. Example of Property Panel [IECUBE]**



**Figure 2-11. Example of Property Panel [IECUBE2]**



Follow the steps below by selecting the corresponding tab on the [Property panel](#).

- (1) [Connect Settings] tab
- (2) [Debug Tool Settings] tab
- (3) [Flash Self Emulation Settings] tab [IECUBE]
- (4) [DataFlash Emulation Settings] tab [IECUBE]
- (5) [Download File Settings] tab
- (6) [Flash Options Settings] tab [IECUBE2]
- (7) [Hook Transaction Settings] tab

**(1) [Connect Settings] tab**

In the [\[Connect Settings\] tab](#), configuration with regard to the connection to the debug tool can be done.

- (a) [\[Internal ROM/RAM\]](#)
- (b) [\[DataFlash\] \[IECUBE\]](#)
- (c) [\[Clock\]](#)
- (d) [\[Connection with Target Board\]](#)
- (e) [\[Programmable I/O\] \[IECUBE\]](#)
- (f) [\[Flash\] \[IECUBE2\]](#)

**(a) [Internal ROM/RAM]**

You can configure internal ROM/RAM in this category.

The size of internal ROM/RAM of the selected microcontroller is specified by default (when the selected microcontroller is the V850E1 core and incorporates VSB Flash ROM/VSB RAM, the value including its size is specified).

**Remark** There is no need to change the settings in this category if you wish to debug with the same memory mapping of the selected microcontroller.

**Figure 2-12. [Internal ROM/RAM] Category [IECUBE]**

<b>Internal ROM/RAM</b>	
Size of internal ROM[KBytes]	256
Size of internal RAM[Bytes]	16384

**Figure 2-13. [Internal ROM/RAM] Category [IECUBE2]**

<b>Internal ROM/RAM</b>	
Size of internal ROM[KBytes]	3072
Size of internal RAM[Bytes]	245760
Size of DataFlash memory[KBytes]	32

**<1> [Size of internal ROM[KBytes]]****- [IECUBE]**

Specify the internal ROM size to emulate (unit: Kbytes).

To perform debugging using IECUBE memory resources after changing the memory mapping, make a selection from the drop-down list.

Note that when the selected microcontroller is a ROMless product, the property value cannot be changed.

**- [IECUBE2]**

The internal ROM size to emulate is displayed (unit: Kbytes).

You cannot change the value of this property.

**<2> [Size of internal RAM[Bytes]]****- [IECUBE]**

Specify the internal RAM size to emulate (unit: bytes).

To perform debugging using IECUBE memory resources after changing the memory mapping, make a selection from the drop-down list.

**- [IECUBE2]**

The internal RAM size to emulate is displayed (unit: bytes).

You cannot change the value of this property.

**<3> [Size of DataFlash memory[KBytes]] [IECUBE2]**

The size of the data flash memory area of the selected microcontroller is displayed (unit: Kbytes).

You cannot change the value of this property.

**Caution [IECUBE]**

**You should be careful not to overlap the area with other memory mapping area.**

** mark in the setting column indicates that if you change the setting of this property value, CPU reset is generated automatically.**

**(b) [DataFlash] [IECUBE]**

You can configure the data flash function in this category.

Note that this category appears only when the selected microcontroller incorporates the data flash memory.

**Figure 2-14. [DataFlash] Category**

<b>DataFlash</b>	
Use DataFlash memory area	Yes
Size of DataFlash memory[KBytes]	32
Chip select	CS0

**<1> [Use DataFlash memory area]**

Specify whether to use the data flash memory from the drop-down list.

Select [Yes] to use the data flash memory ([No] is selected by default).

**<2> [Size of DataFlash memory[KBytes]]**

This property appears only when the [Use DataFlash memory area] property is set to [Yes].

The size of the data flash memory area of the selected microcontroller is displayed (unit: Kbytes).

You cannot change the value of this property.

**<3> [Chip select]**

This property appears only when the [Use DataFlash memory area] property is set to [Yes].

Select the chip select used for mapping of the data flash memory from the drop-down list.

The selectable chip select values differ depending on the selected microcontroller.

Note that when the selected microcontroller is the V850ES core, you cannot change the value of the property.

**(c) [Clock]**

You can configure the clock in this category.

**Figure 2-15. [Clock] Category [IECUBE]**

<b>Clock</b>	
Main clock frequency [MHz]	4.00
Main clock multiply rate	1
Sub clock frequency[kHz]	32.768
Monitor clock	System

Figure 2-16. [Clock] Category [IECUBE2]

<b>Clock</b>	
Main clock frequency [MHz]	8.00
CPU clock frequency [MHz]	80.00

## &lt;1&gt; [Main clock frequency [MHz]]

Specify the main clock frequency (before multiplication).

You can specify the frequency from the drop-down list or by directly entering a frequency value between 0.001 and 999.999 (unit: MHz).

The drop-down list displays the following frequencies (unit: MHz).

- [V850E1][V850ES]

2.50, 4.00 (default), 5.00, 6.00, 8.00, 13.50, 18.00

- [V850E2]

4.00, 5.00, 7.20, 8.00 (default), 9.60, 10.00, 13.50, 16.00

## &lt;2&gt; [Main clock multiply rate] [IECUBE]

Specify the main clock frequency multiplier.

Select a value from the drop-down list or directly enter a value from 1 to 99.

The drop-down list displays the following multiplier values.

1 (default), 2, 3, 4, 5, 6, 7, 8, 9, 10

## &lt;3&gt; [Sub clock frequency[kHz]] [IECUBE]

This property appears only when the selected microcontroller supports a sub clock.

Specify the sub clock frequency.

You can specify the frequency from the drop-down list or by directly entering a frequency value between 0.001 and 999.999 (unit: kHz).

The drop-down list displays sub clock frequency values which can be used by the currently selected microcontroller (if the frequency value which can be used is fixed, the drop-down list does not appear).

The minimum usable sub clock frequency is specified by default.

## &lt;4&gt; [Monitor clock] [IECUBE]

This property appears only when the selected microcontroller supports a sub clock.

Specify from the following drop-down list a clock on which the monitor program operates while the program is stopped.

System	Operates with main clock (default).
User	Operates with the clock that the program specified.

## &lt;5&gt; [CPU clock frequency[MHz]] [IECUBE2]

Specify the CPU clock frequency for the trace time display.

Directly enter the value between 0.001 and 999.999 (unit: MHz) ([80.00] is specified by default).

**(d) [Connection with Target Board]**

You can configure the connection to the target board in this category.

**Figure 2-17. [Connection with Target Board] Category [IECUBE][IECUBE2]**

<input type="checkbox"/> <b>Connection with Target Board</b>	Connecting with target board	No
--	------------------------------	----

**<1> [Connecting with target board]**

Specify if the target board is connected to IECUBE/IECUBE2 or not, from the drop-down list.

Select [Yes] when the target board is connected to IECUBE/IECUBE2 ([No] is selected by default).

**Caution This property cannot be changed when IECUBE is connected to CubeSuite+.**

**(e) [Programmable I/O] [IECUBE]**

You can configure the programmable I/O area in this category.

Note that this category appears only when the selected microcontroller supports the programmable I/O area.

**Remark** Change this setting to temporarily change variables while debugging.

To set a common value for the project, in the Property panel of the build tool, on the [Common Options] tab, in the [Device] category, set the value in [Programmable I/O area start address] property.

**Figure 2-18. [Programmable I/O] Category**

<input type="checkbox"/> <b>Programmable I/O</b>	Use Programmable I/O area	Yes
	Programmable I/O area start address	<input checked="" type="checkbox"/> 0

**<1> [Use Programmable I/O area]**

Specify whether to use the programmable I/O area.

Select [Yes] to use the programmable I/O area ([No] is selected by default).

**<2> [Programmable I/O area start address]**

This property appears only when the [Use Programmable I/O area] property is set to [Yes].

Specify the start address of the programmable I/O area.

Specify the address within the programmable I/O area ([0] is specified by default).

The address is aligned to 16 Kbytes.

**(f) [Flash] [IECUBE2]**

You can configure the flash self programming function in this category.

**Figure 2-19. [Flash] Category**

<input type="checkbox"/> <b>Flash</b>	Using the flash self programming	No
---------------------------------------	----------------------------------	----

**<1> [Using the flash self programming]**

Specify whether to rewrite the internal flash ROM by using the flash self library of the flash self programming function, from the drop-down list.

Select [Yes] to rewrite the internal flash ROM ([No] is selected by default).  
 Note that if [Yes] is selected in this property, the internal flash ROM will not be cashed.

**Caution** This property cannot be changed when IECUBE2 is connected to CubeSuite+.

## (2) [Debug Tool Settings] tab

In the [Debug Tool Settings] tab, general configurations on the debug tool can be done.

- (a) [Memory]
- (b) [Access Memory While Running]
- (c) [Set Event While Running]
- (d) [Break]
- (e) [Fail-safe Break] [IECUBE]
- (f) [Trace]
- (g) [Timer]
- (h) [Coverage]
- (i) [Mask for Input Signal]
- (j) [External Flash Memory Download]

### (a) [Memory]

You can configure the memory in this category.

Figure 2-20. [Memory] Category [IECUBE][IECUBE2]

<b>Memory</b>	
Memory mappings	[4]
[0]	Internal ROM area
[1]	Non-map area
[2]	Internal RAM area
[3]	I/O Register area
Verify on writing to memory	Yes

### <1> [Memory mappings]

Current memory mapping status is displayed for each type of memory area.

The memory mapping status cannot be changed on this panel. If it is necessary to add a memory mapping, click on the [Memory Mapping] property, and click on the [...] button that appears on the right end of the setting field. The [Memory Mapping dialog box](#) opens; perform the setting from there.

See the section for the [Memory Mapping dialog box](#) for details on how to configure the parameters.

Figure 2-21. Opening Memory Mapping Dialog Box



**Caution** If you are not connected to a debug tool, then only memory mapping areas added by user is displayed.

Connecting to a debug tool (see "[2.4.1 Connect to the debug tool](#)") will display details for each memory type.

## &lt;2&gt; [Verify on writing to memory]

Specify whether to perform a verify check when the memory value is initialized, from the drop-down list.  
Select [Yes] to perform verification (default).

## (b) [Access Memory While Running]

You can configure the memory access while executing a program (the real-time display update function) in this category. See "[\(4\) Display/modify the memory contents during program execution](#)" for details on the real-time display update function.

Figure 2-22. [Access Memory While Running] Category [IECUBE]

<b>Access Memory While Running</b>	
Access by stopping execution	<b>Yes</b>
Update display during the execution	Yes
Display update interval[ms]	500
Set update display during the execution automatically	Yes
Access by release HALT mode	Yes

Figure 2-23. [Access Memory While Running] Category [IECUBE2]

<b>Access Memory While Running</b>	
Access during the execution	<b>Yes</b>
Access by stopping execution	<b>Yes</b>
Access by release HALT mode	<b>No</b>
Update display during the execution	Yes
Display update interval[ms]	500

## &lt;1&gt; [Access during the execution] [IECUBE2]

Specify whether to allow access to the internal RAM area during execution of a program, from the drop-down list.

When the [\[Using the flash self programming\]](#) property in the [Flash] category is set to [No], the internal ROM area is subject to this setting, as with the internal RAM.  
Select [Yes] to allow access ([No] is selected by default).

## &lt;2&gt; [Access by stopping execution]

This property does not appear when the [\[Access during the execution\] \[IECUBE2\]](#) property is set to [No].  
For a memory area not accessible during execution of a program (e.g. target memory area/I/O register area), specify whether to allow access to the area by temporary stopping the execution, from the drop-down list.

If the [\[Using the flash self programming\]](#) property in the [Flash] category is set to [No], then the internal ROM area is handled the same as the internal RAM area.  
Select [Yes] to allow access ([No] is selected by default).

**Remark [V850E2]**

For the internal RAM area, accesses are allowed without temporary stopping regardless of this property setting.

## &lt;3&gt; [Access by release HALT mode]

This property appears only when the [\[Access by stopping execution\]](#) property is set to [Yes].  
Specify whether to allow access to a memory area other than the internal RAM (CPU registers/I/O registers) by releasing the HALT mode, from the drop-down list. For a memory area other than the

internal RAM, the HALT mode cannot be released. If the [Using the flash self programming] property in the [Flash] category is set to [No], then the internal ROM area is handled the same as the internal RAM area.

Select [Yes] to allow access to the memory area by releasing the HALT mode (default).

#### <4> [Update display during the execution]

Specify whether to automatically update the contents in the [Watch panel/Memory panel](#) display during execution of a program.

Select [Yes] to update the display (default).

**Caution [IECUBE]**

This property becomes invalid when the [\[Use for trace data\]](#) property in the [Trace] category is set to [Trace] (see "[2.11.1 Configure the trace operation](#)").

#### <5> [Display update interval[ms]]

This property appears only when the [\[Update display during the execution\]](#) property is set to [Yes].

Specify the interval in 100 ms unit to automatically update the contents in the [Watch panel/Memory panel](#) display during execution of a program.

Directly specify the Integer number between 100 and 65500 (rounding up the fractions less than 100ms) ([500] is selected by default).

#### <6> [Set update display during the execution automatically] [IECUBE]


This property appears only when the [\[Update display during the execution\]](#) property is set to [Yes].

Select [Yes] when letting the IECUBE set the area displayed in the [Watch panel/Memory panel](#) as automatically as possible as an area to be updated by the real-time display update function and updating the displayed content during execution of the program (default).

### (c) [Set Event While Running]

You can configure the setting of events while executing a program in this category.

Figure 2-24. [Set Event While Running] Category



#### <1> [Set event by stopping execution momentarily]

Specify whether to forcibly pause the execution for events that cannot be set while executing a program or operating the tracer/timer.

For details on the event types that are affected by this property, see "[\(2\) Event types that can be set and deleted during execution](#)".

Select [Yes] to set events above while execution ([No] is selected by default).

**(d) [Break]**

You can configure the break function in this category.

**Figure 2-25. [Break] Category [IECUBE][IECUBE2]**

<b>Break</b>	
First using type of breakpoint	Software break
Stop emulation of peripherals when stopping	No
Use open break function	No(Output signal)

**<1> [First using type of breakpoint]**

This property does not appear when the number of the breakpoint type available for the selected microcontroller is only one.

Specify from the following drop-down list a breakpoint type to use with priority when setting it with a one click operation of the mouse in the [Editor panel/Disassemble panel](#).

See "[2.8.2 Stop the program at the arbitrary position \(breakpoint\)](#)" for details on breakpoints.

Software break	Sets software breakpoint with priority (default).
Hardware break	Sets hardware breakpoint with priority.

**<2> [Stop emulation of peripherals when stopping]**

Specify from the drop-down list whether the peripheral emulation function of emulator is stopped while stopping the program execution.

Select [Yes] to terminate ([No] is selected by default).

**<3> [Use open break function]**

This property appears only when the selected microcontroller supports the open break function.

Specify from the following drop-down list whether to use the open break function.

Yes(Hi-Z)	The open break target pin becomes the Hi-Z state after the CPU is stopped.
No(Output signal)	The open break target pin outputs the signal even after the CPU is stopped (default).

**(e) [Fail-safe Break] [IECUBE]**

You can configure the fail-safe break function in this category.

See "[2.8.5 Stop the program when an invalid execution is detected \[IECUBE\]](#)" for details on the fail-safe break function and this category configuration.

**(f) [Trace]**

You can configure the trace function in this category.

See "[2.11 Collect Execution History of Programs \[IECUBE\]\[IECUBE2\]\[Simulator\]](#)" for details on the trace function and this category configuration.

**(g) [Timer]**

You can configure the timer function in this category.

See "[2.12 Measure Execution Time of Programs](#)" for details on the timer function.

**Caution [IECUBE2]**

**This category become invalid when the [Use for trace data] property in the [Trace] category is set to other than [Timer].**

Figure 2-26. [Timer] Category [IECUBE]

<input checked="" type="checkbox"/> <b>Timer</b>	Rate of frequency division of timer	1/1(20ns/1.4min)
--	-------------------------------------	------------------

Figure 2-27. [Timer] Category [IECUBE2]

<input checked="" type="checkbox"/> <b>Timer</b>	Rate of frequency division of timer	1/1(5ns/21.4s)
--	-------------------------------------	----------------

**<1> [Rate of frequency division of timer]**

Specify the frequency division ratio of the timer counter (32 bits, 50 MHz [IECUBE]/33 bits, 200 MHz [IECUBE2]) used for timer measurement, from the drop-down list.

In the drop-down list, following frequency division ratios are shown (resolution/maximum measurement time are shown in "( )").

**- [IECUBE]**

1/1(20ns/1.4min) (default),	1/2(40ns/2.8min),	1/4(80ns/5.7min),
1/8(160ns/11.4min),	1/16(320ns/22.8min),	1/32(640ns/45.6min),
1/64(1280ns/1.5h),	1/128(2560ns/3.0h),	1/256(5120ns/6.0h),
1/512(10240ns/12.2h),	1/1024(20480ns/24.4h),	1/2048(40960ns/48.8h) ,
1/4096(81920ns/97.6h)		

**- [IECUBE2]**

1/1(5ns/42.9s) (default),	1/2(10ns/1.4min),	1/4(20ns/2.8min),
1/8(40ns/5.71min),	1/16(80ns/11.42min),	1/32(160ns/22.8min),
1/64(320ns/45.6min),	1/128(640ns/1.5h),	1/256(1280ns/3.0h),
1/512(2560ns/6.0h),	1/1024(5120ns/12.2h),	1/2048(10240ns/24.4h),
1/4096(20480ns/48.8h),	1/8192(40960ns/97.6h),	1/16384(81920ns/195.2h)

**(h) [Coverage]**

You can configure the coverage function in this category.

See "[2.13 Measure Coverage \[IECUBE\]\[IECUBE2\]\[Simulator\]](#)" for details on the coverage function and this category configuration.

**(i) [Mask for Input Signal]**

You can configure the input signal masking in this category.

Figure 2-28. [Mask for Input Signal] Category [IECUBE]

<input checked="" type="checkbox"/> <b>Mask for Input Signal</b>	
Mask NMI0 signal	No
Mask NMI1 signal	No
Mask NMI2 signal	No
Mask HLDREQ signal	No
Mask RESET signal	No
Mask STOP signal	No
Mask WAIT signal	No

Figure 2-29. [Mask for Input Signal] Category [IECUBE2]

<b>Mask for Input Signal</b>	
Mask HLDREQ signal	No
Mask STOP signal	No
Mask WAIT signal	No
MASK of RESET signal	Mask TARGET RESET signal

With the properties shown below, select [Yes] to mask the signal from the drop-down list (all properties below are set to [No] by default).

#### - [IECUBE]

- [Mask NMI $n$  signal]
- [Mask HLDREQ signal]<sup>Note 1</sup>
- [Mask RESET signal]
- [Mask STOP signal]
- [Mask WAIT signal]<sup>Note 1</sup>

#### - [IECUBE2]

- [Mask HLDREQ signal]<sup>Note 1</sup>
- [Mask STOP signal]
- [Mask WAIT signal]<sup>Note 1</sup>
- [Mask of RESET signal]<sup>Note 2</sup>

- Notes**
1. When [No] is specified with the [Connection with Target Board] property in the [Connect Setting] tab, these properties are fixed to [Yes] after connecting to the debug tool (changes not allowed).
  2. Select either one of [Mask TARGET RESET signal] (default) or [Mask TARGET RESET signal and INTERNAL RESET signal] to mask RESET signal. If you do not wish to mask RESET signal, then select [Do not mask] (note, however, that this item appears only when [Yes] is specified with the [Connection with Target Board] property in the [Connect Setting] tab).

#### (j) [External Flash Memory Download]

You can configure downloading to an external flash memory in this category.

See "[\(5\) Download to external flash memory \[IECUBE\]\[IECUBE2\]\[MINICUBE\]\[E1/E20\(LPD\)/\(JTAG\)\]](#)" for details on how to download to an external flash memory and this category configuration.

### (3) [Flash Self Emulation Settings] tab [IECUBE]

In the [Flash Self Emulation Settings] tab [IECUBE] tab, general configurations on flash self programming emulation (Code flash) can be done.

Note that this tab appears only when the selected microcontroller incorporates the flash memory.

For the list of availability of emulation for flash function, and the cautions, see [\[Special notes on flash self programming emuration\]](#).

- (a) [Flash Self Emulation]
- (b) [Macro Service Error]
- (c) [Security Flag Emulation]
- (d) [Reset Vector/Boot Swap]

#### (a) [Flash Self Emulation]

You can configure the flash self programming emulation function in this category.

Figure 2-30. [Flash Self Emulation] Category

<b>Flash Self Emulation</b>	
Flash self-programming	No
Flash Macro service specification	Flash self-programming Ver. 2.00 or earlier

**<1> [Flash self-programming]**

Specify whether to use the flash self programming emulation function, from the drop-down list.  
Select [Yes] to use the flash self programming emulation function ([No] is selected by default).

**<2> [Flash Macro service specification]**

This property appears only when the flash memory process is Type01<sup>Note</sup>.  
Select a specification of the flash macro service from the following drop-down list.

Flash self programming Ver.2.00 or earlier (default)
Flash self programming Ver.3.00 or later

**Note** The determination of the flash memory process is made when connected to the debug tool.  
Consequently, this will not be hidden when disconnected from the debug tool.

**(b) [Macro Service Error]**

In this category, you can configure the operation of flash functions in the self programming library, that are used for the flash macro service when performing the flash self programing.

For details on the flash functions, see "V850 Microcontrollers Flash Memory Self Programming Library Type0x".

Figure 2-31. [Macro Service Error] Category

<b>Macro Service Error</b>	
Generate FlashBlockErase error	No
Generate FlashBlockIVerify error	No
Generate FlashWordWrite error	No
Generate FlashBlockBlankCheck error	No
Generate FlashSetInfo error	No
Generate FlashFLMDCheck error	No

With the following properties, specify whether to return the error value when the flash memory is damaged (the error returned when the flash memory is damaged will not be generated during normal emulation).  
Select [Yes] to return the error value (all the properties are set to [Yes] by default).

- [Generate FlashBlockErase error]
- [Generate FlashBlockVerify error]
- [Generate FlashWordWrite error]
- [Generate FlashBlockBlankCheck error]
- [Generate FlashSetInfo error]
- [Generate FlashFLMDCheck error]

**(c) [Security Flag Emulation]**

You can configure the function on the security flag emulation in this category.

The initial value of the security flag is emulated when the security has been set to the flash memory.

Figure 2-32. [Security Flag Emulation] Category

<b>□ Security Flag Emulation</b>	
Disable flash ROM erase	No
Disable block erase	No
Disable read	No
Disable program	No
Disable boot block cluster reprogram	No

**<1> [Disable flash ROM erase]**

This property appears only when the flash memory used supports this function.

Specify whether to emulate to disable flash ROM erase, from the drop-down list.

Select [Yes] to emulate to disable flash ROM erase ([No] is selected by default).

**<2> [Disable block erase]**

Specify whether to emulate to disable block erase, from the drop-down list.

Select [Yes] to emulate to disable block erase ([No] is selected by default).

**<3> [Disable read]**

This property does not appear when the flash memory process is Type01 and the specification type of the flash self programming is Ver.2.00 or earlier<sup>Note</sup>.

Specify whether to emulate to disable reading, from the drop-down list.

Select [Yes] to emulate to disable reading ([No] is selected by default).

**Note** The determination of the flash memory process is made when connected to the debug tool.

Consequently, this will not be hidden when disconnected from the debug tool.

**<4> [Disable program]**

Specify whether to emulate to disable writing, from the drop-down list.

Select [Yes] to emulate to disable writing ([No] is selected by default).

**<5> [Disable boot block cluster reprogram]**

This property appears only when the flash memory process is Type02, Type03 or Type04<sup>Note</sup>.

Specify whether to emulate to disable rewrite boot area, from the drop-down list.

Select [Yes] to emulate to disable rewrite boot area ([No] is selected by default).

**Note** The determination of the flash memory process is made when connected to the debug tool.

Consequently, this will not be hidden when disconnected from the debug tool.

**(d) [Reset Vector/Boot Swap]**

You can configure the reset vector and boot swap function in this category.

Figure 2-33. [Reset Vector/Boot Swap] Category

<b>□ Reset Vector/Boot Swap</b>	
Reset vector address	<input type="button" value="HEX"/> 0
Boot swap cluster	0

**<1> [Reset vector address]**

This property appears only when the flash memory process is Type01 and the specification type of the flash self programming is Ver.3.00 or later<sup>Note</sup>.

Specify the reset vector address.

Directly enter the value in hexadecimal number from 0x0 to 0xFFFFFFFF ([0] is specified by default).

**Note** The determination of the flash memory process is made when connected to the debug tool.

Consequently, this will not be hidden when disconnected from the debug tool.

**<2> [Boot swap cluster]**

This property appears only when the flash memory process is Type04<sup>Note</sup>.

Specify the target area of boot swap clusters.

Directly enter the value in decimal number from 0 to 127 ([0] is specified by default). The value set in this property is reflected to the target area in a boot block cluster. Prohibition of boot area rewriting can be set to the target area of boot swap clusters by using the microcontroller's security function.

[Table 2-2. Relationship between Boot Swap Cluster and Boot Block Cluster](#) below shows the relationship between the value set in this property and the target area of boot block clusters.

**Note** The determination of the flash memory process is made when connected to the debug tool.

Consequently, this will not be hidden when disconnected from the debug tool.

**Table 2-2. Relationship between Boot Swap Cluster and Boot Block Cluster**

Value to Be Set	When The Product's Flash Memory Size Is 256 KBytes or Smaller		When The Product's Flash Memory Size Is 384 KBytes or Larger	
	Boot Block Clusters	Boot Swap Clusters	Boot Block Clusters	Boot Swap Clusters
0	00000H - 007FFH	00000H - 01FFFFH	00000H - 007FFH	RESV - 03FFFFH
1	RESV - 00FFFFH		RESV - 01FFFFH	
2	RESV - 017FFFH		RESV - 02FFFFH	
3	RESV - 01FFFFH		RESV - 03FFFFH	
4	RESV - 027FFFH	00000H - 03FFFFH	RESV - 04FFFFH	RESV - 07FFFFH
:	:		:	
7	RESV - 03FFFFH		RESV - 07FFFFH	
8	RESV - 047FFFH	00000H - 07FFFFH	RESV - 08FFFFH	RESV - 0FFFFFH
:	:		:	
15	RESV - 07FFFFH		RESV - 0FFFFFH	
16	RESV - 087FFFH	00000H - 0FFFFH	RESV - 10FFFFH	RESV - 1FFFFFH
:	:		:	
31	RESV - 0FFFFFH		RESV - 1FFFFFH	
32	RESV - 107FFFH		RESV - 20FFFFH	
:	:		:	
127	RESV - 3FFFFFH		RESV - 7FFFFFH	

**(4) [DataFlash Emulation Settings] tab [IECUBE]**

In the [DataFlash Emulation Settings] tab [IECUBE], general configurations on the data flash emulation function can be done.


Note that this tab appears only when the selected microcontroller incorporates the data flash memory.

- (a) [DataFlash Emulation]
- (b) [EEPROM Library Error]
- (c) [Writing Time/Erasing Time]

**(a) [DataFlash Emulation]**

You can configure the data flash emulation function in this category.

**Figure 2-34. [DataFlash Emulation] Category**



**<1> [DataFlash emulation]**

Specify whether to use the data flash emulation function, from the drop-down list.

Select [Yes] to use the data flash emulation function ([No] is selected by default).

**(b) [EEPROM Library Error]**

You can configure the EEPROM emulation library in this category.

Specify the operation for the EEPROM emulation library functions.

For details on the EEPROM emulation library functions, see "V850 Microcontrollers Flash Memory Self Programming Library Type0x".

**Figure 2-35. [EEPROM Library Error] Category**

<input type="checkbox"/> EEPROM Library Error	
Generate WordWrite error	<input checked="" type="checkbox"/> Yes
Address generated WordWrite error	<input type="checkbox"/> HEX 0
Generate BlockErase error	<input checked="" type="checkbox"/> Yes
Address generated BlockErase error	<input type="checkbox"/> HEX 0
Generate BlockIVerify error	<input checked="" type="checkbox"/> Yes
Address generated BlockIVerify error	<input type="checkbox"/> HEX 0
Generate BlockBlankCheck error	<input checked="" type="checkbox"/> Yes
Address generated BlockBlankCheck error	<input type="checkbox"/> HEX 0

With the properties shown below, specify whether to return error values in the corresponding functions to emulate from the drop-down list (the error values in the functions will not be generated during normal emulation). All properties below are set to [No] by default.

Select [Yes] to return the error values forcibly, then specify an address within the data flash memory, at which the corresponding function error is to be generated, in the [Address generated XXX error] property which is listed newly in the lower area. Directly enter the address in hexadecimal number from 0x0 to 0xFFFFFFFF (0) is specified by default).

- [Generate WordWrite error]
- [Generate BlockErase error]
- [Generate BlockIVerify error]
- [Generate BlockBlankCheck error]

### (c) [Writing Time/Erasing Time]

You can configure the delay time for writing to and erasing the data flash memory in this category.

Figure 2-36. [Writing Time/Erasing Time] Category

<input checked="" type="checkbox"/> Writing Time/Erasing Time	
Writing time	Typical number of times that is assumed by flash macro specifications
Erasing time	Typical number of times that is assumed by flash macro specifications

#### <1> [Writing time]

You can simulate the delay time for writing to the data flash memory.

Specify the value to simulate the delay time from the following drop-down list.

No retry	Specifies "0" as the number of times of retry. The delay time is 0 (the writing speed is fastest).
Typical number of times that is assumed by flash macro specifications	Specifies the typical number of times that is assumed by flash macro specifications (default).
Maximum number of times that is assumed by flash macro specifications	Specifies the maximum number of times that is assumed by flash macro specifications.
Retries for the maximum number of times specified	Specifies the maximum number of times of retry. The delay time is maximum (the writing speed is longest).

#### <2> [Erasing time]

You can simulate the delay time for erasing the data flash memory.

Specify the value to simulate the delay time from the following drop-down list.

No retry	Specifies "0" as the number of times of retry. The delay time is 0 (the erasing speed is fastest).
Typical number of times that is assumed by flash macro specifications	Specifies the typical number of times that is assumed by flash macro specifications (default).
Maximum number of times that is assumed by flash macro specifications	Specifies the maximum number of times that is assumed by flash macro specifications.
Retries for the maximum number of times specified	Specifies the maximum number of times of retry. The delay time is maximum (the erasing speed is longest).

### (5) [Download File Settings] tab

In the [Download File Settings] tab, configuration on downloading file to the debug tool can be done.

See "[2.5.1 Execute downloading](#)" for details on each category configuration.

### (6) [Flash Options Settings] tab [IECUBE2]

In the [Flash Options Settings] tab [V850E2], configuration on options for the flash memory incorporated in the V850E2 microcontroller can be done.

Note that this tab appears only when the selected V850E2 microcontroller supports the flash options.

To configure options, specify the corresponding items on the [Flash Options Setting dialog box \[V850E2\]](#), that is opened by clicking the [...] button appears at the right of the field by selecting the [Flash options] property in the [Flash Options] category on this tab (the [...] button appears only while connected to the debug tool).


Click the [Write] button on this dialog box after specifying each item.

See [Flash Options Setting dialog box \[V850E2\]](#) for details on the configuration.

Figure 2-37. Opening Flash Options Setting Dialog Box



Figure 2-38. Flash Options Settings (Flash Options Setting Dialog Box [IECUBE2])



#### (7) [Hook Transaction Settings] tab

In the [Hook Transaction Settings] tab, configuration on the hook transaction can be done.

See "[2.16 Use Hook Function](#)" for details on each category configuration and the function of the hook transaction.

### 2.3.3 [MINICUBE]/[MINICUBE2]

Configure the operating environment on the [Property panel](#) below when using MINICUBE/MINICUBE2.

Figure 2-39. Example of Property Panel [MINICUBE[V850E1][V850ES]]




Figure 2-40. Example of Property Panel [MINICUBE[V850E2]]




Figure 2-41. Example of Property Panel [MINICUBE2[V850E1][V850ES]]





Figure 2-42. Example of Property Panel [MINICUBE2[V850E2]]



Follow the steps below by selecting the corresponding tab on the [Property panel](#).

- (1) [\[Connect Settings\] tab](#)
- (2) [\[Debug Tool Settings\] tab](#)
- (3) [\[Download File Settings\] tab](#)
- (4) [\[Flash Options Settings\] tab \[V850E2\]](#)
- (5) [\[Hook Transaction Settings\] tab](#)

**(1) [Connect Settings] tab**

In the [\[Connect Settings\] tab](#), configuration with regard to the connection to the debug tool can be done.

- (a) [\[Internal ROM/RAM\]](#)
- (b) [\[DataFlash\] \[V850E1\]\[V850ES\]](#)
- (c) [\[Clock\]](#)
- (d) [\[Connection with Target Board\] \[MINICUBE2\]](#)
- (e) [\[Flash\]](#)
- (f) [\[Programmable I/O\] \[V850E1\]\[V850ES\]](#)

**(a) [Internal ROM/RAM]**

The configuration of internal ROM/RAM is displayed in this category.

**Figure 2-43. [Internal ROM/RAM] Category [MINICUBE[V850E1][V850ES]][MINICUBE2]**

<b>Internal ROM/RAM</b>	
Size of internal ROM[KBytes]	256
Size of internal RAM[Bytes]	16384

**Figure 2-44. [Internal ROM/RAM] Category [MINICUBE[V850E2]]**

<b>Internal ROM/RAM</b>	
Size of internal ROM[KBytes]	256
Size of internal RAM[Bytes]	16384
Size of DataFlash memory[KBytes]	16

**<1> [Size of internal ROM[KBytes]]**

The internal ROM size to emulate is displayed (unit: Kbytes).

If the selected microcontroller is the V850E1 core and incorporates VSB Flash ROM, it displays the value including the size of VSB Flash ROM.

You cannot change the value of this property.

**<2> [Size of internal RAM[Bytes]]**

The internal RAM size to emulate is displayed (unit: bytes).

If the selected microcontroller is the V850E1 core and incorporates VSB RAM, it displays the value including the size of VSB RAM. If the selected microcontroller version supports multi-core, it displays "total RAM size(RAM size for a core x the number of cores)".

You cannot change the value of this property.

**<3> [Size of DataFlash memory[KBytes]] [MINICUBE[V850E2]]**

The data flash memory size is displayed (unit: Kbytes).

If the currently selected microcontroller does not incorporate the data flash, [0] is displayed.

You cannot change the value of this property.

**(b) [DataFlash] [V850E1][V850ES]**

You can configure the data flash function in this category.

Note that this category appears only when the selected microcontroller incorporates the data flash memory.

Figure 2-45. [DataFlash] Category

<b>DataFlash</b>	
Use DataFlash memory area	Yes
Size of DataFlash memory[KBytes]	32
Chip select	CS0

**<1> [Use DataFlash memory area]**

Specify whether to use the data flash memory, from the drop-down list.

Select [Yes] to use the data flash memory ([No] is selected by default).

**<2> [Size of DataFlash memory[KBytes]]**

This property appears only when the [Use DataFlash memory area] property is set to [Yes].

The size of the data flash memory area of the selected microcontroller is displayed (unit: Kbytes).

You cannot change the value of this property.

**<3> [Chip select]**

This property appears only when the [Use DataFlash memory area] property is set to [Yes].

Select the chip select used for mapping of the data flash memory from the drop-down list.

The selectable chip select values differ depending on the selected microcontroller.

Note that when the selected microcontroller is other than the V850ES core, you cannot change the value of the property.

**(c) [Clock]**

You can configure the clock in this category.

Figure 2-46. [Clock] Category [MINICUBE[V850E1][V850ES]]

<b>Clock</b>	
Main clock frequency [MHz]	4.00
Main clock multiply rate	1
Sub clock frequency[kHz]	32.768
Monitor clock	System
TCK/DCK clock [MHz]	10MHz

Figure 2-47. [Clock] Category [MINICUBE2[V850E1][V850ES]]

<b>Clock</b>	
Main clock frequency [MHz]	4.00
Main clock multiply rate	1
Sub clock frequency[kHz]	32.768
Monitor clock	System

Figure 2-48. [Clock] Category [MINICUBE[V850E2]] [MINICUBE2[V850E2]]

<b>Clock</b>	
Main clock frequency [MHz]	8.00
Timer clock frequency[MHz]	80.00

Figure 2-49. [Clock] Category [MINICUBE][MINICUBE2] (some products of V850E2)

<b>Clock</b>	
CPU clock frequency[MHz]	80.00
Timer clock frequency[MHz]	80.00

## &lt;1&gt; [Main clock frequency [MHz]]

Specify the main clock frequency (before multiplier).

You can specify the frequency from the drop-down list or by directly entering a frequency value between 0.001 and 999.999 (unit: MHz).

The drop-down list displays the following frequencies (unit: MHz).

- [V850E1][V850ES]

2.50, 4.00 (default), 5.00, 6.00, 8.00, 13.50, 18.00

- [V850E2]

4.00, 5.00, 7.20, 8.00 (default), 9.60, 10.00, 13.50, 16.00

**Caution [V850E2]**

This property does not appear when the [CPU clock frequency [MHz]] [V850E2] property is shown.

## &lt;2&gt; [Main clock multiply rate] [V850E1][V850ES]

Specify the main clock frequency multiplier.

Select a value from the drop-down list or directly enter a value from 1 to 99.

The drop-down list displays the following multiplier values.

1 (default), 2, 3, 4, 5, 6, 7, 8, 9, 10

## &lt;3&gt; [Sub clock frequency[kHz]] [V850E1][V850ES]

This property appears only when the selected microcontroller supports a sub clock.

Specify the sub clock frequency.

You can specify the frequency from the drop-down list or by directly entering a frequency value number between 0.001 and 999.999 (unit: kHz).

The usable sub clock frequency values differ depending on the selected microcontroller.

The drop-down list displays sub clock frequency values which can be used by the currently selected microcontroller.

The minimum usable sub clock frequency is specified by default.

## &lt;4&gt; [Monitor clock] [V850E1][V850ES]

This property appears only when the selected microcontroller supports a sub clock.

Specify a clock for monitor programs to operate while the program is stopped.

Specify from the following drop-down list.

System	Operates with main clock (default).
User	Operates with the clock that the program specified.

## &lt;5&gt; [TCK/DCK clock[MHz]] [MINICUBE[V850E1][V850ES]]

Specify a clock supplied from MINICUBE to the debug control unit (DCU), from the drop-down list.

The drop-down list displays the following frequency values.

10MHz (default), 20MHz

- Cautions 1.** Normally, do not change the setting from [10MHz].  
 When [20MHz] is specified, it may not be possible to connect to the debug tool.
2. This property cannot be changed when MINICUBE is connected to CubeSuite+.

**<6> [Timer clock frequency[MHz]] [V850E2]**

Specify the clock frequency for using timer function.

Directly enter the value between 0.001 and 999.999 (unit: MHz) ([80.00] is specified by default).

Note that this property cannot be changed when the [CPU clock frequency [MHz]] [V850E2] property is shown (this property is fixed to the same value as the [CPU clock frequency [MHz]] property).

**<7> [CPU clock frequency [MHz]] [V850E2]**

This property appears only for some products of V850E2.

Specify the CPU clock frequency (after multiplier).

You can specify the frequency from the drop-down list or by directly entering a frequency value between 0.001 and 999.999 (unit: MHz).

The drop-down list displays the following frequencies (unit: MHz).

80.00 (default), 100.00

**(d) [Connection with Target Board] [MINICUBE2]**

You can configure the connection between MINICUBE2 and the target board in this category.

Figure 2-50. [Connection with Target Board] Category [MINICUBE2]



**<1> [Communication method]**

Specify the port from the drop-down list to which to connect MINICUBE2 when performing serial communication between MINICUBE2 and the device on the target board.

The type of the port in the drop-down list differs depending on the selected microcontroller.

Note, however, that if the port that can be used for serial communication is limited by the currently selected microcontroller, it is not possible to change the communication method displayed by default (the default communication method depends on the currently selected microcontroller).

**Caution** This property cannot be changed when MINICUBE2 is connected to CubeSuite+.

**(e) [Flash]**

You can configure the flash memory rewriting in this category.

**Caution** Properties in this category cannot be changed when MINICUBE/MINICUBE2 is connected to CubeSuite+.

Figure 2-51. [Flash] Category [MINICUBE[V850E1][V850ES]]



Figure 2-52. [Flash] Category [MINICUBE[V850E2]]

<input type="checkbox"/> <b>Flash</b>	<input type="checkbox"/> Security ID Using the flash self programming	<input type="checkbox"/> <b>HEX</b> FFFFFFFFFFFFFFFFFFFF No
---------------------------------------	--	--

Figure 2-53. [Flash] Category [MINICUBE2[V850E1][V850ES]]

<input type="checkbox"/> <b>Flash</b>	<input type="checkbox"/> Security ID Erase flash ROM when starting	<input type="checkbox"/> <b>HEX</b> FFFFFFFFFFFFFFFFFFFF No
---------------------------------------	---	--

Figure 2-54. [Flash] Category [MINICUBE2[V850E2]]

<input type="checkbox"/> <b>Flash</b>	<input type="checkbox"/> Security ID Erase flash ROM when starting	<input type="checkbox"/> <b>HEX</b> FFFFFFFFFFFFFFFFFFFF No
---------------------------------------	---	--

**<1> [Security ID]**

This property appears only when the selected microcontroller supports the ROM security function (on-chip debug security ID) for flash memory.

Specify a security ID for reading codes in the internal ROM or internal flash memory.

For details on the on-chip debug security ID, see MINICUBE/MINICUBE2 User's Manual.

**- [V850E1][V850ES]**

Directly enter 20 digits hexadecimal number (10 bytes) ([FFFFFFFFFFFFFFFFFF]) is specified by default).

**- [V850E2]**

Directly enter 24 digits hexadecimal number (12 bytes) ([FFFFFFFFFFFFFFFFFF]) is specified by default).

**Remark [V850E1][V850ES]**

When you change the setting of the property, a message appears prompting you to select whether or not to change the security ID of the build tool.

**<2> [Using the flash self programming] [MINICUBE[V850E2]]**

Specify whether to rewrite the internal flash ROM by using the flash self library of the flash self programming function, from the drop-down list.

Select [Yes] to rewrite the internal flash ROM ([No] is selected by default).

Note that if [Yes] is selected in this property, the internal flash ROM will not be cashed.

**<3> [Erase flash ROM when starting] [MINICUBE2]**

Specify whether to erase flash ROM when connecting to the debug tool, from the drop-down list.

Select [Yes] to erase flash ROM ([No] is selected by default).

Note that this property is set to [No] after connecting to the debug tool.

**(f) [Programmable I/O] [V850E1][V850ES]**

You can configure the programmable I/O area in this category.

Note that this category is only valid when the selected microcontroller supports the programmable I/O area.

**Remark** Change this setting to temporarily change variables while debugging.  
To set a common value for the project, in the Property panel of the build tool, on the [Common Options] tab, in the [Device] category, set the value in [Programmable I/O area start address] property.

Figure 2-55. [Programmable I/O] Category



**<1> [Use Programmable I/O area]**

Specify whether to use the programmable I/O area.  
Select [Yes] to use the programmable I/O area ([No] is selected by default).

**<2> [Programmable I/O area start address]**

This property appears only when the [Use Programmable I/O area] property is set to [Yes].  
Specify the start address of the programmable I/O area.  
Specify the address within the programmable I/O area ([0] is specified by default).  
The address is aligned to 16 Kbytes.

**(2) [Debug Tool Settings] tab**

In the [Debug Tool Settings] tab, general configurations on the debug tool can be done.

- (a) [Memory]
- (b) [Access Memory While Running]
- (c) [Set Event While Running]
- (d) [Break]
- (e) [Mask for Input Signal]
- (f) [External Flash Memory Download] [MINICUBE]

**(a) [Memory]**

You can configure the memory in this category.

Figure 2-56. [Memory] Category [MINICUBE][MINICUBE2]

<b>Memory</b>	
<input checked="" type="checkbox"/> Memory mappings	<b>[4]</b>
<input checked="" type="checkbox"/> [0]	Internal ROM area
<input checked="" type="checkbox"/> [1]	Non-map area
<input checked="" type="checkbox"/> [2]	Internal RAM area
<input checked="" type="checkbox"/> [3]	I/O Register area
Verify on writing to memory	Yes

**<1> [Memory mappings]**

Current memory mapping status is displayed for each type of memory area.  
The memory mapping status cannot be changed on this panel. If it is necessary to add a memory mapping, click on the [Memory Mapping] property, and click on the [...] button that appears on the right end of the setting field. The [Memory Mapping dialog box](#) opens; perform the setting from there.  
See the section for the [Memory Mapping dialog box](#) for details on how to configure the parameters.

Figure 2-57. Opening Memory Mapping Dialog Box

<input type="checkbox"/> Memory	
<input type="checkbox"/> Memory mappings	[4]
<input type="checkbox"/> [0]	Internal ROM area
<input type="checkbox"/> [1]	Non-map area

**Caution** If you are not connected to a debug tool, then only memory mapping areas added by user is displayed.

Connecting to a debug tool (see "2.4.1 Connect to the debug tool") will display details for each memory type.

#### <2> [Verify on writing to memory]

Specify whether to perform a verify check when the memory value is initialized, from the drop-down list.  
Select [Yes] to perform verification (default).

#### (b) [Access Memory While Running]

You can configure the memory access while executing a program (the real-time display update function) in this category. See "(4) Display/modify the memory contents during program execution" for details on the real-time display update function.

Figure 2-58. [Access Memory While Running] Category [MINICUBE[V850E1][V850ES]]

<input type="checkbox"/> Access Memory While Running	
Access by stopping execution	Yes
Update display during the execution	Yes
Display update interval[ms]	500
Access by release HALT mode	Yes

Figure 2-59. [Access Memory While Running] Category [MINICUBE[V850E2]]

<input type="checkbox"/> Access Memory While Running	
Access during the execution	Yes
Access by stopping execution	Yes
Access by release HALT mode	No
Update display during the execution	Yes
Display update interval[ms]	500

Figure 2-60. [Access Memory While Running] Category [MINICUBE2]

<input type="checkbox"/> Access Memory While Running	
Access by stopping execution	No
Update display during the execution	Yes
Display update interval[ms]	500

#### <1> [Access during the execution] [MINICUBE[V850E2]]

Specify whether to allow access to the internal RAM area during execution of a program, from the drop-down list.

When the [Using the flash self programming] [MINICUBE[V850E2]] property in the [Flash] category is set to [No], the internal ROM area is subject to this setting, as with the internal RAM.

Select [Yes] to allow access ([No] is selected by default).

**<2> [Access by stopping execution]**

This property does not appear when the selected microcontroller version supports multi-core or the [\[Access during the execution\] \[MINICUBE\[V850E2\]\]](#) property is set to [No].

For a memory area not accessible during execution of a program (e.g. target memory area/SFRI/O register area), specify whether to allow access to the area by temporary stopping the execution, from the drop-down list.

If the [\[Using the flash self programming\] \[MINICUBE\[V850E2\]\]](#) property in the [Flash] category is set to [No], then the internal ROM area is handled the same as the internal RAM area.

Select [Yes] to allow access ([No] is selected by default).

**Remark [V850E2]**

For the internal RAM area, accesses are allowed without temporary stopping regardless of this property setting.

**<3> [Update display during the execution]**

Specify whether to update the display in the [Watch panel/Memory panel](#) while executing a program.

Select [Yes] to update the display (default).

**<4> [Display update interval[ms]]**

This property is valid only when the [\[Update display during the execution\]](#) property is set to [Yes].

Specify the interval in 100ms unit to update the contents in the [Watch panel/Memory panel](#) display while executing a program.

Directly enter the Integer number between 100 and 65500 (rounding up the fractions less than 100ms) ([500] is specified by default).

**<5> [Access by release HALT mode] [MINICUBE]**

This property appears only when the [\[Access by stopping execution\]](#) property is set to [Yes].

Specify whether to allow access to a memory area other than the internal RAM (CPU registers/I/O registers) by releasing the HALT mode, from the drop-down list. For a memory area other than the internal RAM, the HALT mode cannot be released. If the [\[Using the flash self programming\] \[MINICUBE\[V850E2\]\]](#) property in the [Flash] category is set to [No], then the internal ROM area is handled the same as the internal RAM area.

Select [Yes] to allow access to the memory area by releasing the HALT mode (default).

**(c) [Set Event While Running]**

You can configure the setting of events while executing a program in this category.

Figure 2-61. [Set Event While Running] Category

**Set Event While Running**

Set event by stopping execution momentarily  No

**<1> [Set event by stopping execution momentarily]**

Specify whether to forcibly pause the execution for events that cannot be set while executing a program or operating the tracer/timer.

For details on the event types that are affected by this property, see "[\(2\) Event types that can be set and deleted during execution](#)".

Select [Yes] to set events above while execution ([No] is selected by default).

**(d) [Break]**

You can configure the break function in this category.

**Figure 2-62. [Break] Category [MINICUBE]**

<b>Break</b>	
First using type of breakpoint	Software break
Stop emulation of peripherals when stopping	No
Use open break function	No(Output signal)

**Figure 2-63. [Break] Category [MINICUBE2]**

<b>Break</b>	
First using type of breakpoint	Software break

**<1> [First using type of breakpoint]**

This property does not appear when the number of the breakpoint type available for the selected microcontroller is only one.

Specify from the following drop-down list a breakpoint type to use with priority when setting it with a one click operation of the mouse in the [Editor panel/Disassemble panel](#).

See "[2.8.2 Stop the program at the arbitrary position \(breakpoint\)](#)" for details on breakpoints.

Software break	Sets software breakpoint with priority (default).
Hardware break	Sets hardware breakpoint with priority.

**<2> [Stop emulation of peripherals when stopping] [MINICUBE]**

Specify from the drop-down list whether to terminate the peripheral emulation while stopping the program execution.

Select [Yes] to terminate ([No] is selected by default).

**<3> [Use open break function] [MINICUBE]**

This property appears only when the selected microcontroller supports the open break function.

Specify from the following drop-down list whether to use the open break function.

Yes(Hi-Z)	The open break target pin becomes the Hi-Z state after the CPU is stopped.
No(Output signal)	The open break target pin outputs the signal even after the CPU is stopped.

**(e) [Mask for Input Signal]**

You can configure the input signal masking in this category.

**Figure 2-64. [Mask for Input Signal] Category [MINICUBE[V850E1][V850ES]]**

<b>Mask for Input Signal</b>	
Mask NMI0 signal	No
Mask NMI1 signal	No
Mask NMI2 signal	No
Mask HLDREQ signal	No
Mask RESET signal	No
Mask STOP signal	No
Mask WAIT signal	No
Mask DBINT signal	No

Figure 2-65. [Mask for Input Signal] Category [MINICUBE[V850E2]]

<b>Mask for Input Signal</b>	
Mask HLDREQ signal	No
Mask RESET signal	No
Mask STOP signal	No
Mask WAIT signal	No

Figure 2-66. [Mask for Input Signal] Category [MINICUBE2]

<b>Mask for Input Signal</b>	
Mask RESET signal	No

With the properties shown below, select [Yes] to mask the signal from the drop-down list (all properties below are set to [No] by default).

- [Mask NMI*n* signal] **[MINICUBE[V850E1][V850ES]]**
- [Mask HLDREQ signal] **[MINICUBE]**
- [Mask RESET signal]
- [Mask STOP signal] **[MINICUBE]**
- [Mask WAIT signal] **[MINICUBE]**
- [[Mask DBINT signal] **[MINICUBE[V850E1][V850ES]]**]

#### (f) [External Flash Memory Download] **[MINICUBE]**

You can configure downloading to an external flash memory in this category.

See "[\(5\) Download to external flash memory \[IECUBE\]\[IECUBE2\]\[MINICUBE\]\[E1/E20\(LPD\)/\(JTAG\)\]](#)" for details on how to download to an external flash memory and this category configuration.

#### (3) [Download File Settings] tab

In the [\[Download File Settings\] tab](#), configuration on downloading file to the debug tool can be done.

See "[2.5.1 Execute downloading](#)" for details on each category configuration.

#### (4) [Flash Options Settings] tab **[V850E2]**

In the [\[Flash Options Settings\] tab \[V850E2\]](#), configuration on options for the flash memory incorporated in the V850E2 microcontroller can be done.

Note that this tab appears only when the selected V850E2 microcontroller supports the flash options.

To configure options, specify the corresponding items on the [Flash Options Setting dialog box \[V850E2\]](#), that is opened by clicking the [...] button appears at the right of the field by selecting the [Flash options] property in the [Flash Options] category on this tab (the [...] button appears only while connected to the debug tool).


Click the [Write] button on this dialog box after specifying each item.

See [Flash Options Setting dialog box \[V850E2\]](#) for details on the configuration.

Figure 2-67. Opening Flash Options Setting Dialog Box



Figure 2-68. Flash Options Settings (Flash Options Setting Dialog Box [MINICUBE][MINICUBE2])



#### (5) [Hook Transaction Settings] tab

In the [Hook Transaction Settings] tab, configuration on the hook transaction can be done.


See "[2.16 Use Hook Function](#)" for details on each category configuration and the function of the hook transaction.

## 2.3.4 [E1]

Configure the operating environment on the [Property panel](#) below when using E1.

Note that the contents of the [Property panel](#) differ depending on the communication method (serial communications [**E1(Serial)**]/LPD communications [**E1(LPD)**]/JTAG communications [**E1(JTAG)**]) between E1 and the target board.

**Figure 2-69. Example of Property Panel [E1(Serial)][V850E1][V850ES]]**



**Figure 2-70. Example of Property Panel [E1(Serial)][V850E2]]**




Figure 2-71. Example of Property Panel [E1(JTAG)[V850E1][V850ES]]





Figure 2-72. Example of Property Panel [E1(LPD)/(JTAG) [V850E2]]



Follow the steps below by selecting the corresponding tab on the [Property panel](#).

- (1) [\[Connect Settings\] tab](#)
- (2) [\[Debug Tool Settings\] tab](#)
- (3) [\[Download File Settings\] tab](#)
- (4) [\[Flash Options Settings\] tab \[V850E2\]](#)
- (5) [\[Hook Transaction Settings\] tab](#)

**(1) [Connect Settings] tab**

In the [\[Connect Settings\] tab](#), configuration with regard to the connection to the debug tool can be done.

- (a) [\[Internal ROM/RAM\]](#)
- (b) [\[DataFlash\] \[V850E1\]\[V850ES\]](#)
- (c) [\[Clock\]](#)
- (d) [\[Connection with Target Board\]](#)
- (e) [\[Flash\]](#)
- (f) [\[Programmable I/O\] \[V850E1\]\[V850ES\]](#)

**(a) [Internal ROM/RAM]**

The configuration of internal ROM/RAM is displayed in this category.

**Figure 2-73. [Internal ROM/RAM] Category [E1[V850E1][V850ES]]**

<b>Internal ROM/RAM</b>	
Size of internal ROM[KBytes]	256
Size of internal RAM[Bytes]	16384

**Figure 2-74. [Internal ROM/RAM] Category [E1[V850E2]]**

<b>Internal ROM/RAM</b>	
Size of internal ROM[KBytes]	256
Size of internal RAM[Bytes]	16384
Size of DataFlash memory[KBytes]	16

**<1> [Size of internal ROM[KBytes]]**

The internal ROM size to emulate is displayed (unit: Kbytes).

If the selected microcontroller is the V850E1 core and incorporates VSB Flash ROM, it displays the value including the size of VSB Flash ROM.

You cannot change the value of this property.

**<2> [Size of internal RAM[Bytes]]**

The internal RAM size to emulate is displayed (unit: bytes).

If the selected microcontroller is the V850E1 core and incorporates VSB RAM, it displays the value including the size of VSB RAM. If the selected microcontroller version supports multi-core, it displays "total RAM size(RAM size for a core x the number of cores)".

You cannot change the value of this property.

**<3> [Size of DataFlash memory[KBytes]] [V850E2]**

The data flash memory size is displayed (unit: Kbytes).

If the currently selected microcontroller does not incorporate the data flash, [0] is displayed.

You cannot change the value of this property.

**(b) [DataFlash] [V850E1][V850ES]**

You can configure the data flash function in this category.

Note that this category appears only when the selected microcontroller incorporates the data flash memory.

Figure 2-75. [DataFlash] Category

<b>DataFlash</b>	
Use DataFlash memory area	Yes
Size of DataFlash memory[KBytes]	32
Chip select	CS0

**<1> [Use DataFlash memory area]**

Specify whether to use the data flash memory, from the drop-down list.

Select [Yes] to use the data flash memory ([No] is selected by default).

**<2> [Size of DataFlash memory[KBytes]]**

This property appears only when the [Use DataFlash memory area] property is set to [Yes].

The size of the data flash memory area of the selected microcontroller is displayed (unit: Kbytes).

You cannot change the value of this property.

**<3> [Chip select]**

This property appears only when the [Use DataFlash memory area] property is set to [Yes].

Select the chip select used for mapping of the data flash memory from the drop-down list.

The selectable chip select values differ depending on the selected microcontroller.

Note that when the selected microcontroller is other than the V850ES core, you cannot change the value of the property.

**(c) [Clock]**

You can configure the clock in this category.

Figure 2-76. [Clock] Category [E1(Serial)][V850E1][V850ES]]

<b>Clock</b>	
Main clock frequency [MHz]	4.00
Main clock multiply rate	1
Sub clock frequency[kHz]	32.768
Monitor clock	System

Figure 2-77. [Clock] Category [E1(JTAG)][V850E1][V850ES]]

<b>Clock</b>	
Main clock frequency [MHz]	4.00
Main clock multiply rate	1
Sub clock frequency[kHz]	32.768
Monitor clock	System
TCK/DCK clock [MHz]	10MHz

Figure 2-78. [Clock] Category [E1[V850E2]]

<b>Clock</b>	
Main clock frequency [MHz]	8.00
Timer clock frequency[MHz]	80.00

Figure 2-79. [Clock] Category [E1] (some products of V850E2)

<b>Clock</b>	
CPU clock frequency[MHz]	80.00
Timer clock frequency[MHz]	80.00

## &lt;1&gt; [Main clock frequency [MHz]]

Specify the main clock frequency (before multiplier).

You can specify the frequency from the drop-down list or by directly entering a frequency value between 0.001 and 999.999 (unit: MHz).

The drop-down list displays the following frequencies (unit: MHz).

- [V850E1][V850ES]

2.50, 4.00 (default), 5.00, 6.00, 8.00, 13.50, 18.00

- [V850E2]

4.00, 5.00, 7.20, 8.00 (default), 9.60, 10.00, 13.50, 16.00

**Caution [V850E2]**

This property does not appear when the [CPU clock frequency [MHz]] [V850E2] property is shown.

## &lt;2&gt; [Main clock multiply rate] [V850E1][V850ES]

Specify the main clock frequency multiplier.

Select a value from the drop-down list or directly enter a value from 1 to 99.

The drop-down list displays the following multiplier values.

1 (default), 2, 3, 4, 5, 6, 7, 8, 9, 10

## &lt;3&gt; [Sub clock frequency[kHz]] [V850E1][V850ES]

This property appears only when the selected microcontroller supports a sub clock.

Specify the sub clock frequency.

You can specify the frequency from the drop-down list or by directly entering a frequency value number between 0.001 and 999.999 (unit: kHz).

The usable sub clock frequency values differ depending on the selected microcontroller.

The drop-down list displays sub clock frequency values which can be used by the currently selected microcontroller.

The minimum usable sub clock frequency is specified by default.

## &lt;4&gt; [Monitor clock] [V850E1][V850ES]

This property appears only when the selected microcontroller supports a sub clock.

Specify a clock for monitor programs to operate while the program is stopped.

Specify from the following drop-down list.

System	Operates with main clock (default).
User	Operates with the clock that the program specified.

## &lt;5&gt; [TCK/DCK clock[MHz]] [E1(JTAG)][V850E1][V850ES]]

Specify a clock supplied from E1(JTAG) to the debug control unit (DCU), from the drop-down list.

The drop-down list displays the following frequency values.

10MHz (default), 20MHz

- Cautions 1.** Normally, do not change the setting from [10MHz].  
**When [20MHz] is specified, it may not be possible to connect to the debug tool.**
2. This property cannot be changed when E1(JTAG) is connected to CubeSuite+.

**<6> [Timer clock frequency[MHz]] [V850E2]**

Specify the clock frequency for using timer function.

Directly enter the value between 0.001 and 999.999 (unit: MHz) ([80.00] is specified by default).

Note that this property cannot be changed when the [\[CPU clock frequency \[MHz\]\] \[V850E2\]](#) property is shown (this property is fixed to the same value as the [CPU clock frequency [MHz]] property).

**<7> [CPU clock frequency [MHz]] [V850E2]**

This property appears only for some products of V850E2.

Specify the CPU clock frequency (after multiplier).

You can specify the frequency from the drop-down list or by directly entering a frequency value between 0.001 and 999.999 (unit: MHz).

The drop-down list displays the following frequencies (unit: MHz).

80.00 (default), 100.00

**(d) [Connection with Target Board]**

You can configure the connection between E1 and the target board in this category.

**Caution Properties in this category cannot be changed when E1 is connected to CubeSuite+.**

**Figure 2-80. [Connection with Target Board] Category [E1(Serial)]**

<b>□ Connection with Target Board</b>	
Communication method	UARTA0
Power target from the emulator (MAX 200mA)	Yes
Supply voltage	3.3V

**Figure 2-81. [Connection with Target Board] Category [E1(LPD)/(JTAG)]**

<b>□ Connection with Target Board</b>	
Power target from the emulator (MAX 200mA)	Yes
Supply voltage	3.3V

**<1> [Communication method] [E1(Serial)]**

Specify the port from the drop-down list to which to connect E1(Serial) when performing serial communication between E1(Serial) and the device on the target board.

The type of the port in the drop-down list differs depending on the selected microcontroller.

Note, however, that if the port that can be used for serial communication is limited by the currently selected microcontroller, it is not possible to change the communication method displayed by default (the default communication method depends on the currently selected microcontroller).

**<2> [Power target from the emulator (MAX 200mA)]**

Specify whether to supply power to the target board from E1.

Select [Yes] to supply power to the target board ([No] is selected by default).

## &lt;3&gt; [Supply voltage]

This property appears only when the [Power target from the emulator (MAX 200mA)] property is displayed and also [Yes] is set to it.

Specify the power voltage supplied to the target board from the following drop-down list.

3.3V (default), 5.0V

## (e) [Flash]

You can configure the flash memory rewriting in this category.

**Caution** Properties in this category cannot be changed when E1 is connected to CubeSuite+.

Figure 2-82. [Flash] Category [E1(Serial)]

<input type="checkbox"/> Flash	
Security ID	<input type="button" value="HEX"/> FFFFFFFFFFFFFFFFFFFF
Erase flash ROM when starting	No

Figure 2-83. [Flash] Category [E1(JTAG)[V850E1][V850ES]]

<input type="checkbox"/> Flash	
Security ID	<input type="button" value="HEX"/> FFFFFFFFFFFFFFFFFFFF

Figure 2-84. [Flash] Category [E1(LPD)/(JTAG)[V850E2]]

<input type="checkbox"/> Flash	
Security ID	<input type="button" value="HEX"/> FFFFFFFFFFFFFFFFFFFF
Using the flash self programming	No

## &lt;1&gt; [Security ID]

This property appears only when the selected microcontroller supports the ROM security function (on-chip debug security ID) for flash memory.

Specify a security ID for reading codes in the internal ROM or internal flash memory.

For details on the on-chip debug security ID, see E1 User's Manual.

- [V850E1][V850ES]

Directly enter 20 digits hexadecimal number (10 bytes) ([FFFFFFFFFFFFFFFFFF]) is specified by default).

- [V850E2]

Directly enter 24 digits hexadecimal number (12 bytes) ([FFFFFFFFFFFFFF]) is specified by default).

**Remark** [V850E1][V850ES]

When you change the setting of the property, a message appears prompting you to select whether or not to change the security ID of the build tool.

## &lt;2&gt; [Erase flash ROM when starting] [E1(Serial)]

Specify whether to erase flash ROM when connecting to the debug tool, from the drop-down list.

Select [Yes] to erase flash ROM ([No] is selected by default).

Note that this property is set to [No] after connecting to the debug tool.

## &lt;3&gt; [Using the flash self programming] [E1(LPD)/(JTAG)[V850E2]]

Specify whether to rewrite the internal flash ROM by using the flash self library of the flash self programing function, from the drop-down list.

However, the setting of this property is ignored in the case of a hot plug-in connection.

Select [Yes] to rewrite the internal flash ROM ([No] is selected by default).

Note that if [Yes] is selected in this property, the internal flash ROM will not be cashed.

## (f) [Programmable I/O] [V850E1][V850ES]

You can configure the programmable I/O area in this category.

Note that this category is only valid when the selected microcontroller supports the programmable I/O area.

**Remark** Change this setting to temporarily change variables while debugging.

To set a common value for the project, in the Property panel of the build tool, on the [Common Options] tab, in the [Device] category, set the value in [Programmable I/O area start address] property.

Figure 2-85. [Programmable I/O] Category

Programmable I/O	
Use Programmable I/O area	Yes
Programmable I/O area start address	<input checked="" type="checkbox"/> 0

## &lt;1&gt; [Use Programmable I/O area]

Specify whether to use the programmable I/O area.

Select [Yes] to use the programmable I/O are ([No] is selected by default).

## &lt;2&gt; [Programmable I/O area start address]

This property appears only when the [Use Programmable I/O area] property is set to [Yes].

Specify the start address of the programmable I/O area.

Specify the address within the programmable I/O area ([0] is specified by default).

The address is aligned to 16 Kbytes.

## (2) [Debug Tool Settings] tab

In the [Debug Tool Settings] tab, general configurations on the debug tool can be done.

- (a) [Memory]
- (b) [Access Memory While Running]
- (c) [Set Event While Running]
- (d) [Break]
- (e) [Mask for Input Signal]
- (f) [External Flash Memory Download] [E1(LPD)/(JTAG)]

**(a) [Memory]**

You can configure the memory in this category.

**Figure 2-86. [Memory] Category [E1]**

<b>Memory</b>		[4]
Memory mappings		
[0]	Internal ROM area	
[1]	Non-map area	
[2]	Internal RAM area	
[3]	I/O Register area	
Verify on writing to memory	Yes	


**<1> [Memory mappings]**

Current memory mapping status is displayed for each type of memory area.

The memory mapping status cannot be changed on this panel. If it is necessary to add a memory mapping, click on the [Memory Mapping] property, and click on the [...] button that appears on the right end of the setting field. The [Memory Mapping dialog box](#) opens; perform the setting from there.

See the section for the [Memory Mapping dialog box](#) for details on how to configure the parameters.

**Figure 2-87. Opening Memory Mapping Dialog Box**



<b>Memory</b>		[4]
Memory mappings		
[0]	Internal ROM area	
[1]	Non-map area	

**Caution** If you are not connected to a debug tool, then only memory mapping areas added by user is displayed.

Connecting to a debug tool (see "[2.4.1 Connect to the debug tool](#)") will display details for each memory type.

**<2> [Verify on writing to memory]**

Specify whether to perform a verify check when the memory value is initialized, from the drop-down list. Select [Yes] to perform verification (default).

**(b) [Access Memory While Running]**

You can configure the memory access while executing a program (the real-time display update function) in this category. See "[\(4\) Display/modify the memory contents during program execution](#)" for details on the real-time display update function.

**Figure 2-88. [Access Memory While Running] Category [E1(Serial)]**

<b>Access Memory While Running</b>	
Access by stopping execution	No
Update display during the execution	Yes
Display update interval[ms]	500

Figure 2-89. [Access Memory While Running] Category [E1(JTAG)[V850E1][V850ES]]

<b>Access Memory While Running</b>	
Access by stopping execution	Yes
Update display during the execution	Yes
Display update interval[ms]	500
Access by release HALT mode	Yes

Figure 2-90. [Access Memory While Running] Category [E1(LPD)/(JTAG)[V850E2]]

<b>Access Memory While Running</b>	
Access during the execution	Yes
Access by stopping execution	Yes
Access by release HALT mode	No
Update display during the execution	Yes
Display update interval[ms]	500

#### <1> [Access during the execution] [E1(LPD)/(JTAG)[V850E2]]

Specify whether to allow access to the internal RAM area during execution of a program, from the drop-down list.

When the [Using the flash self programming] [E1(LPD)/(JTAG)[V850E2]] property in the [Flash] category is set to [No], the internal ROM area is subject to this setting, as with the internal RAM.

Select [Yes] to allow access ([No] is selected by default).

#### <2> [Access by stopping execution]

This property does not appear when the selected microcontroller version supports multi-core or the [Access during the execution] [E1(LPD)/(JTAG)[V850E2]] property is set to [No].

For a memory area not accessible during execution of a program (e.g. target memory area/I/O register area), specify whether to allow access to the area by temporary stopping the execution, from the drop-down list.

If the [Using the flash self programming] [E1(LPD)/(JTAG)[V850E2]] property in the [Flash] category is set to [No], then the internal ROM area is handled the same as the internal RAM area.

Select [Yes] to allow access ([No] is selected by default).

#### Remark [V850E2]

For the internal RAM area, accesses are allowed without temporary stopping regardless of this property setting.

#### <3> [Update display during the execution]

Specify whether to automatically update the display in the [Watch panel/Memory panel](#) while executing a program.

Select [Yes] to update the display (default).

#### <4> [Display update interval[ms]]

This property is valid only when the [Update display during the execution] property is set to [Yes].

Specify the interval in 100ms unit to automatically update the contents in the [Watch panel/Memory panel](#) display while executing a program.

Directly enter the Integer number between 100 and 65500 (rounding up the fractions less than 100ms) ([500] is specified by default).

**<5> [Access by release HALT mode] [E1(LPD)/(JTAG)]**

This property appears only when the [Access by stopping execution] property is set to [Yes].

Specify whether to allow access to a memory area other than the internal RAM (CPU registers/I/O registers) by releasing the HALT mode, from the drop-down list. For a memory area other than the internal RAM, the HALT mode cannot be released. If the [Using the flash self programming] [E1(LPD)/(JTAG)[V850E2]] property in the [Flash] category is set to [No], then the internal ROM area is handled the same as the internal RAM area.

Select [Yes] to allow access to the memory area by releasing the HALT mode (default).

**(c) [Set Event While Running]**

You can configure the setting of events while executing a program in this category.

Figure 2-91. [Set Event While Running] Category

<input type="checkbox"/> Set Event While Running
Set event by stopping execution momentarily No

**<1> [Set event by stopping execution momentarily]**

Specify whether to forcibly pause the execution for events that cannot be set while executing a program or operating the tracer/timer.

For details on the event types that are affected by this property, see "[\(2\) Event types that can be set and deleted during execution](#)".

Select [Yes] to set events above while execution ([No] is selected by default).

**(d) [Break]**

You can configure the break function in this category.

Figure 2-92. [Break] Category [E1(Serial)]

<input type="checkbox"/> Break
First using type of breakpoint Software break

Figure 2-93. [Break] Category [E1(LPD)/(JTAG)]

<input type="checkbox"/> Break
First using type of breakpoint Software break
Stop emulation of peripherals when stopping No
Use open break function No(Output signal)

**<1> [First using type of breakpoint]**

This property does not appear when the number of the breakpoint type available for the selected microcontroller is only one.

Specify from the following drop-down list a breakpoint type to use with priority when setting it with a one click operation of the mouse in the [Editor panel/Disassemble panel](#).

See "[2.8.2 Stop the program at the arbitrary position \(breakpoint\)](#)" for details on breakpoints.

Software break	Sets software breakpoint with priority (default).
Hardware break	Sets hardware breakpoint with priority.

<2> [Stop emulation of peripherals when stopping] [E1(LPD)/(JTAG)]

Specify from the drop-down list whether to terminate the peripheral emulation while stopping the program execution.

Select [Yes] to terminate ([No] is selected by default).

<3> [Use open break function] [E1(LPD)/(JTAG)]

This property appears only when the selected microcontroller supports the open break function.

Specify from the following drop-down list whether to use the open break function.

Yes(Hi-Z)	The open break target pin becomes the Hi-Z state after the CPU is stopped.
No(Output signal)	The open break target pin outputs the signal even after the CPU is stopped.

(e) [Mask for Input Signal]

You can configure the input signal masking in this category.

Figure 2-94. [Mask for Input Signal] Category [E1(Serial)]

Mask for Input Signal	
Mask RESET signal	No

Figure 2-95. [Mask for Input Signal] Category [E1(JTAG)[V850E1][V850ES]]

Mask for Input Signal	
Mask NMIO signal	No
Mask NMII signal	No
Mask NMII2 signal	No
Mask HLDRQ signal	No
Mask RESET signal	No
Mask STOP signal	No
Mask WAIT signal	No
Mask DBINT signal	No

Figure 2-96. [Mask for Input Signal] Category [E1(LPD)/(JTAG)[V850E2]]

Mask for Input Signal	
Mask HLDRQ signal	No
Mask RESET signal	No
Mask STOP signal	No
Mask WAIT signal	No

With the properties shown below, select [Yes] to mask the signal from the drop-down list (all properties below are set to [No] by default).

- [Mask NMI<sub>n</sub> signal] [E1(JTAG)[V850E1][V850ES]]
- [Mask HLDRQ signal] [E1(LPD)/(JTAG)]
- [Mask RESET signal]
- [Mask STOP signal] [E1(LPD)/(JTAG)]
- [Mask WAIT signal] [E1(LPD)/(JTAG)]
- [[Mask DBINT signal] [E1(JTAG)[V850E1][V850ES]]]

**(f) [External Flash Memory Download] [E1(LPD)/(JTAG)]**

You can configure downloading to an external flash memory in this category.

See "[\(5\) Download to external flash memory \[IECUBE\]\[IECUBE2\]\[MINICUBE\]\[E1/E20\(LPD\)/\(JTAG\)\]](#)" for details on how to download to an external flash memory and this category configuration.

**(3) [Download File Settings] tab**

In the [\[Download File Settings\] tab](#), configuration on downloading file to the debug tool can be done.

See "[2.5.1 Execute downloading](#)" for details on each category configuration.

**(4) [Flash Options Settings] tab [V850E2]**

In the [\[Flash Options Settings\] tab \[V850E2\]](#), configuration on options for the flash memory incorporated in the V850E2 microcontroller can be done.

Note that this tab appears only when the selected V850E2 microcontroller supports the flash options.

To configure options, specify the corresponding items via the [Flash Options Setting dialog box \[V850E2\]](#), that is opened by clicking the [...] button appears at the right of the field by selecting the [Flash options] property in the [Flash Options] category on this tab (the [...] button appears only while connected to the debug tool).


Click the [Write] button on this dialog box after specifying each item.

See [Flash Options Setting dialog box \[V850E2\]](#) for details on the configuration.

Figure 2-97. Opening Flash Options Setting Dialog Box



Figure 2-98. Flash Options Settings (Flash Options Setting Dialog Box [E1])



**(5) [Hook Transaction Settings] tab**

In the [\[Hook Transaction Settings\] tab](#), configuration on the hook transaction can be done.

See "[2.16 Use Hook Function](#)" for details on each category configuration and the function of the hook transaction.

## 2.3.5 [E20]

Configure the operating environment on the [Property panel](#) below when using E20.

Note that the contents of the [Property panel](#) differ depending on the communication method (serial communications **[E20(Serial)]**, LPD communications **[E20(LPD)]** or JTAG communications **[E20(JTAG)]**) between E20 and the target board.

Figure 2-99. Example of Property Panel [E20(Serial)][V850E1][V850ES]]




Figure 2-100. Example of Property Panel [E20(Serial)][V850E2]]



Figure 2-101. Example of Property Panel [E20(JTAG)[V850E1][V850ES]]





Figure 2-102. Example of Property Panel [E20(LPD)/(JTAG)[V850E2]]



Follow the steps below by selecting the corresponding tab on the [Property panel](#).

- (1) [\[Connect Settings\] tab](#)
- (2) [\[Debug Tool Settings\] tab](#)
- (3) [\[Download File Settings\] tab](#)
- (4) [\[Flash Options Settings\] tab \[V850E2\]](#)
- (5) [\[Hook Transaction Settings\] tab](#)

#### (1) [\[Connect Settings\] tab](#)

In the [\[Connect Settings\] tab](#), configuration with regard to the connection to the debug tool can be done.

- (a) [\[Internal ROM/RAM\]](#)
- (b) [\[DataFlash\] \[V850E1\]\[V850ES\]](#)

- (c) [Clock]
- (d) [Connection with Target Board] [E20(Serial)]
- (e) [Flash]
- (f) [Programmable I/O] [V850E1][V850ES]

**(a) [Internal ROM/RAM]**

The configuration of internal ROM/RAM is displayed in this category.

**Figure 2-103. [Internal ROM/RAM] Category [E20[V850E1][V850ES]]**

<b>Internal ROM/RAM</b>	
Size of internal ROM[KBytes]	256
Size of internal RAM[Bytes]	16384

**Figure 2-104. [Internal ROM/RAM] Category [E20[V850E2]]**

<b>Internal ROM/RAM</b>	
Size of internal ROM[KBytes]	256
Size of internal RAM[Bytes]	16384
Size of DataFlash memory[KBytes]	16

**<1> [Size of internal ROM[KBytes]]**

The internal ROM size to emulate is displayed (unit: Kbytes).

If the selected microcontroller is the V850E1 core and incorporates VSB Flash ROM, it displays the value including the size of VSB Flash ROM.

You cannot change the value of this property.

**<2> [Size of internal RAM[Bytes]]**

The internal RAM size to emulate is displayed (unit: bytes).

If the selected microcontroller is the V850E1 core and incorporates VSB RAM, it displays the value including the size of VSB RAM. If the selected microcontroller version supports multi-core, it displays "total RAM size(RAM size for a core x the number of cores)".

You cannot change the value of this property.

**<3> [Size of DataFlash memory[KBytes]] [E20(LPD)/(JTAG)[V850E2]]**

The data flash memory size is displayed (unit: Kbytes).

If the currently selected microcontroller does not incorporate the data flash, [0] is displayed.

You cannot change the value of this property.

**(b) [DataFlash] [V850E1][V850ES]**

You can configure the data flash function in this category.

Note that this category appears only when the selected microcontroller incorporates the data flash memory.

**Figure 2-105. [DataFlash] Category**

<b>DataFlash</b>	
Use DataFlash memory area	Yes
Size of DataFlash memory[KBytes]	32
Chip select	CS0

## &lt;1&gt; [Use DataFlash memory area]

Specify whether to use the data flash memory, from the drop-down list.

Select [Yes] to use the data flash memory ([No] is selected by default).

## &lt;2&gt; [Size of DataFlash memory[KBytes]]

This property appears only when the [Use DataFlash memory area] property is set to [Yes].

The size of the data flash memory area of the selected microcontroller is displayed (unit: Kbytes).

You cannot change the value of this property.

## &lt;3&gt; [Chip select]

This property appears only when the [Use DataFlash memory area] property is set to [Yes].

Select the chip select used for mapping of the data flash memory from the drop-down list.

The selectable chip select values differ depending on the selected microcontroller.

Note that when the selected microcontroller is other than the V850ES core, you cannot change the value of the property.

## (c) [Clock]

You can configure the clock in this category.

Figure 2-106. [Clock] Category [E20(Serial)[V850E1][V850ES]]

Clock	
Main clock frequency [MHz]	4.00
Main clock multiply rate	1
Sub clock frequency[kHz]	32.768
Monitor clock	System

Figure 2-107. [Clock] Category [E20(JTAG)[V850E1][V850ES]]

Clock	
Main clock frequency [MHz]	4.00
Main clock multiply rate	1
Sub clock frequency[kHz]	32.768
Monitor clock	System
TCK/DCK clock [MHz]	10MHz

Figure 2-108. [Clock] Category [E20[V850E2]]

Clock	
Main clock frequency [MHz]	8.00
Timer clock frequency[MHz]	80.00

Figure 2-109. [Clock] Category [E20] (some products of V850E2)

Clock	
CPU clock frequency[MHz]	80.00
Timer clock frequency[MHz]	80.00

## &lt;1&gt; [Main clock frequency [MHz]]

Specify the main clock frequency (before multiplier).

You can specify the frequency from the drop-down list or by directly entering a frequency value between 0.001 and 999.999 (unit: MHz).

The drop-down list displays the following frequencies (unit: MHz).

- [V850E1][V850ES]

2.50, 4.00 (default), 5.00, 6.00, 8.00, 13.50, 18.00

- [V850E2]

4.00, 5.00, 7.20, 8.00 (default), 9.60, 10.00, 13.50, 16.00

**Caution [V850E2]**

This property does not appear when the [CPU clock frequency [MHz]] [V850E2] property is shown.

<2> [Main clock multiply rate] [V850E1][V850ES]

Specify the main clock frequency multiplier.

Select a value from the drop-down list or directly enter a value from 1 to 99.

The drop-down list displays the following multiplier values.

1 (default), 2, 3, 4, 5, 6, 7, 8, 9, 10

<3> [Sub clock frequency[kHz]] [V850E1][V850ES]

This property appears only when the selected microcontroller supports a sub clock.

Specify the sub clock frequency.

You can specify the frequency from the drop-down list or by directly entering a frequency value number between 0.001 and 999.999 (unit: kHz).

The usable sub clock frequency values differ depending on the selected microcontroller.

The drop-down list displays sub clock frequency values which can be used by the currently selected microcontroller.

The minimum usable sub clock frequency is specified by default.

<4> [Monitor clock] [V850E1][V850ES]

This property appears only when the selected microcontroller supports a sub clock.

Specify a clock for monitor programs to operate while the program is stopped.

Specify from the following drop-down list.

System	Operates with main clock (default).
User	Operates with the clock that the program specified.

<5> [TCK/DCK clock[MHz]] [E20(JTAG)][V850E1][V850ES]]

Specify a clock supplied from E20(JTAG) to the debug control unit (DCU), from the drop-down list.

The drop-down list displays the following frequency values.

10MHz (default), 20MHz

**Cautions 1. Normally, do not change the setting from [10MHz].**

**When [20MHz] is specified, it may not be possible to connect to the debug tool.**

**2. This property cannot be changed when E20(JTAG) is connected to CubeSuite+.**

<6> [Timer clock frequency[MHz]] [V850E2]

Specify the clock frequency for using timer function.

Directly enter the value between 0.001 and 999.999 (unit: MHz)([80.00] is specified by default).

Note that this property cannot be changed when the [CPU clock frequency [MHz]] [V850E2] property is shown (this property is fixed to the same value as the [CPU clock frequency [MHz]] property).

## &lt;7&gt; [CPU clock frequency [MHz]] [V850E2]

This property appears only for some products of V850E2.

Specify the CPU clock frequency (after multiplier).

You can specify the frequency from the drop-down list or by directly entering a frequency value between 0.001 and 999.999 (unit: MHz).

The drop-down list displays the following frequencies (unit: MHz).

80.00 (default), 100.00

## (d) [Connection with Target Board] [E20(Serial)]

You can configure the connection between E20 and the target board in this category.

**Caution Properties in this category cannot be changed when E20 is connected to CubeSuite+.**

Figure 2-110. [Connection with Target Board] Category [E20(Serial)]

<input type="checkbox"/> Connection with Target Board	Communication method	UARTA0
---	----------------------	--------

## &lt;1&gt; [Communication method]

Specify the port from the drop-down list to which to connect E20(Serial) when performing serial communication between E20(Serial) and the device on the target board.

The type of the port in the drop-down list differs depending on the selected microcontroller.

Note, however, that if the port that can be used for serial communication is limited by the currently selected microcontroller, it is not possible to change the communication method displayed by default (the default communication method depends on the currently selected microcontroller).

## (e) [Flash]

You can configure the flash memory rewriting in this category.

**Caution Properties in this category cannot be changed when E20 is connected to CubeSuite+.**

Figure 2-111. [Flash] Category [E20(Serial)]

<input type="checkbox"/> Flash	Security ID	<input checked="" type="button"/> HEX FFFFFFFFFFFFFFFFFFFF
	Erase flash ROM when starting	No

Figure 2-112. [Flash] Category [E20(JTAG)[V850E1][V850ES]]

<input type="checkbox"/> Flash	Security ID	<input checked="" type="button"/> HEX FFFFFFFFFFFFFFFFFFFF
--------------------------------	-------------	--

Figure 2-113. [Flash] Category [E20(JTAG)[V850E2]]

<input type="checkbox"/> Flash	Security ID	<input checked="" type="button"/> HEX FFFFFFFFFFFFFFFFFFFF
	Using the flash self programming	No

## &lt;1&gt; [Security ID]

This property appears only when the selected microcontroller supports the ROM security function (on-chip debug security ID) for flash memory.

Specify a security ID for reading codes in the internal ROM or internal flash memory.

For details on the on-chip debug security ID, see E20 User's Manual.

## - [V850E1][V850ES]

Directly enter 20 digits hexadecimal number (10 bytes) ([FFFFFFFFFFFFFFFFFFFF]) is specified by default).

## - [V850E2]

Directly enter 24 digits hexadecimal number (12 bytes) ([FFFFFFFFFFFFFFFFFFFF]) is specified by default).

**Remark [V850E1][V850ES]**

When you change the setting of the property, a message appears prompting you to select whether or not to change the security ID of the build tool.

## &lt;2&gt; [Erase flash ROM when starting] [E20(Serial)]

Specify whether to erase flash ROM when connecting to the debug tool, from the drop-down list.

Select [Yes] to erase flash ROM ([No] is selected by default).

Note that this property is set to [No] after connecting to the debug tool.

## &lt;3&gt; [Using the flash self programming] [E20(LPD)/(JTAG)[V850E2]]

Specify whether to rewrite the internal flash ROM by using the flash self library of the flash self programing function, from the drop-down list.

However, the setting of this property is ignored in the case of a hot plug-in connection.

Select [Yes] to rewrite the internal flash ROM ([No] is selected by default).

Note that if [Yes] is selected in this property, the internal flash ROM will not be cashed.

## (f) [Programmable I/O] [V850E1][V850ES]

You can configure the programmable I/O area in this category.

Note that this category is only valid when the selected microcontroller supports the programmable I/O area.

**Remark** Change this setting to temporarily change variables while debugging.

To set a common value for the project, in the Property panel of the build tool, on the [Common Options] tab, in the [Device] category, set the value in [Programmable I/O area start address] property.

**Figure 2-114. [Programmable I/O] Category**

Programmable I/O	
Use Programmable I/O area	Yes
Programmable I/O area start address	HEX 0

## &lt;1&gt; [Use Programmable I/O area]

Specify whether to use the programmable I/O area.

Select [Yes] to use the programmable I/O are ([No] is selected by default).

## &lt;2&gt; [Programmable I/O area start address]

This property appears only when the [Use Programmable I/O area] property is set to [Yes].

Specify the start address of the programmable I/O area.

Specify the address within the programmable I/O area ([0] is specified by default).  
The address is aligned to 16 Kbytes.

## (2) [Debug Tool Settings] tab

In the [Debug Tool Settings] tab, general configurations on the debug tool can be done.

- (a) [Memory]
- (b) [Access Memory While Running]
- (c) [Set Event While Running]
- (d) [Break]
- (e) [Mask for Input Signal]
- (f) [External Flash Memory Download] [E20(LPD)/(JTAG)]

### (a) [Memory]

You can configure the memory in this category.

Figure 2-115. [Memory] Category [E20]

Memory		[4]
Memory mappings		
[0]	Internal ROM area	
[1]	Non-map area	
[2]	Internal RAM area	
[3]	I/O Register area	
Verify on writing to memory	Yes	

#### <1> [Memory mappings]

Current memory mapping status is displayed for each type of memory area.

The memory mapping status cannot be changed on this panel. If it is necessary to add a memory mapping, click on the [Memory Mapping] property, and click on the [...] button that appears on the right end of the setting field. The [Memory Mapping dialog box](#) opens; perform the setting from there.

See the section for the [Memory Mapping dialog box](#) for details on how to configure the parameters.

Figure 2-116. Opening Memory Mapping Dialog Box



**Caution** If you are not connected to a debug tool, then only memory mapping areas added by user is displayed.

Connecting to a debug tool (see "[2.4.1 Connect to the debug tool](#)") will display details for each memory type.

#### <2> [Verify on writing to memory]

Specify whether to perform a verify check when the memory value is initialized, from the drop-down list.

Select [Yes] to perform verification (default).

**(b) [Access Memory While Running]**

You can configure the memory access while executing a program (the real-time display update function) in this category. See "[\(4\) Display/modify the memory contents during program execution](#)" for details on the real-time display update function.

**Figure 2-117. [Access Memory While Running] Category [E20(Serial)]**

<b>Access Memory While Running</b>	
Access by stopping execution	No
Update display during the execution	Yes
Display update interval[ms]	500

**Figure 2-118. [Access Memory While Running] Category [E20(JTAG)[V850E1][V850ES]]**

<b>Access Memory While Running</b>	
Access by stopping execution	Yes
Update display during the execution	Yes
Display update interval[ms]	500
Access by release HALT mode	Yes

**Figure 2-119. [Access Memory While Running] Category [E20(LPD)/(JTAG)[V850E2]]**

<b>Access Memory While Running</b>	
Access during the execution	Yes
Access by stopping execution	Yes
Access by release HALT mode	No
Update display during the execution	Yes
Display update interval[ms]	500

**<1> [Access during the execution] [E20(LPD)/(JTAG)[V850E2]]**

Specify whether to allow access to the internal RAM area during execution of a program, from the drop-down list.

When the [\[Using the flash self programming\] \[E20\(LPD\)/\(JTAG\)\[V850E2\]\]](#) property in the [Flash] category is set to [No], the internal ROM area is subject to this setting, as with the internal RAM. Select [Yes] to allow access ([No] is selected by default).

**<2> [Access by stopping execution]**

This property does not appear when the selected microcontroller version supports multi-core or the [\[Access during the execution\] \[E20\(LPD\)/\(JTAG\)\[V850E2\]\]](#) property is set to [No].

For a memory area not accessible during execution of a program (e.g. target memory area/I/O register area), specify whether to allow access to the area by temporary stopping the execution, from the drop-down list.

If the [\[Using the flash self programming\] \[E20\(LPD\)/\(JTAG\)\[V850E2\]\]](#) property in the [Flash] category is set to [No], then the internal ROM area is handled the same as the internal RAM area.

Select [Yes] to allow access ([No] is selected by default).

**Remark [V850E2]**

For the internal RAM area, accesses are allowed without temporary stopping regardless of this property setting.

**<3> [Update display during the execution]**

Specify whether to automatically update the display in the [Watch panel/Memory panel](#) while executing a program.

Select [Yes] to update the display (default).

**<4> [Display update interval[ms]]**

This property is valid only when the [\[Update display during the execution\]](#) property is set to [Yes].

Specify the interval in 100ms unit to automatically update the contents in the [Watch panel/Memory panel](#) display while executing a program.

Directly enter the Integer number between 100 and 65500 (rounding up the fractions less than 100ms) ([500] is specified by default).

**<5> [Access by release HALT mode] [E20(LPD)/(JTAG)]**

This property appears only when the [\[Access by stopping execution\]](#) property is set to [Yes].

Specify whether to allow access to a memory area other than the internal RAM (CPU registers/I/O registers) by releasing the HALT mode, from the drop-down list. For a memory area other than the internal RAM, the HALT mode cannot be released. If the [\[Using the flash self programming\] \[E20\(LPD\)/\(JTAG\)\[V850E2\]\]](#) property in the [Flash] category is set to [No], then the internal ROM area is handled the same as the internal RAM area.

Select [Yes] to allow access to the memory area by releasing the HALT mode (default).

**(c) [Set Event While Running]**

You can configure the setting of events while executing a program in this category.

Figure 2-120. [Set Event While Running] Category

<input type="checkbox"/> <b>Set Event While Running</b>
Set event by stopping execution momentarily <input type="radio"/> No

**<1> [Set event by stopping execution momentarily]**

Specify whether to forcibly pause the execution for events that cannot be set while executing a program or operating the tracer/timer.

For details on the event types that are affected by this property, see "[\(2\) Event types that can be set and deleted during execution](#)".

Select [Yes] to set events above while execution ([No] is selected by default).

**(d) [Break]**

You can configure the break function in this category.

Figure 2-121. [Break] Category [E20(Serial)]

<input type="checkbox"/> <b>Break</b>
First using type of breakpoint <input type="radio"/> Software break

Figure 2-122. [Break] Category [E20(LPD)/(JTAG)]

<input type="checkbox"/> <b>Break</b>
First using type of breakpoint <input type="radio"/> Software break
Stop emulation of peripherals when stopping <input type="radio"/> No
Use open break function <input type="radio"/> No(Output signal)

**<1> [First using type of breakpoint]**

This property does not appear when the number of the breakpoint type available for the selected microcontroller is only one.

Specify from the following drop-down list a breakpoint type to use with priority when setting it with a one click operation of the mouse in the [Editor panel/Disassemble panel](#).

See "[2.8.2 Stop the program at the arbitrary position \(breakpoint\)](#)" for details on breakpoints.

Software break	Sets software breakpoint with priority (default).
Hardware break	Sets hardware breakpoint with priority.

**<2> [Stop emulation of peripherals when stopping] [E20(LPD)/(JTAG)]**

Specify from the drop-down list whether to terminate the peripheral emulation while stopping the program execution.

Select [Yes] to terminate ([No] is selected by default).

**<3> [Use open break function] [E20(LPD)/(JTAG)]**

This property appears only when the selected microcontroller supports the open break function.

Specify from the following drop-down list whether to use the open break function.

Yes(Hi-Z)	The open break target pin becomes the Hi-Z state after the CPU is stopped.
No(Output signal)	The open break target pin outputs the signal even after the CPU is stopped.

**(e) [Mask for Input Signal]**

You can configure the input signal masking in this category.

**Figure 2-123. [Mask for Input Signal] Category [E20(Serial)]**

<b>Mask for Input Signal</b>	
Mask RESET signal	No

**Figure 2-124. [Mask for Input Signal] Category [E20(JTAG)[V850E1][V850ES]]**

<b>Mask for Input Signal</b>	
Mask NMIO signal	No
Mask NMII signal	No
Mask NMII2 signal	No
Mask HLDRQ signal	No
Mask RESET signal	No
Mask STOP signal	No
Mask WAIT signal	No
Mask DBINT signal	No

**Figure 2-125. [Mask for Input Signal] Category [E20(LPD)/(JTAG)[V850E2]]**

<b>Mask for Input Signal</b>	
Mask HLDRQ signal	No
Mask RESET signal	No
Mask STOP signal	No
Mask WAIT signal	No

With the properties shown below, select [Yes] to mask the signal from the drop-down list (all properties below are set to [No] by default).

- [Mask NMI/n signal] **[E20(JTAG)][V850E1][V850ES]**
- [Mask HLDRQ signal] **[E20(LPD)/(JTAG)]**
- [Mask RESET signal]
- [Mask STOP signal] **[E20(LPD)/(JTAG)]**
- [Mask WAIT signal] **[E20(LPD)/(JTAG)]**
- [[Mask DBINT signal] **[E20(JTAG)][V850E1][V850ES]**]

**(f) [External Flash Memory Download] [E20(LPD)/(JTAG)]**

You can configure downloading to an external flash memory in this category.

See "[\(5\) Download to external flash memory \[IECUBE\]\[IECUBE2\]\[MINICUBE\]\[E1/E20\(LPD\)/\(JTAG\)\]](#)" for details on how to download to an external flash memory and this category configuration.

**(3) [Download File Settings] tab**

In the [\[Download File Settings\] tab](#), configuration on downloading file to the debug tool can be done.

See "[2.5.1 Execute downloading](#)" for details on each category configuration.

**(4) [Flash Options Settings] tab [V850E2]**

In the [\[Flash Options Settings\] tab \[V850E2\]](#), configuration on options for the flash memory incorporated in the V850E2 microcontroller can be done.

Note that this tab appears only when the selected V850E2 microcontroller supports the flash options.

To configure options, specify the corresponding items via the [Flash Options Setting dialog box \[V850E2\]](#), that is opened by clicking the [...] button appears at the right of the field by selecting the [Flash options] property in the [Flash Options] category on this tab (the [...] button appears only while connected to the debug tool).


Click the [Write] button on this dialog box after specifying each item.

See [Flash Options Setting dialog box \[V850E2\]](#) for details on the configuration.

**Figure 2-126. Opening Flash Options Setting Dialog Box**



Figure 2-127. Flash Options Settings (Flash Options Setting Dialog Box [E20])



#### (5) [Hook Transaction Settings] tab


In the [Hook Transaction Settings] tab, configuration on the hook transaction can be done.

See "[2.16 Use Hook Function](#)" for details on each category configuration and the function of the hook transaction.

### 2.3.6 [EZ Emulator]

Configure the operating environment on the [Property panel](#) below when using EZ Emulator.

**Figure 2-128. Example of Property Panel [EZ Emulator]**



Follow the steps below by selecting the corresponding tab on the [Property panel](#).

- (1) [Connect Settings] tab
- (2) [Debug Tool Settings] tab
- (3) [Download File Settings] tab
- (4) [Hook Transaction Settings] tab

#### (1) [Connect Settings] tab

In the [\[Connect Settings\] tab](#), configuration with regard to the connection to the debug tool can be done.

- (a) [Internal ROM/RAM]
- (b) [DataFlash]
- (c) [Clock]
- (d) [Connection with Target Board]
- (e) [Flash]
- (f) [Programmable I/O]

#### (a) [Internal ROM/RAM]

The configuration of internal ROM/RAM is displayed in this category.

**Figure 2-129. [Internal ROM/RAM] Category [EZ Emulator]**

Internal ROM/RAM	
Size of internal ROM[KBytes]	256
Size of internal RAM[Bytes]	16384

**<1> [Size of internal ROM[KBytes]]**

The internal ROM size to emulate is displayed (unit: Kbytes).

If the selected microcontroller is the V850E1 core and incorporates VSB Flash ROM, it displays the value including the size of VSB Flash ROM.

You cannot change the value of this property.

**<2> [Size of internal RAM[Bytes]]**

The internal RAM size to emulate is displayed (unit: bytes).

If the selected microcontroller is the V850E1 core and incorporates VSB RAM, it displays the value including the size of VSB RAM. If the selected microcontroller version supports multi-core, it displays "total RAM size(RAM size for a core x the number of cores)".

You cannot change the value of this property.

**(b) [DataFlash]**

You can configure the data flash function in this category.

Note that this category appears only when the selected microcontroller incorporates the data flash memory.

**Figure 2-130. [DataFlash] Category**

DataFlash	
Use DataFlash memory area	Yes
Size of DataFlash memory[KBytes]	32
Chip select	CS0

**<1> [Use DataFlash memory area]**

Specify whether to use the data flash memory, from the drop-down list.

Select [Yes] to use the data flash memory ([No] is selected by default).

**<2> [Size of DataFlash memory[KBytes]]**

This property appears only when the [\[Use DataFlash memory area\]](#) property is set to [Yes].

The size of the data flash memory area of the selected microcontroller is displayed (unit: Kbytes).

You cannot change the value of this property.

**<3> [Chip select]**

This property appears only when the [\[Use DataFlash memory area\]](#) property is set to [Yes].

Select the chip select used for mapping of the data flash memory from the drop-down list.

The selectable chip select values differ depending on the selected microcontroller.

Note that when the selected microcontroller is other than the V850ES core, you cannot change the value of the property.

**(c) [Clock]**

You can configure the clock in this category.

**Figure 2-131. [Clock] Category [EZ Emulator]**

Clock	
Main clock frequency [MHz]	4.00
Main clock multiply rate	1
Sub clock frequency[kHz]	32.768
Monitor clock	System

**<1> [Main clock frequency [MHz]]**

Specify the main clock frequency (before multiplier).

You can specify the frequency from the drop-down list or by directly entering a frequency value between 0.001 and 999.999 (unit: MHz).

The drop-down list displays the following frequencies (unit: MHz).

2.50, 4.00 (default), 5.00, 6.00, 8.00, 13.50, 18.00

**<2> [Main clock multiply rate]**

Specify the main clock frequency multiplier.

Select a value from the drop-down list or directly enter a value from 1 to 99.

The drop-down list displays the following multiplier values.

1 (default), 2, 3, 4, 5, 6, 7, 8, 9, 10

**<3> [Sub clock frequency[kHz]]**

This property appears only when the selected microcontroller supports a sub clock.

Specify the sub clock frequency.

You can specify the frequency from the drop-down list or by directly entering a frequency value number between 0.001 and 999.999 (unit: kHz).

The usable sub clock frequency values differ depending on the selected microcontroller.

The drop-down list displays sub clock frequency values which can be used by the currently selected microcontroller.

The minimum usable sub clock frequency is specified by default.

**<4> [Monitor clock]**

This property appears only when the selected microcontroller supports a sub clock.

Specify a clock for monitor programs to operate while the program is stopped.

Specify from the following drop-down list.

System	Operates with main clock (default).
User	Operates with the clock that the program specified.

**(d) [Connection with Target Board]**

You can configure the connection between EZ Emulator and the target board in this category.

**Figure 2-132. [Connection with Target Board] Category [EZ Emulator]**



**<1> [Communication method]**

Specify the port from the drop-down list to which to connect EZ Emulator when performing serial communication between EZ Emulator and the device on the target board.

The type of the port in the drop-down list differs depending on the selected microcontroller.

Note, however, that if the port that can be used for serial communication is limited by the currently selected microcontroller, it is not possible to change the communication method displayed by default (the default communication method depends on the currently selected microcontroller).

**Caution This property cannot be changed when EZ Emulator is connected to CubeSuite+.**

**(e) [Flash]**

You can configure the flash memory rewriting in this category.

**Figure 2-133. [Flash] Category [EZ Emulator]**

<b>Flash</b>	
Security ID	<input checked="" type="checkbox"/> <b>HEX</b> FFFFFFFFFFFFFFFFFFFF
Erase flash ROM when starting	No

**<1> [Security ID]**

This property appears only when the selected microcontroller supports the ROM security function (on-chip debug security ID) for flash memory.

Specify a security ID for reading codes in the internal ROM or internal flash memory.

Directly enter 20 digits hexadecimal number (10 bytes) ([FFFFFFFFFFFFFFFFFF]) is specified by default).

For details on the on-chip debug security ID, see EZ Emulator User's Manual.

**Caution This property cannot be changed when EZ Emulator is connected to CubeSuite+.**

**Remark** When you change the setting of the property, a message appears prompting you to select whether or not to change the security ID of the build tool.

**<2> [Erase flash ROM when starting]**

Specify whether to erase flash ROM when connecting to the debug tool, from the drop-down list.

Select [Yes] to erase the flash ROM ([No] is selected by default).

Note that this property is set to [No] after connecting to the debug tool.

**Caution This property cannot be changed when EZ Emulator is connected to CubeSuite+.**

**(f) [Programmable I/O]**

You can configure the programmable I/O area in this category.

Note that this category is only valid when the selected microcontroller supports the programmable I/O area.

**Remark** Change this setting to temporarily change variables while debugging.

To set a common value for the project, in the Property panel of the build tool, on the [Common Options] tab, in the [Device] category, set the value in [Programmable I/O area start address] property.

**Figure 2-134. [Programmable I/O] Category**

<b>Programmable I/O</b>	
Use Programmable I/O area	<input checked="" type="checkbox"/> Yes
Programmable I/O area start address	<input checked="" type="checkbox"/> <b>HEX</b> 0

**<1> [Use Programmable I/O area]**

Specify whether to use the programmable I/O area.

Select [Yes] to use the programmable I/O area ([No] is selected by default).

**<2> [Programmable I/O area start address]**

This property appears only when the [Use Programmable I/O area] property is set to [Yes].

Specify the start address of the programmable I/O area.

Specify the address within the programmable I/O area ([0] is specified by default).

The address is aligned to 16 Kbytes.

## (2) [Debug Tool Settings] tab

In the [Debug Tool Settings] tab, general configurations on the debug tool can be done.

- (a) [Memory]
- (b) [Access Memory While Running]
- (c) [Set Event While Running]
- (d) [Break]
- (e) [Mask for Input Signal]

### (a) [Memory]

You can configure the memory in this category.

Figure 2-135. [Memory] Category [EZ Emulator]

<b>Memory</b>	
Memory mappings	[4]
[0]	Internal ROM area
[1]	Non-map area
[2]	Internal RAM area
[3]	I/O Register area
Verify on writing to memory	Yes

### <1> [Memory mappings]

Current memory mapping status is displayed for each type of memory area.

The memory mapping status cannot be changed on this panel. If it is necessary to add a memory mapping, click on the [Memory Mapping] property, and click on the [...] button that appears on the right end of the setting field. The [Memory Mapping dialog box](#) opens; perform the setting from there.

See the section for the [Memory Mapping dialog box](#) for details on how to configure the parameters.

Figure 2-136. Opening Memory Mapping Dialog Box

<b>Memory</b>	
Memory mappings	[4]
[0]	Internal ROM area
[1]	Non-map area

**Caution** If you are not connected to a debug tool, then only memory mapping areas added by user is displayed.

Connecting to a debug tool (see "[2.4.1 Connect to the debug tool](#)") will display details for each memory type.

### <2> [Verify on writing to memory]

Specify whether to perform a verify check when the memory value is initialized, from the drop-down list.

Select [Yes] to perform verification (default).

**(b) [Access Memory While Running]**

You can configure the memory access while executing a program (the real-time display update function) in this category. See "[\(4\) Display/modify the memory contents during program execution](#)" for details on the real-time display update function.

**Figure 2-137. [Access Memory While Running] Category [EZ Emulator]**

<b>Access Memory While Running</b>	
Access by stopping execution	No
Update display during the execution	Yes
Display update interval[ms]	500

**<1> [Access by stopping execution]**

Specify whether to allow access to the memory area while executing a program.  
Select [Yes] to allow access ([No] is selected by default).

**<2> [Update display during the execution]**

Specify whether to automatically update the display in the [Watch panel/Memory panel](#) while executing a program.  
Select [Yes] to update the display (default).

**<3> [Display update interval[ms]]**

This property is valid only when the [\[Update display during the execution\]](#) property is set to [Yes].  
Specify the interval in 100ms unit to automatically update the contents in the [Watch panel/Memory panel](#) display while executing a program.  
Directly enter the Integer number between 100 and 65500 (rounding up the fractions less than 100ms) ([500] is specified by default).

**(c) [Set Event While Running]**

You can configure the setting of events while executing a program in this category.

**Figure 2-138. [Set Event While Running] Category**

<b>Set Event While Running</b>	
Set event by stopping execution momentarily	No

**<1> [Set event by stopping execution momentarily]**

Specify whether to forcibly pause the execution for events that cannot be set while executing a program or operating the tracer/timer.  
For details on the event types that are affected by this property, see "[\(2\) Event types that can be set and deleted during execution](#)".  
Select [Yes] to set events above while execution ([No] is selected by default).

**(d) [Break]**

You can configure the break function in this category.

**Figure 2-139. [Break] Category [EZ Emulator]**

<b>Break</b>	
First using type of breakpoint	Software break

**<1> [First using type of breakpoint]**

This property does not appear when the number of the breakpoint type available for the selected microcontroller is only one.

Specify from the following drop-down list a breakpoint type to use with priority when setting it with a one click operation of the mouse in the [Editor panel/Disassemble panel](#).

See "[2.8.2 Stop the program at the arbitrary position \(breakpoint\)](#)" for details on breakpoints.

Software break	Sets software breakpoint with priority (default).
Hardware break	Sets hardware breakpoint with priority.

**<2> [Stop emulation of peripherals when stopping] [E20(LPD)/(JTAG)]**

Specify from the drop-down list whether to terminate the peripheral emulation while stopping the program execution.

Select [Yes] to terminate ([No] is selected by default).

**(e) [Mask for Input Signal]**

You can configure the input signal masking in this category.

**Figure 2-140. [Mask for Input Signal] Category [EZ Emulator]**



With the properties shown below, select [Yes] to mask the signal from the drop-down list (all properties below are set to [No] by default).

- [Mask RESET signal]

**(3) [Download File Settings] tab**

In the [\[Download File Settings\] tab](#), configuration on downloading file to the debug tool can be done.

See "[2.5.1 Execute downloading](#)" for details on each category configuration.

**(4) [Hook Transaction Settings] tab**


In the [\[Hook Transaction Settings\] tab](#), configuration on the hook transaction can be done.

See "[2.16 Use Hook Function](#)" for details on each category configuration and the function of the hook transaction.


### 2.3.7 [Simulator]

Configure the operating environment on the [Property panel](#) below when using Simulator.

**Figure 2-141. Example of Property Panel [Simulator[V850E1][V850ES]]**



**Figure 2-142. Example of Property Panel [Simulator[V850E2]]**



Follow the steps below by selecting the corresponding tab on the [Property panel](#).

- (1) [Connect Settings] tab
- (2) [Debug Tool Settings] tab
- (3) [Download File Settings] tab
- (4) [Flash Options Settings] tab [V850E2]
- (5) [Hook Transaction Settings] tab

#### Cautions 1. [V850E1][V850ES]

The instruction simulator for V850E1/V850ES cannot simulate the clock generator. For this reason, the CPU operation clock will always have the main clock frequency set in the [Main

clock frequency [MHz]] property in the [Clock] category on the [\[Connect Settings\] tab](#) of the [Property panel](#) (even if a built-in peripheral I/O register with a clock generator is manipulated, the CPU's operation clock will not change).

## 2. [V850E2]

The instruction simulator for V850E2 supports as following functions (other functions are not supported).

- CPU instruction
- Exceptions
- System register protection
- Memory protection
- Timing supervision function
- Floating-point operation function

Furthermore be sure to following notes.

- The access to external memory area is not supported
- A simulation result of the floating-point unit (FPU) has a margin of errors compared to real devices. The simulator uses the floating-point library of Visual C++, and store a result calculated by 80-bit in a register.
- System error exception and Memory error exception are not supported.
- The simulation of cache memory is not supported.
- The instructions (SYNCE, SYNCMD, and SYNCP) are not supported. If these were executed, the operation is same as NOP execution.
- The operation clock of CPU is always 4MHz. The setting of the [Main clock frequency [MHz]] property in the [Clock] category on the [\[Connect Settings\] tab](#) of the [Property panel](#) is ignored.
- It is impossible to use data flash area. If CPU access this area, CPU breaks and error is happen.
- The value of Option byte storage register "OPBT0" is always "0".
- EH\_RESET register features are not supported. In the case of a CPU reset, the reset address will always be "0x0".
- The number of execution clocks of each instruction will be the number of execution clocks when another instruction is executed immediately after that instruction is executed.

**Remark** When Simulator to be used corresponds to peripheral function simulations, you can use the Simulator GUI. See "[2.17 Use the Simulator GUI \[Simulator\]](#)" for details on the Simulator GUI.

### (1) [\[Connect Settings\] tab](#)

In the [\[Connect Settings\] tab](#), configuration with regard to the connection to the debug tool can be done.

- (a) [\[Internal ROM/RAM\]](#)
- (b) [\[Clock\]](#)
- (c) [\[Configuration\]](#)
- (d) [\[Programmable I/O\] \[V850E1\]\[V850ES\]](#)

#### (a) [\[Internal ROM/RAM\]](#)

You can configure internal ROM/RAM in this category.

The size of internal ROM/RAM of the selected microcontroller is specified by default (when the selected microcontroller is the V850E1 core and incorporates VSB Flash ROM/VSB RAM, the value including its size is specified).

There is no need to change the settings in this category if you wish to debug with the same memory mapping of the selected microcontroller.

Figure 2-143. [Internal ROM/RAM] Category [Simulator[V850E1][V850ES]]

<b>Internal ROM/RAM</b>	
Size of internal ROM[KBytes]	256
Size of internal RAM[Bytes]	16384

Figure 2-144. [Internal ROM/RAM] Category [Simulator[V850E2]]

<b>Internal ROM/RAM</b>	
Size of internal ROM[KBytes]	3072
Size of internal RAM[Bytes]	245760

## &lt;1&gt; [Size of internal ROM[KBytes]]

## - [V850E1][V850ES]

Specify the internal ROM size to simulate (unit: Kbytes).

To perform debugging after changing the memory mapping, make a selection from the drop-down list.

Note that when the selected microcontroller is a ROMless product, the property value cannot be changed.

## - [V850E2]

The internal ROM size to simulate is displayed (unit: Kbytes).

You cannot change the value of this property.

## &lt;2&gt; [Size of internal RAM[Bytes]]

## - [V850E1][V850ES]

Specify the internal RAM size to simulate (unit: bytes).

To perform debugging after changing the memory mapping, make a selection from the drop-down list.

## - [V850E2]

The internal RAM size to simulate is displayed (unit: bytes).

You cannot change the value of this property.

## (b) [Clock]

You can configure the clock in this category.

Figure 2-145. [Clock] Category [Simulator]

<b>Clock</b>	
Main clock frequency [MHz]	4.00
Sub clock frequency[kHz]	32.768
Select Timer/Trace clock frequency	CPU clock frequency
Unit of Timer/Trace clock frequency	MHz
Timer/Trace clock frequency	----

## &lt;1&gt; [Main clock frequency [MHz]]

Specify the main clock frequency.

You can specify the frequency from the drop-down list or by directly entering a frequency value between 0.001 and 999.999 (unit: MHz).

The drop-down list displays the following frequencies (unit: MHz).

## - [V850E1][V850ES]

1.00, 2.00, 3.00, 3.57, 4.00 (default), 4.19, 4.91, 5.00, 6.00, 8.00, 8.38, 10.00, 12.00, 16.00, 20.00, 25.00, 30.00, 32.00, 33.33, 34.00, 40.00, 48.00, 50.00, 64.00, 80.00

- [V850E2]

1.00, 2.00, 3.00, 3.57, 4.00, 4.19, 4.91, 5.00, 6.00, 7.20, 8.00 (default), 8.38, 9.60, 10.00, 12.00, 16.00, 20.00, 25.00, 30.00, 32.00, 33.33, 34.00, 40.00, 48.00, 50.00, 64.00, 80.00

<2> [Sub clock frequency[kHz]]

This property appears only when the selected microcontroller supports a sub clock.

Specify the sub clock frequency.

You can specify the frequency from the drop-down list or by directly entering a frequency value between 0.001 and 999.999 (unit: kHz).

The drop-down list displays the following frequencies (unit: kHz).

32.768 (default)

<3> [Select Timer/Trace clock frequency]

Specify the clock frequency for using timer/trace function.

Specify from the following drop-down list.

CPU clock frequency	Uses the CPU clock frequency (default).
Specify clock frequency	Specifies an arbitrary frequency (property items to specify become valid in the lower area).

<4> [Unit of Timer/Trace clock frequency]

This property appears only when the [Select Timer/Trace clock frequency] property is set to [Specify clock frequency].

Specify from the following drop-down list the unit of the clock frequency for timer/trace.

MHz	The unit of the frequency is in MHz (default).
KHz	The unit of the frequency is in kHz.

<5> [Timer/Trace clock frequency]

The operation of this property differs depending on the specification of the [Select Timer/Trace clock frequency] property.

- When [Specify clock frequency] is specified:

Specify the clock frequency for timer/trace.

Directly enter the value between 1 [kHz] and 999.999 [MHz] ([4.00] [V850E1][V850ES]/[8.00] [V850E2] is specified by default).

Unit is depending on the specification with the [Unit of Timer/Trace clock frequency] property.

- When [CPU clock frequency] is specified:

While disconnected from the debug tool: [---\_---] is displayed.

While connected to the debug tool: [CPU clock frequency] is displayed.

(c) [Configuration]

You can configure the customization of the simulator in this category.

**Caution Properties in this category cannot be changed when Simulator is connected to CubeSuite+.**

Figure 2-146. [Configuration] Category

<input type="checkbox"/> Configuration	
Use simulator configuration file	<input checked="" type="checkbox"/> Yes
Simulator configuration file	

**<1> [Use simulator configuration file]**

Specify from the drop-down list whether to use the simulator configuration file to perform user customization (adding of user models) of the simulator.

Select [Yes] to use the simulator configuration file ([No] is selected by default).

**<2> [Simulator configuration file]**

This property appears only when the [Use simulator configuration file] property is set to [Yes].

Specify the simulator configuration file to use.

Directly enter the file name, or select the file with the [Select Simulator Configuration File dialog box \[Simulator\]](#) opened by clicking on the [...] button that appears on the right end of the setting field.

**(d) [Programmable I/O] [V850E1][V850ES]**

You can configure the programmable I/O area in this category.

Note that this category is only valid when the selected microcontroller supports the programmable I/O area.

**Remark** Change this setting to temporarily change variables while debugging.

To set a common value for the project, in the Property panel of the build tool, on the [Common Options] tab, in the [Device] category, set the value in [Programmable I/O area start address] property.

Figure 2-147. [Programmable I/O] Category

<input type="checkbox"/> Programmable I/O	
Use Programmable I/O area	<input checked="" type="checkbox"/> Yes
Programmable I/O area start address	<input checked="" type="checkbox"/> HEX 0

**<1> [Use Programmable I/O area]**

Specify whether to use the programmable I/O area.

Select [Yes] to use the programmable I/O area ([No] is selected by default).

**<2> [Programmable I/O area start address]**

This property appears only when the [Use Programmable I/O area] property is set to [Yes].

Specify the start address of the programmable I/O area. Specify the address within the programmable I/O area ([0] is specified by default).

The address is aligned to 16 Kbytes.

**(2) [Debug Tool Settings] tab**

In the [\[Debug Tool Settings\] tab](#), general configurations on the debug tool can be done.

- (a) [\[Memory\]](#)
- (b) [\[Access Memory While Running\]](#)
- (c) [\[Break\]](#)
- (d) [\[Trace\]](#)
- (e) [\[Timer\]](#)

- (f) [Coverage]
- (g) [Simulator GUI]

**(a) [Memory]**

You can configure the memory in this category.

Figure 2-148. [Memory] Category [Simulator]

<b>Memory</b>		[4]
Memory mappings		
[0]	Internal ROM area	
[1]	Non-map area	
[2]	Internal RAM area	
[3]	I/O Register area	

**<1> [Memory mappings]**

Current memory mapping status is displayed for each type of memory area.

The memory mapping status cannot be changed on this panel. If it is necessary to add a memory mapping, click on the [Memory Mapping] property, and click on the [...] button that appears on the right end of the setting field. The [Memory Mapping dialog box](#) opens; perform the setting from there.

See the section for the [Memory Mapping dialog box](#) for details on how to configure the parameters.

Figure 2-149. Opening Memory Mapping Dialog Box



<b>Memory</b>		[4]
Memory mappings		
[0]	Internal ROM area	
[1]	Non-map area	

**Caution** If you are not connected to a debug tool, then only memory mapping areas added by user is displayed.

Connecting to a debug tool (see "[2.4.1 Connect to the debug tool!](#)") will display details for each memory type.

**(b) [Access Memory While Running]**

You can configure the memory access while executing a program (the real-time display update function) in this category. See "[\(4\) Display/modify the memory contents during program execution](#)" for details on the real-time display update function.

Figure 2-150. [Access Memory While Running] Category [Simulator]

<b>Access Memory While Running</b>	
Update display during the execution	Yes
Display update interval[ms]	500

**<1> [Update display during the execution]**

Specify whether to automatically update the display in the [Watch panel/Memory panel](#) during a program execution.

Select [Yes] to update the display (default).

**<2> [Display update interval[ms]]**

This property is valid only when the [\[Update display during the execution\]](#) property is set to [Yes].


Specify the interval in 100ms unit to automatically update the contents in the [Watch panel/Memory panel](#) display while executing a program.

Directly enter the Integer number between 100 and 65500 (rounding up the fractions less than 100ms) ([500] is selected by default).

**(c) [Break]**

You can configure the break function in this category.

**Figure 2-151. [Break] Category [Simulator]**



**<1> [Execute instruction at breakpoint when break]**

Specify the timing to stop the program execution by breakpoints either after or before the execution of the instruction at the breakpoint.

Select [Yes] to stop after the execution of the instruction ([No] is selected by default).

See "[2.8.2 Stop the program at the arbitrary position \(breakpoint\)](#)" for details on breakpoints.

**(d) [Trace]**

You can configure the trace function in this category.

See "[2.11 Collect Execution History of Programs \[IECUBE\]\[IECUBE2\]\[Simulator\]](#)" for details on the trace function and this category configuration.

**(e) [Timer]**

You can configure the timer function in this category.

See "[2.12 Measure Execution Time of Programs](#)" for details on the timer function.

**Figure 2-152. [Timer] Category [Simulator]**



**<1> [Use timer function]**

Specify whether to use the timer function, from the drop-down list.

Select [Yes] to use the timer function ([No] is selected by default).

**(f) [Coverage]**

You can configure the coverage function in this category.

See "[2.13 Measure Coverage \[IECUBE\]\[IECUBE2\]\[Simulator\]](#)" for details on the coverage function and this category configuration.

**(g) [Simulator GUI]**

You can configure the Simulator GUI function in this category.

See "[2.17 Use the Simulator GUI \[Simulator\]](#)" for details on the Simulator GUI function and this category configuration.

**(3) [Download File Settings] tab**

In the [\[Download File Settings\] tab](#), configuration on downloading file to the debug tool can be done.

See "[2.5.1 Execute downloading](#)" for details on each category configuration.

**(4) [Flash Options Settings] tab [V850E2]**

In the [\[Flash Options Settings\] tab \[V850E2\]](#), configuration on options for the flash memory incorporated in the V850E2 microcontroller can be done.

Note that this tab appears only when the selected V850E2 microcontroller supports the flash options.

To configure options, specify the corresponding items on the [Flash Options Setting dialog box \[V850E2\]](#), that is opened by clicking the [...] button appears at the right of the field by selecting the [Flash options] property in the [Flash Options] category on this tab (the [...] button appears only while connected to the debug tool).


Click the [Write] button on this dialog box after specifying each item.

See [Flash Options Setting dialog box \[V850E2\]](#) for details on the configuration.

**Figure 2-153. Opening Flash Options Setting Dialog Box**



**Figure 2-154. Flash Options Settings (Flash Options Setting Dialog Box [Simulator])**

**(5) [Hook Transaction Settings] tab**

In the [\[Hook Transaction Settings\] tab](#), configuration on the hook transaction can be done.

See "[2.16 Use Hook Function](#)" for details on each category configuration and the function of the hook transaction.

## 2.4 Connect to/Disconnect from the Debug Tool

This section describes how to connect to/disconnect from the debug tool.


### 2.4.1 Connect to the debug tool

By selecting [Connect to Debug Tool] from the [Debug] menu, CubeSuite+ starts communicating with the debug tool selected in the active project.

After succeeding in the connection to the debug tool, the [Statusbar](#) of the [Main window](#) changes as follows:

For details on each item displayed on the [Statusbar](#), see the section of the "[Main window](#)".

**Figure 2-155. Statusbar Indicating Successful Connection to Debug Tool**



**Caution** If the version of compiler being used is not supported by CubeSuite+, [Connect to Debug Tool] will be disabled.


- Remarks 1.** When the button on the [Debug toolbar](#) is clicked, the specified file is downloaded automatically after connecting to the debug tool (see "[2.5.1 Execute downloading](#)").  
When the button on this toolbar is clicked, the project is built automatically, and then the built file is downloaded after connecting to the debug tool.
- 2. [Simulator]**  
When a microcontroller whose Simulator supports peripheral function simulations is selected, the [Simulator GUI window](#) is automatically opened after connecting to the debug tool (default).

### 2.4.2 Disconnect from the debug tool

By clicking the button on the [Debug toolbar](#), CubeSuite+ cuts off the communication with the connected debug tool.

After disconnecting from the debug tool, the [Statusbar](#) of the [Main window](#) changes as follows:

**Figure 2-156. Statusbar Indicating Disconnection from Debug Tool**



**Caution** The debug tool cannot be disconnected from CubeSuite+ while the program is running.

**Remark** Disconnecting the debug tool will close all the panels and dialog boxes that can be displayed only during the connection.

#### 2.4.3 Connect to the debug tool using hot plug-in [E1/E20(LPD)/(JTAG)[V850E2]]

With hot plug-in function, you can connect the debug tool to the target board during execution of a program (without having to turn off the system) and debug the program while it is in execution.

Follow the steps below to establish hot plug-in connection.

##### Cautions 1. [E1(JTAG)[V850E2]]

To establish hot plug-in connection, you need the optional hot plug adapter for the E1 emulator, between E1 and the target board.

2. When a hot plug-in connection is made, an automatic rewrite of internal flash ROM using the flash self library cannot be performed.

##### (1) Execute the program

Execute the program which has been downloaded onto the microcontroller on the target board without connecting to the emulator.

##### (2) Select the debug tool

In the active project, select the debug tool which supports hot plug-in connection (E1/E20(LPD)/(JTAG)).


##### (3) Connect the debug tool to CubeSuite+ using hot plug-in

Select [Hot Plug-in] from [Debug] menu to initiate the preparation for hot plug-in connection.

##### (4) Connect to the target board

Following message will appear once you are ready to start hot plug-in connection. Connect the emulator to the target system and click [OK]. This will start the communication with the debug tool which is selected in the currently active project.


Figure 2-157. Message Indicating that Hot Plug-in Connection Is Ready to Be Started



##### (5) Hot plug-in connection completed

Once the connection to the debug tool is successfully completed, the [Statusbar](#) on the [Main window](#) will change as shown below. For details on each item displayed on the statusbar, see the section of the "[Main window](#)".

Figure 2-158. Statusbar Indicating Successful Hot plug-in Connection to Debug Tool



## 2.5 Download/Upload Programs

This section describes how to download programs (such as load module files) to debug to CubeSuite+ and how to upload the memory contents being debugged from CubeSuite+ to files.

### 2.5.1 Execute downloading

Download the load module file to be debugged to the debug tool that is currently connected.

Follow the steps below on the [Download File Settings] tab in the [Property panel](#) for the downloading, and then execute the downloading.

#### (1) [Download] category setting

**Figure 2-159. [Download] Category**

<b>Download</b>	
Download files	[1]
[0]	Debug Build\v850esfx3.out
File	Debug Build\v850esfx3.out
File type	Load module file
Download object	Yes
Download symbol information	Yes
CPU Reset after download	Yes
Download Mode	Speed priority
Erase flash ROM before download	No
Automatic change method of event setting position	Suspend event
Check reserved area overwriting when downloading	Yes

**Caution** Properties displayed in this category differ depending on the debug tool used in the project.

#### (a) [Download files]

The names of files to be downloaded and download conditions are displayed (the number enclosed with "[ ]" indicates the number of files to be download).

Files that are specified as build target files in the main project or subprojects will automatically be selected as the files to be downloaded<sup>Note</sup>.

However, you can manually change the download files and the condition. In this case, see "[2.5.2 Advanced downloading](#)".

**Note** To download the load module files created by an external build tool (e.g., compilers and assemblers other than the build tools supplied with CubeSuite+), a debug-dedicated project needs to be created.

If you use a debug-dedicated project as the subject to debug, add your a download file to Download files node on project tree. The file to be downloaded will be reflected in this property.

See "CubeSuite+ Integrated Development Environment User's Manual: Start" for details on the using an external build tool and a debug-dedicated project.

#### (b) [CPU Reset after download]

Specify whether to reset the CPU after downloading.

Select [Yes] to reset the CPU (default).

#### (c) [Download Mode] (except [Simulator])

Specify the download mode for downloading to the flash ROM.

Select one of the options from the following drop-down list.

Speed priority	Fills free space between the first data and the final data with FFH (the previous value in free space before the first data and after the final data is retained). Download speed will be faster because the writing data is reduced (default).
Data priority	Retains the previous value in free space. Download speed will be very slow because data in free space are read once.

**(d) [Erase flash ROM before download]**

This property is valid only when the [Download Mode] (except [Simulator]) property is set to [Speed priority](default).

Specify whether to erase the flash ROM before downloading.

Select [Yes] to erase the flash ROM ([No] is selected by default).

**(e) [Automatic change method of event setting position]**

If the file is downloaded again during debugging then the location (address) set for the currently configured event may change to midway in the instruction.

Specify with this property how to handle the target event in this circumstance.

Select one of the options from the following drop-down list.

Move to the head of instruction	Sets the event to the top address of the instruction.
Suspend event	Disables the event (suspended state) (default).

Note, however, that this property setting only applies to the location setting of events without debugging information. The location setting of events with debug information is always moved to the beginning of the source text line.

**(f) [Check reserved area overwriting when downloading] [MINICUBE2][E1/E20(Serial)][EZ Emulator]**

Specify whether to output a message when overwriting to an area reserved for use by the emulator is attempted at the time of downloading.

Select [Yes] to output a message (default).

**(2) [Debug Information] category setting**

Figure 2-160. [Debug information] Category

<b>Debug Information</b>	
Execute to the specified symbol after CPU Reset	Yes
Specified symbol	_main
Startup start symbol	_start
Startup end symbol	_startend

**(a) [Execute to the specified symbol after CPU Reset]**

Specify from the drop-down list whether to execute the program to the specified symbol position after CPU reset or downloading (for only when the [CPU Reset after download] property is set to [Yes]).

Select [Yes] to execute the program to the specified symbol position after CPU reset (default).

**Remark** When the [CPU Reset after download] property is set to [Yes], the operation after downloading is as follows:

If [Yes] is selected for this property, the [Editor panel](#) will open automatically with displaying source

text of the position specified with the [Specified symbol] property after downloading.

If [No] is selected for this property, the Editor panel will open with displaying source text of the reset address (when if the source text has not been allocated to the reset address, the contents of the reset address is displayed in the [Disassemble panel](#)).

#### (b) [Specified symbol]

This property appears only when the [Execute to the specified symbol after CPU Reset] property is set to [Yes].

Specify the position at which the program is stop after CPU reset.

Directly enter an address expression between 0 and "*last address in address space*" ([\_\_main] is specified by default).

Note, however, that the program will not be executed if the specified address expression cannot be converted into an address.

**Remark** Normally, specify the following.

For assembler source: Start label corresponding to main function

For C source: Symbol assigned to the start of the main function name

#### (c) [Startup start symbol]

Specify the start symbol of the text area (code area) of the startup routine.

Directly enter an address expression between 0 and "*last address in address space*" ([\_\_start] is specified by default).

This setting is not needed if the source is assembly language.

#### (d) [Startup end symbol]

Specify the end symbol of the text area (code area) of the startup routine.

Directly enter an address expression between 0 and "*last address in address space*" ([\_\_startend] is specified by default).

This setting is not needed if the source is assembly language.

- Cautions**
1. To automatically display the source text right after downloading the file, the startup symbol must be correctly specified.
  2. By default, CPU reset automatically occurs after downloading the file, and then the program is executed to the specified symbol position. If this operation above is not needed, specify [No] with both of the [CPU Reset after download] and [Execute to the specified symbol after CPU Reset] property.

### (3) Execute download

Click the  button on the [Debug toolbar](#).

If this operation is performed while disconnecting from the debug tool, the application automatically connects to the debug tool, and then performs the download.

**Remark** When a program that has been modified during debugging is re-downloaded, you can easily build and download it by selecting [Build & Download] from the [Debug] menu on the [Main window](#).

If the load module file is successfully downloaded, the [Editor panel](#) opens automatically, and the contents of the downloaded file's source text are displayed.

**Remark** You can automatically overwrite the value of I/O register/CPU register with the specified values before and after performing the download (see "[2.16 Use Hook Function](#)" for details).

### 2.5.2 Advanced downloading

You can change the download files and the condition to download.

With CubeSuite+, the following file types can be downloaded.

**Table 2-3. Type of Files That Can be Downloaded**

File Type	File Format	Extension
Load module file	Load module format	.lmf [CX] .out [CA850] .extension [GHS] <sup>Note 1</sup>
Hex file	Intel Hex format (Standard)	.hex
	Intel Hex format (Extension)	
	Intel Hex format (Extension linear)	
	Motorola S type Hex format - (S0, S1, S9 - 16 bit-address) - (S0, S2, S8 - 24 bit-address) - (S0, S3, S7 - 32 bit-address)	
	Extended Tektronix Hex format	
Hex file with ID tag <sup>Note 2</sup> (except [Simulator])	Intel Hex format (Extension) with ID tag	.hex
	Intel Hex format (Extension linear) with ID tag	
	Motorola S type Hex format with ID tag - (S0, S2, S8 - 24 bit-address) - (S0, S3, S7 - 32 bit-address)	
	Extended Tektronix Hex format with ID tag	
	Intel Hex format (Extension) in the flash programmer format	
Hex file (Flash Programmer) <sup>Note 2</sup> (except [Simulator])	Intel Hex format (Extension linear) in the flash programmer format	.hex
	Motorola S type Hex format in the flash programmer format - (S0, S2, S8 - 24 bit-address) - (S0, S3, S7 - 32 bit-address)	
	Extended Tektronix Hex format in the flash programmer format	
	Binary data file	.bin

**Notes 1.** Notes on using GHS compiler (Green Hills Software, Inc., USA)

(When GHS compiler is used, a debug-dedicated project needs to be created.)

- Supported version
  - MULTI (Ver. 5.x)
- Supported options
  - Debug option: -G -dual\_debug (recommended)
  - Optimization option -Ospace, -O, -Ospeed, -Onone
  - Other than above: -prepare Dispose, -call
- C++ language and GNU C expanded specifications are not supported.
- Notes on debugging
  - Debugging of assembler sources is not possible.
  - No breakpoints can be set to functions that are defined in "#include".

- The value of a watch-expression of variable may be displayed incorrectly, because debug information does not include valid period information of variables. This item applies to cases where a variable is optimized and deleted, or a value is temporarily assigned to a register.
- Floating point rounding accuracy differs between the compiler and debugger.
- Only a current function is displayed in the [Call Stack panel](#) because the call stack information cannot be acquired.
- Step execution in "#include" statement and "setjmp"/"longjmp" function is not possible.
- A return out execution from a variable-length argument function may fail.
- **[IECUBE]**

When the flash library is ROMized, the flash self programming emulation function cannot be used.

2. This file type is enabled only when the selected microcontroller incorporates a data flash memory.


You can change the download files or download conditions in the following [Download Files dialog box](#).

The Download Files dialog box is opened by clicking the [...] button that appears at the right edge in the column of the [Download files] property when you select it in the [Download] category on the [\[Download File Settings\] tab](#) of the [Property panel](#).

**Figure 2-161. Opening Download Files Dialog Box**



**Figure 2-162. Advanced Downloading (Download Files Dialog Box)**



This section describes how to configure on the [Download Files dialog box](#) above when the following cases.

For details on the contents and function in each area, see the section for the [Download Files dialog box](#).

- (1) Change download conditions for load module files
- (2) Add download files (\*.hex/\*.bin)
- (3) Download multiple load module files

- (4) Perform source level debugging with a hex or binary data format file
- (5) Download to external flash memory [IECUBE][IECUBE2][MINICUBE][E1/E20(LPD)/(JTAG)]

**(1) Change download conditions for load module files**

Follow the steps below in the [Download Files dialog box](#) to change the download conditions (object information and symbol information) for load module files to download.

**(a) Select a load module file**

Select a load module file to download in the [Download file list] area.

**(b) Change download conditions**

Current download conditions for the selected load module file are displayed in the [Download file property] area.

Change each items displayed in the property.

Download object	Specify whether to download the object information from the specified file.		
	Default	Yes	
	Modifying	Select from the drop-down list.	
	Available values	Yes	Downloads object information.
		No	Does not download object information.
Download symbol information	Specify whether to download the symbol information from the specified file <sup>Note</sup> .		
	Default	Yes	
	Modifying	Select from the drop-down list.	
	Available values	Yes	Downloads symbol information.
		No	Does not download symbol information.

**Note** If the symbol information have not been downloaded, the source level debugging cannot be performed.

**(c) Click the [OK] button**

Enable all the configuration in this dialog box and change the download conditions.

**(2) Add download files (\*.hex/\*.bin)**

Follow the steps below to add download files other than the load module format (hex files (\*.hex) or binary data files (\*.bin)) in the [Download Files dialog box](#).

**(a) Click the [Add] button**

When the [Add] button is clicked, a blank list item "-" is displayed in the last line of the [Download file list] area.

**(b) Property configuration of the download files to add**

Configure the download conditions for the download file to add in the [Download file property] area.

Configure each item displayed with the following condition.

When the configuration is completed, the file name specified in this property is displayed in the blank list of the [Download file list] area.

File	Specify the download file (in hex format (*.hex) or binary data format (*.bin)) to download (up to 259 characters).	
	Default	Blank
	Modifying	Directly enter from the keyboard, or specify with the <a href="#">Select Download File dialog box</a> opened by clicking the [...] button.
	Available values	See " <a href="#">Table 2-3. Type of Files That Can be Downloaded</a> ".
File type	Specify the type of the file to download. Select [Hex file] or [Binary data file].	
	Default	Load module file
	Modifying	Select from the drop-down list.
	Available values	Either one of the following - Load module file - Hex file - Hex file with ID Tag <sup>Note</sup> - Binary data file
Offset	Specify the offset from the address at which the file's download is to start. Note that this item appears only when [File type] is set to [Hex file].	
	Default	0
	Modifying	Directly enter from the keyboard.
	Available values	0x0 to 0xFFFFFFFF in hexadecimal number
Start address	Specify the address at which to start the file's download. Note that this item appears only when [File type] is set to [Binary data file].	
	Default	0
	Modifying	Directly enter from the keyboard.
	Available values	0x0 to 0xFFFFFFFF in hexadecimal number

**Note For other than [Simulator]**

This item appears only when the selected microcontroller incorporates the data flash memory and the data flash memory function is valid (i.e. when the [Use DataFlash memory area] property in the [DataFlash] category on the [\[Connect Settings\] tab](#) of the [Property panel](#) is set to [Yes]).

**Remark** The settings of whether to download the object information or symbol information can be made only when the type of the file to download is load module files.

**(c) Check the order of download**

The order of the download is the display order of the files displayed in the [Download file list] area. If you want to change the order, use the [Up]/[Down] button.

**(d) Click the [OK] button**

Enable all the configuration in this dialog box and add a download file (the file name is displayed in the [Download] category on the [\[Download File Settings\] tab](#) of the [Property panel](#)).

### (3) Download multiple load module files

Follow the steps below on the [Download Files dialog box](#) to download multiple load module files.

**Caution** When debugging a program consisting of multiple load module files, care should be taken to avoid overlapping of location addresses.

#### (a) Click the [Add] button

When the [Add] button is clicked, a blank list item "-" is displayed in the last line of the [Download file list] area.

#### (b) Property configuration of the download files to add

Configure the download conditions for the download file to add in the [Download file property] area.

Configure each item displayed with the following condition.

When the configuration is completed, the file name specified in this property is displayed in the blank list of the [Download file list] area.

File	Specify the name of the load module file to be added (up to 259 characters).	
Default	Blank	
Modifying	Directly enter from the keyboard, or specify with the <a href="#">Select Download File dialog box</a> opened by clicking the [...] button.	
Available values	See " <a href="#">Table 2-3. Type of Files That Can be Downloaded</a> "	
File type	Specify the type of the file to download. Here, select [Load module file].	
Default	Load module file	
Download object	Specify whether to download the object information from the specified file.	
Default	Yes	
Modifying	Select from the drop-down list.	
Available values	Yes	Downloads object information.
	No	Does not download object information.
Download symbol information	Specify whether to download the symbol information from the specified file <sup>Note</sup> .	
Default	Yes	
Modifying	Select from the drop-down list.	
Available values	Yes	Downloads symbol information.
	No	Does not download symbol information.

**Note** If the symbol information have not been downloaded, the source level debugging cannot be performed.

**Remark** You can decrease the memory usage by selecting [No] for the [Download symbol information] item if the symbol information is not required for the module (in this case, however, the source level debugging can not be performed for the file).

#### (c) Check the order of download

The order of the download is the display order of the files displayed in the [Download file list] area.

If you want to change the order, use the [Up]/[Down] button.

**(d) Click the [OK] button**

Enable all the configuration in this dialog and add the specified load module file (the specified file name is displayed in the [Download] category on the [\[Download File Settings\] tab of the Property panel](#)).

**(4) Perform source level debugging with a hex or binary data format file**

Even when a hex file (\*.hex) or a binary data file (\*.bin) is specified to be the subject file to download, it is possible to do source level debugging by downloading symbol information for the load module file from which the subject file was created, along with the subject file that you download.

To do so, follow the steps below on the [Download Files dialog box](#).

**(a) Click the [Add] button**

When the [Add] button is clicked, a blank list item "-" is displayed in the last line of the [Download file list] area.

**(b) Property configuration of the load module file to add**

Configure each item displayed with the following condition in the [Download file property] area.

File	Specify a load module file from which the hex file (*.hex) or binary data file (*.bin) that you want to download was created. Directly enter from the keyboard, or specify with the <a href="#">Select Download File dialog box</a> opened by clicking the [...] button that appears at right by selecting this property.
File type	Select [Load module file] (default).
Download object	Specify [No].
Download symbol information	Select [Yes] (default).

**(c) Click the [OK] button**

Enable all the configuration in this dialog box and add the specified load module file (Only the symbol information included in the load module file will be downloaded).

**(5) Download to external flash memory [IECUBE][IECUBE2][MINICUBE][E1/E20(LPD)/(JTAG)]**

The download files specified in the [Download Files dialog box](#) can be downloaded to the flash memory connected to an external bus of the microcontroller used.

In this case, follow the procedure described below.


**(a) Configuration of external flash memory information**

Configure the external flash memory information file (\*.fdb) and its download conditions (i.e. setting for the external flash memory) with the [External Flash Memory Download dialog box](#), which is opened by clicking the [...] button that appears at the right edge in the column of the [External Flash Memory Setting] property when you select it in the [External Flash Memory Download] category on the [\[Debug Tool Settings\] tab of the Property panel](#).

Figure 2-163. [External Flash Memory Download] Category



Figure 2-164. Download to External Flash Memory (External Flash Memory Download Dialog Box)



In the [External Flash Memory Download dialog box](#) shown above, click the [Add] button to newly register a external flash memory information file to be used, and then configure the following properties in the [Exterior Flash Setting property] area.

#### <1> [File name]

Specify the external flash memory information file (\*.fdb).

Directly enter the file name (the reference point of the path is the project folder) or select the file with the [External Flash Memory Download dialog box](#), which is opened by clicking on the [...] button that appears at the right edge in this field when you select this property.

The flash memory information file can be downloaded from our website (Development Tools Download webpage).

#### <2> [Start address]

Specify the start address of the external flash memory.

Directly enter the address from 0x0 to 0xFFFFFFFF ([0] is selected by default).

#### <3> [Data width]

Specify the data width (access size) of the external flash memory from the drop-down list (see "Table 2-4. Parameter Set Values (For External Flash Memory)").

The drop-down list displays the following data widths (unit: Kbytes).

8 (default), 16, 32

#### <4> [Number of parallel]

Specify the number of external flash memories in parallel (see "Table 2-4. Parameter Set Values (For External Flash Memory)").

You can specify the number from the drop-down list or by directly entering an integer number between 1 and 99.

The drop-down list displays the following numbers.

1 (default), 2, 4

## &lt;5&gt; [Number of serial]







Specify the number of external flash memories in serial (see "Table 2-4. Parameter Set Values (For External Flash Memory)").

You can specify the number from the drop-down list or by directly entering an integer number between 1 and 99.

The drop-down list displays the following numbers.

1 (default), 2

**Table 2-4. Parameter Set Values (For External Flash Memory)**

Connection of Flash Memory	Data Width	Number of Parallel	Number of Serial
	8	1	1
	8	1	2
	16	1	1
	16	2	1
	16	1	2
	32	4	1

**(b) Setting of external bus**

Change the peripheral I/O register setting so as to use external buses, which enables accessing from the microcontroller to flash memory.

This setting can be changed via the [IOR panel](#), but the specification of the batch processing to proceed right before downloading by using the hook function is recommended, because the setting must be changed for individual registers (see "[2.16 Use Hook Function](#)").

**(c) Execute download**

Execute download (see "[\(3\) Execute download](#)").

**2.5.3 Execute uploading**

The contents of the memory of the debug tool currently connected can be saved (uploaded) in an arbitrary file.

You can upload the data in the [Data Save dialog box](#) that is opened by selecting the [Debug] menu >> [Upload...].

In this dialog box, follow the steps below.

**Figure 2-165. Execute Uploading (Data Save Dialog Box)**

**(1) Specify [File Name]**

Specify the name of the file to save.

You can either type a filename directly into the text box (up to 259 characters), or select one from the input history via the drop-down list (up to 10 items). You can also specify the file by clicking the [...] button, and selecting a file via the [Select Data Save File dialog box](#).

**(2) Specify [File Type]**

Select the format in which to save the file from the following drop-down list.

The following file formats can be selected.

**Table 2-5. Type of Files That Can be Uploaded**

Displayed List Items in [File Type]
Intel Hex format (*.hex) <sup>Note</sup>
Motorola Hex format (S0, S3, S7- 32bit-address) (*.hex)
Extended Tektronix Hex format (*.hex)
Intel Hex format with ID Tag (*.hex)
Motorola Hex format with ID Tag (S0, S3, S7- 32bit-address) (*.hex)
Extended Tektronix Hex format with ID Tag (*.hex)
Intel Hex format (Flash Programmer) (*.hex)
Motorola Hex format (S0, S3, S7- 32bit-address) (Flash Programmer) (*.hex)
Binary data (*.bin)

**Note** If the space specified via the "[Specify \[Save Range Address/Symbol\]](#)" is greater than 1 MB, then the Intel hex-format file will be saved as "Extended Linear (32-bit address)"; if it is within 1 MB, then it will be saved as "Extended (20-bit address)".

**Remark [\[IECUBE\]\[MINICUBE\]\[MINICUBE2\]\[E1\]\[E20\]](#)**

Items containing "with ID tag" or "(Flash Programmer)" shown below appear only when the selected microcontroller incorporates the data flash memory.

Select any one of these items to save the data with the ID tag information.

Select any one of these items to save the data in the flash programmer format.

**(3) Specify [Save Range Address/Symbol]**

Specify the range of addresses to save via "start address" and "end addresses".

Directly enter hexadecimal number/address expression in each text box or select from the input history displayed in the drop-down list (up to 10 items).

**Remark** A symbol name at the current caret position can be complemented by pressing the [Ctrl] + [Space] key in each text box (see "[2.18.2 Symbol name completion function](#)").

**(4) Click the [Save] button**

Save the contents of the memory in the specified file in specified format as upload data.

## 2.6 Display/Change Programs

This section describes how to display and change programs when a load module file with the debug information is downloaded to a debug tool.

Downloaded programs can be displayed in the following panels.

### - Editor panel

The source file is displayed and can be edited.

Furthermore, the source level debugging/instruction level debugging (see "[2.7.3 Execute programs in steps](#)") and the display of the code coverage measurement result (see "[2.13.2 Display the coverage measurement result](#)") can be performed in this panel.

### - Disassemble panel

The result of disassembling the downloaded program (the memory contents) is displayed and can be edited (line assemble).

Furthermore, the instruction level debugging (see "[2.7.3 Execute programs in steps](#)") and the display of the code coverage measurement result (see "[2.13.2 Display the coverage measurement result](#)") can be performed in this panel. In this panel, the disassemble results can be displayed with the corresponding source text (default).

**Remark** It is normally necessary to download a load module file with debugging information in order to perform the source level debugging, but it is also possible to do so by downloading a hex format (\*.hex) or binary data format (\*.bin) file (see "[\(4\) Perform source level debugging with a hex or binary data format file](#)").

### 2.6.1 Display source files


The source file is displayed in the [Editor panel](#) below. The Editor panel automatically opens with displaying source text of the specified position (see "[2.5.1 Execute downloading](#)") when a load module file is successfully downloaded.

If you want to open the Editor panel manually, double-click on the source file in the [Project Tree panel](#).

For details on the contents and function in each area, see the section for the [Editor panel](#).

- Remarks 1.** You can open a file with a specific encoding selected in the [Encoding dialog box](#) that is opened by selecting the [File] menu >> [Open with encoding...].
2. You can zoom in and out of this panel (see "[\(m\) Zoom in or out on a view](#)") by using the [Ctrl] key + mouse-wheel combination.

Figure 2-166. Display Source File (Editor Panel)



This section describes the following.

- (1) Change display mode
- (2) Set the columns to display
- (3) Display multiple source files in a single panel
- (4) Display variables
- (5) Search characters
- (6) Move to the specified line
- (7) Jump to functions
- (8) Jump to a desired line (tag jump)

#### (1) Change display mode

When connected to the debug tool and the downloaded source file is opened, the code data, label and disassembled text can be displayed combined with the source code by clicking the button (toggle) on the toolbar (mixed display mode).

Figure 2-167. Editor Panel (Normal Display Mode)





Figure 2-168. Editor Panel (Mixed Display Mode)



- Cautions**
1. The mixed display mode is enabled only when connected to the debug tool and the downloaded source file is opened in this panel.
  2. In the mixed display mode, the source files cannot be edited and saved. In addition, [Redo]/[Cut]/[Paste]/[Delete]/[Select All]/[Replace...]/[Outlining]/[Advanced] from the [Edit] menu are disabled.

## (2) Set the columns to display

The columns and marks displayed on this panel can be set by selecting the toolbar items shown below. Note that this setting applies to all of the [Editor panels](#).


Columns	The following items are displayed to show or hide the columns or marks on all of the <a href="#">Editor panels</a> . Remove the check to hide the items (all the items are checked by default).
Line Number	Shows the line number, in the line number area.
Selection	Shows the mark that indicates the line modification status, in the line number area.
Out of date module indicator	Shows the mark that indicates the update status of the downloaded load module file, in the line number area. Note that this item is enabled only when connected to the debug tool.
Coverage	Shows the coverage area. Note that this item is enabled only when connected to the debug tool.
Address	Shows the address area. Note that this item is enabled only when connected to the debug tool.
Op Code	Shows the code area. Note that this item is enabled only when connected to the debug tool and the mixed display mode is selected.
Label	Shows the label area. Note that this item is enabled only when connected to the debug tool and the mixed display mode is selected.
Event	Shows the event area. Note that this item is enabled only when connected to the debug tool.
Main	Shows the main area. Note that this item is enabled only when connected to the debug tool.
Column Header	Shows the column header.

### (3) Display multiple source files in a single panel


If the current PC moves between multiple source files when debugging (e.g. when performing step execution), each of the source files will be opened in a separate editor panel. If this is the case, the recycle mode lets you display multiple source files in a single **Editor panel**.

Select the [Use window recycling] check box on the [General - Text Editor] category in the [Option dialog box](#) to enable this feature.

**Figure 2-169. Normal Operation**



**Figure 2-170. Recycle Mode Operation**



- Cautions 1.** The recycle mode is enabled only when connected to the debug tool and the downloaded source file is opened in this panel.
- 2.** When the current PC value in program execution corresponds to a line in the [Editor panel](#) while editing is being conducted in the recycle mode, that Editor panel is released from the recycle mode, and a new Editor panel is opened in the recycle mode.


**Remark** If the [Editor panel](#) that displays the corresponding source file is already opened, then the source file is not opened in the panel of the recycle mode, but the Editor panel being opened is displayed.

#### (4) Display variables

When hovering the mouse cursor over a variable in the source text, "<variable name> = <variable value>" is pop-up displayed.

The display format of the variable value is same as "Table A-17. Display Format of Watch-Expressions (Default)" depending on the type of the variable.

**Figure 2-171. Pop-up Display of Variables (Editor Panel)**




#### (5) Search characters

Character searching in the source text is taken place in the Find and Replace dialog box opens with selecting the button on the toolbar.

In this dialog box, follow the steps below.

**Figure 2-172. Character Search in Source Text (Find and Replace Dialog Box)**



##### (a) Specify [Search text]

Enter characters to search.

A word (variable/function) at the caret position in the [Editor panel](#) is specified by default.

If you want to change it, directly enter the characters into the text box (up to 1024 characters) or select from the input history in the drop-down list (up to 10 items).

##### (b) Specify [Search location]

Select [Current document (*file name*)] from the drop-down list.

**(c) Click the [Find Previous]/[Find Next] button**

When the [Find Previous] button is clicked, search will start in the order from the large address number to small and the search results are displayed selected in the [Editor panel](#).

When the [Find Next] button is clicked, search will start in the order from the small address number to large and the search results are displayed selected in the [Editor panel](#).

**Remarks 1.** Click the [Option] button to specify to use wild card, case sensitivity, word by word search, and so on.


2. In the Find and Replace dialog box, various search/replace operation can be performed by selecting [Find in Files], [Quick Replace] or [Replace in Files] tab.

**(6) Move to the specified line**

You can move to the specified line in the source text in the [Go to Line dialog box](#) which opens when selecting [Go to...] from the context menu.

In this dialog box, follow the steps below.

**Figure 2-173. Move to Specified Line in Source Text (Go to Line Dialog Box)**

**(a) Specify [Line number (valid line range)]**

"(valid line range)" shows the range of valid lines in the current file.

Directly enter a decimal value as the number of the line you want to move the caret to.

You can also enter a symbol in this area.

By default, the number of the line where the caret is currently located in the [Editor panel](#) is displayed.

**(b) Click the [OK] button**

Caret is moved to the specified line.


**(7) Jump to functions**

It automatically recognizes the currently selected characters or the word at the caret position as the function name or variable name **[CX]** and jumps to the first executable line of the target function.

Select [Jump to Function] from the context menu after moving the caret to the target function on the source text.

**Caution** When multiple statements are described in a line, a jump to an illegal location may be made.

Figure 2-174. Jump to Functions



Note that this function is available only when the following conditions are satisfied for each specific build tool.

#### (a) When CA850 is used

- The target function resides in an active project.
- The type of the project specified as the active project is "Application".
- A file with the symbol information is selected for the [Download files] property. In case it is disconnected from the debug tool, the above file is specified as the first file in the [Download files] property (when the file is in the hex format, the setting for downloading the symbol information is required (see "(4) Perform source level debugging with a hex or binary data format file")).

**Caution** A jump to a static function cannot be made when disconnected from the debug tool.

#### (b) When CX is used

- When disconnected from the debug tool:
  - The type of the project specified as the active project is "Application".
  - The target function is a global function.
  - The target function is defined in a file that is specified as the first file in the [Download files] property. In addition, the file includes the symbol information.
- When connected to the debug tool and downloaded the load module file:
  - The downloaded load module file includes the symbol information for the function.
  - Calling the target function from the file corresponding to the address of the program counter (PC). For example, a jump to a static function defined other than in the file corresponding to the address of the program counter (PC) is not possible.

#### (c) When an external build tool is used

- The target function resides in an active project.
- A file with the symbol information is selected for the [Download files] property. In case it is disconnected from the debug tool, the above file is specified as the first file in the [Download files] property (when the file is in the format other than the load module file, the setting for downloading the symbol information is required (see "(4) Perform source level debugging with a hex or binary data format file")).

**Caution** A jump to a static function cannot be made when disconnected from the debug tool.

**Remark** The judgement of words will depend on the build tool being used.

#### (8) Jump to a desired line (tag jump)

If the information of a file name, a line number and a column number exist in the line at the caret position, you can open the file in another [Editor panel](#) and jump to the corresponding line and the corresponding column (if the Editor panel is already open, you can jump to the panel).


Select [Tag Jump] from the context menu after moving the caret to the line on the source text.

The tag jump is operated as follows:

**Table 2-6. Operation of Tag Jump**

Example of Character String	Operation
C:\work\src.c	Jumps to the top line of the file "C:\work\src.c".
Tmp\src.c	Jumps to the top line of the file "Tmp\src.c". (The reference point of the path is the project folder.)
C:\work\src.c(10)	Jumps to the tenth line from the top of the file "C:\work\src.c".
C:\"work sub\src.c"(10)	Jumps to the tenth line from the top of the file "C:\"work sub\src.c"". (Path specification (path/file name) including space characters must be enclosed in "").
C:\work\src.c(10,5)	Jumps to the fifth column of the tenth line from the top of the file "C:\work\src.c".

**Figure 2-175. Tag Jump**



- Remarks 1.** Jumps are case-insensitive.
- 2.** The reference point of the path is the project folder in which the file is registered. If the file is not registered in any project, the reference point of the path will be the active folder.
  - 3.** Path specifications (path/file names) including space characters must be enclosed in "".

### 2.6.2 Display the result of disassembling


The result of disassembling the downloaded program (disassembled text) is displayed in the [Disassemble panel](#) below.

Select [View] menu >> [Disassemble] >> [Disassemble 1 - 4].

The maximum of 4 Disassemble panels can be opened. Each panel is identified by the names "Disassemble1", "Disassemble2", "Disassemble3" and "Disassemble4" on the titlebar.

For details on the contents and function in each area, see the section for the [Disassemble panel](#).

**Figure 2-176. Display Result of Disassembling (Disassemble Panel)**



**Remark** You can set the scroll range of the vertical scroll bar on this panel via the [Scroll Range Settings dialog box](#) which is opened by clicking the  button from [View] on the toolbar.

This section describes the following.


- (1) Change display mode
- (2) Change display format
- (3) Move to the specified address
- (4) Move to the symbol defined location
- (5) Save the disassembled text contents

#### (1) Change display mode

The result of disassembling is displayed in the mixed display mode (both the disassembled text and the source text) by default.

When you click the  button (toggle function) on the toolbar, the source text is displayed or hidden.

Figure 2-177. Display Example of Source Text Hidden



### (2) Change display format

The display format of the disassembly area can be changed using buttons below on the toolbar.

<b>View</b>	The following buttons to change the display format are displayed.
	Displays the offset value of the label. The offset value from the nearest label is displayed when a label is defined for the address.
	Displays the address value as the result of disassembling in the format "symbol + offset value" (default). Note that when a symbol has been defined as the address value, only the symbol is displayed.
	Displays the name of the register by its function name (default).
	Displays the name of the register by its absolute name.

### (3) Move to the specified address

You can move to the specified address in the disassembled text in the [Go to the Location dialog box](#) which opens when selecting [Go to...] from the context menu.

In this dialog box, follow the steps below.

Figure 2-178. Move to Specified Address in Disassembled Text (Go to the Location Dialog Box)



#### (a) Specify [Address/Symbol]

Specify the address you want to move the caret to.

You can either type an address expression directly into the text box (up to 1024 characters), or select them from the input history via the drop-down list (up to 10 items).

**Remark** A symbol name at the current caret position can be complemented by pressing the [Ctrl] + [Space] key in this text box (see "[2.18.2 Symbol name completion function](#)").

**(b) Click the [OK] button**

Caret is moved to the specified address.

**(4) Move to the symbol defined location**

You can move the caret to the address where the symbol is defined.

Click the button on the toolbar after moving the caret to the instruction which refers to the symbol.

Furthermore, click the button on the toolbar following the previous operation returns the caret to the instruction which refers to the symbol at previous caret is defined.

**(5) Save the disassembled text contents**


Contents of the disassembled text can be saved in text files (\*.txt)/CSV files (\*.csv).

When saving to the file, the latest information is acquired from the debug tool, and it is saved in accordance with the display format on this panel.

The [Data Save dialog box](#) can be opened by selecting the [File] menu >> [Save Disassemble Data As...]. (when this operation takes place with the range selected on the panel, the disassembled data can be saved only for the selected range).

In this dialog box, follow the steps below.

**Figure 2-179. Save Disassembled Text Contents (Data Save Dialog Box)**



**(a) Specify [File Name]**

Specify the name of the file to save.

You can either type a filename directly into the text box (up to 259 characters), or select one from the input history via the drop-down list (up to 10 items).

You can also specify the file by clicking the [...] button, and selecting a file via the [Select Data Save File dialog box](#).

**(b) Specify [File Type]**

Select the format in which to save the file from the following drop-down list.

The following file formats can be selected.

List Item	Format
Text files (*.txt)	Text format (default)
CSV (Comma-Separated Variables)(*.csv)	CSV format <sup>Note</sup>

**Note** The data is saved with entries separated by commas (,).

If the data contains commas, each entry is surrounded by double quotes "" in order to avoid illegal formatting.

**(c) Specify [Save Range Address/Symbol]**

Specify the range of addresses to save via "start address" and "end addresses".

Directly enter hexadecimal number/address expression in each text box or select from the input history displayed in the drop-down list (up to 10 items).

If a range is selected in the panel, that range is specified as the default. If there is no selection, then the range currently visible in the panel is specified.

**Remark** A symbol name at the current caret position can be complemented by pressing the [Ctrl] + [Space] key in each text box (see "2.18.2 Symbol name completion function").

**(d) Click the [Save] button**

Disassembling data is saved in the specified file with the specified format.

**Figure 2-180. Output Example of Disassembling Data**

Label (symbol name)	← Label (symbol) line
:	
File name	← Source text line
:	
Address	← Disassembling line
Offset	
Code	
Result of Disassembling	
:	

**Remarks 1.** When the contents of the panel are overwritten and saved by selecting the [File] menu >>[Save Disassemble Data], the **Disassemble panels** (Disassemble1-4) are handled individually for these respectively. In addition, saving range is same as the previously specified address range.

**2.** You can print the current screen image of this panel by selecting the [File] menu >> [Print...].

### 2.6.3 Run a build in parallel with other operations

CubeSuite+ can automatically start a build when one of the following events occurs (rapid build function).

**(1) For other than the debug-only project**

- When any one of the following files that are added to the project is updated:  
(C source file, assembler source file, header file, link directive file, symbol information file, object module file, and library file)
- When a build target file has been added to or removed from the project
- When the link order of object module files and library files is changed
- When the property of the build tool or the build target file is changed

**(2) For the debug-only project**

- When you have edited and saved the C source file, assembler source file and header file that are added to the debug-dedicated project
- When a C source file, assembler source file, or header file has been added to or removed from the debug-dedicated project
- When the property of the debug-dedicated project is changed

If a rapid build is enabled, it is possible to perform a build in parallel with the above operations.

To enable/disable a rapid build, select [Rapid Build] from the [Build] menu. A rapid build is enabled by default.

**Caution** When an external text editor is used, check the [Observe registered files changing] check box on the [General - Build/Debug] category in the [Option dialog box](#) to enable this function.

- Remarks 1.**
1. After editing source files, it is recommended to save frequently by pressing the [Ctrl] + [S] key.
  2. Enable/Disable setting of the rapid build applies to the entire project (main project and subprojects).
  3. If you disable a rapid build while it is running, it will be stopped at that time.

#### 2.6.4 Perform line assembly

Instructions and code displayed in the [Disassemble panel](#) can be edited (line assembly).

This section describes the following.

- (1) [Edit instructions](#)
- (2) [Edit code](#)

##### (1) Edit instructions

Follow the steps below to edit instructions.

###### (a) Switch to edit mode

Double-click the instruction to edit or select [Edit Disassemble] from the context menu after moving the caret to the instruction to edit.

###### (b) Edit instructions

Use keyboard to directly edit the instructions.

###### (c) Write to memory

Press the [Enter] key to line assemble the edited instructions after editing. The code is automatically written to the memory.

If the edited instruction is invalid, the instruction is shown in red and will not be written to the memory.

If there is a space because of overwriting the displayed result of disassembling by another instruction, its byte number is automatically compensated with nop instruction as follows:

**Examples 1.** Overwriting the prepare instruction (8-byte instruction) with the jarl instruction (4-byte instruction)

Before editing	0432	mov	0x4, r6
	1d38	mov	r29, r7
	8f071b0effff0000	prepare	r20, r21, r22, 0x1c, 0x0000ffff
	0132	mov	0x1, r6
After editing	0432	mov	0x4, r6
	1d38	mov	r29, r7
	bffffe265	jarl	0x100, lp
	0000	nop	
	0000	nop	
	0132	mov	0x1, r6

2. Overwriting the mov instruction (2-byte instruction) with the jarl instruction (4-byte instruction)

Before editing	0432                         mov      0x4, r6 1d38                         mov      r29, r7 8f071b0effff0000          prepare r20, r21, r22, 0x1c, 0x0000ffff 0132                         mov      0x1, r6
After editing	0432                         mov      0x4, r6 bffffe265                   jarl     0x100, lp 0000                         nop 0000                         nop 0000                         nop 0132                         mov      0x1, r6

**Caution Handling the prepare instruction and dispose instruction**

The following table shows the instruction formats of the prepare instruction and dispose instruction. The operand "list12" comprises 12-bit value where a different register is assigned to each bit.

Instruction format of the prepare instruction	prepare      list12, imm5
	prepare      list12, imm5, sp/imm
Instruction format of the dispose instruction	dispose     imm5, list12
	dispose     imm5, list12, [reg1]

When displaying the results of disassembling the prepare instruction and dispose instruction in the [Disassemble panel](#), the corresponding register names for the operand "list12" are displayed instead of its values as shown in the following examples.

**Examples 1.** When the code is "0xbf, 0x07, 0xe1, 0xff" (4-byte prepare instruction)

View	prepare   r20, r21, r22, r23, r24, r25, r26, r27, r28, r29, r30, r31, 0x20
Syntax	prepare   0xffff, 0x20

**2.** When the code is "0x90, 0x07, 0xbb, 0xaa 0xff, 0xff, 0xff, 0xff" (8-byte prepare instruction)

View	prepare   r20, r22, r24, r26, r28, r31, 0x20, 0x7fffffff
Syntax	prepare   0x555, 0x20, 0x7fffffff

**3.** When the code is "0x51, 0x06, 0xe0, 0xff" (4-byte dispose instruction)

View	dispose   0x20, r20, r21, r22, r23, r24, r25, r26, r27, r28, r29, r30, r31
Syntax	dispose   0x20, 0xffff

**4.** When the code is "0x50, 0x06, 0xaa, 0xaa" (4-byte dispose instruction)

View	dispose   0x20, r20, r22, r24, r26, r28, r31, [r10]
Syntax	dispose   0x20, 0x555, [r10]

Note, however, that it is possible to specify both the value and the register name for the operand "list12" when line assembling the prepare instruction and dispose instruction.

**Examples 1.** In both of the cases (1) and (2) below, the same set of values "0x91, 0x07, 0xe1, 0xff" will be generated as a result of line assembly.

(1)	prepare r20, r21, r22, r23, r24, r25, r26, r27, r28, r29, r30, r31, 0x20
(2)	prepare 0xffff, 0x20

2. In both of the cases (1) and (2) below, the same set of values "0xbe, 0x07, 0xbb, 0xaa 0xff, 0xff, 0xff, 0x7f" will be generated as a result of line assembly.

(1)	prepare r20, r22, r24, r26, r28, r31, 0x20, 0x7fffffff
(2)	prepare 0x555, 0x20, 0x7fffffff

3. In both of the cases (1) and (2) below, the same set of values "0x51, 0x06, 0xe0, 0xff" will be generated as a result of line assembly.

(1)	dispose 0x20, r20, r21, r22, r23, r24, r25, r26, r27, r28, r29, r30, r31
(2)	dispose 0x20, 0xffff

4. In both of the cases (1) and (2) below, the same set of values "0x50, 0x06, 0xaa, 0xaa" will be generated as a result of line assembly.

(1)	dispose 0x20, r20, r22, r24, r26, r28, [r10]
(2)	dispose 0x20, 0x555, [r10]

## (2) Edit code

Follow the steps below to edit code.

### (a) Switch to edit mode

Double-click the code to edit or select [Edit Code] from the context menu after moving the caret to the code to edit.

### (b) Edit code

Use keyboard to directly edit the code.

### (c) Write to memory

Press the [Enter] key to write the code to the memory after editing.

If the edited instruction is invalid, the instruction is shown in red and will not be written to the memory.

When the code is written to the memory, the result of disassembling is also updated.

## 2.7 Execute Programs

This section describes how to execute programs.

Main operations in this section are taken place from the debug toolbar or the [Debug] menu in the [Main window](#), where commands to control the execution of programs are included.

**Cautions 1.** Items of the debug toolbar and the [Debug] menu are valid only while connected to the debug tool.

### 2. [V850E1]

If the selected microcontroller is V850E/MA3 and other V850E Core, the following cautions apply when executing programs within the internal RAM area (addresses from 0xFFFF0000 to 0xFFFFFFF).

- When CPU stops, the displayed address on the [Disassemble panel](#) is "0x03FF0000 to 0x03FFFF".
- In the case using Step in execution for the function in the internal RAM, the actual operation become Step over execution.

### Remark [V850E2]


When the selected microcontroller version supports multi-core, the control of the program execution is performed synchronously in each core (note, however, that step executions are performed only in a core (PEn) currently being selected).

You can select a core (PEn) to be debugged and display its status, via the [Debug Manager panel \[V850E2\]](#).

Figure 2-181. Debug Toolbar



Figure 2-182. [Debug] Menu



### 2.7.1 Reset microcontroller (CPU)

To reset CPU, click the  button on the debug toolbar.

When CPU is reset, the current PC value is set to the reset address.

**Remark** You can automatically overwrite the value of I/O register/CPU register with the specified values after CPU reset under breaking (see "[2.16 Use Hook Function](#)" for details).

### 2.7.2 Execute programs

The following types of CubeSuite+ execution functions are provided.

Select any of the following operations according to the purpose of debugging.

See "[2.8 Stop Programs \(Break\)](#)" for details on how to stop the program in execution.

- (1) Execute after resetting microcontroller (CPU)
- (2) Execute from the current address
- (3) Execute after changing PC value

**Remark** You can automatically overwrite the value of I/O register/CPU register with the specified values before starting program execution (see "[2.16 Use Hook Function](#)" for details).

#### (1) Execute after resetting microcontroller (CPU)

Click the  button on the debug toolbar.

Reset CPU and start execution of the program from the reset address.

When this operation is performed, the program continues to be executed until either of the following occurs:

- The  button has been clicked (see "[2.8.1 Stop the program manually](#)").
- The PC has reached a breakpoint (see "[2.8.2 Stop the program at the arbitrary position \(breakpoint\)](#)").
- A break event condition has been met (see "[2.8.3 Stop the program at the arbitrary position \(break event\)](#)" or "[2.8.4 Stop the program with the access to variables/I/O registers](#)").
- A fail-safe break has occurred (see "[2.8.5 Stop the program when an invalid execution is detected \[IECUBE\]](#)").
- [Other break causes](#) have occurred.

**Remark** This operation is the same as when the  button is clicked after clicking the  button.

#### (2) Execute from the current address

Perform any of the following operations to start executing the program from the address at the current PC value.

##### (a) Normal execution

Click the  button on the debug toolbar.

When this operation is performed, the program continues to be executed until either of the following occurs:

- The  button has been clicked (see "[2.8.1 Stop the program manually](#)").
- The PC has reached a breakpoint (see "[2.8.2 Stop the program at the arbitrary position \(breakpoint\)](#)").
- A break event condition has been met (see "[2.8.3 Stop the program at the arbitrary position \(break event\)](#)" or "[2.8.4 Stop the program with the access to variables/I/O registers](#)").
- A fail-safe break has occurred (see "[2.8.5 Stop the program when an invalid execution is detected \[IECUBE\]](#)").
- [Other break causes](#) have occurred.

**(b) Execution ignoring break-related events**

Click the  button on the debug toolbar.

When this operation is performed, the program continues to be executed until either of the following occurs:

- The  button has been clicked (see "[2.8.1 Stop the program manually](#)").
- A fail-safe break has occurred (see "[2.8.5 Stop the program when an invalid execution is detected \[IECUBE\]](#)").
- [Other break causes](#) have occurred.

**Remark** If you have started the execution with this operation, the occurrence of Action event will also be ignored.

**(c) Execution to the caret position**

To start this operation, move the caret to the line/instruction to stop the program in the [Editor panel](#)/[Disassemble panel](#), then select [Go to Here] from the context menu.

When this operation is performed, the program continues to be executed until either of the following occurs:

- The PC has reached the address of the caret position.
- The  button has been clicked (see "[2.8.1 Stop the program manually](#)").
- A fail-safe break has occurred (see "[2.8.5 Stop the program when an invalid execution is detected \[IECUBE\]](#)").
- [Other break causes](#) have occurred.

**Caution** When the corresponding address of the line at the caret position does not exist, the program is executed to the corresponding address of the lower valid line (if the corresponding address does not exist, an error message will appear).

**Remark** If you have started the execution with this operation, the occurrence of Action event will also be ignored.

**(3) Execute after changing PC value**

The program is executed after forcibly changing the current PC value to an arbitrary address.

To start this operation, move the caret to the line/instruction to start the program in the [Editor panel](#)/[Disassemble panel](#), then select [Set PC to Here] from the context menu (the current PC value is set to the address of the line/instruction where the caret currently exists).

Then execute either one of the execution method described in "[\(2\) Execute from the current address](#)".

**2.7.3 Execute programs in steps**

When either of the following operation has occurred, the program will stop automatically after conducting step execution in the source level (1 line of source text) or in the instruction level (1 instruction).

Once the program is stopped, the contents of each panel will be updated automatically. As such, step execution is suited for debugging the program execution in transition either in source or instruction level.

The unit in which the program is step-executed depends on the setting of the [Editor panel](#) as follows:

- When the  button on the toolbar is invalid (default):

Step execution is conducted in source level.

Note, however, that when the focus is in the [Disassemble panel](#) or the line information does not exist in the address specified by the current PC value, the step execution is conducted in instruction level.

- When the  button on the toolbar is valid:  
Step execution is conducted in instruction level.

**Remark** The  button is only enabled if the mixed display mode is selected on the Editor panel (see "[\(1\) Change display mode](#)").

Step execution is divided into the following types:

- (1) Step in function (Step in execution)
- (2) Step over function (Step over execution)
- (3) Execute until return is completed (Return out execution)

- Cautions**
1. Breakpoints, break events, and action events that have been set do not occur during step execution.
  2. An error message will appear while processing a function prologue or epilogue if the return address cannot be acquired.
  3. If an instruction to move to standby mode (HALT/STOP/IDLE) is executed during step execution, the program will break at the next instruction after the standby mode instruction. This behavior differs depending on the debug tool used.
    - For other than [Simulator]  
It will not go into standby mode during step execution.
    - [Simulator]  
It will go into standby mode during step execution.  
It will appear that standby mode has been released. Check the CPU status on the Main window's statusbar to see if standby mode has been released.
  4. For other than [Simulator]
    - Interrupts are not acknowledged and fail-safe breaks [IECUBE] do not occur during step execution.
    - It will not go into standby mode during step execution.
  5. [Simulator]  
You may jump to an interrupt handler during step execution.

#### (1) Step in function (Step in execution)

When the function is called, the program is stopped at the top of the called function.

Click the  button on the debug toolbar to perform Step in execution.

- Cautions**
1. Step in execution for a function without the debug information is not possible.
  2. If Step in execution is performed for the longjmp function, program execution may not complete and may wait for a time-out.

#### (2) Step over function (Step over execution)

In the case of a function call by the jalr instruction, all the source lines/instructions in the function are treated as one step and executed until the position where execution returns from the function (step execution will continue until the same nest is formed as when the jalr instruction has been executed).

Click the  button on the debug toolbar to perform Step over execution.

In the case of an instruction other than jalr, operation is the same as when the  button is clicked.

**Caution** If Step over execution is performed for the longjmp function, program execution may not complete and may wait for a time-out.

**(3) Execute until return is completed (Return out execution)**

Step-execute the program so that the program will stop when it returns from the current function to the caller function. When the execution of source line/instruction that require checking has been completed, you can perform step execution using this instruction so that you can make the program return to the caller function without step executing the remaining instructions inside the function.

Click the  button on the debug toolbar to perform Return out execution.

- Cautions**
1. If Return out execution is performed in the main function, the program is stopped in the startup routine.
  2. Return out execution cannot be performed immediately after stepping in a function.
  3. Return out execution cannot be performed while processing a function prologue or epilogue.
  4. If Return out execution is performed in a function that called the longjmp function, breaks may not occur.
  5. If Return out execution is performed in a recursive function, the program will be executed in free-run mode.

## 2.8 Stop Programs (Break)

This section describes how to stop the program in execution.

**Cautions 1.** If a forced break is performed while in standby mode (HALT/STOP/IDLE), the current PC position will indicate the address of the next instruction after the standby mode instruction.

This behavior differs depending on the debug tool used.

- For other than [Simulator]

The forced break will release standby mode.

- [Simulator]

The forced break will not release standby mode.

It will appear that standby mode has been released. Check the **CPU status** on the **Main window**'s statusbar to see if standby mode has been released.

### 2. [E1][E20][EZ Emulator]

Do not decrease the voltage of the target system during a break. A reset that is generated by the low-voltage detector (LVI) or by power-on-clear (POC) during a break causes an incorrect operation of CubeSuite+ or communication errors.

A break during emulation of power supply off also causes communication errors.

**Remark** When the program in execution is stopped, a statement of the cause of the break appears on the **Statusbar** in the **Main window**.

### 2.8.1 Stop the program manually

The program in execution is forcibly stopped by clicking the  button on the debug toolbar.

### 2.8.2 Stop the program at the arbitrary position (breakpoint)

The program in execution can be stopped at the arbitrary position by setting a breakpoint. A breakpoint can be set by one-clicking with the mouse.

You need to configure the type of breakpoints to use before setting a breakpoint.

This section describes the following operations.

- (1) Set the type of breakpoints/break timing to use
- (2) Set a breakpoint
- (3) Delete a breakpoint

#### (1) Set the type of breakpoints/break timing to use

The type of breakpoints/break timing to use are set in the [Break] category on the **[Debug Tool Settings] tab** of the **Property panel**.

The setting method differs depending on the debug tool used.

- (a) For other than [Simulator]
- (b) For [Simulator]

## (a) For other than [Simulator]

Figure 2-183. [Break] Category [IECUBE][IECUBE2][MINICUBE][E1/E20(LPD)/(JTAG)]

Break	
First using type of breakpoint	Software break
Stop emulation of peripherals when stopping	No
Use open break function	No(Output signal)

Figure 2-184. [Break] Category [MINICUBE2][E1/E20(Serial)][EZ Emulator]

Break	
First using type of breakpoint	Software break

## &lt;1&gt; [First using type of breakpoint]

Specify the type of preferential breakpoint with a single click of the mouse.

Select from the drop-down list below for each use of the breakpoint.

Hardware break	The debug tool consecutively checks the break condition while the program is in execution and stops the program when the condition is met <sup>Note</sup> . Once set, it is treated as a Hardware Break event (execution system).
Software break	Temporarily replaces the instruction code for a specified address with a break instruction and stops the program when this instruction is executed (default). Once set, it is treated as a Software Break event.

**Note** There are two types of Hardware Break event (execution type): "before execution break," which breaks before the instruction at the specified address is executed; and "after execution break," which breaks after the instruction at the specified address is executed. Both of these break types are implemented using the debug tool's resources. CubeSuite+ starts by using "before execution break" resource to set hardware breakpoints, and as soon as that resource becomes unavailable, uses "after execution break" resource (see "(1) Maximum number of enabled events"). For this reason, the user cannot select between "before" and "after" execution.

- Cautions**
1. The [First using type of breakpoint] property does not appear when the number of the breakpoint type available for the selected microcontroller is only one.
  2. If the number of the set breakpoints of the specified type exceeds the limit settable (see "(1) Maximum number of enabled events"), a breakpoint of another type will be used.

## (b) For [Simulator]

Figure 2-185. [Break] Category [Simulator]

Break	
Execute instruction at breakpoint when break	No

## &lt;1&gt; [Execution instruction at breakpoint when break]

You can specify the timing to stop the program execution by breakpoints whether after or before the execution of the instruction at the breakpoint. Specify in this property whether to break after executing the instruction.

Select [Yes] to break after execution of the instruction ([No] is selected by default).  
All set breakpoints are handled as Hardware Break events.

**Caution** When [Yes] is selected, all of action events currently being set are handled as Hardware Break events (see "2.14 Set an Action into Programs").

## (2) Set a breakpoint

Breakpoints can be set via the Editor panel/Disassemble panel in which the source text/disassembly text is displayed.

Within the Main area (Editor panel) or Event area (Disassemble panel) in which a valid address is displayed, click on the location where you want to set a breakpoint.

A breakpoint is set to the instruction at the start address corresponding to the clicked line.


When a breakpoint is set, the following event mark appears at the breakpoint location, and the source text line/disassembled text line is highlighted.

It is interpreted as if a break event (Software Break or Hardware Break) has been set at the target address, and it is managed in the Events panel (see "2.15 Manage Events" for details).

Table 2-7. Event Marks of Breakpoint

Debug Tool	Event Type	Setting of [First using type of breakpoint]	Event Mark
For other than Simulator	Break	Software Break	
		Hardware Break	
Simulator	Break	-	

Figure 2-186. Breakpoint Setting Example (Disassemble Panel)



- Cautions**
- Since a breakpoint is set as a break event and managed as a event, restrictions apply to the number of breakpoints that can be simultaneously set. Also see "2.15.6 Notes for setting events" for details on breakpoints (e.g. limits on the number of enabled events).
  - [V850E1][V850ES]: [IECUBE][MINICUBE][E1/E20(JTAG)]
    - The pseudo-RRM function (see "(4) Display/modify the memory contents during program execution") and software break function are exclusive of each other. Therefore, no software breakpoints can be set when the [Access by stopping execution] property in the [Access memory while running] category on the [Debug Tool Settings] tab of the Property panel is set to [Yes].
    - If a Software Break conflicts with a Hardware Break, the PC value may be corrected to an illegal value (a message will appear in this case). In such a case, reset the CPU to prevent the program from executing an illegal instruction.
  - No software breakpoints can be set to the data flash memory area.
  - Breakpoints can only be set at lines that have valid addresses.

**Remarks 1.** Event marks differ depending on the event state (see "2.15.1 Change the state of set events (valid/invalid)").

When an event is set at the point where other event is already set, the event mark (■) is displayed meaning more than one event is set at the point.

## 2. [Simulator]

The type of breakpoint that can be set is locked to hardware breakpoints.


## 3. For other than [Simulator]

You can set hardware breakpoints/software breakpoints without depending on the specification of "(1) Set the type of breakpoints/break timing to use" by following the step below.

Type	Operation1 <sup>Note</sup>	Operation2
Hardware breakpoint	[Ctrl] + mouse click	Select [Break Settings] >> [Set Hardware Break] from the context menu.
Software breakpoint	[Shift] + mouse click	Select [Break Settings] >> [Set Software Break] from the context menu.

**Note** "Operation1" is only available in the [Disassemble panel](#).

Figure 2-187. Example of Setting Breakpoint in Events Panel



### (3) Delete a breakpoint

Click event marks displayed in the [Editor panel](#)/[Disassemble panel](#) to delete set breakpoints (the event mark will be erased).

## 2.8.3 Stop the program at the arbitrary position (break event)

The program in execution can be stopped at the arbitrary position by setting a break event (execution type).

This section describes the following operations.

- (1) Set a break event (execution type)
- (2) Delete a break event (execution type)

### (1) Set a break event (execution type)

Perform this operation in the [Editor panel](#)/[Disassemble panel](#) in which the source text/disassembly text is displayed.

Follow the operation listed below from the context menu, in accordance with your desired event type, after moving the caret to the target line that has a valid address.

Event Type	Operation	Description
Hardware Break	Select [Break Settings] >> [Set Hardware Break]	The debug tool consecutively checks the break condition while the program is in execution and stops the program when the condition is met. <sup>Note</sup>
Software Break (except [Simulator])	Select [Break Settings] >> [Set Software Break]	Temporarily replaces the instruction code for a specified address with a break instruction and stops the program when this instruction is executed.

**Note** There are two types of Hardware Break event (execution type): "before execution break," which breaks before the instruction at the specified address is executed; and "after execution break," which breaks after the instruction at the specified address is executed. Both of these break types are implemented using the debug tool's resources. CubeSuite+ starts by using "before execution break" resource to set Hardware Breaks, and as soon as that resource becomes unavailable, uses "after execution break" resource (see "[\(1\) Maximum number of enabled events](#)"). For this reason, the user cannot select between "before" and "after" execution.

A break event is set to the instruction at the start address corresponding to the line of the caret position. When a break event (execution type) is set, the following event mark appears at the break event location, and the source text line or disassembled text line will be highlighted.

When you have performed this operation, the set break event is managed in the [Events panel](#) as a Hardware Break event (execution type)/Software Break event (execution type) (see "[2.15 Manage Events](#)" for details).


**Table 2-8. Event Marks of Break Event**

Event Type	Event Mark
Hardware Break	
Software Break (except [Simulator])	

- Cautions**
1. When setting a break event (execution type), also see "[2.15.6 Notes for setting events](#)" for details (e.g. limits on the number of valid events).
  2. [V850E1][V850ES]: [IECUBE][MINICUBE][E1/E20(JTAG)]
    - The pseudo-RRM function (see "[\(4\) Display/modify the memory contents during program execution](#)") and software break function are exclusive of each other. Therefore, no Software Breaks can be set when the [Access by stopping execution] property in the [Access memory while running] category on the [\[Debug Tool Settings\] tab of the Property panel](#) is set to [Yes].
    - If a Software Break conflicts with a Hardware Break, the PC value may be corrected to an illegal value (a message will appear in this case). In such a case, reset the CPU to prevent the program from executing an illegal instruction.
  3. No software breakpoints can be set to the data flash memory area.

**Remark** Event marks differ depending on the event state (see "[2.15.1 Change the state of set events \(valid/invalid\)](#)"). When an event is set at the point where other event is already set, the event mark () is displayed meaning more than one event is set at the point.

Figure 2-188. Example of Setting Hardware Break Event (Execution Type) in Events Panel



## (2) Delete a break event (execution type)

To delete a break event (execution type) you have set, click the event mark displayed in the [Editor panel](#)/[Disassemble panel](#).

Also, there is another way to delete a set break event. Select a Software Break event/Hardware Break event in the [Events panel](#), and then click the button in the toolbar (see "[2.15.4 Delete events](#)").

### 2.8.4 Stop the program with the access to variables/I/O registers

By setting a break event with the access, the program can be stopped when an arbitrary variable or I/O register is accessed with the specified type.

You can also limit the accessed value.

The following types can be specified with the access.

Table 2-9. Types of Accesses to Variables

Access Type	Description
Read	The program is stopped with the read access to (after reading) the specified variable/I/O register.
Write	The program is stopped with the write access to (after writing) the specified variable/I/O register.
Read/Write	The program is stopped with the read access/write access to (after reading or writing) the specified variable/I/O register.

**Caution** The program is not stopped with the access via DMA (Direct Memory Access).

This section describes the following.

- (1) Set a break event (access type)
- (2) Delete a break event (access type)

## (1) Set a break event (access type)

Use one of the following methods to set a break event (access type) that stops programs with the access to a variable/I/O register.

**Caution** Also see "[2.15.6 Notes for setting events](#)" for details on breakpoints (e.g. limits on the number of enabled events).

**(a) Set a break event to a variable/I/O register in the Editor panel/Disassemble panel**

Perform this operation in the [Editor panel/Disassemble panel](#) in which the source text/disassembly text is displayed.

Follow the operation listed below from the context menu, in accordance with your desired access type, after selecting an arbitrary variable or I/O register on the source text/disassembled text. Note, however, that only global variables, static variables inside functions, and file-internal static variables can be used.


Access Type	Operation
Read	Select [Break Settings] >> [Set Read Break to], and then press the [Enter] key.
Write	Select [Break Settings] >> [Set Write Break to], and then press the [Enter] key.
Read/Write	Select [Break Settings] >> [Set R/W Break to], and then press the [Enter] key.

At this time, if you have specified a value in the text box in the context menu, break will occur only when the specified value is used for the reading, writing or reading/writing. On the other hand, if no value is specified, reading., writing or reading/writing the selected variable by any value will cause the break to occur.

**Cautions 1. Variables within the current scope can be specified.**

2. **Variables or I/O register at lines that have no valid addresses cannot be used for break events.**

Figure 2-189. Example of Setting Break Event (Access Type) on Variable in Editor Panel



**(b) Set a break event (access type) to a registered watch-expression**

You can set break events in the [Watch panel](#).

Follow the operation listed below from the context menu, in accordance with your desired access type, after selecting the registered watch-expression (multiple selections not allowed).

Note, however, that only global variables, static variables inside functions, file-internal static variables, and I/O register can be used.


Access Type	Operation
Read	Select [Access Break] >> [Set Read Break to], and then press the [Enter] key.
Write	Select [Access Break] >> [Set Write Break to], and then press the [Enter] key.
Read/Write	Select [Access Break] >> [Set R/W Break to], and then press the [Enter] key.

At this time, if you have specified a value in the text box in the context menu, break will occur only when the specified value is used for the reading., writing or reading/writing. On the other hand, if no value is specified, reading., writing or reading/writing the selected watch-expression by any value will cause the break to occur.

**Caution A watch-expression within the current scope can be specified.**


To target a watch-expression outside the current scope, select a watch-expression with a specified scope.

Figure 2-190. Example of Setting Hardware Break Event (Access Type) on Watch-Expression



When you have performed the above operation, the set break event (access type) is managed in the [Events panel](#) as a Hardware Break event (access type) (see "[2.15 Manage Events](#)" for details).

Figure 2-191. Example of Setting Hardware Break Event (Access Type) in Events Panel



## (2) Delete a break event (access type)

To delete a break event (access type) you have set, select a Hardware Break event in the **Events panel**, and then click the  button in the toolbar (see "2.15.4 Delete events").

### 2.8.5 Stop the program when an invalid execution is detected [IECUBE]

The system forcibly breaks the program execution when unexpected program behavior such as invalid access to internal ROM/internal RAM/I/O register/external memory is detected (fail-safe break function).

This function has various break conditions. Enable/disable each break condition in the [Fail-safe Break] category on the [Debug Tool Settings] tab of the **Property panel**.

**Caution** The fail-safe break function becomes invalid during step execution.

Figure 2-192. [Fail-safe Break] Category

<input type="checkbox"/> Fail-safe Break	
Stop when wrote to Internal ROM	 Yes
Stop when accessed to non-mapping Internal ROM	 Yes
Stop when accessed to non-mapping Internal RAM	 Yes
Verify when wrote to Read-only Internal RAM	 Yes
Stop when read from read protected I/O Register	Yes
Stop when wrote to write protected I/O Register	Yes
Stop when accessed to non-mapping I/O Register	Yes
Stop when wrote to write protected External Memory	Yes
Stop when accessed to non-mapping External Memory	Yes

In the following property setting, select [Yes] to enable and [No] to disable the function from the drop-down list. All the properties are set to [Yes] by default.

 mark in the setting column indicates that if you change the setting of this property value, CPU reset is generated automatically.

- [Stop when wrote to Internal ROM]<sup>Note 1</sup>
- [Stop when accessed to non-mapping Internal ROM]<sup>Note 1</sup>
- [Stop when accessed to non-mapping Internal RAM]
- [Verify when wrote to Read-only Internal RAM]<sup>Note 2</sup>
- [Stop when read from read protected I/O Register]
- [Stop when wrote to write protected I/O Register]
- [Stop when accessed to non-mapping I/O Register]
- [Stop when wrote to write protected External memory]
- [Stop when accessed to non-mapping External Memory]

- Notes 1.** This property is invalid when the selected microcontroller is a ROMless product.
2. Specify whether to perform a verify check that detects a write operation to the write protected area in the internal RAM when the program execution is stopped.

#### 2.8.6 Other break causes

The cause of the break other than the described above is as follows:

Moreover, you can confirm the break cause with the [Status message](#) on the statusbar in the [Main window](#).

**Table 2-10. Other Break Causes**

Break Cause	Debug Tool to Use				
	IECUBE	IECUBE2	MINICUBE E1/E20(LPD) E1/E20(JTAG)	MINICUBE2 E1/E20(Serial) EZ Emulator	Simulator
Full of the trace memory <sup>Note 1</sup>	✓	✓	-	-	✓
Execution time-over detected	✓	✓	✓ <sup>Note 2</sup>	-	-
An access to non-mapped area	✓	-	-	-	✓
A writing to write-protected area	✓	-	-	-	✓
Flash macro service in progress	-	✓	✓	✓	-
An occurrence of Temporary Break <sup>Note 3</sup>	✓	✓	✓	✓	✓
An occurrence of Escape Break	✓	✓	✓	✓	-
A writing to IRAM write-protected area	✓	-	-	-	-
An occurrence of the illegal instruction exception	✓	✓	✓	-	-
Failure to execute/uncertain cause	✓	✓	✓	✓	-

- Notes 1.** The operation depends on the setting of the [Operation after trace memory is full] property in the [Trace] category on the [\[Debug Tool Settings\]](#) tab of the [Property panel](#).
2. Only for V850E2 core
  3. A break that is internally used by CubeSuite+. (Users cannot use it.)

## 2.9 Display/Change the Memory, Register and Variable

This section describes how to display/change the memory, register and variable.

### Remark [V850E2]

When the selected microcontroller version supports multi-core, each information is handled as follows:

- Range and values of memory  
The same contents are displayed regardless of a core (PE<sub>n</sub>) currently being selected.
- Register values (including IOR/PC)  
Values acquired from a core (PE<sub>n</sub>) currently being selected are displayed/set.
- Symbols (including watch-expressions/variable names)  
Addresses and values are determined based on the PC value of a core (PE<sub>n</sub>) currently being selected.  
For example, even if a symbol that is valid within only the particular core, its address and value are determined based on the selected core.

You can select a core (PE<sub>n</sub>) to be debugged and display its status, via the [Debug Manager panel \[V850E2\]](#).

### 2.9.1 Display/change the memory

The contents of the memory can be displayed and its values can be changed in the [Memory panel](#) below.

Select the [View] menu >> [Memory] >> [Memory 1 - 4].

The maximum of 4 Memory panels can be opened. Each panel is identified by the names "Memory1", "Memory2", "Memory3" and "Memory4" on the titlebar.

For details on the contents and function in each area, see the section for the [Memory panel](#).

**Figure 2-193. Display Memory Contents (When Microcontroller without Data Flash Memory)**





Figure 2-194. Display Memory Contents (When Microcontroller with Data Flash Memory)



**Remarks 1.** You can set the scroll range (as start and end address) of the vertical scroll bar on this panel via the [Scroll Range Settings dialog box](#) which is opened by clicking the button from [View] on the toolbar.

**2. Except for [Simulator]**

When the selected microcontroller incorporates the data flash memory, the value of the ID tag for the data flash memory can also be displayed or changed.

For details on the ID tag, see the section for the [Memory panel](#).

This section describes the following.


- (1) Specify the display position
- (2) Change display format of values
- (3) Modify the memory contents
- (4) Display/modify the memory contents during program execution
- (5) Search the memory contents
- (6) Modify the memory contents in batch (initialize)
- (7) Save the memory contents

**(1) Specify the display position**

It is possible to specify the display start position of the memory contents by specifying an address expression in the display position specification area (starting with address 0x0 by default).

**Remark** An offset value of the display start position of memory values can be set via the [Address Offset Settings dialog box](#) that is opened by selecting [Address Offset Value Settings...] from the context menu.

Figure 2-195. Display Position Specification Area (Memory Panel)



**(a) Specify an address expression**

Directly enter the address expression of the memory value address to display in the text box. You can specify an input expression with up to 1024 characters. The result of the expression is treated as the display start position address.

Note that address values greater than the microcontroller address space cannot be specified.

- Remarks 1.** A symbol name at the current caret position can be complemented by pressing the [Ctrl] + [Space] key in this text box (see "2.18.2 Symbol name completion function").
2. If the specified address expression is the symbol and its size can be recognized, everything from the start address to the end address of that symbol is displayed selected.

**(b) Specify automatic/manual evaluation of the address expression**

The timing to change the display start position can be determined by specifying in the [Move when Stop] check box and the [Move] button.

[Move when Stop]	<input checked="" type="checkbox"/>	The caret is moved to the address which is automatically calculated from the address expression after the program is stopped.
	<input type="checkbox"/>	The address expression is not automatically evaluated after the program is stopped. Click the [Move] button to manually evaluate the address expression.
[Move]	When the [Move when Stop] check box is not checked, click this button to evaluate the address expression and move the caret to the result address of the evaluation.	

**(2) Change display format of values**

The display format of the address area/memory value area/character strings area can be changed using buttons below on the toolbar.

Note that these buttons are disabled during execution of a program.

Notation	The following buttons to change the notation of memory values are displayed.
	Displays memory values in hexadecimal number (default).
	Displays memory values in signed decimal number.
	Displays memory values in unsigned decimal number.
	Displays memory values in octal number.
	Displays memory values in binary number.
Size Notation	The following buttons to change the notation of sizes of memory values are displayed.
	Displays memory values in 4-bit width.
	Displays memory values in 8-bit width (default).
	Displays memory values in 16-bit width. Values are converted depending on the endian of the target memory area.
	Displays memory values in 32-bit width. Values are converted depending on the endian of the target memory area.
	Displays memory values in 64-bit width. Values are converted depending on the endian of the target memory area.

Encoding	The following buttons to change the encoding of character strings are displayed.
	Displays character strings in ASCII code (default).
	Displays character strings in Shift_JIS code.
	Displays character strings in EUC-JP code.
	Displays character strings in UTF-8 code.
	Displays character strings in UTF-16 code.
	Displays character strings as a single-precision floating-point value <sup>Note</sup> .
	Displays character strings as a double-precision floating-point value.
	Displays character strings as a complex number of single-precision floating-point.
	Displays character strings as a complex number of double-precision floating-point.
	Displays character strings as an imaginary number of single-precision floating-point.
	Displays character strings as an imaginary number of double-precision floating-point.
View	The following buttons to change the display format are displayed.
	Opens the <a href="#">Scroll Range Settings dialog box</a> to set the scroll range for this panel.
Column Number Settings...	Opens the <a href="#">Column Number Settings dialog box</a> to set the number of view columns in the memory value area.
Address Offset Value Settings...	Opens the <a href="#">Address Offset Settings dialog box</a> to set an offset value for addresses displayed in the address area.

**Note** For details on the display of a floating-point value, see the section for the [Memory panel](#).

### (3) Modify the memory contents

The memory values can be edited.

Directly edit from the keyboard after moving the caret to the line to modify in memory value area/characters area.

The color of the memory value changes when it is in editing. Press the [Enter] key to write the edited value to the target memory (if the [Esc] key is pressed before the [Enter] key is pressed, the editing is cancelled).

However, the character string that can be inputted during the editing is limited to that character string that can be handled by the display notation that has been currently specified. In the character strings area, modification can only be made with "ASCII" character code.

This operation can be taken place while the program is in execution. See "[\(4\) Display/modify the memory contents during program execution](#)" for details on how to operate it.

When you modify the values, be aware of the following examples.

**Examples 1.** The value exceeds the upper limit of the display bit wide

If you edit the display value "105" as "1" to "3" in the decimal 8-bit display, the value will be changed to the upper limit of "127".

**2.** The symbol, "-" is entered between numbers

If you edit the display value "32768" as "32-68" with signed decimal 16-bit display, "3" and "2" are changed to the blank and the value is changed to "-68".

**3.** The blank symbol (space) is entered between numbers

If you edit the display value "32767" as "32 67", "3" and "2" are changed to the blank and the value is changed to "67".

4. The same value is entered

Even if the same value as the current memory value is specified, the specified value is written to the memory.

#### (4) Display/modify the memory contents during program execution

The [Memory panel](#)/[Watch panel](#) has the real-time display update function that can update/modify the display contents of the memory/watch-expression in real-time while executing the program.

Using the real-time display update function allows you to display/modify the value of memory/watch-expression not only while the program is stopped, but also in execution.

The real-time display update function is realized by the [RRM function \(reading\)](#) [[IECUBE](#)][[Simulator](#)], a [Pseudo-RRM function \(reading\)](#) ([other than \[Simulator\]](#)) or by the [DMM function/pseudo-DMM function \(modifying\)](#). Each function has a different area that can be used for reading and writing.

Firstly, enable the real-time display update function by making the basic settings below on the [\[Debug Tool Settings\]](#) tab of the [Property panel](#).

**Table 2-11. Basic Settings for Real-time Display Update Function**

Category	Property	Setting Value
[Access memory while running]	[Update display during the execution]	[Yes] (default)
	[Display update interval[ms]]	[Integer number between 100 and 65500]

**Caution** Local variables are not subject to the real-time display update function.

**Remark** See "[\(3\) Modify the memory contents](#)" or "[\(6\) Modify the contents of watch-expressions](#)" for details on how to modify values in the [Memory panel](#)/[Watch panel](#).

#### (a) RRM function (reading) [[IECUBE](#)][[Simulator](#)]

This function is used to read the contents of the memory or of watch-expressions in real-time during execution of a program. Memory and watch-expressions allocated to this area can always be displayed in real-time.

The following area can be read by the RRM function.

##### Cautions 1. [[IECUBE](#)]

If the values of a variable expression are aligned across RRM area banks (256-byte boundaries), the upper address will be an illegal value (the value will be displayed in the error color).

##### 2. [[IECUBE2](#)]

RRM function is not supported.

**Table 2-12. Target Area of RMM Function**

Area	<a href="#">IECUBE</a> <sup>Note 1</sup>	Simulator	
		V850E1/V850ES	V850E2
Internal ROM	✓	✓	✓
Internal RAM	✓	✓	✓
HBUS shared memory	-	-	✓
Back-up RAM	-	-	✓

Area	IECUBE <sup>Note 1</sup>	Simulator	
		V850E1/V850ES	V850E2
Data flash (except ID tag)	✓	-	-
Emulation memory	✓	✓	✓
Target memory	✓	✓	✓
CPU register	-	✓	✓ <sup>Note 2</sup>
I/O register	-	✓	✓

**Notes 1. [IECUBE]**

The target area for the RRM function is limited to up to 8 locations within 2048 bytes.

Therefore, in CubeSuite+, it follows the determination rule (priority order) below and determines the target of the real-time display update within the above limitation (the panel displayed in front right before the program execution is the only target).

- (1) Ascending order of watch-expressions listed in the [Watch panel](#) (if more than one panel is opened, the smallest in number is configured first).
- (2) Ascending order of the addresses listed in the [Memory panel](#) (if more than one memory panel is opened, the smallest in number is configured first).

Note that when a read-protected area is included in this target area, the display contents of the area are not updated.

2. Impossible during tracer/timer execution

Note that to enable the RRM function, the settings below are required in addition to the [Basic Settings for Real-time Display Update Function](#).

Debug Tool	Property	Setting Value
IECUBE	[Access memory while running] category >> [Set update display during the execution automatically]	[Yes]
	[Access memory while running] category >> [Access by stopping execution]	[Yes] <sup>Note</sup>
	[Trace] category >> [Use for trace data] property	[RRM]
Simulator	No setting is required.	

**Note [V850E1][V850ES]: [IECUBE][MINICUBE][E1/E20(JTAG)]**

If a software breakpoint is being set to a valid state, the software breakpoint must be set to an invalid state. No software breakpoints can be set after specifying this property to [Yes].

**(b) Pseudo-RRM function (reading) (other than [Simulator])**

This function is used to read the contents of memory or a watch-expression through software emulation by briefly halting the program.

The following area can be read by the pseudo-RRM function.

**Caution If CPU status shifts to the standby mode (HALT/STOP/IDLE) mode, a monitor time-out error will occur.**

**[IECUBE][IECUBE2][MINICUBE][E1/E20(LPD)/(JTAG)]**

**However, when the [Access by release HALT mode] property in the [Access memory while**

[running] category has been set to [Yes], if CPU status shifts to the HALT mode, the pseudo-RRM function will continue to operate by automatically releasing the HALT mode.

**Table 2-13. Target Area of Pseudo-RRM Function [V850E1][V850ES]**

Area	IECUBE	MINICUBE E1/E20(JTAG)	MINICUBE2 E1/E20(Serial) EZ Emulator
Internal ROM	✓	✓	-
Internal RAM	✓	✓	✓ Note
Data flash (except ID tag)	✓	✓	✓
Emulation memory	✓	-	-
Target memory	✓	✓	-
CPU register	✓	✓	-
I/O register	✓	✓	-

**Note** Impossible while interrupts are disabled (DI)

**Table 2-14. Target Area of Pseudo-RRM Function [V850E2]**

Area	IECUBE2		MINICUBE E1/E20(LPD)/(JTAG)		MINICUBE2 E1/E20(Serial)
	Setting A	Setting B	Setting A	Setting B	
Internal ROM <sup>Note 1</sup>	✓ Note 3	✓ Note 3	✓ Note 4	✓ Note 4	-
Internal RAM <sup>Note 2</sup>	✓	✓	✓	✓	✓ Note 5
HBUS shared memory	-	✓	-	✓	-
Back-up RAM	-	✓	-	✓	✓ Note 5
Data flash (except ID tag)	-	✓	-	✓ Note 4	-
Target memory	-	✓	✓	✓ Note 4	-
CPU register	-	✓	✓	✓ Note 4	-
I/O register	-	✓	✓	✓ Note 4	-

- Notes 1.** This refers to data that were in the cache before execution, so the values are not real-time.
- 2.** Possible without briefly halting execution (other than MINICUBE2/E1(Serial)/E20(Serial))
- 3.** Possible only when the [Using the flash self programming] property in the [Flash] category on the [\[Connect Settings\] tab](#) of the [Property panel](#) is set to [No]
- 4.** Possible only when the selected microcontroller is single-core product
- 5.** Impossible while interrupts are disabled (DI)

Note that to enable the pseudo-RRM function, the setting below is required in addition to the [Basic Settings for Real-time Display Update Function](#).

Debug Tool	Property		Setting Value
[V850E2] IECUBE2 MINICUBE E1/E20(LPD) E1/E20(JTAG)	Setting A	[Access memory while running] category >> [Access during the execution]	[Yes]
	Setting B	[Access memory while running] category >> [Access during the execution]	[Yes]
		[Access memory while running] category >> [Access by stopping execution]	[Yes]
Other than above	[Access memory while running] category >> [Access by stopping execution]		[Yes] <sup>Note</sup>

**Note [V850E1][V850ES]: [IECUBE][MINICUBE][E1/E20(JTAG)]**

If a software breakpoint is being set to a valid state, the software breakpoint must be set to an invalid state. No software breakpoints can be set after specifying this property to [Yes].

**(c) DMM function/pseudo-DMM function (modifying)**

This function is used to write to the memory or watch-expressions in real-time during execution of a program. The following area can be modified by the DMM function or the pseudo-DMM function.

**Caution If CPU status shifts to the standby mode (HALT/STOP/IDLE) mode, a monitor time-out error will occur.**

**[IECUBE][IECUBE2][MINICUBE][E1/E20(LPD)/(JTAG)]**

However, when the [Access by release HALT mode] property in the [Access memory while running] category has been set to [Yes], if CPU status shifts to the HALT mode, the DMM function will continue to operate by automatically releasing the HALT mode.

Table 2-15. Target Area of DMM and Pseudo-DMM Function [V850E1][V850ES]

Area	IECUBE	MINICUBE E1/E20(JTAG)	MINICUBE2 E1/E20(Serial) EZ Emulator	Simulator
Internal ROM	-	-	-	○
Internal RAM	▲	▲	▲ Note 1	○
Emulation memory	▲	-	-	○
Target memory	▲	▲	-	○
CPU register	▲	▲	▲ Note 1	○ Note 2
I/O register (only for standard I/O registers)	▲	▲	▲	○

Table 2-16. Target Area of DMM and Pseudo-DMM Function [V850E2]

Area	IECUBE2		MINICUBE E1/E20(LPD)/(JTAG)		MINICUBE2 E1(Serial) E20(Serial)	Simulator
	Setting A	Setting B	Setting A	Setting B		
Internal ROM	-	-	-	-	-	○
Internal RAM	○	○	○	○	▲ Note 1	○
HBUS shared memory	-	▲	-	▲ Note 2	-	○
Back-up RAM	-	▲	-	▲ Note 2	▲ Note 1	○
Emulation memory	-		-	-	-	○
Target memory	-	▲	-	▲ Note 2	-	○
CPU register	-	▲	-	▲ Note 2	▲ Note 1	○ Note 3
I/O register	-	▲	-	▲ Note 2	▲ Note 1	○ Note 3

▲: Possible by briefly halting execution

○: Possible without briefly halting execution

**Notes 1.** Impossible while interrupts are disabled (DI)

2. Impossible during tracer/timer execution
3. Impossible for the multi-core product

To enable the DMM function or the pseudo-DMM function, the setting below is required in addition to the [Basic Settings for Real-time Display Update Function](#).

Debug Tool	Property			Setting Value
[V850E2] IECUBE2 MINICUBE E1/E20(LPD) E1/E20(JTAG)	Setting A		[Access memory while running] category >> [Access during the execution]	[Yes]
	Setting B		[Access memory while running] category >> [Access during the execution]	[Yes]
			[Access memory while running] category >> [Access by stopping execution]	[Yes]
Simulator	No setting is required.			
Other than above	[Access memory while running] category >> [Access by stopping execution]			[Yes] <sup>Note</sup>

#### Note [V850E1][V850ES]: [IECUBE][MINICUBE][E1/E20(JTAG)]

If a software breakpoint is being set to a valid state, the software breakpoint must be set to an invalid state. No software breakpoints can be set after specifying this property to [Yes].

The memory values/watch-expressions updated by the real-time display update function are highlighted in pink on the [Memory panel/Watch panel](#). Moreover, the background color of the memory values updated by the RRM function using IECUBE are highlighted as follows on the [Memory panel](#) in accordance with the access status (character colors and background colors depend on the configuration in the [\[General - Font and Color\] category](#) of the [Option dialog box](#)).

Access Condition	Display Example
Read or fetch	00 00 00 00

Access Condition	Display Example
Write	00 00 00 00
Read and write	00 00 00 00

**Caution** When a 2-, 4-, or 8-byte variable is to be read through the RRM or pseudo-RRM function, the process of assigning a value to the variable may be divided into two steps. If reading of the variable takes place between the two steps, an incorrect value may be read out because the assignment is not completed.

Figure 2-196. Example of Memory Display by Real-time Display Update Function





Figure 2-197. Example of Memory Display by Real-time Display Update Function (RRM Function) [IECUBE]



##### (5) Search the memory contents

Values of memory can be searched in the [Memory Search dialog box](#) that is opened by selecting [Find...] from the context menu. The search is operated either in the memory value area or character strings area, in which the caret exists. In this dialog box, follow the steps below.

Figure 2-198. Search Memory Contents (Memory Search Dialog Box)



- Cautions**
1. The contents of the memory cannot be searched during execution of a program.
  2. Character strings displayed as floating-point values cannot be searched.
  3. Search for values of the ID tag for the data flash memory cannot be performed.

#### (a) Specify [Search Data]

Specify data to search.

You can either type a value directly into the text box (up to 256 bytes), or select one from the input history via the drop-down list (up to 10 items).

If the search is performed in the memory value area, the value must be entered in the same display format (notation and size) as that area.

If the search is performed in the character strings area, then the target of the search must be a string. The specified string is converted into the encoding format displayed in that area, and searched for.

If a memory value was selected immediately prior to opening this dialog box, then that value will appear as default.

#### (b) Specify [Search Range]

Select the range to search from the following drop-down list.

Specify address range	Searches in the address range specified in the [Address] area.
Memory mapping	Searches within the selected memory mapping range. This list item displays individual memory mapping configured in the <a href="#">Memory Mapping dialog box</a> (except the non-mapped area). Display format: <memory type> <address range> <size>

#### (c) Specify [Address]

This item is only enabled if [Specify address range] is selected in the (b) Specify [Search Range].

Specify the range of memory address to search via the start and end addresses. You can either type address expressions directly into the text boxes (up to 1024 characters), or select them from the input history via the drop-down list (up to 10 items).

The results of calculating the address expressions you have entered are treated as start and end addresses, respectively.

Note, however, that the largest address that can be searched is the maximum address of the program space (0x03FFFFFF) (the mirror area cannot be searched).

An address value greater than the value expressed within 32 bits cannot be specified.

- Remarks**
1. A symbol name at the current caret position can be complemented by pressing the [Ctrl] + [Space] key in each text box (see "2.18.2 Symbol name completion function").
  2. If the start address field is left blank, it is treated as if "0x0" were specified.

3. If the end address field is left blank, then it is treated as if the maximum value in the microcontroller's address space were specified.

**(d) Click the [Search Backward]/[Search Forward] button**

When the [Search Backward] button is clicked, search will start in the order from the large address number to small and the search results are displayed selected in the [Memory panel](#).

When the [Search Forward] button is clicked, search will start in the order from the small address number to large and the search results are displayed selected in the Memory panel.


**(6) Modify the memory contents in batch (initialize)**

Contents of the memory can be modified in batch (initialize).

When [Fill...] from the context menu is selected, the [Memory Initialize dialog box](#) opens to modify the memory value of the specified address range in batch.

In this dialog box, follow the steps below.

**Figure 2-199. Modify Memory Contents in Batch (Memory Initialize Dialog Box)**



**Caution This operation cannot be performed for values of the ID tag for the data flash memory.**

**(a) Specify [Start address/symbol] and [End address/symbol]**

Specify the range of memory address to initialize via the [Start address/symbol] and [End address/symbol].

You can either type address expressions directly into the text boxes (up to 1024 characters), or select them from the input history via the drop-down list (up to 10 items).

The results of calculating the address expressions you have entered are treated as start and end addresses, respectively.

Note that address values greater than the microcontroller address space cannot be specified.

**Caution You cannot specify the range of address aligned across the different endian area.**

**Remark** A symbol name at the current caret position can be complemented by pressing the [Ctrl] + [Space] key in each text box (see "2.18.2 Symbol name completion function").

**(b) Specify [Initialize data]**

Specify the initializing data to write to the memory.

You can either type the initial value into the text box directly in hexadecimal number, or select one from the input history via the drop-down list (up to 10 items).

You can specify more than one initial value. Specify up to 16 values of up to 4 bytes (8 characters) each, separated by spaces.

Each initial value is parsed from the end of the string, with each two characters interpreted as a byte.

If the string has an odd number of characters, then the first character is interpreted as one byte.

Note that if a initial value consists of more than one byte, then the target memory is overwritten with the value converted into an array of bytes of the specified address range's endian, as follows.

Input Character Strings (Initial Value)	How Data is Overwritten (in Bytes)	
	LittleEndian	BigEndian
1	01	01
0 12	00 12	00 12
00 012 345	00 12 00 45 03	00 00 12 03 45
000 12 000345	00 00 12 45 03 00	00 00 12 00 03 45

**(c) Click the [OK] button**

Click the [OK] button.

The memory area in the specified address range is repeatedly overwritten with the specified initial data pattern. If the end address is reached in the middle of the pattern, then writing ends at that point.

Note that if an illegal value is specified, a message will appear, and the memory value will not be initialized.


**(7) Save the memory contents**

Contents of the memory can be saved with range selection in text files (\*.txt)/CSV files (\*.csv).

When saving to the file, the latest information is acquired from the debug tool, and it is saved in accordance with the display format on this panel.

The [Data Save dialog box](#) can be opened by selecting the [File] menu >> [Save Memory Data As...]. (when this operation is taken place with range selection on the panel, the memory data only in the selected range is saved). In this dialog box, follow the steps below.

**Figure 2-200. Save Memory Data (Data Save Dialog Box)**



**(a) Specify [File Name]**

Specify the name of the file to save.

You can either type a filename directly into the text box (up to 259 characters), or select one from the input history via the drop-down list (up to 10 items).

You can also specify the file by clicking the [...] button, and selecting a file via the [Select Data Save File dialog box](#).

**(b) Specify [File Type]**

Select the format in which to save the file from the following drop-down list.

The following file formats can be selected.

List Item	Format
Text files (*.txt)	Text format (default)
CSV (Comma-Separated Variables)(*.csv)	CSV format <sup>Note</sup>

**Note** The data is saved with entries separated by commas (,).

If the data contains commas, each entry is surrounded by double quotes "" in order to avoid illegal formatting.

**(c) Specify [Save Range Address/Symbol]**

Specify the range of addresses to save via "start address" and "end addresses".

Directly enter hexadecimal number/address expression in each text box or select from the input history displayed in the drop-down list (up to 10 items).

If a range is selected in the panel, that range is specified as the default. If there is no selection, then the range currently visible in the panel is specified.

**Remark** A symbol name at the current caret position can be complemented by pressing the [Ctrl] + [Space] key in each text box (see "2.18.2 Symbol name completion function").

**(d) Click the [Save] button**

Saves the memory data to a file with the specified filename, in the specified format.

**Figure 2-201. Output Example of Memory Data**

[Text files (\*.txt)]

(Hexadecimal notation/8-bit width/ASCII code)

+0 +1 +2 +3 +4 +5 +6 +7 +8 +9 +a +b +c +d +e +f	
00000000   00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00	
00000010   11 11 11 11 11 11 11 11 11 11 11 11 11 11 11 11	

[CSV files (\*.csv)]

(Hexadecimal notation/8-bit width/ASCII code)

00000000,00,00,00,00,00,00,00,00,00,00,00,00,00,00,00, 00000010,11,11,11,11,11,11,11,11,11,11,11,11,11,11,11,
--

**Remark** When the contents of the panel are overwritten by selecting the [File] menu>> [Save Memory Data], each Memory panel (Memory1-4) is treated as a different panel.

In addition, saving range is same as the previously specified address range.


### 2.9.2 Display/change the CPU register

The contents of the CPU register (program register/system register) can be shown and the value can be changed in the [CPU Register panel](#) below.

Select the [View] menu >> [CPU Register].

For details on the contents and function in each area, see the section for the [CPU Register panel](#).

Figure 2-202. Display the Contents of CPU Register (CPU Register Panel)



This section describes the following.

- (1) Change display format of values
- (2) Modify the CPU register contents
- (3) Display/modify the CPU register contents during program execution
- (4) Save the CPU register contents

#### (1) Change display format of values

The display format of the [value] area can be changed using buttons below on the toolbar.

Notation	The following buttons to change the notation of a data value are displayed.
	Displays the value of the selected item (including sub-items) in the default notation (default).
	Displays the value of the selected item (including sub-items) in hexadecimal number.
	Displays the value of the selected item (including sub-items) in signed decimal number.
	Displays the value of the selected item (including sub-items) in unsigned decimal number.
	Displays the value of the selected item (including sub-items) in octal number.
	Displays the value of the selected item (including sub-items) in binary number.
	Displays the character strings of the selected item (including sub-items) in ASCII code. If the character size is 2 bytes and above, it is displayed with the characters for each 1 byte arranged side-by-side.
	Displays the value of the selected item in Float. Note that when the value is not 4-byte data, displays it in the default notation.
	Displays the value of the selected item in Double. Note that when the value is not 8-byte data, displays it in the default notation.
	Adds the value in hexadecimal number enclosing with "()" at the end of the value.

### (2) Modify the CPU register contents

The CPU register values can be edited.

Select the value of the CPU register to edit in the [Value] area, then click on it again to switch the value to edit mode (press the [Esc] key to cancel the edit mode).

To write the edited value to the target memory, directly enter the value from the keyboard then press the [Enter] key.

**Caution** This operation cannot be performed during program execution.

### (3) Display/modify the CPU register contents during program execution

By registering a CPU register to the [Watch panel](#) as a watch-expression, the value of the CPU register can be displayed/modified not only while the program is stopped, but in execution.

See "[2.9.6 Display/change watch-expressions](#)" for details on the watch-expression.

### (4) Save the CPU register contents

The [Save As dialog box](#) can be opened by selecting the [File] menu >> [Save CPU Register Data As...], and all the contents in the CPU register can be saved to a text file (\*.txt) or CSV file (\*.csv).

When saving to files, retrieve the latest information from the debug tool.

**Figure 2-203. Output Example of CPU Register Data**

Register name	Value
<hr/>	
Category name	
-Register name	Value
:	:


#### 2.9.3 Display/change the I/O register

Contents of the I/O register can be displayed and its values can be changed in the [IOR panel](#) below.

Select the [View] menu >> [IOR].

For details on the contents and function in each area, see the section for the [IOR panel](#).

**Figure 2-204. Display the Contents of I/O register (IOR Panel)**



This section describes the following.

- (1) Search for an I/O register
- (2) Organize I/O registers
- (3) Change display format of values
- (4) Modify the I/O register contents
- (5) Display/modify the I/O register contents during program execution
- (6) Save the I/O register contents

### **(1) Search for an I/O register**

An I/O register can be searched for.

Specify the I/O register name to search with the text box in the search area (case-insensitive). You can either type character strings directly from the key board (up to 512 characters), or select one from the input history via the drop-down list (up to 10 items).

Then, click either one of the following button.

	Searches up for the I/O register name containing the string specified in the text box, and selects the I/O register that is found.
	Searches down for the I/O register name containing the string specified in the text box, and selects the I/O register that is found.

- Remarks 1.** The hidden I/O register name being classified with a category can be searched (the category is opened and the I/O register is selected).
2. After typing character strings to search, to press the [Enter] key is the same function as clicking the button, and to press the [Shift] + [Enter] key is the same function as clicking the button.

### **(2) Organize I/O registers**

The each I/O register can be categorized (by folders) and displayed in the tree view.

- Cautions 1. Categories cannot be created within categories.**  
**2. I/O registers cannot be added or deleted.**

#### **(a) Create new category**

Move the caret to the I/O register name to create a new category then click the button in the toolbar and directly enter the new category name.

#### **(b) Edit category name**

Click the category name to edit, and click it again, then directly modify the category name from the keyboard.

#### **(c) Delete categories**

Select categories to delete then click the button in the toolbar.

However, the categories that can be deleted are only the empty categories.

#### **(d) Change the display order**

I/O register name is categorized when I/O register is dragged and dropped in the category.

Also, the display order of the categories and the I/O register names (upper or lower position) can be changed easily by drag and drop operation.

### (3) Change display format of values

The display format of the [value] area can be changed using buttons below on the toolbar.

Notation	The following buttons to change the notation of a data value are displayed.
	Displays the value of the selected item in hexadecimal number (default).
	Displays the value of the selected item in signed decimal number.
	Displays the value of the selected item in unsigned decimal number.
	Displays the value of the selected item in octal number.
	Displays the value of the selected item in binary number.
	Displays the value of the selected item in ASCII code.
	Adds the value in hexadecimal number enclosing with "()" at the end of the value of the selected item.

### (4) Modify the I/O register contents

The I/O register values can be edited.

Select the value of the I/O register to edit in the [Value] area, then click on it again to switch the value to edit mode (press the [Esc] key to cancel the edit mode).

To write the edited value to the target memory, directly enter the value from the keyboard then press the [Enter] key.

**Cautions 1. This operation cannot be performed during program execution.**

**2. The value of the read-only I/O register cannot be edited.**

**Remarks 1.** If a number with fewer digits than the size of the I/O register is entered, the higher-order digits will be padded with zeroes.  
**2.** If a number with more digits than the size of the I/O register is entered, the higher-order digits will be masked.  
**3.** ASCII characters can be entered to the I/O register value.  
 - When the numeric "0x41" is written to the I/O register "WTM"  
     >> "0x41" is written in the port "WTM".  
 - When the ASCII character "A" is written to the I/O register "WTM"  
     >> "0x41" is written in the port "WTM".

### (5) Display/modify the I/O register contents during program execution

By registering an I/O register to the [Watch panel](#) as a watch-expression, the value of the I/O register can be displayed/modified not only while the program is stopped, but in execution.

See "[2.9.6 Display/change watch-expressions](#)" for details on the watch-expression.

### (6) Save the I/O register contents

The [Save As dialog box](#) can be opened by selecting the [File] menu >> [Save IOR Data As...], and all the contents of the I/O register can be saved in a text file (\*.txt) or CSV file (\*.csv). At this time, the values of all I/O registers become targets irrespective of the setting of display/non-display on this panel.

When saving the contents to the file, the values of the I/O register are reacquired and save the latest values acquired.

Note that the values of read-protected I/O register are not re-read. If you want to save the latest values of those, select [Force Read Value] from the context menu then save the file.

Figure 2-205. Output Example of I/O register

IOR name	Value	Type (Byte Size)	Address
<hr/>			
Category name			
- IOR name	Value	Type (Byte Size)	Address
:	:	:	:

#### 2.9.4 Display/change global variables/static variables

Global variables or static variables are displayed and its values can be changed in the [Watch panel](#).

Register the variables to display/modify their values to the Watch panel as the watch-expressions.

For details, see "[2.9.6 Display/change watch-expressions](#)".

#### 2.9.5 Display/change local variables

Contents of local variables can be displayed and its values can be changed in the [Local Variables panel](#) below.

Select the [View] menu >> [Local Variable].

Specify the scope in the scope area to display the contents of the target local variable.


In the Local Variables panel, the name of local variables and functions are displayed. The argument of the function is also displayed as the local variable.

For details on the contents and function in each area, see the section for the [Local Variables panel](#).

**Caution Nothing is displayed on this panel during execution of a program.**

**When the program is stopped, items in each area are displayed.**

Figure 2-206. Display the Contents of Local Variables (Local Variables Panel)



This section describes the following.

- (1) Change display format of values
- (2) Modify the contents of local variables
- (3) Save the contents of local variables

### (1) Change display format of values

The display format of the [value] area can be changed using buttons below on the toolbar.

Notation	The following buttons to change the notation of a data value are displayed.
	Displays values on this panel in the default notation according to the type of variable (default).
	Displays values on this panel in hexadecimal number.
	Displays values on this panel in decimal number.
	Displays values on this panel in octal number.
	Displays values on this panel in binary number.
	Displays array indexes on this panel in decimal number (default).
	Displays array indexes on this panel in hexadecimal number.
	Displays values on this panel in Float. Note that when the value is not 4-byte data, or has the type information, displays it in the default notation.
	Displays values on this panel in Double. Note that when the value is not 4-byte data, or has the type information, displays it in the default notation.
	Adds the value in hexadecimal number enclosing with "(" at the end of the value.
Encoding	The following buttons to change the encoding of character variables are displayed.
	Displays character variables in ASCII code (default).
	Displays character variables in Shift_JIS code.
	Displays character variables in EUC-JP code.
	Displays character variables in UTF-8 code.
	Displays character variables in UTF-16 code.

### (2) Modify the contents of local variables

Values and arguments of local variables can be edited.

Select the value of the local variables/arguments to edit in the [Value] area, then click on it again to switch the value to edit mode (press the [Esc] key to cancel the edit mode).

To write the edited value to the target memory, directly enter the value from the keyboard then press the [Enter] key. At this time, the edited value is checked and if it is incompatible with the type, the editing is invalidated.

**Caution This operation cannot be performed during program execution.**

- Remarks**
- If a number with fewer digits than the size of the variable is entered, the higher-order digits will be padded with zeroes.
  - If a number with more digits than the size of the variable is entered, the higher-order digits will be masked.
  - If the display format of a character array (type char or unsigned char) is set to ASCII, then the value can also be entered as a string (ASCII/Shift\_JIS/EUC-JP/Unicode (UTF-8/UTF-16)).
  - ASCII characters can be entered to values of local variables.
    - Entering via an ASCII character  
In the [Value] area for the variable "ch", enter "A"  
>> "0x41" will be written to the memory area allocated to "ch"
    - Entering via a numeric value  
In the [Value] area for the variable "ch", enter "0x41"  
>> "0x41" will be written to the memory area allocated to "ch"

- Entering via an ASCII string  
Set the display format of character array "str" to ASCII, and in the [Value] area, enter ""ABC""  
>> "0x41, 0x42, 0x43, 0x00" will be written to the memory area allocated to "str"

### (3) Save the contents of local variables

The [Save As dialog box](#) can be opened by selecting the [File] menu >> [Save Local Variables Data As...], and all the contents in the local variables can be saved in a text file (\*.txt) or CSV file (\*.csv). When saving to files, retrieve the latest information from the debug tool. If arrays, pointer type variables, structures/unions, and CPU registers (only those with the part name) are displayed expanded, the value of each expanded element is also saved. When they are not expanded, "+" mark is added on the top of the item and the value becomes blank.

**Figure 2-207. Output Example of Local Variables**

Scope : Current scope				
[V] Variable	[P] Parameter	[F] Function		
Name		Value	Type (Byte Size)	Address
[V] Variable name[1]		Value	Type	Address
- [V] Variable name[0]		Value	Type	Address
:	:	:	:	:

### 2.9.6 Display/change watch-expressions

By registering C language variables, CPU register, I/O register, and assembler symbols to the [Watch panel](#) as watch-expressions, you can always retrieve their values from the debug tool and monitor the values in batch.


The values of watch-expressions can be updated during the program is in execution (see "[\(7\) Display/modify the contents of watch-expressions during program execution](#)").

Select the [View] menu >> [Watch] >> [Watch 1 - 4] to open the Watch panel.

The Watch panel can be opened up to 4 panels. Each panel is identified by the names "Watch1", "Watch2", "Watch3" and "Watch4" on the titlebar, and the watch-expressions can be registered/deleted/moved individually, and they are saved as the user information of the project.

For details on the contents and function in each area, see the section for the [Watch panel](#).

**Figure 2-208. Display the Contents of Watch-Expression (Watch Panel)**



This section describes the following.

- (1) Register a watch-expression
- (2) Organize the registered watch-expressions
- (3) Edit the registered watch-expressions
- (4) Delete a watch-expression
- (5) Change display format of values
- (6) Modify the contents of watch-expressions
- (7) Display/modify the contents of watch-expressions during program execution
- (8) Export/import watch-expressions
- (9) Save the contents of watch-expressions

### (1) Register a watch-expression

There are three ways as follows to register watch-expressions (watch-expressions are not registered as default).

- Cautions 1.** Watch-expressions can be registered up to 128 in one watch panel (if this restriction is violated, a message appears).
2. Due to compiler optimization, the data for the target variable may not be on the stack or in a register in blocks where that variable is not used. In such cases, if the variable is registered as a watch-expression, then the value will be displayed as a question mark "?".

- Remarks 1.** Each watch-expression registered in each watch panel (Watch1 to Watch4) is managed in each panel and saved as the user information of the project.
2. More than one watch-expression with the same name can be registered.


#### (a) Register from other panels

Watch-expressions can be registered from other panel in CubeSuite+.

In other panel, drag and drop the watch-expression to register in any watch panel (Watch1 to Watch4).

For the relationship between panels that can use this operation and targets that can be registered as watch-expressions, see "[Table A-12. Relationship between Panels and Targets That Can be Registered as Watch-Expressions](#)".

**Figure 2-209. Registering Watch-Expressions from Other Panels**




**Remark** You can also add a watch-expression by doing the following. First, select the target for which you wish to register a watch-expression, or move the caret to one of the target strings (the target is determined automatically). Next, from the context menu, select [Register Watch1] (but this is limited to the [Watch panel](#) (Watch 1)).

**(b) Directly register in the Watch panel**

Click the  button in the toolbar in any the [Watch panel](#) (Watch1 to Watch4) to display the following entry box in the [Watch] area.

Figure 2-210. Entry Box of Watch-Expression



Directly input a watch-expression from the keyboard in the entry box then press the [Enter] key.

The input format of the watch-expression is the following tables.

- [Table A-13. Input Format of Watch-Expression](#)
- [Table A-14. Scope Specification of C language Used with Watch-Expression Registration](#)
- [Table A-15. Scope Specification of CPU Register with Watch-Expression Registration](#)
- [Table A-16. Scope Specification of I/O register with Watch-Expression Registration](#)

**Remark** A symbol name at the current caret position can be complemented by pressing the [Ctrl] + [Space] key in this area (see "[2.18.2 Symbol name completion function](#)").

**(c) Register from other application**

Select the character strings of C language variables/CPU registers/I/O register/assembler symbols from an external editor and drag and drop it in the [Watch panel](#) (Watch 1 to Watch 4).

The dropped character strings are registered as a watch-expression.

**(2) Organize the registered watch-expressions**

Registered watch-expressions can be organized in categories (folders) and displayed in tree view (there is no category as default).

**Cautions 1. Categories cannot be created within categories.**

2. Up to 64 categories can be created in one watch panel (if this restriction is violated, a message appears).

**(a) Create new category**

Move the caret to the position to create a new category then click the  button in the toolbar and directly enter the new category name.

**(b) Edit category name**

Click the category name to edit, and click it again, then directly modify the category name from the keyboard.

**(c) Delete categories**

Select categories to delete then click the  button in the toolbar.

**(d) Change the display order**

Registered watch-expressions are categorized when they are dragged and dropped in the category.

Also, the display order of the categories and the watch-expressions (upper or lower position) can be changed easily by drag and drop operation.

**Remark** Drag and drop the watch-expressions/categories in other watch panel (Watch1 to Watch4) to copy them.

**(3) Edit the registered watch-expressions**

Registered watch-expressions can be edited.

Double-click the watch-expression to edit to switch the watch-expression to edit mode (press the [Esc] key to cancel the edit mode).

Directly edit from the keyboard and then press the [Enter] key.

**(4) Delete a watch-expression**

To delete watch-expressions, select the one you want to delete in the [Watch panel](#) then click the  button in the toolbar.

**(5) Change display format of values**

The display format of the [value] area can be changed using buttons below on the toolbar.

Notation	The following buttons to change the notation of a data value are displayed.
	Displays the value of the selected watch-expression in the default notation (see " <a href="#">Table A-17. Display Format of Watch-Expressions (Default)</a> ") according the type of variable (default).
	Displays the value of the selected item in hexadecimal number.
	Displays the value of the selected item in signed decimal number.
	Displays the value of the selected item in unsigned decimal number.
	Displays the value of the selected item in octal number.
	Displays the value of the selected item in binary number.
	Displays the value of the selected item in ASCII code.
	Displays the value of the selected item in Float. Note that this item becomes valid only when the selected watch-expression value is 4-byte data.
	Displays the value of the selected item in Double. Note that this item becomes valid only when the selected watch-expression value is 8-byte data.
	Adds the value in hexadecimal number enclosing with "()" at the end of the value of the selected item (except the item displayed in hexadecimal number).

**(6) Modify the contents of watch-expressions**

The values of watch-expressions can be edited.

Double-click the value of the watch-expression to edit in the [Value] area to switch the value to edit mode (press the [Esc] key to cancel the edit mode).

To write the edited value to the target memory, directly enter the value from the keyboard then press the [Enter] key.

Note that only those values that correspond one by one to variables of C language, CPU registers, I/O register or assembler symbols can be edited. In addition, read-only I/O register values cannot be edited.

This operation can be taken place while the program is in execution. See "[\(4\) Display/modify the memory contents during program execution](#)" for details on how to operate it.

- Remarks**
1. If a number with fewer digits than the size of the variable is entered, the higher-order digits will be padded with zeroes.
  2. If a number with more digits than the size of the variable is entered, the higher-order digits will be masked.
  3. If the display format of a character array (type char or unsigned char) is set to ASCII, then the value can also be entered as a string (ASCII/Shift\_JIS/EUC-JP/Unicode (UTF-8/UTF-16)).
  4. ASCII characters can be entered to values of watch-expressions.
    - Entering via an ASCII character
 

In the [Value] area for the variable "ch", enter "A"  
 >> "0x41" will be written to the memory area allocated to "ch"
    - Entering via a numeric value
 

In the [Value] area for the variable "ch", enter "0x41"  
 >> "0x41" will be written to the memory area allocated to "ch"
    - Entering via an ASCII string
 

Set the display format of character array "str" to ASCII, and in the [Value] area, enter ""ABC""  
 >> "0x41, 0x42, 0x43, 0x00" will be written to the memory area allocated to "str"

#### (7) Display/modify the contents of watch-expressions during program execution

The [Memory panel/Watch panel](#) has the real-time display update function that can update/modify the display contents of the memory/watch-expression in real-time while executing the program.

Using the real-time display update function allows you to display/modify the value of memory/watch-expression not only while the program is stopped, but also in execution.

See "[\(4\) Display/modify the memory contents during program execution](#)" for details on how to operate it.

#### (8) Export/import watch-expressions

This feature is for the export of currently registered watch-expressions to a file and the importing of such files, enabling the re-registration of watch-expressions.

To do this, follow the procedure described below.

##### (a) Export watch-expressions

Save watch-expressions currently being registered (including categories) in a file format that is possible to import.

With the [Watch panel](#) in focus, select [Save Watch Data As...] from the [File] menu.


On the [Save As dialog box](#) that is automatically opened, specify the following items, and then click the [Save] button.

- [File name]: Specify the name of a file to be saved (the file extension must be ".csv").
- [Save as type]: Select "Importable CSV (Comma-Separated Variables)(\*.csv)"

**Caution** Neither values nor the type information of watch-expressions can be saved.

Items that are expanded after analyzing watch-expressions (i.e. an array, structure, and so on) cannot be saved.

Figure 2-211. Export of Watch-Expressions

**(b) Import watch-expressions**


Import the file that exported in (a) to the [Watch panel](#).

On the [Watch panel](#) to which you want to import watch-expressions, select [Import Watch Expression] from the context menu.

On the [Open Watch Expression Data File dialog box](#) that is automatically opened, specify the file that exported previously, and then click the [Open] button.

**Remark** If watch-expressions have been already registered, then imported watch-expressions will be registered at the bottom of them.

Figure 2-212. Import of Watch-Expressions



**(9) Save the contents of watch-expressions**

By selecting the [File] menu >> [Save Watch Data As...], the [Save As dialog box](#) can be opened, and all the contents of the watch-expression and its value can be saved in a text file (\*.txt) or CSV file (\*.csv).

When saving the contents to the file, all the values of the watch-expression are reacquired and save the latest values acquired.

If arrays, pointer type variables, structures/unions, and CPU registers (only those with the part name) are displayed expanded, the value of each expanded element is also saved. When they are not expanded, "+" mark is added on the top of the item and the value becomes blank.

Note that the values of read-protected I/O register are not re-read. If you want to save the latest values of those, select [Force Read Value] from the context menu then save the file.

**Figure 2-213. Output Example of Watch Data**

Watch-expression	Value	Type (Byte Size)	Address	Memo
<hr/>				
-Category name				
Watch-expression	Value	Type (Byte Size)	Address	Memo
:	:	:	:	:

**Remark** When the contents of the panel are overwritten by selecting the [File] menu >> [Save Watch Data], each watch panel (Watch1 to Watch4) is treated as a different panel.

## 2.10 Display Information on Function Call from Stack

This section describes how to show the information on function call from the stack.

The CubeSuite+ compiler (CA850/CX) pushes function-call information onto the stack, in accordance with the ANSI standard.

It is thus possible to learn the function call depth, the location of the caller, parameters, and other information by analyzing the function-call information.

This "function-call information" is called the call stack information; this term will be used in the rest of this document.

### 2.10.1 Display call stack information

Call stack information is displayed in the [Call Stack panel](#) below.


Select the [View] menu >> [Call Stack].

For details on the contents and function in each area, see the section for the [Call Stack panel](#).

**Caution Nothing is displayed on this panel during execution of a program.**

**When the program is stopped, items in each area are displayed.**

Figure 2-214. Display Call Stack Information (Call Stack Panel)



This section describes the following.

- (1) Change display format of values
- (2) Jump to the source line
- (3) Display local variables
- (4) Save the contents of call stack information

#### (1)Change display format of values

The display format of this panel can be changed using buttons below on the toolbar.

Note that these buttons are disabled during execution of a program.

Notation	The following buttons to change the notation of a data value are displayed.
	Displays values on this panel in the default notation according to the type of variable (default).
	Displays values on this panel in hexadecimal number.
	Displays values on this panel in decimal number.
	Displays values on this panel in octal number.
	Displays values on this panel in binary number.
Encoding	The following buttons to change the encoding of character variables are displayed.
	Displays character variables in ASCII code (default).
	Displays character variables in Shift_JIS code.
	Displays character variables in EUC-JP code.
	Displays character variables in UTF-8 code.
	Displays character variables in UTF-16 code.

## (2) Jump to the source line

Double-clicking on the line will open the [Editor panel](#) with the caret moved to the source line of the calling function indicated by the selected line (If the panel is already open, the screen will jump to the editor panel).

**Remark** Selecting [Jump to Disassemble] from the context menu will open the [Disassemble panel](#) (Disassemble 1) with the caret moved to address of the calling function indicated by the selected line (If the panel is already open, the screen will jump to the Disassemble panel (Disassemble 1)).

## (3) Display local variables

Selecting [Jump to Local Variable at This Time] from the context menu will open the [Local Variables panel](#) that displays the local variables indicated by the currently selected line.

## (4) Save the contents of call stack information

By selecting the [File] menu >> [Save Call Stack Data As...], the [Save As dialog box](#) can be opened, and all the contents in the call stack information can be saved in a text file (\*.txt) or CSV file (\*.csv).

When saving to files, retrieve the latest information from the debug tool.

**Figure 2-215. Output Example of Call Stack Information**

Depth	Call stack
0	Call stack information
1	Call stack information
:	:

## 2.11 Collect Execution History of Programs [IECUBE][IECUBE2][Simulator]

This section describes how to collect the execution history of the program.

A history of program execution is generally called a trace; this term will be used in the remainder of this document.

It is nearly impossible to find the cause of runaway program execution from the memory contents, stack information, and the like after the runaway has occurred. The collected trace data, however, can be used to trace program execution up to the runaway directly, making this an effective tool for discovering hidden bugs.

### Cautions 1. [IECUBE]

**Some of the trace function, the real-time display update function (RRM function) and the coverage function are used on a mutually exclusive basis.**

### 2. [IECUBE2]

**Some of the trace function, the timer function (except for the Run-Break timer) and the coverage function are used on a mutually exclusive basis.**

### 3. [MINICUBE][MINICUBE2][E1][E20][EZ Emulator]

The trace function is not supported.

#### 2.11.1 Configure the trace operation

When the trace function starts, trace data which has recorded in it an execution history of the currently executed program is collected in trace memory (when program execution stops, the trace function also automatically stops).

Before the trace function can be used, it is necessary to make settings relating to the operation of a trace.

Note that the method on how to set differs depending on the debug tool used.

- (1) [IECUBE]
- (2) [IECUBE2]
- (3) [Simulator]

##### (1) [IECUBE]

This trace operation can be configured in the [Trace] category on the [\[Debug Tool Settings\]](#) tab in the [Property panel](#).

Figure 2-216. [Trace] Category [IECUBE]

Trace	
Use for trace data	Trace
Select trace data	Branch PC + Access Data
Trace priority	Speed priority
Clear trace memory before running	Yes
Operation after trace memory is full	Non stop and overwrite to trace memory
Rate of frequency division of trace time tag	1/1(20ns/1.4min)
Trace memory size[frames]	8K
Enable trace data complement	Yes

##### (a) [Use for trace data]

Some of the trace function, the real-time display update function (RRM function) and the coverage function are used on a mutually exclusive basis. Accordingly, you need to specify a function used preferentially. Select [Trace] from the following drop-down list.

Trace	Uses the trace function preferentially. - Real-time display update function (RRM function) Cannot be used - Coverage function Cannot be used
RRM	Uses the real-time display update function (RRM function) preferentially (default). - Trace function Only trace branch instructions internally (the behavior is the same as when the [Select trace data] property is set to [Branch PC]). Trace-related events also become invalid. - Coverage function Cannot be used
Coverage	Uses the coverage function preferentially. - Trace function Only trace instructions internally (the behavior is the same as when the [Select trace data] property is set to [Branch PC]). Trace-related events also become invalid. - Coverage function Cannot be used

**(b) [Select trace data]**

This property appears only when the [Use for trace data] property is set to [Trace].

Specify the type of trace data to be collected from the following drop-down list.

Branch PC
All PC
Access Data
Branch PC + Access Data (default)
All PC + Access Data
Access PC + Access Data
Branch PC + Access PC + Access Data

**Remarks 1.** Meaning of the type of trace data to be collected is as follows:

Branch PC	PC values of branch origin and branch destination instructions
All PC	PC values of all instructions
Access Data	Access address and access data
Access PC	PC values of instructions that caused access

2. The DMA start point and end point are traced regardless of the trace condition.

**(c) [Trace priority]**

This property is valid only when the [Use for trace data] property is set to [Yes].

Specify which item should be given priority when using the trace function from the following drop-down list.

Speed priority	Traces giving priority to the real-time performance (default).
Data priority	Traces after stopping the execution pipeline of the CPU temporarily so that no data is missed.

**(d) [Clear trace memory before running]**

Specify from the drop-down list whether to clear (initialize) the trace memory before tracing starts in this property. Select [Yes] to clear the memory (default).

**Remark** You can forcibly clear the trace memory when clicking the  button in the toolbar in the [Trace panel](#) [[IECUBE](#)][[IECUBE2](#)][[Simulator](#)].

**(e) [Operation after trace memory is full]**

Specify the operation after the trace memory is full with the collected trace data from the following drop-down list.

Non stop and overwrite to trace memory	Continues overwriting the older trace data after the trace memory is full (default). When the <a href="#">[Clear trace memory before running]</a> property is set to [Yes], at the time of a resumption, trace data is collected after clearing the trace memory.
Stop trace	When the trace memory is full, CubeSuite+ stops writing trace data (the program does not stop execution). When the <a href="#">[Clear trace memory before running]</a> property is set to [No], trace data is not collected even if the program is executed again.
Stop	When the trace memory is full, CubeSuite+ stops writing trace data and the program stops execution. When the <a href="#">[Clear trace memory before running]</a> property is set to [No], the program cannot be executed again even if it is executed.

**(f) [Rate of frequency division of trace time tag]**

Specify from the drop-down list the frequency division ratio of the counter to be used for time tag display (the [Time] item in the [Trace panel](#) [[IECUBE](#)][[IECUBE2](#)][[Simulator](#)]).

The drop-down list displays the following frequency division ratios (values in "()" indicate the resolution and the maximum measurement time when using a time tag counter of 32-bit and a external clock of 50 MHz).

1/1(20ns/1.4min),	1/2(40ns/2.8min),	1/4(80ns/5.7min),
1/8(160ns/11.4min),	1/16(320ns/22.8min),	1/32(640ns/45.6min),
1/64(1280ns/1.5h),	1/128(2560ns/3.0h),	1/256(5120ns/6.0h),
1/512(10240ns/12.2h),	1/1024(20480ns/24.4h),	1/2048(40960ns/48.8h),
1/4096(81920ns/97.6h)		

**(g) [Trace memory size[frames]]**

Specify from the drop-down list the size of trace memory (i.e. the number of trace frames) in this property.

The trace frame is a unit of trace data. One trace frame is used for each operation in fetch/write/read.

The drop-down list displays the number of trace frames as follows:

8K (default), 32K, 64K, 128K, 256K

**(h) [Enable trace data complement]**

Specify whether to perform complementary display when displaying the collected trace data in the [Trace panel](#) [[IECUBE](#)][[IECUBE2](#)][[Simulator](#)].

Complement display of instructions between branch instructions that cannot be traced by hardware can be performed.

Select [Yes] to perform complementary display (default).

Note that the trace memory is cleared automatically if you change the setting of this property.

## (2) [IECUBE2]

This trace operation can be configured in the [Trace] category on the [\[Debug Tool Settings\]](#) tab in the [Property panel](#).

**Figure 2-217. [Trace] Category [IECUBE2]**

<b>Trace</b>	
Use for trace data	Trace
Select trace data	Branch PC + Access Data
DMA is traced	<b>Yes</b>
Select DMA trace data	Access Type + Access Address + Data Si
Trace priority	Speed priority
Clear trace memory before running	Yes
Operation after trace memory is full	Non stop and overwrite to trace memory
Trace memory size[frames]	8K
Enable trace data complement	Yes

### (a) [Use for trace data]

Some of the trace function, the timer function (except for the Run-Break timer) and the coverage function are used on a mutually exclusive basis. Accordingly, you need to specify a function used preferentially. Select [Trace] from the following drop-down list.

Trace	Uses the trace function preferentially. - Timer function Cannot be used Timer-related events (except for the Run-Break timer) also become invalid. - Coverage function Cannot be used
Timer	Uses the timer function preferentially. - Trace function Cannot be used Trace-related events also become invalid. - Coverage function Cannot be used
Coverage	Uses the coverage function preferentially. - Trace function Only trace branch instructions internally (the behavior is the same as when the <a href="#">[Select trace data]</a> property is set to [Branch PC]). Trace-related events also become invalid. - Timer function Cannot be used Timer-related events (except for the Run-Break timer) also become invalid.

### (b) [Select trace data]

This property appears only when the [\[Use for trace data\]](#) property is set to [Trace].

Specify the type of trace data to be collected from the following drop-down list.

Branch PC
Access Data
Branch PC + Access Data (default)
Access PC + Access Data
Branch PC + Access PC + Access Data

**Remark** Meaning of the type of trace data to be collected is as follows:

Branch PC	PC values of branch origin and branch destination instructions
Access Data	Access address and access data
Access PC	PC values of instructions that caused access

**(c) [DMA is traced]**

Specify whether to trace the access data via DMA from the following drop-down list.

Select [Yes] to perform the DMA trace ([No] is selected by default).

**(d) [Select DMA trace data]**

This property appears only when the [DMA is traced] property is set to [Trace].

Specify the type of DMA trace data to be collected from the following drop-down list.

Access Type + Access Address + Data Size + Access Data
Access Type + Access Address + Data Size
Access Type + Channel Number
Access Type + Channel Number + Transfer Count
Access Type + Access Data + Channel Number + Transfer Count

**Remark** Meaning of the type of DMA trace data to be collected is as follows:

Access Type	Type of the memory access (Read, Write, Read/Write)
Access Address	Target address of the memory access
Data Size	Access size
Access Data	Access data
Channel Number	DMA channel number
Transfer Count	DMA transfer count

**(e) [Trace priority]**

This property is valid only when the [Use for trace data] property is set to [Yes].

Specify which item should be given priority when using the trace function from the following drop-down list.

Speed priority	Traces giving priority to the real-time performance (default).
Data priority	Traces after stopping the execution pipeline of the CPU temporarily so that no data is missed.

**(f) [Clear trace memory before running]**

Specify from the drop-down list whether to clear (initialize) the trace memory before tracing starts in this property. Select [Yes] to clear the memory (default).

**Remark** You can forcibly clear the trace memory when clicking the  button in the toolbar in the [Trace panel](#) [[IECUBE](#)][[IECUBE2](#)][[Simulator](#)].

**(g) [Operation after trace memory is full]**

Specify the operation after the trace memory is full with the collected trace data from the following drop-down list.

Non stop and overwrite to trace memory	Continues overwriting the older trace data after the trace memory is full (default). When the <a href="#">[Clear trace memory before running]</a> property is set to [Yes], at the time of a resumption, trace data is collected after clearing the trace memory.
Stop trace	When the trace memory is full, CubeSuite+ stops writing trace data (the program does not stop execution). When the <a href="#">[Clear trace memory before running]</a> property is set to [No], trace data is not collected even if the program is executed again.
Stop	When the trace memory is full, CubeSuite+ stops writing trace data and the program stops execution. Regardless of the setting of the <a href="#">[Clear trace memory before running]</a> property, the trace memory will clear before tracing starts.

**(h) [Trace memory size[frames]]**

Specify from the drop-down list the size of trace memory (i.e. the number of trace frames) in this property.

The trace frame is a unit of trace data. One trace frame is used for each operation in fetch/write/read.

The drop-down list displays the number of trace memory as follows:

8K (default), 32K, 64K, 128K, 256K

**(i) [Enable trace data complement]**

Specify whether to perform complementary display when displaying the collected trace data in the [Trace panel](#) [[IECUBE](#)][[IECUBE2](#)][[Simulator](#)].

Complement display of instructions between branch instructions that cannot be traced by hardware can be performed.

Select [Yes] to perform complementary display (default).

Note that the trace memory is cleared automatically if you change the setting of this property.

**(3) [Simulator]**

This trace operation can be configured in the [Trace] category on the [\[Debug Tool Settings\]](#) tab of the [Property panel](#).

**Figure 2-218. [Trace] Category [Simulator]**

<b>Trace</b>	
Use trace function	Yes
Clear trace memory before running	Yes
Operation after trace memory is full	Non stop and overwrite to trace memory
Accumulate trace time	No
Trace memory size[frames]	4K
Rate of frequency division of trace time tag	1/1

**(a) [Use trace function]**

Specify whether to use trace function from the drop-down list in this property.

Select [Yes] to use the trace function ([No] is selected by default).

**(b) [Clear trace memory before running]**

Specify from the drop-down list whether to clear (initialize) the trace memory before tracing starts in this property.

Select [Yes] to clear the memory (default).

**Remark** You can forcibly clear the trace memory when clicking the  button in the toolbar in the [Trace panel](#) [[IECUBE](#)][[IECUBE2](#)][[Simulator](#)].

**(c) [Operation after trace memory is full]**

Specify the operation after the trace memory is full with the collected trace data from the following drop-down list.

Non stop and overwrite to trace memory	Continues overwriting the older trace data after the trace memory is full (default). When the <a href="#">[Clear trace memory before running]</a> property is set to [Yes], at the time of a resumption, the trace data is collected after clearing the trace memory.
Stop trace	When the trace memory is full, CubeSuite+ stops writing trace data (the program does not stop execution). When the <a href="#">[Clear trace memory before running]</a> property is set to [No], the trace data is not collected even if the program is executed again.
Stop	When the trace memory is full, CubeSuite+ stops writing trace data and the program stops execution. When the <a href="#">[Clear trace memory before running]</a> property is set to [No], the program cannot be executed again even if it is executed.

**(d) [Accumulate trace time]**

Specify from the drop-down list whether to display the trace time with accumulated time in this property.

Specify [Yew] to display trace time with accumulated time. Specify [No] to display the trace time with differential time (default).

**(e) [Trace memory size[frames]]**

Specify from the drop-down list the trace memory size (trace frame number) in this property.

The trace frame is a unit of trace data. One trace frame is used for each operation in fetch/write/read.

Drop down list includes the following trace frame numbers.

4K (default), 8K, 12K, 16K, 20K, 24K, 28K, 32K, 36K, 40K, 44K, 48K, 52K, 56K, 60K, 64K, 128K, 192K, 256K, 320K, 384K, 448K, 512K, 576K, 640K, 704K, 768K, 832K, 896K, 960K, 1M, 2M, 3M

**(f) [Rate of frequency division of trace time tag]**

Specify from the drop-down list the frequency division ratio of the counter to be used for time tag display (the [\[Time\]](#) item in the [Trace panel](#) [[IECUBE](#)][[IECUBE2](#)][[Simulator](#)]).

The drop-down list displays the following frequency division ratio.

1/1 (default), 1/2, 1/4, 1/8, 1/16, 1/32, 1/64, 1/128, 1/256, 1/512, 1/1K, 1/4K, 1/8K, 1/16K, 1/64K, 1/256K, 1/1M

### 2.11.2 Collect execution history until stop of the execution

In the debug tool, there is a function to collect the execution history from the start of program execution to the stop.

Therefore, the trace data collection is automatically started when the program starts executing and stopped when the program stops.

See "[2.11.6 Display the collected execution history](#)" for how to check the collected trace data.

**Remark** This function is actuated by an Unconditional Trace event, one of the built-in events that are set in the debug tool by default.

Consequently, if the Unconditional Trace event is set to **Invalid state** by clearing the check box in the [Events panel](#), trace data linked to the start of program execution will not be collected (the Unconditional Trace event is set to **Valid state** by default).

Note that Unconditional Trace event and Trace event described later (see "[2.11.3 Collect execution history in the arbitrary section](#)") are used exclusively of each other. Therefore, if Trace event with **Valid state** is set, Unconditional Trace event is automatically set to **Invalid state**.

### 2.11.3 Collect execution history in the arbitrary section

The execution history is collected as trace data only for the arbitrary section while the program is in execution by setting a Trace event.

This Trace event consists of a trace start event and a trace end event.

To use this function, follow the procedure described below.

- (1) Set a Trace event
- (2) Execute the program
- (3) Delete a Trace event

**Cautions 1.** Also see "[2.15.6 Notes for setting events](#)" for details on Trace events (e.g. limits on the number of enabled events).

2. The event type (execution type/access type) that can be set as trace start and end events differ with each debug tool used.

3. **[IECUBE][IECUBE2]**

If the **[Use trace function]** property in the **[Trace]** category on the [\[Debug Tool Settings\] tab](#) of the [Property panel](#) is set to other than **[Trace]**, all of events related to trace that have currently been set become **Invalid state**.

4. **[IECUBE][IECUBE2]**

You cannot set/delete trace start events/trace end events while a tracer is running. Note, however, that it is possible to do it by forcibly pausing a tracer if the **[Set event by stopping execution momentarily]** property in the **[Set Event While Running]** category on the [\[Debug Tool Settings\] tab](#) of the [Property panel](#) is set to **[Yes]**.

5. **[Simulator]**

Trace start events and trace stop events cannot be set/deleted while a tracer is running.

#### (1) Set a Trace event

Set a trace start event and a trace end event that starts/stops collecting the trace data.

##### (a) For execution-related events

By setting execution-related events for the trace start and trace end events, it is possible to start and finish the collection of trace data at any place.

Perform this operation in the [Editor panel/Disassemble panel](#) in which the source text/disassembly text is displayed.

Follow the operation listed below from the context menu, in accordance with your desired event type, after moving the caret to the target line that has a valid address.

Event Type	Operation
Trace start	Select [Trace Settings] >> [Start Tracing]
Trace end	Select [Trace Settings] >> [Stop Tracing]

**Caution [Simulator]**

**Simulator will not display a trace end event as the results of a trace. For this reason, set a trace end event to one line below the range that you wish to display as the trace data.**


A trace start or a trace end event is set to the instruction at the start address corresponding to the line of the caret position.

Once a trace start event or a trace end event is set, the following event mark is displayed in the event area of the line that an event is set.

**Table 2-17. Event Marks of Trace Start Event and Trace End Events**

Event Type	Event Mark
Trace start	
Trace end	

**Figure 2-219. Trace Start and Trace End Events Setting Example (Disassemble Panel)**




**(b) For access-related events**

In this product version, this function is not supported.

When a trace start event and a trace end event are set, they are managed collectively on the [Events panel](#) as one instance of a Trace event (see "2.15 Manage Events"). When you click the "+" mark at a Trace event item, detailed information on the trace start and trace end events you have set is displayed.

Figure 2-220. Example of Trace Start and Trace End Events (Execution Type) in Events Panel



- Remarks**
- When either of trace start event/trace end event is set as [Valid state](#), the check box of Unconditional Trace event in the [Events panel](#) is automatically cleared, therefore, trace data collection does not automatically start with the start of the program execution (the tracer will not run until the condition of the trace start event that has been set is met).
  - A trace end event is not indispensable for a Trace event.
  - Event marks differ depending on the event state (see "[2.15.1 Change the state of set events \(valid/invalid\)](#)").  
When an event is set at the point which other event is already set, the event mark ( ) is displayed meaning more than one event is set at the point.
  - [Simulator]**  
When either of trace start event/trace end event is set to [Valid state](#), the [Use trace function] property in the [Trace] category on the [\[Debug Tool Settings\] tab](#) of the [Property panel](#) is automatically set to [Yes] and the trace function will be enabled.

## (2) Execute the program

Execute the program (see "[2.7 Execute Programs](#)").

Collection of trace data is started or finished when the condition set for a trace start event or a trace end event is met.

See "[2.11.6 Display the collected execution history](#)" for how to check the collected trace data.

## (3) Delete a Trace event

To delete a Trace event you have set, on the [Editor panel/Disassemble panel](#), right-click the event mark in the event area and select [Delete Event] from the context menu that is displayed.

Also, there is another way to delete a set event. Select the Trace event you want to delete on the [Events panel](#), and then click the button in the toolbar (see "[2.15.4 Delete events](#)").

**Caution** If either a trace start or trace end event is deleted from the event marks on the event area, all of the corresponding event marks are deleted.

### 2.11.4 Collect execution history only when the condition is met

The program execution history can be collected only when a condition is met.

By setting a Point Trace event, the execution history is collected as trace data only when an arbitrary variable or I/O register is accessed with the specified type.

To use this function, follow the procedure described below.

- (1) Set a Point Trace event
- (2) Execute the program
- (3) Delete a Point Trace event

#### **(1) Set a Point Trace event**

Set a Point Trace event by one of the following operation.

**Cautions 1.** Also see "[2.15.6 Notes for setting events](#)" for details on Point Trace events (e.g. limits on the number of enabled events).

2. You cannot set/delete Point Trace events while a tracer is running. Note, however, that it is possible to do it by forcibly pausing a tracer if the [Set event by stopping execution momentarily] property in the [Set Event While Running] category on the [\[Debug Tool Settings\]](#) tab of the [Property panel](#) is set to [Yes].

**Remarks 1.** [\[IECUBE2\]](#)

Accesses via DMA can be traced.

2. [\[Simulator\]](#)

When a Point Trace event is set to [Valid state](#), the [Use trace function] property in the [Trace] category on the [\[Debug Tool Settings\]](#) tab of the [Property panel](#) is automatically set to [Yes] and the trace function will be enabled.

**(a) When the access is to the variable/I/O register on the Editor panel/Disassemble panel**

Perform this operation in the [Editor panel/Disassemble panel](#) in which the source text/disassembly text is displayed.

Follow the operation listed below from the context menu, in accordance with your desired access type, after selecting the variable or I/O register as the subject to access.

Note, however, that only global variables, static variables inside functions, and file-internal static variables can be used.

Access Type	Operation
Read	Select [Trace Settings] >> [Record Reading Value].
Write	Select [Trace Settings] >> [Record Writing Value].
Read/Write	Select [Trace Settings] >> [Record R/W Value].

**Caution Variables within the current scope can be specified.**

**(b) When the access is to the registered watch-expression**

Perform this operation in the [Watch panel](#).

Select the watch-expression as the subject to access and perform the following operation from the context menu (see "[2.9.6 Display/change watch-expressions](#)").

Note, however, that only global variables, static variables inside functions, file-internal static variables, and I/O register can be used.


Access Type	Operation
Read	Select [Trace Output] >> [Record Reading Value].
Write	Select [Trace Output] >> [Record Writing Value].
Read/Write	Select [Trace Output] >> [Record R/W Value].

**Caution A watch-expression within the current scope can be specified.**

**To target a watch-expression outside the current scope, select a watch-expression with a specified scope.**

By performing the above operation, it is interpreted as if a Point Trace event has been set at the target variable/I/O register/watch-expression, and it is managed in the [Events panel](#) (see "[2.15 Manage Events](#)" for details).

**Figure 2-221. Example of Setting Point Trace Event in Events Panel**



## (2) Execute the program

Execute the program (see "[2.7 Execute Programs](#)").

If the conditions for a Point Trace event that you have set are met while the program is executing, that information is collected as trace data.

See "[2.11.6 Display the collected execution history](#)" for details on checking trace data.

**Figure 2-222. Example of Point Trace Event Results View (When Using Simulator)**

Number	Time (h:min:s.ms,μs,ns)	Line/Address	Source/Disassemble	Address	Data
4083			<<<_global_a=30599>>>		
4083			<<<_global_a=30600>>>		
4084			<<<_global_a=30600>>>	0x03ff710c	R 30600
4084			<<<_global_a=30600>>>	0x03ff710c	R 30600
4085			<<<_global_a=30600>>>	0x03ff710c	R 30600
4085			<<<_global_a=30600>>>	0x03ff710c	R 30600
4086			<<<_global_a=30601>>>	0x03ff710c	R 30601
4086			<<<_global_a=30601>>>	0x03ff710c	R 30601
4087			<<<_global_a=30601>>>	0x03ff710c	R 30601

### (3) Delete a Point Trace event

To delete a Point Trace event you have set, select the Point Trace event you want to delete on the [Events panel](#), and then click the  button in the toolbar (see "[2.15.4 Delete events](#)").

#### 2.11.5 Stop/restart collection of execution history

It is possible to temporarily stop or restart the collection of execution history during program execution.

**Caution**  [IECUBE][IECUBE2]

This function is enabled only when the [Use for trace data] property in the [Trace] category on the [\[Debug Tool Settings\] tab](#) of the [Property panel](#) is set to [Trace].

##### (1) Stop collection of execution history temporarily

By clicking the  button on the toolbar in the [Trace panel \[IECUBE\]\[IECUBE2\]\[Simulator\]](#) during program execution, it is possible to temporarily stop collection of trace data without stopping program execution.

Use this function when you want to stop only the trace function without halting the program and check the trace data that has been collected until you stop it.

##### (2) Restart collection of execution history

If you have halted the trace function during program execution, you can start collection of trace data again by clicking the  button on the toolbar in the [Trace panel \[IECUBE\]\[IECUBE2\]\[Simulator\]](#).

Note that the trace data that has been collected before you restart is cleared once.

#### 2.11.6 Display the collected execution history


The collected trace data is displayed in the [Trace panel \[IECUBE\]\[IECUBE2\]\[Simulator\]](#) below.

Select the [View] menu >> [Trace].

The trace data displays by mixing the disassembled text and source text by default, but it is also possible to display either one of these by selecting the [Display mode](#).

For details on the contents and function in each area, see the section for the [Trace panel \[IECUBE\]\[IECUBE2\]\[Simulator\]](#).

Figure 2-223. Display Trace Data (Trace Panel)



This section describes the following.

- (1) Change display mode
- (2) Change display format of values
- (3) Link with other panels

#### (1) Change display mode


Display mode can be changed to the purpose when clicking the buttons below in the toolbar.

Note that these buttons are disabled while the tracer is running.

**Table 2-18. Display Modes of Trace Panel**

Button	Display Mode	Displayed Content
	Mixed display mode	Displays the instruction (disassemble results), labels, source text (corresponding source line), point trace results, and break causes (default).
	Disassemble display mode	Displays the instruction (disassemble results), labels, point trace results, and break causes.
	Source display mode	Displays the source text (corresponding source line), and break causes. However, when a place where no debugging information is present is executed, "<No Debug Information>" is displayed.

**Figure 2-224. Example of Source Display Mode View (Trace Panel)**



#### (2) Change display format of values

The display format of the [Line Number/Address], [Address] and [Data] area can be changed using buttons below on the toolbar.

Note that these buttons are disabled while the tracer is running.

Notation	The following buttons to change the notation of a data value are displayed.
	Displays values on this panel in hexadecimal number (default).
	Displays values on this panel in decimal number.
	Displays values on this panel in octal number.
	Displays values on this panel in binary number.

### (3) Link with other panels

Items in the trace panel can be linked to other panels using the currently selected line address as a pointer (window focus will not move).

Click the  button on the toolbar to start linking to the [Editor panel](#). Click the  button on the toolbar to start linking to the [Disassemble panel](#).

If the button is clicked again, the link is disconnected.

**Remark** The [Editor panel/Disassemble panel](#) opens when selecting the [Jump to Source]/[Jump to Disassemble] from the context menu with moving the caret to the source line/address corresponding to the address of the currently selected line (focus is moved).

#### 2.11.7 Clear the trace memory

To clear the collected trace data contents, click the  button on the toolbar.

Note that this button is disabled while a tracer is running.

**Remark** When [Yes] is specified in the [Clear trace memory before running] property in the [Trace] category on the [\[Debug Tool Settings\]](#) tab of the [Property panel](#), the trace memory is cleared each time a program is executed.

#### 2.11.8 Search the trace data

To search the collected trace data, click the  button to open the [Trace Search dialog box](#) [[\[IECUBE\]\[IECUBE2\]\[Simulator\]](#)] (note that the search is disabled during execution of a program).


In this dialog box, follow the steps below.

When the tab on the tab selection area is selected, the trace data can be searched in instruction level/source level.

Note however, that if you search the trace data at the instruction level, the display mode must be set in the [Trace panel](#) [[\[IECUBE\]\[IECUBE2\]\[Simulator\]](#)] to the [Mixed display mode](#) or [Disassemble display mode](#).

When searching at the source level, the mode must be set to the [Mixed display mode](#) or [Source display mode](#).

Figure 2-225. Search Trace Data (Trace Search Dialog Box)



This section describes the following.


- (1) Search in the instruction level
- (2) Search in the source level

#### (1) Search in the instruction level

Search the trace data in the instruction level.

Select the [Instruction Level] tab and then follow the steps below.

**Figure 2-226. Search Trace Data in Instruction Level**



##### (a) Specify [Fetch Address]

Specify the fetch address if it is a required search parameter.

You can either type address expressions directly into the text boxes, or select it from the input history via the drop-down list (up to 10 items).

The fetch address can also be specified as a range. In this case, specify a range by specifying address expressions in both the left and right text boxes.

If the right-hand text box is blank or contains the text [(Input when range is specified)], then the fixed address specified in the left-hand text box will be searched.

Note that if an address value greater than the microcontroller address space is specified, the upper address value is masked.

An address value greater than the value expressed within 32 bits cannot be specified.

##### (b) Specify [Mnemonic]

Specify the mnemonic if it is a required search parameter.

The specified character strings in this area is searched within the [Source/Disassemble] area of the Trace panel [IECUBE][IECUBE2][Simulator].

You can either type a mnemonic directly into the text boxes, or select one from the input history via the drop-down list (up to 10 items).

Searches are case-insensitive, and partial matches are also allowed.

**(c) Specify [Access Address]**

Specify the access address if it is a required search parameter.

You can either type the address value directly into the text boxes (in hexadecimal number), or select it from the input history via the drop-down list (up to 10 items).

The access address can also be specified as a range. In this case, specify a range by specifying address expressions in both the left and right text boxes.

If the right-hand text box is blank or contains the text [(Input when range is specified)], then the fixed address specified in the left-hand text box will be searched.

Note that if an address value greater than the microcontroller address space is specified, the upper address value is masked.

An address value greater than the value expressed within 32 bits cannot be specified.

**(d) Specify [Access Status]**

This item is only enable if a value for [Specify \[Access Address\]](#) is specified.

Select the access type (Read/Write, Read, Write, Vector Read and DMA) from drop-down list.

Select [(No Specification)] if you do not wish to limit access types.

**(e) Specify [Data]**

This item is only enable if a value for [Specify \[Access Address\]](#) is specified.

Specify the access data.

You can either type the data directly into the text boxes (in hexadecimal number), or select it from the input history via the drop-down list (up to 10 items).

The data can also be specified as a range. In this case, specify a range by specifying data in both the left and right text boxes.

If the right-hand text box is blank or contains the text [(Input when range is specified)], then the fixed data specified in the left-hand text box will be searched.

**(f) Specify [Number]**

Specify the range within the trace data to search via the number displayed in the [Number] area of the [Trace panel \[IECUBE\]\[IECUBE2\]\[Simulator\]](#).

Specify the starting number in the left text box, and the ending number in the right text box ("0" to "*last number*" are specified by default).

You can either type the numbers directly into the text boxes (in base-10 format), or select them from the input history via the drop-down list (up to 10 items).

If the left-hand text box is left blank, it is treated as if "0" were specified.

If the right-hand text box is left blank, it is treated as if the last number were specified.

**(g) Click the [Search Backward]/[Search Forward] button**

When the [Search Backward] button is clicked, search is taken place in the order from the large number to small and the search results are shown selected in the [Trace panel \[IECUBE\]\[IECUBE2\]\[Simulator\]](#).


When the [Search Backward] button is clicked, search is taken place in the order from the small number to large and the search results are shown selected in the [Trace panel \[IECUBE\]\[IECUBE2\]\[Simulator\]](#).

**(2) Search in the source level**

Search the trace data in the source level.

Select the [Source Level] tab.

Figure 2-227. Search Trace Data in Source Level



#### (a) Search with specifying the source line (default)

Select the [The execution part is retrieved specifying the source line] item in the [Search object] area and then follow the operation below.

##### <1> Specify [Source and Line]

The specified character strings in this area is searched within the [Line/Address] area of the [Trace panel](#) [[IECUBE](#)][[IECUBE2](#)][[Simulator](#)].

You can either type the character strings of the source line to be find directly into the text box, or select them from the input history via the drop-down list (up to 10 items).

Searches are case-insensitive, and partial matches are also allowed.

##### Examples 1. main.c#40

2. main.c
3. main

##### <2> Specify [Number]

Specify the range within the trace data to search via the number displayed in the [Number] area of the [Trace panel](#) [[IECUBE](#)][[IECUBE2](#)][[Simulator](#)].

Specify the starting number in the left text box, and the ending number in the right text box ("0" to "last number" are specified by default).

You can either type the numbers directly into the text boxes (in base-10 format), or select them from the input history via the drop-down list (up to 10 items).

If the left-hand text box is left blank, it is treated as if "0" were specified.

If the right-hand text box is left blank, it is treated as if the last number were specified.

**<3> Click the [Search Backward]/[Search Forward] button**

When the [Search Backward] button is clicked, search is taken place in the order from the large number to small and the search results are shown selected in the [Trace panel \[IECUBE\]\[IECUBE2\]\[Simulator\]](#).

When the [Search Backward] button is clicked, search is taken place in the order from the small number to large and the search results are shown selected in the [Trace panel \[IECUBE\]\[IECUBE2\]\[Simulator\]](#).

**(b) Search with specifying the function name**

Select the [The execution part is retrieved specifying the function] item in the [Search object] area and then follow the operation below.

**<1> Specify [Function Name]**

You can either type the function name to be find directly into the text box, or select it from the input history via the drop-down list (up to 10 items).

Searches are case-insensitive, and only complete matches are retrieved.

**<2> Specify [Number]**

Specify the range within the trace data to search via the number displayed in the [Number] area of the [Trace panel \[IECUBE\]\[IECUBE2\]\[Simulator\]](#).

Specify the starting number in the left text box, and the ending number in the right text box ("0" to "last number" are specified by default).

You can either type the numbers directly into the text boxes (in base-10 format), or select them from the input history via the drop-down list (up to 10 items).

If the left-hand text box is left blank, it is treated as if "0" were specified.

If the right-hand text box is left blank, it is treated as if the last number were specified.

**<3> Click the [Search Backward]/[Search Forward] button**

When the [Search Backward] button is clicked, search is taken place in the order from the large number to small and the search results are shown selected in the [Trace panel \[IECUBE\]\[IECUBE2\]\[Simulator\]](#).

When the [Search Backward] button is clicked, search is taken place in the order from the small number to large and the search results are shown selected in the [Trace panel \[IECUBE\]\[IECUBE2\]\[Simulator\]](#).

**(c) Search with specifying the global variable**

Select the [The execution part is retrieved specifying the global variable] item in the [Search object] area and then follow the operation below.

**<1> Specify [Variable Name]**

You can either type the variable name to be find directly into the text box, or select it from the input history via the drop-down list (up to 10 items).

Searches are case-insensitive, and only complete matches are retrieved.

**<2> Specify [Kind]**

Select the access type ([Reference/Substitution], [Reference], or [Substitution]) from the drop-down list.

**<3> Specify [Value]**

You can either type the accessed variable value directly into the text box, or select one from the input history via the drop-down list (up to 10 items).

The variable value can also be specified as a range. In this case, specify a range by specifying variable values in both the left and right text boxes.

If the right-hand text box is blank, then access locations with the fixed variable values specified in the left-hand text box will be searched for.

**<4> Specify [Number]**

Specify the range within the trace data to search via the number displayed in the [Number] area of the Trace panel [[IECUBE](#)][[IECUBE2](#)][[Simulator](#)].

Specify the starting number in the left text box, and the ending number in the right text box ("0" to "last number" are specified by default).

You can either type the numbers directly into the text boxes (in base-10 format), or select them from the input history via the drop-down list (up to 10 items).

If the left-hand text box is left blank, it is treated as if "0" were specified.

If the right-hand text box is left blank, it is treated as if the last number were specified.

**<5> Click the [Search Backward]/[Search Forward] button**

When the [Search Backward] button is clicked, search is taken place in the order from the large number to small and the search results are shown selected in the Trace panel [[IECUBE](#)][[IECUBE2](#)][[Simulator](#)].

When the [Search Backward] button is clicked, search is taken place in the order from the small number to large and the search results are shown selected in the Trace panel [[IECUBE](#)][[IECUBE2](#)][[Simulator](#)].

**2.11.9 Save the contents of execution history**


Contents of the collected trace data can be saved with range selection in text files (\*.txt)/CSV files (\*.csv).

When saving to the file, the latest information is acquired from the debug tool, and it is saved in accordance with the display format on this panel.

The following [Data Save dialog box](#) can be opened by selecting the [File] menu >> [Save Trace Data As...].

In this dialog box, follow the steps below.

**Figure 2-228. Save Execution History (Data Save Dialog Box)**

**(1) Specify [File Name]**

Specify the name of the file to save.

You can either type a filename directly into the text box (up to 259 characters), or select one from the input history via the drop-down list (up to 10 items).

You can also specify the file by clicking the [...] button, and selecting a file via the [Select Data Save File dialog box](#).

**(2) Specify [File Type]**

Select the format in which to save the file from the following drop-down list.

The following file formats can be selected.

List Item	Format
Text files (*.txt)	Text format (default)
CSV (Comma-Separated Variables)(*.csv)	CSV format <sup>Note</sup>

**Note** The data is saved with entries separated by commas (,).

If the data contains commas, each entry is surrounded by double quotes "" in order to avoid illegal formatting.

### (3) Specify [Save Range Number]

Specify the range of the number to save via "start number" and "end number".

Directly enter decimal number in each text box or select from the input history displayed in the drop-down list (up to 10 items).

When saving all the trace data, select the [All Trace Data] item in the drop-down list at the left (the right text box becomes invalid).

If a range is selected in the panel, that range is specified as the default. If there is no selection, then the range currently visible in the panel is specified.

### (4) Click the [Save] button

Trace data is saved in the specified file with the specified format.

**Figure 2-229. Output Example of Trace Data**

Number	Time	Line	Number/Address	Source/Disassemble	Address	Data
Number	Time	Line	Number/Address	Source/Disassemble	Address	Data
:	:	:	:	:	:	:

## 2.12 Measure Execution Time of Programs

This section describes how to measure the execution time of the program.

### 2.12.1 Measure execution time until stop of the execution

In the debug tool, there is a function to measure the program execution time (Run-Break time) from the start to the stop.

Therefore, when the program starts its execution, the execution time is automatically measured.

You can check the result of the measurement by either one of the following.

#### Cautions 1. [MINICUBE2]

The Run-Break time for a step execution cannot be measured.

#### 2. [Simulator]


To measure the Run-Break time, [Yes] must be specified with the [Use timer function] property in the [Timer] category on category on the [\[Debug Tool Settings\]](#) tab of the [Property panel](#).

**Remark** This function is operated by a Run-Break Timer event, which is one of the built-in events set by default in the debug tool. The Run-Break timer event is always [Valid state](#) (settings not changeable).

#### (1) Check in the status bar

After the program is stopped, the result of the measurement is displayed in the status bar on the [Main window](#) (when measurements have not been performed yet, "Not measured" is displayed).


Figure 2-230. Example of Result of Run-Break Timer Event (Status Bar)



#### (2) Check on the Events panel

After the program is stopped, the result of the measurement is displayed in the [Events panel](#) opened by selecting the [\[View\]](#) menu >> [\[Event\]](#), in event type as "Run-Break Timer".

Figure 2-231. Example of Result of Run-Break Timer Event (Events Panel)



### 2.12.2 Measure execution time in the arbitrary section

In the program execution process, the execution time in the arbitrary section can be measured by setting Timer Result event. This Timer Result event consists of a timer start event and a timer end event.

To use this function, follow the procedure described below.

- (1) Set a Timer Result event
- (2) Execute the program
- (3) Delete a Timer Result event

**Cautions 1. [V850E1][V850ES]: [MINICUBE2][E1][E20][EZ Emulator]**

**Timer Result event is not supported.**

2. Also see "[2.15.6 Notes for setting events](#)" for details on Timer Result events (e.g. limits on the number of enabled events).
3. **[IECUBE2]**  
Some of the trace function, the timer function (except for the Run-Break timer) and the coverage function are used on a mutually exclusive basis. Therefore, to use the timer function, [Timer] must be specified with the [Use for trace data] property in the [Trace] category on the [\[Debug Tool Settings\] tab](#) of the [Property panel](#).
4. **[Simulator]**  
To use this function, [Yes] must be specified with the [Use timer function] property in the [Timer] category on the [\[Debug Tool Settings\] tab](#) of the [Property panel](#).

**(1) Set a Timer Result event**

Set a timer start event and a timer end event that starts/stops a timer measurement.

**(a) For execution-related events**

Perform this operation in the [Editor panel/Disassemble panel](#) in which the source text/disassembly text is displayed.

Follow the operation listed below from the context menu, in accordance with your desired event type, after moving the caret to the target line that has a valid address.

Event Type	Operation
Timer start	Select [Timer Settings] >> [Start Timer]
Timer end	Select [Timer Settings] >> [Stop Timer]

**Caution [Simulator]**

**Simulator will not include the time for a timer end event in the measurement results. For this reason, set a timer end event to one line below the range for which you wish to measure the run time.**


A timer start event or a timer end event is set to the instruction at the start address corresponding to the line of the caret position.

Once a timer start event or a timer end event is set, the following event mark is displayed in the event area of the line that an event is set.

Table 2-19. Event Marks of Timer Start Event/Timer End Event

Event Type	Event mark
Timer start	
Timer end	

Figure 2-232. Timer Start and Timer End Events Setting Example (Disassemble Panel)




#### (b) For access-related events

In this product version, this function is not supported.

When a timer start event and a timer end event are set, they are managed collectively on the [Events panel](#) as one instance of a Timer Result event (see ["2.15 Manage Events"](#)). When you click the "+" mark at a Timer Result event item, detailed information on the timer start and timer end events you have set is displayed.

Figure 2-233. Example of Timer Start and Timer End Events (Execution Type) in Events Panel



**Remark** Event marks differ depending on the event state (see ["2.15.1 Change the state of set events \(valid/invalid\)"](#)).

When an event is set at the point which other event is already set, the event mark ( ) is displayed meaning more than one event is set at the point.

### (2) Execute the program


Execute the program (see "[2.7 Execute Programs](#)").

When an instruction for which a timer start event or a timer end event has been set is executed, a timer measurement is started or finished.

After the program is stopped, the result of the measurement is displayed in the [Events panel](#) opened by selecting the [View] menu >> [Event], in event type as "Timer Result".

This Timer Result is a particular type of event that is displayed on only the [Events panel](#) when either a timer start event or a timer end event has been set.

**Figure 2-234. Example of Result of Timer Result Event (Timer Start Event/Timer End Event)**



### (3) Delete a Timer Result event

To delete a Timer Result event you have set, on the [Editor panel/Disassemble panel](#), right-click the event mark in the event area and select [Delete Event] from the context menu that is displayed.

Also, there is another way to delete a set event. Select the Timer Result event you want to delete on the [Events panel](#), and then click the button in the toolbar (see "[2.15.4 Delete events](#)").

**Caution** If either a timer start or timer end event is deleted from the event marks on the event area, all of the corresponding event marks are deleted.

#### 2.12.3 Measurable time ranges

The scope of time that can be measured via timers using Run-Break Timer events (see "[2.12.1 Measure execution time until stop of the execution](#)" for details) or Timer Result events (see "[2.12.2 Measure execution time in the arbitrary section](#)" for details) is shown below.

If the maximum measurable length of time is exceeded, a timer-over break is generated, and program execution stops.

**Table 2-20. Measurable Time Ranges [V850E1][V850ES]**

Debug Tool	Run-Break Timer Event			Timer Result Event	
IECUBE	Min.	20 ns		Min.	20 ns
	Max.	Approx. 195 hours 12 min (time for 4K cycles) Overflow detection included		Max.	Approx. 195 hours 12 min (time for 4K cycles) Maximum pass count: 65535 times Overflow detection included

Debug Tool	Run-Break Timer Event		Timer Result Event
MINICUBE E1/E20(JTAG)	Min.	200 ns	-
	Max.	Approx. 7 min. (time for TCK/DCK = 10 MHz) Overflow detection included	
MINICUBE2 E1/E20(Serial) EZ Emulator	Min.	100 µs	-
	Max.	Approx. 119 hours 18 min Overflow detection included	
Simulator	Depends on the clock frequency for timer/trace		Depends on the clock frequency for timer/trace

**Table 2-21. Measurable Time Ranges [V850E2]**

Debug Tool	Run-Break Timer Event		Timer Result Event	
IECUBE2	Min.	200 ns	Min.	5 ns
	Max.	Approx. 7 min. (time for TCK/DCK = 10 MHz) Overflow detection included	Max.	Approx. 24 hours (time for 4K cycles) Pass count counter: 16-bit Overflow detection included
MINICUBE E1/E20(JTAG)	Min.	200 ns	Depends on the clock frequency for timer/trace Pass count counter: 32-bit Overflow detection included	
	Max.	Approx. 7 min. (time for TCK/DCK = 10 MHz) Overflow detection included		
E1/E20(LPD)	Min.	100 ns (CPU clock = 80 MHz) 125 ns (CPU clock = 64 MHz) 166 ns (CPU clock = 48 MHz)	Depends on the clock frequency for timer/trace Pass count counter: 32-bit Overflow detection included	
	Max.	Approx. 3.5 min. (CPU clock = 80 MHz) Approx. 4.5 min (CPU clock = 64 MHz) Approx. 6 min (CPU clock = 48 MHz) Overflow detection included		
MINICUBE2 E1/E20(Serial)	Min.	100 µs	Depends on the clock frequency for timer/trace Pass count counter: 32-bit Overflow detection included	
	Max.	Approx. 119 hours 18 min Overflow detection included		
Simulator	Depends on the clock frequency for timer/trace		Depends on the clock frequency for timer/trace	

## 2.13 Measure Coverage [IECUBE][IECUBE2][Simulator]

This section describes coverage measurements that are conducted using the coverage function.

There are several kinds of coverage measurement methods. Of these, CubeSuite+ performs, in areas designated below, a code coverage measurement of fetch-related operations on source lines and functions (C0 coverage) and a data coverage measurement of access-related operations on variables [Simulator].

The area in which CubeSuite+ performs coverage measurements are as follows:

**Table 2-22. Subject Areas of Coverage Measurement**

Debug Tool		Code Coverage Measurement Area
V850E1 V850ES	IECUBE Simulator	Both area below - 1 MByte space of addresses 0x000000 to 0xFFFFFFF(fixed measurement areas) - Any 1 MByte space other than the internal ROM area (see " <a href="#">2.13.1 Configure the coverage measurement</a> ")
V850E2 (Single-core only)	IECUBE2	4 MBytes space of the internal ROM
	Simulator	Both area below - 1 MByte space of addresses 0x000000 to 0xFFFFFFF(fixed measurement areas) - Any 1 MByte space other than the internal ROM area (see " <a href="#">2.13.1 Configure the coverage measurement</a> ")

### Cautions 1. [IECUBE]

The coverage function can be used only when the coverage board is mounted on IECUBE.

Some of the trace function, the real-time display update function (RRM function) and the coverage function are used on a mutually exclusive basis.

### 2. [IECUBE2]

Some of the trace function, the timer function (except for the Run-Break timer) and the coverage function are used on a mutually exclusive basis.

### 3. [MINICUBE][MINICUBE2][E1][E20][EZ Emulator]

The coverage function is not supported.

**Remark** C0 coverage: Instruction coverage (statement coverage)

For example, if all instructions (statements) in code are executed at least once, then C0 = 100%.

### 2.13.1 Configure the coverage measurement

You need to configure the code coverage measurement before using the coverage function.

The setting method differs depending on the debug tool used.

- (1) [IECUBE]
- (2) [IECUBE2]
- (3) [Simulator]

#### (1) [IECUBE]

**Caution** The coverage function can be used only when the coverage board is mounted on IECUBE. Therefore, when no coverage boards are mounted on IECUBE used, the following configurations become invalid after connecting to the debug tool.

Some of the trace function, the real-time display update function (RRM function) and the coverage function are used on a mutually exclusive basis.

Therefore, first, specify [Coverage] with the [Use for trace data] property in the [Trace] category on the [Debug Tool Settings] tab of the [Property panel](#) to use the coverage function with priority.

Note that settings described below are invalid when this property is set to other than [Coverage].

**Figure 2-235. [Trace] Category (Setting for Coverage Function)**

<b>Trace</b>	
Use for trace data	<b>Coverage</b>
Clear trace memory before running	Yes
Operation after trace memory is full	Non stop and overwrite to trace memory

Then, configure the code coverage measurement function in the [Coverage] category on the [Debug Tool Settings] tab of the [Property panel](#) as follows:

**Figure 2-236. [Coverage] Category [IECUBE]**

<b>Coverage</b>	
Reuse coverage result	No
Coverage area of measurement(1MBytes)	[HEX] 3F00000

#### (a) [Reuse coverage result]

The currently obtained results of code coverage measurements are automatically saved when CubeSuite+ is disconnected from the debug tool. The next time it is connected to the debug tool, specify from the drop-down list whether or not you want to reproduce the contents of saved measurement results.

Select [Yes] to reproduce the contents of previously obtained code coverage measurement results ([No] is selected by default).

The file that saves results of code coverage measurements (raw.csr.cv) will be created in the folder where the load module file currently being downloaded exists.

#### (b) [Coverage area of measurement(1MBytes)]

Specify the code coverage measurement area (see "[Table 2-22. Subject Areas of Coverage Measurement](#)").

Directly enter the start address of any 1 MByte space of addresses 0x100000 to 0x3FFFFFF in hexadecimal number (*[the start address of the internal RAM area]* is specified by default).

### (2) [IECUBE2]

Some of the trace function, the timer function (except for the Run-Break timer) and the coverage function are used on a mutually exclusive basis.

Therefore, first, specify [Coverage] with the [Use for trace data] property in the [Trace] category on the [Debug Tool Settings] tab of the [Property panel](#) to use the coverage function with priority.

Note that settings described below are invalid when this property is set to other than [Coverage].

**Figure 2-237. [Trace] Category (Setting for Coverage Function)**

<b>Trace</b>	
Use for trace data	<b>Coverage</b>
Clear trace memory before running	Yes
Operation after trace memory is full	Non stop and overwrite to trace memory

Then, configure the code coverage measurement function in the [Coverage] category on the [Debug Tool Settings] tab of the [Property panel](#) as follows:

**Figure 2-238. [Coverage] Category [IECUBE2]**

<input type="checkbox"/> Coverage	
Reuse coverage result	No

**(a) [Reuse coverage result]**

The currently obtained results of code coverage measurements are automatically saved when CubeSuite+ is disconnected from the debug tool. The next time it is connected to the debug tool, specify from the drop-down list whether or not you want to reproduce the contents of saved measurement results.

Select [Yes] to reproduce the contents of previously obtained code coverage measurement results ([No] is selected by default).

**(3) [Simulator]**

You can configure the coverage measurement function in the [Coverage] category on the [Debug Tool Settings] tab of the [Property panel](#) as follows:

**Figure 2-239. [Coverage] Category [Simulator]**

<input type="checkbox"/> Coverage	
Use coverage function	Yes
Reuse coverage result	No
Coverage area of measurement(1MBytes)	<input checked="" type="checkbox"/> 3F00000

**(a) [Use coverage function]**

Specify whether to use the coverage function from the drop-down list.

Select [Yes] to use the coverage function ([No] is selected by default).

**(b) [Reuse coverage result]**

This property appears only when the [Use coverage function] property is set to [Yes].

The currently obtained results of code coverage measurements are automatically saved when CubeSuite+ is disconnected from the debug tool. The next time it is connected to the debug tool, specify from the drop-down list whether or not you want to reproduce the contents of saved measurement results.

Select [Yes] to reproduce the contents of previously obtained code coverage measurement results ([No] is selected by default).

**(c) [Coverage area of measurement(1MBytes)]**

This property appears only when the [Use coverage function] property is set to [Yes].

Specify the code coverage measurement area (see "Table 2-22. Subject Areas of Coverage Measurement").

Directly enter the start address of any 1 Mbyte space other than the internal ROM area in hexadecimal number ([the start address of the internal RAM area] is specified by default).

### 2.13.2 Display the coverage measurement result

When the program starts running, a coverage measurement is automatically begun, and when the program stops running, the coverage measurement is terminated at the same time.

#### (1) Code coverage ratio

##### (a) Display of code coverage ratios for source text lines and disassembled text lines

This display is on the [Editor panel/Disassemble panel](#) that displays the target program.

On each panel, the source text lines and disassembled lines for which coverage was measured have their backgrounds displayed, as in "Table 2-24.", in classified colors based on the code coverage ratios calculated following the calculation methods in "Table 2-23."

However, when disconnected from the debug tool, or while the program is under execution, the results are not displayed.

Note that the obtained code coverage measurement results can be reset in whole by selecting [Clear Coverage Information] from the context menu in the [Editor panel/Disassemble panel](#) (the color-coded display on each panel are also cleared).

**Table 2-23. Method for Calculating Code Coverage Ratio for Source Lines and Disassemble Lines**

Panel	Calculation Method
<a href="#">Editor panel</a>	"Number of bytes of code executed in the address range corresponding to the source text line" / "Total number of bytes of code in the address range corresponding to the source text line"
<a href="#">Disassemble panel</a>	"Number of bytes of code executed in the address range corresponding to the disassembled text line" / "Total number of bytes of code in the address range corresponding to the disassembled text line"

**Table 2-24. View of Code Coverage Measurement Result (Default)**

Code Coverage	Background Color
100 %	Source text/disassembled text
1 to 99 %	Source text/disassembled text
0 % (not yet executed)	Source text/disassembled text

- Remarks 1.**
1. Code coverage measurement results are automatically updated at a break in each panel.
  2. The above background colors depend on the configuration in the [\[General - Font and Color\] category](#) of the [Option dialog box](#).
  3. The above background colors do not apply to the lines that are outside of the subject area (see "Table 2-22. Subject Areas of Coverage Measurement").
  4. If the downloaded lode module file is older than the source file currently being open, the displaying of the code coverage measurement result is not performed in the [Editor panel](#).

Figure 2-240. View of Code Coverage Measurement Result (Editor Panel)

```

75
76 00000a4c void main(void)
77
78
79 00000a4e     /* Start user code. Do not edit comment gen */
80 00000a52     TMP0_Start();
81 00000a56     TMP1_Start();
82
83     AD_Start();
84
85 00000a5a     while (1)
86 00000a5e     {
87 00000a62         func1();
88 00000a64     func2();
89
90 00000a66     /* End user code. Do not edit comment gen */
91 00000a68     void func1()
92 00000a6c     {
93
94 00000a6c     UINT i;

```

Figure 2-241. View of Code Coverage Measurement Result (Disassemble Panel)

00000a4c	_main:	d50d	br _main+0x1a
00000a4e		bfff32fd	jalr _TMP0_Start, ip
00000a52		bfff02fe	jalr _TMP1_Start, ip
00000a56		bfff46f8	jalr _AD_Start, ip
00000a5a		80ff12	Code on this line has been executed by 100% ip
00000a5e		80ff3a	ip
00000a62		c5fd	br _main+0xe
00000a64		1e02	callt 0xe
00000a66		0002	
00000a68		b5f5	Code on this line has been executed by 0% x2
00000a6a		0000	(not yet executed)
00000a6c	_func1:	a50d	br _func1+0x14
00000a6e		00e8	mov r0, r29
00000a70		80ff1400	jalr func1a, ip

**(b) Display of code coverage ratios for each function**

Code coverage ratios for each function can be checked via the [Code Coverage[%]] item in the Function List panel of the analyze tool. For details on "the code coverage ratio of the function", see "CubeSuite+ Integrated Development Environment User's Manual: Analysis".

**(2) Data coverage ratio [Simulator]**

Data coverage ratios for each variable can be checked via the [Data Coverage[%]] item in the Variable List panel of the analyze tool. For details on "the data coverage ratio of the variable", see "CubeSuite+ Integrated Development Environment User's Manual: Analysis".

## 2.14 Set an Action into Programs

This section describes how to set the specified action into the program.

### 2.14.1 Insert printf

By setting a Printf event that is one of "action events", the value of the specified variable expression can be output to the [Output panel](#) by executing a printf command after temporarily stopping the program in execution at an arbitrary position.

To use this function, follow the steps below.

- Cautions 1.** [Also see "2.15.6 Notes for setting events" for details on action events \(e.g. limits on the number of enabled events\).](#)
2. [No action events occur during step execution \(](#) [/](#) [/](#) [\) or execution ignoring break-related events \(](#) [\).](#)
  3. [\[Simulator\]](#)  
When [Yes] is specified with the [Execute instruction at breakpoint when break] property in the [Break] category on the [\[Debug Tool Settings\] tab](#) in the [Property panel](#), all of action events currently being set are handled as Hardware Break events (i.e. no Printf events occur).

#### (1) Set a Printf event


Set a Printf event to the position where you want to execute the printf command in the [Editor panel/Disassemble panel](#).

Select [Register Action Event...] from the context menu after moving the caret to the line/address<sup>Note</sup> to set a Printf event in the Editor panel/Disassemble panel to open the following the [Action Events dialog box](#).

In this dialog box, follow the steps below.

**Note** Printf events can only be set at lines that have valid addresses.

**Figure 2-242. Set Printf Event (Action Events Dialog Box: [Printf event] tab)**



#### (a) Specify [Output string]

Directly enter from the keyboard the characters to add when output to the [Output panel](#).

Characters must be in one line (spaces allowed).

**(b) Specify [Variable expression]**

Specify the variable expression for the Printf event to take place.

Type a variable expression directly into the text box (up to 1024 characters).

You can specify up to 10 variable expressions for a single Printf event by separating them with commas ",".

If this dialog box opens with a variable expression selected in the [Editor panel/Disassemble panel](#), the selected variable expression appears as the default.

For the basic input format that can be specified as variable expressions and the values output by Printf event, see "[Table A-22. Relationship between Variable Expressions and Output Value \(Printf Event\)](#)".

**Remark** A symbol name at the current caret position can be complemented by pressing the [Ctrl] + [Space] key in this text box (see "[2.18.2 Symbol name completion function](#)").

**(c) Specify [Address]**

Specify the address at which to set the Printf event.

The address of the location currently being specified is displayed by default.

If you want to edit this area, you can either type an address expression directly into the text box (up to 1024 characters), or select them from the input history via the drop-down list (up to 10 items).

**Remark** A symbol name at the current caret position can be complemented by pressing the [Ctrl] + [Space] key in this text box (see "[2.18.2 Symbol name completion function](#)").

**(d) Click the [OK] button**

Set the Printf event to the line/address at the caret position in the [Editor panel/Disassemble panel](#).

When the Printf event is set, the mark is displayed in the event area on the Editor panel/Disassemble panel, and the set Printf event is managed in the [Events panel](#) (see "[2.15 Manage Events](#)").

**(2) Execute the program**


Execute the program (see "[2.7 Execute Programs](#)").

By executing the program, the program momentarily stops immediately before executing the instruction at the location where this event is set, and the value of the variable expression specified in this dialog box is output to the [Output panel](#).

**(3) Check the output result**

The output result format from the Printf event in the [Debug Tool] tab of the [Output panel](#) are as follows (see "[Figure A-61. Output Result Format of Printf Event](#)").

**Figure 2-243. Example of Output Result of Printf Event**



**(4) Edit the Printf event**

You can edit the Print event that has been set once.

To do this, on the [Events panel](#), select [Edit Condition...] from the context menu after selecting the Printf event to be edited. On the [Action Events dialog box](#) opened automatically, edit the items, and then click the [OK] button.

## 2.15 Manage Events

An event represents a certain status of the target system when debugging such as "Address 0x1000 is fetched" and "Data is written to address 0x2000".

In CubeSuite+, these events are used as the action trigger of the debug function such as breakpoint, start/stop the tracing, and start/stop the timer.


This section describes how to manage those events.

Select the [View] menu >> [Event].

Events are all managed in the [Events panel](#). In the Events panel, you can confirm the details of the currently set events in a list, and they can be deleted and changed enable/disable status.

For details on the contents and function in each area, see the section for the [Events panel](#).

**Figure 2-244. Manage Events (Events Panel)**



**Remark** For details on how to set various events, see the section below:


- [Set a breakpoint](#)
- [Set a break event \(execution type\)](#)
- [Set a break event \(access type\)](#)
- [Set a Trace event](#)
- [Set a Point Trace event](#)
- [Set a Timer Result event](#)

### 2.15.1 Change the state of set events (valid/invalid)

By changing the check on the check box of the event name, the setting state of the event can be changed (the [Event mark](#) is changed depending on the setting state of the event).

The following are types of the setting state of the event.

**Figure 2-245. Event Name Check Box**



**Table 2-25. Setting State of Event**

<input checked="" type="checkbox"/>	Valid state	Event occurs when the specified condition is met. It is possible to set the event to an invalid state by removing the check.
<input type="checkbox"/>	Invalid state	Event does not occur when the specified condition is met. It is possible to set the event to a valid state by removing the check.
<input type="checkbox"/>	Suspended State	The conditions that have been specified cannot be set with the program of the debugging target. It is not possible to operate the check box.

- Remarks 1.** Both of the timer start event and the timer end event is must be set for the Timer Result event. Therefore, it is not possible to set a particular event to a valid state by only the setting of one of these (at the same time as both events are set, they are treated as grouped events as a Timer Result).
2. It is not possible to set the Run-Break Timer event to an invalid/suspended state.
  3. The setting state of the event can be changed from the menu displayed by right clicking on the [Event mark](#) in the [Editor panel/Disassemble panel](#).
  4. The setting of the Unconditional Trace event and the Trace event to valid or invalid state is exclusively controlled. Therefore, the Unconditional Trace event, which is a built-in event, is valid state by default, but if either a trace start event/trace end event is set, it automatically becomes invalid state, and the Trace event, which is a event name that is collectively called with a trace start event and a trace end event, becomes valid state. Conversely, if the set Trace event is invalid state, the Unconditional Trace event automatically becomes valid state.

### 2.15.2 Display only particular event types

Click on the toolbar button to display only the particular event type.

	Displays events related to the Hardware Break.
	Displays events related to the Software Break. (except [Simulator])
	Displays events related to the trace. [IECUBE][IECUBE2] [Simulator]
	Displays events related to the timer <sup>Note</sup> .
	Displays events related to the action event (Printf event).
	Displays the built-in events (Unconditional Trace event and Run-Break Timer event).

#### Note [V850E1][V850ES]: [MINICUBE2][E1][E20][EZ Emulator]

This button is disabled.

### 2.15.3 Jump to the event address

Clicking the following buttons jumps to each panel which selected events address exist.

Note however, that when a Trace event/Timer Result event/ Unconditional Trace event/ Run-Break Timer event is selected, these buttons are disabled.

	Opens the <a href="#">Editor panel</a> and jumps to the source line corresponding to the address where the selected event is being set.
	Opens the <a href="#">Disassemble panel</a> and jumps to the disassemble results corresponding to the address where the selected event is being set.

	Opens the <a href="#">Memory panel</a> and jumps to the source line corresponding to the address where the selected event is being set.
---	---

#### 2.15.4 Delete events

To delete any event and event condition you have set, select the event and click the  button on the toolbar.

Note that it is not possible to delete the built-in events (Unconditional Trace event and Run-Break Timer event).

- Remarks 1.** For the Break event of execution type, it is possible to delete the set event to click the event mark displayed in the [Editor panel](#)/[Disassemble panel](#).
2. To delete all of the events and event conditions you have set at a time, select [Select All] from the context menu, then click the  button (note, however, that it is not possible to delete the built-in events).

#### 2.15.5 Write comment to events

The user can write comments for each event that has been set.

To input comments, click the [Comment] area after selecting the event to input comments, then input directly the desired text from the keyboard (the edit mode is cancelled by pressing the [Esc] key).

After editing the comments, complete the editing by pressing the [Enter] key or moving the focus to outside the edit region.

Up to 256 characters can be inputted for the comments, and this is saved as the settings of the user during use.

#### 2.15.6 Notes for setting events

This section describes notes for setting each type of event.

- (1) Maximum number of enabled events
- (2) Event types that can be set and deleted during execution
- (3) Other notes

##### (1) Maximum number of enabled events

The number of events that can be set to [Valid state](#) simultaneously are subject to the following limitations.

Therefore, if this limit is exceeded when you set one or more new valid state events, some of the events that are already set need to be [Invalid state](#) before you can set a new one.

The meaning of numbers in the table below is as follows:

$x + y$	"Hardware Break (after execution): x" + "Hardware Break (access): y"
$x + y + z$	"Hardware Break (after execution): x" + "Hardware Break (access): y" + "DMA event: z"

**Table 2-26. Maximum Number of Enabled Events [V850E1][V850ES]**

Event Type	IECUBE	Debug Tool to Use				Simulator	
		MINICUBE E1/E20(JTAG)		MINICUBE2 E1/E20(Serial) EZ Emulator			
		With TEU	Without TEU	With Core-event	Without Core-event		
Hardware Break (before execution)	2 <sup>Note 1</sup>	2	2 <sup>Note 2</sup>	2 <sup>Note 2</sup>	-	64 <sup>Note 4</sup>	
Hardware Break (after execution)	8	8	0	0	-		
Hardware Break (access)	6	4	2 <sup>Note 2</sup>	2 <sup>Note 2</sup>	-		
Software Break	2000	2000 (For flash: 0 to 8 <sup>Note 3</sup> )				-	
Trace (trace start/trace end)	4 + 3 <sup>Note 5</sup>	-	-	-	-	32 <sup>Note 5</sup>	
Point Trace	8 + 6 <sup>Note 6</sup>	-	-	-	-	64 <sup>Note 6</sup>	
Timer Result (timer start/timer end)	4 + 3 <sup>Note 5</sup>	-	-	-	-	1	
Action (Printf)	100 <sup>Note 7</sup>					64 <sup>Note 8</sup>	

**Table 2-27. Maximum Number of Enabled Events [V850E2]**

Event Type	IECUBE2	Debug Tool to Use				Simulator	
		MINICUBE E1/E20(LPD)/(JTAG)		MINICUBE2 E1/E20(Serial)			
		With TEU	Without TEU	With Core-event	Without Core-event		
Hardware Break (before execution)	4	4	4 <sup>Note 2</sup>	4 <sup>Note 2</sup>	0	64 <sup>Note 4</sup>	
Hardware Break (after execution)	8	8	0	0	0		
Hardware Break (access)	6	6	4 <sup>Note 2</sup>	4 <sup>Note 2</sup>	0		
Software Break	8 (when TRAM is not incorporated) 40 - 2000 (when TRAM is incorporated)					-	
Trace (trace start/trace end)	4 + 3 + 3 <sup>Note 5, 9</sup>	-	-	-	-	32 <sup>Note 5</sup>	
Point Trace	8 + 6 + 6 <sup>Note 6, 9</sup>	-	-	-	-	64 <sup>Note 6</sup>	
Timer Result (timer start/timer end)	4 + 3 + 3 <sup>Note 5</sup>	2 <sup>Note 10</sup>				1	
Action (Printf)	100 <sup>Note 7</sup>					64 <sup>Note 8</sup>	

- Notes 1.**
- 1 event when the flash emulation function is specified to valid (i.e. when [Yes] is specified with the [Flash self-programming] property in the [Flash self Emulation] category on the [\[Flash Self Emulation Settings\]](#) tab [[IECUBE](#)] of the [Property panel](#)).
  2. Hardware Break events (before execution) and Hardware Break events (access) are combined use.
  3. The number of settable break events that can be set in the flash memory area depends on the ROM collection function of the selected microcontroller.
  4. The before break/after break can be specified in the [Property panel](#).
  5. In this version, only one group can be set (however, two or more trace start/trace end events can be set).
  6. In this version, only one can be set (however, two or more conditions for this event can be set).
  7. Combination with Software Break events (however, up to 100 can be set regardless of their valid/invalid state)
  8. Combination with Hardware Break events (before execution) (however, up to 64 can be set regardless of their valid/invalid state)
  9. When trace start and end events and a Point Trace event are specified together, only the data that matches the Point Trace event condition within the section between the specified trace start and end events can be collected as trace data.
  10. When the selected microcontroller incorporates PMU, two Hardware Break events (before execution) are required.

## (2) Event types that can be set and deleted during execution

Types of events that can be set or removed during execution of the program or during execution of the tracer/timer are described below.

The meaning of each mark in the table below is as follows:

○	Possible
△	Possible, if the program execution is allowed to pause for events ( <a href="#">Property panel</a> >> <a href="#">[Debug Tool Settings]</a> tab >> [Set Event While Running] category >> [Set event by stopping execution momentarily] property >> [Yes])
□	Possible, if the operation of tracer/timer is allowed to pause for events ( <a href="#">Property panel</a> >> <a href="#">[Debug Tool Settings]</a> tab >> [Set Event While Running] category >> [Set event by stopping execution momentarily] property >> [Yes])
▲	Impossible while tracer or timer is executing
-	Impossible, or not supported

Table 2-28. Event Types That Can be Set and Deleted during Execution [V850E1][V850ES]

Event Type	Debug Tool to Use					
	IECUBE	MINICUBE E1/E20(JTAG)		MINICUBE2 E1/E20(Serial) EZ Emulator		Simulator
		With TEU	Without TEU	With Core-event	Without Core-event	
Hardware Break (before execution)	△	△	△	△	-	▲
Hardware Break (after execution)	○	○	▲	▲	-	▲
Hardware Break (access)	○	○	△	△	-	▲

Event Type	Debug Tool to Use					Simulator	
	IECUBE	MINICUBE E1/E20(JTAG)		MINICUBE2 E1/E20(Serial) EZ Emulator			
		With TEU	Without TEU	With Core-event	Without Core-event		
Software Break	△	△	△	△	△	-	
Trace (trace start/trace end)	□ Note 1	-	-	-	-	▲	
Point Trace	□ Note 1	-	-	-	-	▲	
Timer Result (timer start/timer end)	□	-	-	-	-	▲	
Action (Printf)	△	△	△	△	-	▲	

Table 2-29. Event Types That Can be Set and Deleted during Execution [V850E2]

Event Type	Debug Tool to Use					Simulator	
	IECUBE2	MINICUBE E1/E20(LPD)/(JTAG)		MINICUBE2 E1/E20(Serial)			
		With TEU	Without TEU	With Core-event	Without Core-event		
Hardware Break (before execution)	△	△	△	△	-	▲	
Hardware Break (after execution)	○	○	▲	-	-	▲	
Hardware Break (access)	○	○	-	-	-	▲	
Software Break	△	△	△	△	△	-	
Trace (trace start/trace end)	□ Note 2	-	-	-	-	▲	
Point Trace	□ Note 2	-	-	-	-	▲	
Timer Result (timer start/timer end)	□	-	-	-	-	▲	
Action (Printf)	△	△	△	△	△	-	

**Notes 1. [V850E1][V850ES]**

Events cannot be deleted while the timer function or the coverage function is in operation.

**2. [V850E2]**

Events cannot be set nor deleted while the timer function or the coverage function is in operation.

### (3) Other notes

- No events can be set to local variables.
- Events do not occur during step execution (including return execution) and program execution by selecting [Go to Here] from the context menu.
- If the location set for an existing event changes to midway in an instruction because the program to debug has been downloaded again, re-set the event using the following method.
  - If debugging information is available:  
The location setting of events is always moved to the beginning of the source text line.
  - If debugging information is not available:  
Depends on the [Automatic change method of event setting position] property in the [Download] category on the [\[Download File Settings\]](#) tab of the [Property panel](#).
- If a change to internal ROM/RAM changes the location the event is set to a non-mapped area, then set events will not occur (they will also not change to [Invalid state /Suspended State](#) on the [Events panel](#)).

- If you differentiate function or variable names by leading underscores, then CubeSuite+ may misrecognize them, and convert symbols or make break event settings invalid. This applies for cases like when you have two functions, one named "\_reset" and the other named "\_\_reset".

#### - [V850E1][V850ES]: For other than [Simulator]

If there is a conflict between a software break event and one of the following hardware break events, the PC register value may be invalidly corrected. Use a hardware break event instead of a software break event.

- Trace full break
- Time out break
- Non-map break
- Write-protect break
- Illegal I/O access break
- Forced break due to the  button press
- Hardware break event

#### - [V850E1][V850ES]

If there is code (text sections) to be ROMified, any software break event set for that code will be deleted during copy to RAM. For this reason, no break will occur. Use a hardware break if you are using OCD(JTAG) or OCD(Serial) or IECUBE. Note that if you are using a simulator, execution will not break even if a hardware breakpoint is used, but it will break if the tracer or timer is turned on.

##### - For other than [Simulator]

Use a hardware break event.

##### - [Simulator]

Execution will not break even if a hardware break event is used, but it will break if the trace function or the timer function is valid (on the [\[Debug Tool Settings\]](#) tab of the [Property panel](#), specify [Yes] with the [Use trace function]/[Use timer function]property on the [Trace]/[Timer] category).

#### - For other than [IECUBE][IECUBE2]

If a software break event is set in a boot-swap area, then a break instruction will be written to the flash ROM. For this reason, a break instruction will remain after the boot swap.

##### - [E1][E20][EZ Emulator]

Use a hardware break event in a boot-swap area if you wish to.

**- [Simulator]**

Do not use a break event in a boot-swap area.

**- [V850E2]**

When the selected microcontroller version supports multi-core, events are set automatically to be valid in each core (PEn).

## 2.16 Use Hook Function

This section describes how to set hooks in the debug tool by using the hook function.

By setting a hook transaction, you can automatically change the values of the I/O register/CPU register before and after downloading a load module or after resetting the CPU.

Configure the hook transaction in the [Hook Transaction Settings] category on the [\[Hook Transaction Settings\] tab](#) of the [Property panel](#).

**Remark** By setting a I/O register by using the [Before download] property, for example, downloading can be executed at high speeds. Downloading to the external RAM is also facilitated by using this function.

Figure 2-246. [Hook Transaction Settings] Category

<b>Hook Transaction Settings</b>	
<input type="checkbox"/> Before download	Before download[0]
<input type="checkbox"/> After download	After download[0]
<input type="checkbox"/> After CPU reset under breaking	After CPU reset under breaking[0]
<input type="checkbox"/> Before running	Before running[0]
<input type="checkbox"/> After breaking	After breaking[0]

Table 2-30. Properties in [Hook Transaction Settings] Category

Property	Description
Before download	Perform the specified process immediately before downloading the load module file.
After download	Perform the specified process immediately after downloading the load module file.
After CPU reset under breaking	Perform the specified process immediately after resetting the CPU under breaking.
Before running	Perform the specified process immediately before starting program execution.
After breaking	Perform the specified process immediately after breaking program execution.

The properties in the [Hook Transaction Settings] category indicate the timing with which the hook process will be performed. "[] indicates the current number of specified processes (no hook processes are configured by default).

Specify the target process in the property for which you want the hook process to be performed.

To specify a process, select the target property, then open the [Text Edit dialog box](#) by clicking the [...] button that appears on the right edge of the field.

Figure 2-247. Opening Text Edit Dialog Box





Figure 2-248. Use Hook Function (Text Edit Dialog Box)



In this dialog box, directly enter the desired process from the key board.

The format for specifying processes is as follows:

[Format 1]:

Automatically overwrites the value of *I/O register* with *Value*.

```
I/O-register-name Value
```

[Format 2]:

Automatically overwrites the value of *CPU register* with *Value*.

```
CPU-register-name Value
```

[Format 3]:

Automatically executes a script file which is specified with *Python script path* (absolute path or relative path from the project folder).


```
Source Python-script-path
```

- Remarks 1.** When specifying hook processes, lines starting with a hash mark "#" will be treated as comments.  
**2.** A tab character can be used instead of the space character.

Up to 64 characters for one process, and up to 128 processes for each property can be set (one line in the [Text] area in the [Text Edit dialog box](#) is equivalent to one processing).

After the specification of the process is complete, click the [OK] button to set the process to the [Property panel](#).

Figure 2-249. Example of Hook Transaction



## 2.17 Use the Simulator GUI [Simulator]

This section describes how to use the Simulator GUI.


Note that the function of the Simulator GUI described in this section is only supported when a microcontroller whose Simulator supports peripheral function simulations is selected.

Control the Simulator GUI via the [Simulator GUI window](#) below.

This window appears automatically by default after connecting to the debug tool when a microcontroller whose Simulator supports peripheral function simulations is selected and [Simulator] is selected as the debug tool to use.

**Remark** The [Simulator GUI window](#) and windows opened from it cannot be docked to the CubeSuite+ [Main window](#).

**Figure 2-250. Using Simulator GUI (Simulator GUI Window)**



The setting of the display of the [Simulator GUI window](#) can be configured in the [Simulator GUI] category on the [\[Debug Tool Settings\]](#) tab of the [Property panel](#) as follows:

Configure the appropriate settings.

**Caution** After connecting to the debug tool, all the properties in this category will become invalid if a microcontroller whose Simulator does not support peripheral function simulations (instruction simulation version) is selected.

**Figure 2-251. [Simulator GUI] Category**

Simulator GUI	
Display Simulator GUI	Yes
Display Simulator GUI on top of other windows	Yes

### (1) [Display Simulator GUI]

Specify whether to display the [Simulator GUI window](#) from the drop-down list.

Select [Yes] to use the function of the Simulator GUI (default).

When you do not need to use the Simulator GUI, select [No] to close the [Simulator GUI window](#).

## (2) [Display Simulator GUI on top of other windows]

This property appears only when the [Display Simulator GUI] property is set to [Yes].

Specify whether to display the Simulator GUI window in the forefront when program execution starts. Select [Yes] to display it in the forefront (default).


### 2.17.1 Check the I/O waveform of the microcontroller

It is possible to check the I/O waveform of the microcontroller by clicking the  button on the Simulator GUI window's toolbar and opening the [Timing Chart window](#) (shown below).

This window displays a timing chart of the input and output signals of the microcontroller's pins.

See the section on the [Timing Chart window](#) for details about controlling the window.

**Figure 2-252. Checking I/O Waveform of Microcontroller (Timing Chart Window)**




### 2.17.2 Input signals to the pins

To configure the input signal to a pin, click the  on the Simulator GUI window's toolbar. The following [Signal Data Editor window](#) opens.

You can use this window to set the input signal data for the input pin to a numerical value, to be input at an arbitrary time.

See the section on the [Signal Data Editor window](#) for details about controlling the window.

**Figure 2-253. Configuring Input Signal to Pin (Signal Data Editor Window)**




### 2.17.3 Perform serial communication

To configure serial communication, click the  on the [Simulator GUI window's toolbar](#). The following [Serial window](#) opens.

This window provides serial I/O features for communicating with the CPU's built-in serial interface. This enables you to input data to the microcontroller's serial receiver pin, and acquire output data from its serial transmitter pin.

See the section on the [Serial window](#) for details about controlling the window.

**Figure 2-254. Performing Serial Communication (Serial Window)**



### 2.17.4 Use buttons, LEDs, level gauges, and other components


The Simulator GUI allows input manipulation and output display simulation by providing standard connected parts (buttons, LEDs, level gauges, etc.) in which the I/O block for peripheral I/O designed as a GUI interface.

To configure connected parts, click the  on the [Simulator GUI window's toolbar](#). The following [I/O Panel window](#) opens.

This window enables you to configure the various connected parts, building a dummy target system.

See the section on the [I/O Panel window](#) for details about controlling the window.

**Figure 2-255. Configuring Connected Parts (I/O Panel Window)**



## 2.18 About Input Value

This section describes consideration to take when inputting values in each panel and dialog box.

### 2.18.1 Input rule

Following is the rules for input to each panel/dialog box.

#### (1) Character set

Character sets that are allowed to input are as follows:

**Table 2-31. List of Character Set**

Character Set	Outline
ASCII	1- byte alphabets, numbers, symbols
Shift-JIS	2-byte alphabet, number, symbol, Hiragana, Katakana, Kanji and 1-byte Katakana.
EUC-JP	2-byte alphabet, number, symbol, Hiragana, Katakana, Kanji and 1-byte Katakana.
UTF-8	2-byte alphabet, number, symbol, Hiragana, Katakana, Kanji (include Chinese characters) and 1-byte Katakana.
UTF-16	2-byte alphabet, number, symbol, Hiragana, Katakana, Kanji (include Chinese characters) and 1-byte Katakana.

#### (2) Number

Notations allowed when entering numbers are as follows:

**Table 2-32. Notation List**

Notation	Outline
Binary number	Start with 0b and continues with the numbers from 0 to 1. (Case insensitive for alphabets)
Octal number	Start with 0 and continues with the numbers from 0 to 7.
Decimal	Start without 0 and continues with the numbers from 0 to 9.
Hexadecimal number	Start with 0x and continues with the numbers from 0 to 9 and alphabets a to f. (Case insensitive for alphabets) In the input area with the <b>HEX</b> mark, prefix 0x is not needed.

#### (3) Expression and operator

Expression represents constants, register name, I/O register name and symbols and those connected with operators.

When I/O register name, label name, function name and variable name are described as symbols, the address is operated as a value of symbols. The basic input formats are as follows:

**Table 2-33. Basic Input Format of Expressions**

Expression	Description
Variable name of C language	Value of C language variable
<i>Expression</i> [ <i>Index</i> ]	Element of array
<i>Expression</i> .Member name	Member of structures/unions

Expression	Description
Expression->Member name	Member of structures/unions that pointer designates
*Expression	Value of pointer variable
CPU register name	Value of the CPU register
I/O register name	I/O register value
Label name, EQU symbol name and immediate address	Values of label, EQU symbol and immediate address
Bit symbol	Bit symbol value

### 2.18.2 Symbol name completion function

This function helps users input data by selecting one of the listed symbol names that exist in the program, when specifying an address expression and so on.


The list of symbol names appears by pressing the [Ctrl] + [Space] keys when a part of the target symbol name is being input in the text box that supports this function. In this list, double-click the target symbol name (or press the [Space]/[Enter] key after selecting it by using the [Up]/[Down] key) to complement the symbol name currently being input.

At this time, if a key other than the [Space]/[Enter] key is pressed or the focus moves to outside the panel/dialog box currently being operated, then the list of symbol names will disappear (the symbol name completion will not be performed).

**Caution** If there are no character strings in the text box or there are no candidates of the symbol, then the list of symbol names will not appear.

**Remark** See the explanation of the corresponding panel/dialog box as to whether this function can be used or not when inputting a symbol name.

Figure 2-256. Symbol Name Completion Function



### 2.18.3 Icons for invalid input

In some of the dialogs in CubeSuite+, the ! icon will appear at a point where incorrect characters are entered as a warning sign.

**Remark** Placing the cursor over the ! icon will pop up the information that indicates the characters to be entered.

## APPENDIX A WINDOW REFERENCE

Appendix A provides detailed explanations of windows/panels/dialog boxes used for debugging with CubeSuite+.

### A.1 Description

Windows/panels/dialog boxes for debugging are listed below.

**Table A-1. Window/Panel/Dialog Box List**

Window/Panel/Dialog Box Name	Description
Main window	Controls the program execution. Various windows, panels and dialogs can be opened from this window.
Debug Manager panel [V850E2]	Selects a core (PEn) to be debugged and displays the core status.
Project Tree panel	Selects the debug tool to use.
Property panel	Displays detailed information on the debug tool currently selected in the <a href="#">Project Tree panel</a> , and enables the settings of the tool to be changed.
Editor panel	Enables text files to be viewed and edited, and is used to execute source level debug.
Memory panel	Displays and modifies memory values.
Disassemble panel	Displays the results of memory value disassemble and is used to execute line assemble and instruction level debug.
CPU Register panel	Displays the contents of CPU registers, and modifies register values.
IOR panel	Displays and modifies I/O register values.
Local Variables panel	Displays and modifies local variables.
Watch panel	Displays and modifies registered watch-expression values.
Call Stack panel	Displays call stack information on function calls.
Trace panel [IECUBE][IECUBE2][Simulator]	Displays trace data acquired from the debug tool.
Events panel	Displays detailed information on set events, switches the events between enabled and disabled, or deletes them.
Output panel	Displays messages output from the build tool/debug tool/plug-ins, or the results of batch searches carried out using the Find and Replace dialog box.
Memory Mapping dialog box	Sets the memory mapping.
Download Files dialog box	Selects files to be downloaded and sets the download conditions.
External Flash Memory Download dialog box	Selects the external flash memory information file for downloading to the external flash memory and sets the download conditions.
Flash Options Setting dialog box [V850E2]	Configures options for the flash memory.
Text Edit dialog box	Inputs and modifies character strings.
Action Events dialog box	Sets action events.
Encoding dialog box	Selects a file-encoding.
Save Settings dialog box	Specifies the encoding and the new line code of the file being edited.
Bookmarks dialog box	Displays and deletes bookmarks.

Window/Panel/Dialog Box Name	Description
Column Number Settings dialog box	Specifies the number of view columns of memory values on the <a href="#">Memory panel</a> .
Address Offset Settings dialog box	Specifies an offset value for the address display on the <a href="#">Memory panel</a> .
Memory Initialize dialog box	Initializes memory.
Memory Search dialog box	Searches memory.
Print Address Range Settings dialog box	Sets the address range to print the contents of the <a href="#">Disassemble panel</a> .
Print Preview window	Previews the source file before printing.
Trace Search dialog box [IECUBE][IECUBE2][Simulator]	Searches trace data.
Scroll Range Settings dialog box	Sets the scroll range for the <a href="#">Memory panel/Disassemble panel</a> .
Go to Line dialog box	Moves the caret to the specified line.
Go to the Location dialog box	Moves the caret to the specified position.
Data Save dialog box	Saves the settings and other data displayed in the respective windows/panels/dialogs or saves upload data.
Progress Status dialog box	Displays the progress of the processing being executed.
Option dialog box	Makes settings for various environments.
Select Download File dialog box	Selects files to be downloaded.
Open Watch Expression Data File dialog box	Selects a file for importing watch-expressions.
Select Flash Memory Information File dialog box	Selects the external flash memory information file.
Open File dialog box	Selects files to be opened.
Save As dialog box	Saves files or the contents of various windows/panels/dialogs.
Select Data Save File dialog box	Selects the file to save data.
Open Option Setting File dialog box	Selects the option setting file to import to the <a href="#">Option dialog box</a> .
Save Option Setting File dialog box	Saves the set contents of the <a href="#">Option dialog box</a> to a option setting file.
Select Simulator Configuration File dialog box [Simulator]	Selects simulator configuration file.

**Table A-2. Simulator GUI Block-Dedicated Window/Dialog Box List**

Window/Dialog Box Name	Description
Simulator GUI window	Opens and controls various simulator GUI's windows and dialog boxes.
Customize dialog box	Setting of window colors and fonts
Signal Data Editor window	Setting of input signal data
Loop dialog box	Setting of loop information for the <a href="#">Signal Data Editor window</a>
Select Pin dialog box	Selection of display pins in the <a href="#">Signal Data Editor window</a> and <a href="#">Timing Chart window</a>
Timing Chart window	Timing chart display of input and output signals
Search Data dialog box	Detailed search of the <a href="#">Timing Chart window</a>
I/O Panel window	Creation of dummy target system


Window/Dialog Box Name	Description
Parts Button Properties dialog box	Setting of button pin connection information
Analog Button Properties dialog box	Setting of analog button pin connection information
Parts Key Properties dialog box	Setting of key matrix LED pin information
Parts Level Gauge Properties dialog box	Setting of level gauge pin connection information
Parts Led Properties dialog box	Setting of key matrix LED pin information
Parts Segment LED Properties dialog box	Setting of 7/14-segment LED pin connection information
Parts Matrix Led Properties dialog box	Setting of matrix LED pin connection information
Parts Buzzer Properties dialog box	Setting of buzzer pin connection information
Pull up/Pull down dialog box	Setting of pull-up/pull-down resistor pin connection information
Object Properties dialog box	Setting of connection information for figure, character, and bitmap pins
Parts List dialog box	List display of object pin connection status in the <a href="#">I/O Panel window</a>
Serial window	Serial interface communication window
Format (UART) dialog box	Setting of serial format (UART)
Format (CSI) dialog box	Setting of serial format (CSI)

### Main window

This window is automatically opened when CubeSuite+ is started up.

In this window, you can control the program execution and open panels for the debugging process.

**Figure A-1. Main Window**



This section describes the following.

- [\[How to open\]](#)
- [\[Description of each area\]](#)

#### [How to open]

- From the Windows [Start] menu, select [All Programs] >> [Renesas Electronics CubeSuite+] >> [CubeSuite+].

**[Description of each area]****(1) Menubar**

Menu items related to the debugging are as follows:

**Remark** The items that can be selected in each menu can be customized using the User Setting dialog box.

**(a) [View]**

The [View] menu provides the following items and functions (default).

Debug Manager [V850E2]	Opens the <a href="#">Debug Manager panel [V850E2]</a> . This item is disabled when the selected microcontroller version does not support multi-core or when disconnected from the debug tool.
Watch	The following cascade menus are displayed to open the <a href="#">Watch panel</a> . These items are disabled when disconnected from the debug tool.
Watch1	Opens the Watch panel (Watch1).
Watch2	Opens the Watch panel (Watch2).
Watch3	Opens the Watch panel (Watch3).
Watch4	Opens the Watch panel (Watch4).
Local Variable	Opens the <a href="#">Local Variables panel</a> .
Call Stack	Opens the <a href="#">Call Stack panel</a> .
Memory	The following cascade menus are displayed to open the <a href="#">Memory panel</a> . These items are disabled when disconnected from the debug tool.
Memory1	Opens the Memory panel (Memory1).
Memory2	Opens the Memory panel (Memory2).
Memory3	Opens the Memory panel (Memory3).
Memory4	Opens the Memory panel (Memory4).
IOR	Opens the <a href="#">IOR panel</a> . This item is disabled when disconnected from the debug tool.
CPU Register	Opens the <a href="#">CPU Register panel</a> . This item is disabled when disconnected from the debug tool.
Trace [IECUBE][IECUBE2] [Simulator]	Opens the <a href="#">Trace panel [IECUBE][IECUBE2][Simulator]</a> . This item is disabled when disconnected from the debug tool.
Disassemble	The following cascade menus are displayed to open the <a href="#">Disassemble panel</a> . These items are disabled when disconnected from the debug tool.
Disassemble1	Opens the Disassemble panel (Disassemble1).
Disassemble2	Opens the Disassemble panel (Disassemble2).
Disassemble3	Opens the Disassemble panel (Disassemble3).
Disassemble4	Opens the Disassemble panel (Disassemble4).
Event	Opens the <a href="#">Events panel</a> . This item is disabled when disconnected from the debug tool.

Show Current PC Location	Displays the current PC position in the <a href="#">Editor panel</a> . This item is disabled when disconnected from the debug tool.
Back to Last Cursor Position	Goes back to the position before jumping (see "(7) Jump to functions"/"(4) Move to the symbol defined location") to the defined location. This item is disabled when disconnected from the debug tool.
Forward to Next Cursor Position	Forwards to the position before operating [Back to Last Cursor Position].
Tag Jump	Jumps to the corresponding line/column in the corresponding file if the information of a file name/line number/column number exists in the line at the caret position on the <a href="#">Editor panel</a> / <a href="#">Output panel</a> (see "(8) Jump to a desired line (tag jump)").

**Note [E1][E20][EZ Emulator]**

This item is available only when the selected microcontroller incorporates the OCD trace function.

**(b) [Debug]**

The [Debug] menu provides the following items and functions (default).

Download	Downloads the specified file(s) into the debug tool currently selected in the active project. If CubeSuite+ is disconnected from the debug tool at this time, it is automatically connected to the debug tool before a download is executed. This item is disabled during execution of a program or when [Build & Download] is under execution.
Build & Download	Executes the build of a project and downloads the file into the debug tool currently selected in the active project. If CubeSuite+ is disconnected from the debug tool at this time, it is automatically connected to the debug tool before a download is executed. However, when the build has failed, download will not be executed.
Connect to Debug Tool	Connects to the debug tool currently selected in the active project. This item is disabled while connected to the debug tool or if the version of compiler being used is not supported by CubeSuite+.
Hot Plug-in [V850E2] [E1/E20(LPD)] [E1/E20(JTAG)]	Connects to the debug tool currently selected in the active project via the hot plug-in function, in order to debug the target system currently running (see " <a href="#">2.4.3 Connect to the debug tool using hot plug-in [E1/E20(LPD)/(JTAG)[V850E2]]</a> "). This item is disabled while connected to the debug tool.
Upload...	Opens the <a href="#">Data Save dialog box</a> to save the memory contents. This item is disabled during execution of a program, when [Build & Download] is under execution or when disconnected from the debug tool.
Disconnect from Debug Tool	Disconnects from the currently connected debug tool. This item is disabled when [Build & Download] is under execution or when disconnected from the debug tool.
Stop	Forcibly stops the program currently being executed. This item is disabled during non-execution of a program or when disconnected from the debug tool.
Go	Executes the program from the current PC position. Execution of the program will be stopped when the condition of a set break event is met. This item is disabled during execution of a program, when [Build & Download] is under execution, or when disconnected from the debug tool.

Ignore break and go	Executes the program from the current PC position. Execution of the program continues, ignoring set break events and action events. This item is disabled during execution of a program, when [Build & Download] is under execution, or when disconnected from the debug tool.
Step In	Executes the program step by step <sup>Note</sup> from the current PC position (Step in execution). However, in the case of a function call, the program is stopped at the beginning of the function having been called. This item is disabled during execution of a program, when [Build & Download] is under execution, or when disconnected from the debug tool.
Step Over	Executes the program step by step <sup>Note</sup> from the current PC position (Step over execution). In the case of a function call by the <i>jalr</i> instruction, all the source lines/instructions in the function are treated as one step and executed until the position where execution returns from the function (step-by-step execution will continue until the same nest is formed as when the <i>jalr</i> instruction has been executed). In the case of an instruction other than <i>jalr</i> , operation is the same as when [Step In] is selected. This item is disabled during execution of a program, when [Build & Download] is under execution, or when disconnected from the debug tool.
Return Out	Executes the program until execution returns from the current function (or returns to the calling function) <sup>Note</sup> (Return out execution). This item is disabled during execution of a program, when [Build & Download] is under execution, or when disconnected from the debug tool.
CPU Reset	Resets the CPU (does not execute a program) This item is disabled when [Build & Download] is under execution or when disconnected from the debug tool.
Restart	Resets the CPU and then executes the program from the reset address. This item is disabled when [Build & Download] is under execution or when disconnected from the debug tool.

**Note** Step execution can be carried out either in units of source lines or in units of instructions.

For details, see "[2.7.3 Execute programs in steps](#)".

## (2) Debug toolbar

The debug toolbar includes the buttons that control the execution of programs.

The debug toolbar provides the following buttons and functions (default).

- Remarks 1.** The buttons on the toolbar can be customized using the User Setting dialog box. Furthermore, a new toolbar can be created using the same dialog box.
- 2.** A Group of toolbar displayed can be selected with the context menu that is displayed by right-clicking on the toolbar.

	Executes the build of a project and downloads the file into the debug tool currently selected in the active project. If CubeSuite+ is disconnected from the debug tool at this time, it is automatically connected to the debug tool before a download is executed. However, when the build has failed, download will not be executed. The function of this item is the same as that of [Build & Download] in the [Debug] menu.
---	---

	Downloads the specified file(s) into the debug tool currently selected in the active project. If CubeSuite+ is disconnected from the debug tool at this time, it is automatically connected to the debug tool before a download is executed. This item is disabled during execution of a program or when [Build & Download] is under execution. The function of this item is the same as that of [Download] in the [Debug] menu.
	Resets the CPU (does not execute a program) This item is disabled when [Build & Download] is under execution or when disconnected from the debug tool. The function of this item is the same as that of [CPU Reset] in the [Debug] menu.
	Forcibly stops the program currently being executed. This item is disabled during non-execution of a program or when disconnected from the debug tool. The function of this item is the same as that of [Stop] in the [Debug] menu.
	Executes the program from the current PC position. Execution of the program will be stopped when the condition of a set break event is met. This item is disabled during execution of a program, when [Build & Download] is under execution, or when disconnected from the debug tool. The function of this item is the same as that of [Go] in the [Debug] menu.
	Executes the program from the current PC position. Execution of the program continues, ignoring set break events and action events. This item is disabled during execution of a program, when [Build & Download] is under execution, or when disconnected from the debug tool. The function of this item is the same as that of [Ignore break and go] in the [Debug] menu.
	Resets the CPU and then executes the program from the reset address. This item is disabled when [Build & Download] is under execution or when disconnected from the debug tool. The function of this item is the same as that of [Restart] in the [Debug] menu.
	Executes the program step by step <sup>Note</sup> from the current PC position (Step in execution). However, in the case of a function call, the program is stopped at the beginning of the function having been called. This item is disabled during execution of a program, when [Build & Download] is under execution, or when disconnected from the debug tool. The function of this item is the same as that of [Step In] in the [Debug] menu.
	Executes the program step by step <sup>Note</sup> from the current PC position (Step over execution). In the case of a function call by the jarl instruction, all the source lines/instructions in the function are treated as one step and executed until the position where execution returns from the function (step-by-step execution will continue until the same nest is formed as when the jarl instruction has been executed). In the case of an instruction other than jarl, operation is the same as when the  button is clicked. This item is disabled during execution of a program, when [Build & Download] is under execution, or when disconnected from the debug tool. The function of this item is the same as that of [Step Over] in the [Debug] menu.
	Executes the program until execution returns from the current function (or returns to the calling function) <sup>Note</sup> (Return out execution). This item is disabled during execution of a program, when [Build & Download] is under execution, or when disconnected from the debug tool. The function of this item is the same as that of [Return Out] in the [Debug] menu.
	Disconnects from the currently connected debug tool. This item is disabled when [Build & Download] is under execution or when disconnected from the debug tool.

**Note** Step execution can be carried out either in units of source lines or in units of instructions.  
For details, see "[2.7.3 Execute programs in steps](#)".

### (3) Panel display area


This area displays the various panels.

For details on the display content, see the sections describing the individual panels.

### (4) Statusbar

Statusbar displays the following items of information.

**Figure A-2. Statusbar**



#### (a) Status message

This area displays the following messages and other information.

- A brief explanation of the selected menu item
- A message reporting that an invalid value has been input in the panel/dialog
- A message reporting that the specified character string has not been found as a result of a search using the Find and Replace dialog box
- A statement of the cause of the break when a break has occurred (see "[2.8 Stop Programs \(Break\)](#)")

#### (b) Focus panel status information

This area displays status information on the panel currently having the focus.

Note that nothing is displayed here for a panel that has no status information.

#### (c) Selection of debug target core [V850E2]

This area is used to select a core (PE<sub>n</sub>) to be debugged.

Note that nothing is displayed here when the selected microcontroller version does not support multi-core or when disconnected from the debug tool.

**Remark** You can also select a core to be debugged with the [Debug Manager panel \[V850E2\]](#).

#### (d) Running state

This area displays the state of the program with the following icons and character strings.

Note that nothing is displayed here when the debug tool is not connected.

State of Program	Displayed Content
Under execution	RUN
Now halted	BREAK
Step execution in progress	STEP

#### (e) CPU status

This area displays the current CPU status of the debug tool. When there is the possibility that the CPU is in two or more statuses, the corresponding display contents are displayed separated by "&".

Note that nothing is displayed here when the debug tool is not connected.

Debug Tool	Displayed Content	CPU Status
IECUBE IECUBE2 MINICUBE E1/E20(LPD) E1/E20(JTAG)	Halt	In HALT mode
	StopIdle	In hardware STOP mode, software STOP mode, or IDLE mode
	Hold	In bus hold
	Wait	In wait state
	Reset	In reset state
	Pow Off	Power not supplied to the target
MINICUBE2 E1/E20(Serial) EZ Emulator	Reset	In reset state
	Pow Off	Power not supplied to the target
Simulator	Halt	In HALT mode
	StopIdle	In STOP mode or IDLE mode
	Reset	In reset state

**Remark** Nothing is displayed here when the CPU is in status other than those listed above.

#### (f) Current PC position

This area displays the current PC position with a hexadecimal value. When this area is clicked, the caret moves to the current PC position on the [Editor panel](#).

In addition, when the mouse pointer is placed over this area, a pop-up window appears to display the following information.

- Current PC: 0x *current PC value (source name#line count<sup>Note</sup>)*

Note that nothing is displayed here when the debug tool is not connected.

**Note** "symbol name+offset value" is displayed when acquisition of information is impossible.

**Remark** "Running" is displayed in this area during execution of a program.

#### (g) Connection state

This area displays the current state of connection with the debug tool using the following icons and character strings.

Connection State	Displayed Content
Connected	 <i>Debug tool name</i>
Disconnected	 DISCONNECTED

#### (h) Run-Break Timer measurement result

This area displays the result of measurement by the Run-Break Timer event (the unit of value used differs depending on the measurement amount). See "[2.12.1 Measure execution time until stop of the execution](#)".

Note that nothing is displayed here when the debug tool is not connected.

Condition	Displayed Content
Un-measuring	Not measured
Under measurement	Measuring
When a timer measurement overflow has occurred	OVERFLOW

**(i) Debug tool state [IECUBE][IECUBE2][Simulator]**

This area displays the current state of debug tool's functions using the following icons and character strings.

When a function is stopped, clicking the appropriate icon enables the state to be switched between "Use" and "Not use".<sup>Note</sup>

Note that nothing is displayed here when the debug tool is not connected.

Function	Being Executed	Stopped (Use)	Not Use
Trace			
Timer			
Coverage			

**Note [IECUBE][IECUBE2]**

The result of switching will be reflected in the setting of the [Use for trace data] property on the [Trace] category on the [\[Debug Tool Settings\]](#) tab of the [Property panel](#).

**[Simulator]**

The result of switching will be reflected in the setting of the [Use trace function]/[Use timer function]/[Use coverage function] property in the [Trace]/[Timer]/[Coverage] category on the [\[Debug Tool Settings\]](#) tab of the [Property panel](#).

### Debug Manager panel [V850E2]


When the selected microcontroller is the V850E2 multi-core product, this panel is used to select a core (PE: Processor Element) to be debugged and display the core status.

This panel appears only when connected to the debug tool.

**Caution** This panel cannot be opened when the selected microcontroller is the single-core product.

**Remark** Synchronous executions and synchronous breaks are performed in each PE<sub>n</sub> in principle (events are automatically set to be valid in each PE<sub>n</sub>). Note, however, that step executions are performed only in a PE<sub>n</sub> currently being selected.

Figure A-3. Debug Manager Panel



This section describes the following.

- [\[How to open\]](#)
- [\[Description of each area\]](#)
- [\[Toolbar\]](#)

#### [How to open]

- From the [View] menu, select [Debug Manager].

#### [Description of each area]

##### (1) [Selects debug target core] area

Select a core (PE<sub>n</sub>) to be debugged with a option button.

Note that this area becomes invalid during execution of a program.

**Remark** You can also select a core to be debugged on the statusbar in the [Main window](#).

##### (2) [Debug target core status] area

This area displays the status of the core currently being selected.

**Remark** You can also confirm the information displayed in this area on the statusbar in the [Main window](#).

**(a) [Running status]**

Displays the current state of the program with the following icons and character strings.

State of Program	Displayed Content
Running	RUN
Stopped	BREAK
In step execution	STEP

**(b) [Core status]**

Displays the current core statuses of the debug tool. When there is the possibility that the core is in two or more statuses, the corresponding display contents are displayed separated by "&".

Debug Tool	Displayed Content	Core Status
MINICUBE E1/E20(LPD) E1/E20(JTAG)	Halt	In HALT mode
	StopIdle	In Hardware STOP/Software STOP/IDLE mode
	Hold	In bus hold
	Wait	In wait state
	Reset	In reset state
	Pow Off	Power not supplied to the target

**(c) [Current PC]**

Displays the current PC position with a hexadecimal value. When this button is clicked, the caret moves to the current PC position on the [Editor panel](#).


**[Toolbar]**

The function of this toolbar is the same as that of the [Debug toolbar](#) on the [Main window](#). For details on the function of each button, see "[\(2\) Debug toolbar](#)".

### Project Tree panel

This panel is used to display the project components (microcontroller, build tool, debug tool, etc.) in a tree structure. On this panel, you can select or change the debug tool to use.

Figure A-4. Project Tree Panel



The following items are explained here.

- [\[How to open\]](#)
- [\[Description of each area\]](#)
- [\[Context menu\]](#)

#### [How to open]

- From the [View] menu, select [Project Tree].

### [Description of each area]

#### (1) Project tree area

Project components are displayed in tree view with the following given node.

Node	Description
<i>Microcontroller type Debug tool name</i> (Debug tool)	<ul style="list-style-type: none"> <li>- <i>Microcontroller type</i>: The selected microcontroller type (V850 or V850E2) is displayed.</li> <li>- <i>Debug tool name</i>: The debug tool (IECUBE, IECUBE2, MINICUBE, MINICUBE2(Serial), E1(Serial), E1(LPD), E1(JTAG), E20(Serial), E20(LPD), E20(JTAG), EZ Emulator or Simulator) currently being used in the project is displayed.</li> </ul> <p>[Simulator] is selected when a new project is created<sup>Note</sup>.</p>

**Note** If the selected microcontroller version does not support a simulator, then MINICUBE will be selected for it.

Select the debug tool node to configure with the [Property panel](#). If the Property panel is not being opened, double-click the node to open the corresponding Property panel.


### [Context menu]

Using Debug Tool	The following cascade menus are displayed to select the debug tool to use.  Note that the debug tools displayed in this menu differ depending on the microcontroller selected in the project (see " <a href="#">Table 2-1. Relationship between Types of Microcontroller and Connectable Debug Tools</a> ").
<i>Device name</i> IECUBE	Uses IECUBE as the debug tool.
<i>Device name</i> IECUBE2	Uses IECUBE2 as the debug tool.
<i>Device name</i> MINICUBE	Uses MINICUBE as the debug tool.
<i>Device name</i> MINICUBE2(Serial)	Uses MINICUBE2 as the debug tool.
<i>Device name</i> E1(Serial)	Uses E1 with serial communication method as the debug tool.
<i>Device name</i> E1(LPD)	Uses E1 with LPD communication method as the debug tool.
<i>Device name</i> E1(JTAG)	Uses E1 with JTAG communication method as the debug tool.
<i>Device name</i> E20(Serial)	Uses E20 with serial communication method as the debug tool.
<i>Device name</i> E20(LPD)	Uses E20 with LPD communication method as the debug tool.
<i>Device name</i> E20(JTAG)	Uses E20 with JTAG communication method as the debug tool.
<i>Device name</i> EZ Emulator	Uses EZ Emulator with an evaluation kit and so on.
<i>Device name</i> Simulator	Uses Simulator as the debug tool.
Property	Displays the selected category node's property in the <a href="#">Property panel</a> .

## Property panel

This panel is used to display and set the debug tool operation environment that is selected in the [Project Tree panel](#).

**Figure A-5. Property Panel (When IECUBE Is Selected)**



This section describes the following.

- [\[How to open\]](#)
- [\[Description of each area\]](#)
- [\[\[Edit\] menu \(Property panel-dedicated items\)\]](#)
- [\[Context menu\]](#)

### [How to open]

- On the [Project Tree panel](#), select the [*Microcontroller type Debug tool name (Debug Tool)*] node to use, and then select [Property] from the [View] menu or the context menu.
- On the [Project Tree panel](#), double-click the [*Microcontroller type Debug tool name (Debug Tool)*] node to use.

**Remark** If this panel has been opened, the detailed information on the debug tool is displayed by selecting the [*Microcontroller type Debug tool name (Debug Tool)*] node on the [Project Tree panel](#).

### [Description of each area]

#### (1) Detailed information display/change area

In this area, the detailed information on the debug tool that is selected in [Project Tree panel](#) is displayed by category in the list. Also, you can directly change its settings.

The  mark indicates all the items in the category are expanded. The  mark indicates all the items are collapsed. You can expand/collapse the items by clicking these marks or double-clicking the category name.

Note that only the hexadecimal number is allowed in the text box if the **HEX** mark is displayed in the property configuration area.

For details on the information/how to setup in the category and property items contained in it, see the section explaining the corresponding tab.

## (2) Tab selection area

Categories for the display of the detailed information are changed when each tab is selected.

In this panel, following tabs are contained (see the section explaining each tab for details on the display/setting on the tab).

- [Connect Settings] tab
- [Debug Tool Settings] tab
- [Flash Self Emulation Settings] tab [IECUBE]
- [DataFlash Emulation Settings] tab [IECUBE]
- [Download File Settings] tab
- [Flash Options Settings] tab [V850E2]
- [Hook Transaction Settings] tab

## [[Edit] menu (Property panel-dedicated items)]

Undo	Undoes the latest property value editing being done.
Cut	Deletes the selected character string(s) and copies them to the clipboard while editing the property value.
Copy	Copies the contents of the selected range to the clipboard as character string(s).
Paste	Pastes the contents of the clipboard to the property value while editing the property value.
Delete	Deletes the selected character string(s) while editing the property value.
Select All	Selects all the character strings in the selected property while editing the property value.

## [Context menu]

[While not editing the property value]

Reset to Default	Restores the selected setting of the property item to default value.
Reset All to Default	Restores all the selected settings of the property items on the tab to default value.

[While editing the property value]

Undo	Undoes the latest property value editing being done.
Cut	Deletes the selected character string(s) and copies them to the clipboard while editing the property value.
Copy	Copies the contents of the selected range to the clipboard as character string(s).
Paste	Pastes the contents of the clipboard to the property value while editing the property value.
Delete	Deletes the selected character string(s) while editing the property value.
Select All	Selects all the character strings in the selected property while editing the property value.

### [Connect Settings] tab

This tab is used to display the detailed information categorized by the following and the configuration can be changed.

- (1) [Internal ROM/RAM]
- (2) [DataFlash] [V850E1][V850ES] (except [Simulator])
- (3) [Clock]
- (4) [Connection with Target Board] (except [MINICUBE][E20(LPD)/(JTAG)][Simulator])
- (5) [Flash] (except [IECUBE][Simulator])
- (6) [Configuration] [Simulator]
- (7) [Programmable I/O] [V850E1][V850ES]

Figure A-6. Property Panel: [Connect Settings] Tab [IECUBE]




Figure A-7. Property Panel: [Connect Settings] Tab [IECUBE2]






Figure A-8. Property Panel: [Connect Settings] Tab [MINICUBE][E1/E20(JTAG)] ([V850E1][V850ES])




**Note** The [Connection with Target Board] category appears only when E1(JTAG) is used.

Figure A-9. Property Panel: [Connect Settings] Tab [MINICUBE][E1/E20(LPD)/(JTAG)] ([V850E2])




**Note** The [Connection with Target Board] category appears only when E1(LPD)/(JTAG) is used.

Figure A-10. Property Panel: [Connect Settings] Tab [MINICUBE2][E1/E20(Serial)][EZ Emulator] ([V850E1][V850ES])



**Note** The [Power target from the emulator (MAX200mA)] property appears only when E1(Serial) is used.

Figure A-11. Property Panel: [Connect Settings] Tab [MINICUBE2][E1/E20(Serial)] ([V850E2])



**Note** The [Power target from the emulator (MAX200mA)] property appears only when E1(Serial) is used.

Figure A-12. Property Panel: [Connect Settings] Tab [Simulator] ([V850E1][V850ES])





Figure A-13. Property Panel: [Connect Settings] Tab [Simulator] ([V850E2])



**[Description of each category]****(1) [Internal ROM/RAM]**

The detailed information on internal ROM/RAM is displayed and its configuration can be changed.

**Cautions 1. You should be careful not to overlap the area with other memory mapping area.**

**2. [IECUBE]**

**CPU reset is generated automatically if you change the setting of the property in this category.**

Size of internal ROM[KBytes]	Display and change the internal ROM size of the selected microcontroller.	
	Default	- When the selected microcontroller is not a ROMless product <i>Internal ROM size of the selected microcontroller</i> <sup>Note 1</sup> - When the selected microcontroller is a ROMless product 0
	Modifying	<b>[IECUBE][Simulator[V850E1][V850ES]]</b> Select from the drop-down list <sup>Note 2</sup> . <b>[IECUBE2][MINICUBE][MINICUBE2][E1][E20][EZ Emulator][Simulator[V850E2]]</b> Changes not allowed
	Available values	<b>[IECUBE]</b> 0, 8, 32, 64, 128, 256, 512, 1024, 1024 + VSB Flash ROM size (only when the selected microcontroller incorporates VSB Flash ROM) (unit: Kbytes) <b>[Simulator[V850E1][V850ES]]</b> 0, 8, 32, 64, 128, 256, 512, 1024 (unit: Kbytes)
Size of internal RAM[Bytes]	Display and change the internal RAM size of the selected microcontroller.	
	Default	<i>Internal RAM size of the selected microcontroller</i> <sup>Note 3</sup>
	Modifying	<b>[IECUBE][Simulator[V850E1][V850ES]]</b> Select from the drop-down list. <b>[IECUBE2][MINICUBE][MINICUBE2][E1][E20][EZ Emulator][Simulator[V850E2]]</b> Changes not allowed
	Available values	<b>[IECUBE]</b> 4096, 12288, 28672, 61440, 61440 + VSB RAM size (only when the selected microcontroller incorporates VSB RAM) (unit: bytes) <b>[Simulator[V850E1][V850ES]]</b> 4096, 12288, 28672, 61440 (unit: bytes)
Size of DataFlash memory[KBytes] <b>[V850E2]</b> (except [Simulator])	Displays the size of the data flash memory area of the selected microcontroller.	
	Default	<i>Data flash memory size of the selected microcontroller</i>
	Modifying	Changes not allowed

**Notes 1. [V850E1]**

When the selected microcontroller incorporates VSB Flash ROM, it displays the value including the size of VSB Flash ROM.

2. When the selected microcontroller is a ROMless product, the property value cannot be changed.

**3. [V850E1]**

When the selected microcontroller incorporates VSB RAM, it displays the value including the size of RAM.

**[V850E2]**

When the selected microcontroller version supports multi-core, it displays "total RAM size(RAM size for a core x the number of cores)".

**(2) [DataFlash] [V850E1][V850ES] (except [Simulator])**

The detailed information on the data flash memory is displayed and its configuration can be changed.

Note that this category appears only when the selected microcontroller incorporates the data flash memory.

Use DataFlash memory area	Select whether to use the data flash memory.	
	Default	No
	Modifying	Select from the drop-down list.
	Available values	Yes      Uses the data flash memory.
		No      Does not use the data flash memory.
Size of DataFlash memory[KBytes]	Displays the size of the data flash memory area of the selected microcontroller. This property appears only when the [Use DataFlash memory area] property is set to [Yes].	
	Default	<i>Data flash memory size of the selected microcontroller</i>
	Modifying	Changes not allowed
Chip select	Select the chip select used for mapping of the data flash memory. This property appears only when the [Use DataFlash memory area] property is set to [Yes].	
	Default	<i>Chip select of the selected microcontroller</i>
	Modifying	<b>[IECUBE]</b> - <b>[V850ES]</b> Select from the drop-down list. - <b>[V850E1]</b> Changes not allowed <b>For other than [IECUBE]</b> Changes not allowed
	Available values	<i>Chip select values that can be used by the selected microcontroller</i> <sup>Note</sup> .

**Note** The selectable chip select values differ depending on the selected microcontroller.

### (3) [Clock]

The detailed information on clocks is displayed and its configuration can be changed.

Main clock frequency [MHz]  [V850E1][V850ES] (except [Simulator])	Specify the main clock frequency (before multiplication) in MHz unit.  This property does not appear when the [CPU clock frequency[MHz]] property is shown.	
	Default	<ul style="list-style-type: none"> <li>- <b>[V850E1][V850ES]</b></li> <li>4.00</li> <li>- <b>[V850E2]</b></li> <li>8.00</li> </ul>
	Modifying	Select from the drop-down list or directly enter from the keyboard.
	Available values	<ul style="list-style-type: none"> <li>- Either one of the following from the drop-down list</li> </ul> <p><b>[V850E1][V850ES]</b></p> <p><b>For other than [Simulator]</b> 2.50, 4.00, 5.00, 6.00, 8.00, 13.50, 18.00 (unit: MHz)</p> <p><b>[Simulator]</b> 1.00, 2.00, 3.00, 3.57, 4.00, 4.19, 4.91, 5.00, 6.00, 8.00, 8.38, 10.00, 12.00, 16.00, 20.00, 25.00, 30.00, 32.00, 33.33, 34.00, 40.00, 48.00, 50.00, 64.00, 80.00 (unit: MHz)</p> <p><b>[V850E2]</b></p> <p><b>For other than [Simulator]</b> 4.00, 5.00, 7.20, 8.00, 9.60, 10.00, 13.50, 16.00 (unit: MHz)</p> <p><b>[Simulator]</b> 1.00, 2.00, 3.00, 3.57, 4.00, 4.19, 4.91, 5.00, 6.00, 7.20, 8.00, 8.38, 9.60, 10.00, 12.00, 16.00, 20.00, 25.00, 30.00, 32.00, 33.33, 34.00, 40.00, 48.00, 50.00, 64.00, 80.00 (unit: MHz)</p> <ul style="list-style-type: none"> <li>- Directly enter the numbers ranged below</li> </ul> <p>0.001 to 999.999 (unit: MHz)</p>
		<b>[IECUBE2]</b>  Specify the clock frequency for using trace function in MHz unit.  <b>[MINICUBE][MINICUBE2][E1][E20]</b>  Specify the main clock frequency (after multiplication) in MHz unit.  This property appears only for some products of V850E2.
CPU clock frequency[MHz]  [V850E2] (except [Simulator])	Default	80.00
	Modifying	<p><b>[IECUBE2]</b></p> <p>Directly enter from the keyboard.</p> <p><b>[MINICUBE][MINICUBE2][E1][E20]</b></p> <p>Select from the drop-down list or directly enter from the keyboard.</p>
	Available values	<ul style="list-style-type: none"> <li>- Either one of the following from the drop-down list</li> </ul> <p>80.00, 100.00 (unit: MHz)</p> <ul style="list-style-type: none"> <li>- Directly enter the numbers ranged below</li> </ul> <p>0.001 to 999.999 (unit: MHz)</p>
		Specify the main clock frequency multiplier.
		<p>Default</p> <p>1</p>
Main clock multiply rate  [V850E1][V850ES] (except [Simulator])	Modifying	Select from the drop-down list or directly enter from the keyboard.
	Available values	<ul style="list-style-type: none"> <li>- Either one of the following from the drop-down list</li> </ul> <p>1, 2, 3, 4, 5, 6, 7, 8, 9, 10</p> <ul style="list-style-type: none"> <li>- Directly enter the numbers ranged below</li> </ul> <p>Integer number between 1 and 99</p>

Sub clock frequency[kHz] <b>[V850E1][V850ES]</b>	Specify the sub clock frequency in kHz unit. This property appears only when the selected microcontroller supports a sub clock.	
	Default	<b>For other than [Simulator]</b> <i>The minimum usable sub clock frequency</i> <b>[Simulator]</b> 32.768
	Modifying	Select from the drop-down list or directly enter from the keyboard.
	Available values	- Either one of the following from the drop-down list <b>For other than [Simulator]</b> Sub clock frequency values that can be used by the selected microcontroller <sup>Note</sup> <b>[Simulator]</b> 32.768 - Directly enter the numbers ranged below 0.001 to 999.999 (unit: kHz)
Monitor clock <b>[V850E1][V850ES]</b> (except <b>[Simulator]</b> )	Select a clock for monitor programs to operate while the program is stopped. This property appears only when the selected microcontroller supports a sub clock.	
	Default	System
	Modifying	Select from the drop-down list.
	Available values	System      Operates with main clock. User          Operates with the clock that the program specified.
	TCK/DCK clock[MHz]  <b>[V850E1][V850ES]</b> <b>[MINICUBE]</b> <b>[E1/E20(JTAG)]</b>	Select a clock supplied to the debug control unit (DCU). Usually, however, [10MHz] must be selected. When [20MHz] is specified, it may not be possible to connect to the debug tool.
Timer clock frequency[MHz] <b>[V850E2]</b> (except <b>[IECUBE2][Simulator]</b> )	Default	10MHz
	Modifying	Select from the drop-down list. Note that changes can be made only when disconnected from the debug tool.
	Available values	10MHz, 20MHz
	Specify the clock frequency for using timer function.	
	Default	80.00
Select Timer/Trace clock frequency <b>[Simulator]</b>	Modifying	Directly enter from the keyboard. Note that changes cannot be made when the <b>[CPU clock frequency[MHz]]</b> property is shown (this property is fixed to the same value as the <b>[CPU clock frequency]</b> property).
	Available values	0.001 to 999.999 (unit: MHz)
	Select the clock frequency for using timer/trace function.	
	Default	CPU clock frequency
	Modifying	Select from the drop-down list.
Available values	CPU clock frequency	Uses the CPU clock frequency.
	Specify clock frequency	Specifies an arbitrary frequency (property items to specify become valid in the lower area).

Unit of Timer/Trace clock frequency  [Simulator]	Select the unit of the clock frequency for timer/trace.  This property appears only when the [Select Timer/Trace clock frequency] property is set to [Specify clock frequency].		
	Default	MHz	
	Modifying	Select from the drop-down list.	
	Available values	MHz	The unit of the frequency is in MHz.
		KHz	The unit of the frequency is in kHz.
Timer/Trace clock frequency  [Simulator]	The operation of this property differs depending on the specification with the [Select Timer/Trace clock frequency] property.  - When [Specify clock frequency] is specified Specify the clock frequency for timer/trace.  - When [CPU clock frequency] is specified, displays the following (changes not allowed) While disconnected from the debug tool:     [---_---] While connected to the debug tool:       [CPU clock frequency]		
	Default	<ul style="list-style-type: none"> <li>- [V850E1][V850ES]</li> <li>    4.00</li> <li>- [V850E2]</li> <li>    8.00</li> </ul>	
	Modifying	Directly enter from the keyboard.	
	Available values	1 kHz to 999.999 MHz  Unit is depending on the specification with the [Unit of Timer/Trace clock frequency] property.	

**Note** The usable sub clock frequency values differ depending on the type of the selected microcontroller.

If the frequency value which can be use is fixed, the drop-down list does not appear.

#### (4) [Connection with Target Board] (except [MINICUBE][E20(LPD)/(JTAG)][Simulator])

The detailed information on the connection to the target board is displayed and its configuration can be changed.

Connecting with target board  [IECUBE] [IECUBE2]	Select if the target board is connected to IECUBE/IECUBE2 or not.		
	Default	No	
	Modifying	Select from the drop-down list.  Note that changes can be made only when disconnected from the debug tool.	
	Available values	Yes	Target board is connected.
		No	Target board is not connected.
Communication method  [MINICUBE2] [E1/E20(Serial)] [EZ Emulator]	Select the communication method for the emulator to communicate in serial mode with microcontrollers on the target board.		
	Default	Depends on the selected microcontroller.	
	Modifying	Select from the drop-down list.  Note that changes can be made only when disconnected from the debug tool.	
	Available values	Depends on the selected microcontroller <sup>Note</sup> .	

Power target from the emulator (MAX 200mA) <b>[E1]</b>	Select whether to supply power to the target board from E1.	
	Default	No
	Modifying	Select from the drop-down list. Note that changes can be made only when disconnected from the debug tool.
	Available values	Yes      Supplies power to the target board.
		No      Does not supply power to the target board.
Supply voltage <b>[E1]</b>	Select the power voltage supplied to the target board. This property appears only when the [Power target from the emulator (MAX 200mA)] property is displayed and also [Yes] is set to it.	
	Default	3.3V
	Modifying	Select from the drop-down list. Note that changes can be made only when disconnected from the debug tool.
	Available values	3.3V, 5.0V

**Note** The type of the port in the drop-down list differs depending on the selected microcontroller.

##### (5) [Flash] (except [IECUBE][Simulator])

The detailed information on the flash memory writing is displayed and its configuration can be changed.

Security ID <b>[MINICUBE] [MINICUBE2] [E1][E20] [EZ Emulator]</b>	Specify a security ID for reading codes in the internal ROM or internal flash memory <sup>Note</sup> . This property appears only when the selected microcontroller supports the ROM security function (on-chip debug security ID) for flash memory.	
	Default	- <b>[V850E1][V850ES]</b> FFFFFFFFFFFFFFFFFFFF - <b>[V850E2]</b> FFFFFFFFFFFFFFFFFFFF
	Modifying	Directly enter from the keyboard. Note that changes can be made only when disconnected from the debug tool.
	Available values	- <b>[V850E1][V850ES]</b> 20 digits hexadecimal number (10 bytes) - <b>[V850E2]</b> 24 digits hexadecimal number (12 bytes)
Erase flash ROM when starting <b>[MINICUBE2] [E1/E20(Serial)] [EZ Emulator]</b>	Select whether to erase flash ROM when connecting to the debug tool.	
	Default	No
	Modifying	Select from the drop-down list. Note that changes can be made only when disconnected from the debug tool.
	Available values	Yes      Erases the flash ROM when connecting to the debug tool. Note that after connecting to the debug tool, this property automatically selects [No].
		No      Does not erase flash ROM when connecting to the debug tool.

Using the flash self programming <b>[V850E2]</b> <b>[IECUBE2]</b> <b>[MINICUBE]</b> <b>[E1/E20(LPD)]</b> <b>[E1/E20(JTAG)]</b>	Select whether to rewrite the internal flash ROM by using the flash self library of the flash self programming function.  Note that when conducting hot plug-in connection, the setting of this property will be invalid.	
	Default	No
	Modifying	Select from the drop-down list.  Note that changes can be made only when disconnected from the debug tool.
	Available values	Yes Rewrites the internal flash ROM. If [Yes] is selected, the internal flash ROM will not be cashed.
		No Rewrites the flash memory with the normal mode.

**Note** When you change the setting of the property, a message appears prompting you to select whether or not to change the security ID of the build tool (except for the V850E2 core).

For details on the on-chip debug security ID, see User's Manual of the emulator.

#### (6) [Configuration] [Simulator]

The detailed information when customizing the simulator is displayed and its configuration can be changed.

Use simulator configuration file	Select whether to use the simulator configuration file to perform user customization (adding of user models) of the simulator.	
	Default	No
	Modifying	Select from the drop-down list.  Note that changes can be made only when disconnected from the debug tool.
	Available values	Yes Uses the simulator configuration file.
		No Does not use the simulator configuration file.
Simulator configuration file	Specify the simulator configuration file to be use.  This property appears only when the [Use simulator configuration file] property is set to [Yes].	
	Default	Blank
	Modifying	Directly enter from the keyboard, or specify with the <a href="#">Select Simulator Configuration File dialog box [Simulator]</a> opened by clicking the [...] button.  Note that changes can be made only when disconnected from the debug tool.

#### (7) [Programmable I/O] [V850E1][V850ES]

The detailed information on the programmable I/O area is displayed and its configuration can be changed.

Change this setting to temporarily change values while debugging. To set a common value for the project, in the Property panel of the build tool, on the [Common Options] tab, in the [Device] category, set the value in [Programmable I/O area start address] property.

Use Programmable I/O area	Select whether to use the programmable I/O area.	
	Default	No
	Modifying	Select from the drop-down list.  Note that changes can be made only when the selected microcontroller supports the programmable I/O area.
	Available values	Yes Uses the programmable I/O area.
		No Does not use the programmable I/O area.

Programmable I/O area start address	The address is aligned to 16 Kbytes. This property appears only when the [Use Programmable I/O area] property is set to [Yes]. Specify the start address of the programmable I/O area.
Default	0
Modifying	Directly enter from the keyboard.
Available values	Address within the address range of the programmable I/O area.

### [Debug Tool Settings] tab

This tab is used to display the detailed information categorized by the following and the configuration can be changed.

- (1) [Memory]
- (2) [Access Memory While Running]
- (3) [Set Event While Running] (except [Simulator])
- (4) [Break]
- (5) [Fail-safe Break] [IECUBE]
- (6) [Trace] [IECUBE][IECUBE2][Simulator]
- (7) [Timer] [IECUBE][IECUBE2][Simulator]
- (8) [Coverage] [IECUBE][IECUBE2][Simulator]
- (9) [Mask for Input Signal] (except [Simulator])
- (10) [External Flash Memory Download] [IECUBE][IECUBE2][MINICUBE][E1/E20(LPD)/(JTAG)]
- (11) [Simulator GUI] [Simulator]

Figure A-14. Property Panel: [Debug Tool Settings] Tab [IECUBE]




Figure A-15. Property Panel: [Debug Tool Settings] Tab [IECUBE2]




Figure A-16. Property Panel: [Debug Tool Settings] Tab [MINICUBE][E1/E20(JTAG)] ([V850E1][V850ES])




Figure A-17. Property Panel: [Debug Tool Settings] Tab [MINICUBE][E1/E20(LPD)/(JTAG)] ([V850E2])




Figure A-18. Property Panel: [Debug Tool Settings] Tab [MINICUBE2][E1/E20(Serial)][EZ Emulator]




Figure A-19. Property Panel: [Debug Tool Settings] Tab [Simulator] ([V850E1][V850ES])





Figure A-20. Property Panel: [Debug Tool Settings] Tab [Simulator] ([V850E2])



**[Description of each category]****(1) [Memory]**

The detailed information on memories is displayed and its configuration can be changed.

For details on memory types that are displayed, see the "[Memory Mapping dialog box](#)".

Memory mappings	Current memory mapping status is displayed by the types of memory area <sup>Note</sup> .	
	Default	[Total number of the memory mapping types]
	Modifying	Specify with the <a href="#">Memory Mapping dialog box</a> . The Memory Mapping dialog box is opened by clicking the [...] button that appears at the right edge of this field when you select the mapping value (you cannot change the mapping value on this panel).
	Displayed Content	Displays the memory mapping status by the types of memory area. The following detailed information is displayed by clicking the "+" mark of each memory type. - Memory type - Start address - End address - Access width[bits]
Verify on writing to memory (except <b>[Simulator]</b> )	Select whether to perform a verify check when the memory value is initialized.	
	Default	Yes
	Modifying	Select from the drop-down list.
	Available values	Yes
		Executes the verify check.
	No	Does not execute the verify check.

**Note** The type is of the memory mapping area registered in the device file.

**(2) [Access Memory While Running]**

The detailed information on memory accesses while executing a program (real-time display update function: see "[\(4\) Display/modify the memory contents during program execution](#)") is displayed and its configuration can be changed.

Access during the execution <b>[V850E2]</b> <b>[IECIBE2]</b> <b>[MINICUBE]</b> <b>[E1/E20(LPD)]</b> <b>[E1/E20(JTAG)]</b>	Select whether to allow access to the internal RAM area during execution of a program. When the [ <a href="#">Using the flash self programming</a> ] property in the [Flash] category is set to [No], the internal ROM area is subject to this setting, as with the internal RAM.	
	Default	No
	Modifying	Select from the drop-down list.
	Available values	Yes
		Accesses to the internal RAM area during execution of a program.
	No	Does not access to the internal RAM area during execution of a program.

Access by stopping execution (except [Simulator])	<p>For a memory area not accessible during execution of a program (e.g. target memory//O register), specify whether to allow access to the area by temporary stopping the execution. However, for the internal RAM area, the access is allowed without temporary stopping regardless of this setting (if the [Using the flash self programming] property in the [Flash] category is set to [No], then the internal ROM area is handled the same as the internal RAM area).</p> <p><b>[V850E2]</b></p> <p>This property appears only when the selected microcontroller is the single-core product and the [Access during the execution] property is set to [Yes].</p> <table border="1"> <tr> <td>Default</td><td colspan="2">No</td></tr> <tr> <td>Modifying</td><td colspan="2">Select from the drop-down list.</td></tr> <tr> <td rowspan="2">Available values</td><td>Yes</td><td colspan="2">Temporarily stops execution and accesses to the memory.</td></tr> <tr> <td>No</td><td colspan="2" rowspan="2">Does not access to the memory during program execution.</td></tr> </table>			Default	No		Modifying	Select from the drop-down list.		Available values	Yes	Temporarily stops execution and accesses to the memory.		No	Does not access to the memory during program execution.	
Default	No															
Modifying	Select from the drop-down list.															
Available values	Yes	Temporarily stops execution and accesses to the memory.														
	No	Does not access to the memory during program execution.														
Access by release HALT mode <b>[IECUBE]</b> <b>[IECUBE2]</b> <b>[MINICUBE]</b> <b>[E1/E20(LPD)]</b> <b>[E1/E20(JTAG)]</b>	<p>Select whether to allow access to a memory area other than the internal RAM(e.g. CPU registers/I/O registers) by releasing the HALT mode.</p> <p><b>[V850E2]</b></p> <p>This property appears only when the [Access by stopping execution] property is set to [Yes].</p> <table border="1"> <tr> <td>Default</td><td colspan="2">Yes</td></tr> <tr> <td>Modifying</td><td colspan="2">Select from the drop-down list.</td></tr> <tr> <td rowspan="2">Available values</td><td>Yes</td><td colspan="2">For a memory area other than the internal RAM, releases the HALT mode to access to it.</td></tr> <tr> <td>No</td><td colspan="2" rowspan="2">For a memory area other than the internal RAM, does not release the HALT mode to access to it.</td></tr> </table>			Default	Yes		Modifying	Select from the drop-down list.		Available values	Yes	For a memory area other than the internal RAM, releases the HALT mode to access to it.		No	For a memory area other than the internal RAM, does not release the HALT mode to access to it.	
Default	Yes															
Modifying	Select from the drop-down list.															
Available values	Yes	For a memory area other than the internal RAM, releases the HALT mode to access to it.														
	No	For a memory area other than the internal RAM, does not release the HALT mode to access to it.														
Update display during the execution <b>[IECUBE]</b>	<p>Select whether to update the display in the <a href="#">Watch panel/Memory panel</a> during a program execution.</p> <p><b>[IECUBE]</b></p> <p>This property becomes invalid when the [Use for trace data] property in the [Trace] category is set to [Trace].</p> <table border="1"> <tr> <td>Default</td><td colspan="2">Yes</td></tr> <tr> <td>Modifying</td><td colspan="2">Select from the drop-down list.</td></tr> <tr> <td rowspan="2">Available values</td><td>Yes</td><td colspan="2">Updates the display during program execution.</td></tr> <tr> <td>No</td><td colspan="2" rowspan="2">Does not update the display during program execution.</td></tr> </table>			Default	Yes		Modifying	Select from the drop-down list.		Available values	Yes	Updates the display during program execution.		No	Does not update the display during program execution.	
Default	Yes															
Modifying	Select from the drop-down list.															
Available values	Yes	Updates the display during program execution.														
	No	Does not update the display during program execution.														
Display update interval[ms]	<p>Specify the interval in 100ms unit to update the contents in the <a href="#">Watch panel/Memory panel</a> display while executing a program.</p> <p>This property appears only when the [Update display during the execution] property is set to [Yes].</p> <table border="1"> <tr> <td>Default</td><td colspan="2">500</td></tr> <tr> <td>Modifying</td><td colspan="2">Directly enter from the keyboard.</td></tr> <tr> <td>Available values</td><td colspan="2">Integer number between 100 and 65500 (rounding up the fractions less than 100 ms).</td></tr> </table>			Default	500		Modifying	Directly enter from the keyboard.		Available values	Integer number between 100 and 65500 (rounding up the fractions less than 100 ms).					
Default	500															
Modifying	Directly enter from the keyboard.															
Available values	Integer number between 100 and 65500 (rounding up the fractions less than 100 ms).															

<b>[IECUBE]</b>  <b>[IECUBE]</b>  <b>[IECUBE2]</b> <b>[MINICUBE]</b> <b>[E1/E20(LPD)]</b> <b>[E1/20(JTAG)]</b>	Update the contents of the display while executing the program by setting the area shown in the <a href="#">Watch panel/Memory panel</a> automatically as much as possible to the target area for the real-time display update function.  This property appears only when the [Update display during the execution] property is set to [Yes].				
	Default	Yes			
	Modifying	Select from the drop-down list.			
	Available values	<table border="1"> <tr> <td>Yes</td><td>Automatically sets the real-time display update function.</td></tr> <tr> <td>No</td><td>Does not set the real-time display update function.</td></tr> </table>	Yes	Automatically sets the real-time display update function.	No
Yes	Automatically sets the real-time display update function.				
No	Does not set the real-time display update function.				

### (3) [Set Event While Running] (except [Simulator])

The detailed information on the function of the event setting during program execution is displayed and its configuration can be changed.

<b>Set event by stopping execution momentarily</b>	Select whether to forcibly pause the execution for events that cannot be set while executing the program or operating the tracer/timer.  For details on the event types that are affected by this property, see " <a href="#">(2) Event types that can be set and deleted during execution</a> ".	
	Default	No
	Modifying	Select from the drop-down list.
	Available values	Yes Sets these events by stopping the program execution or the tracer/timer operation momentarily.
		No Does not allow to set these events during program execution or the tracer/timer operation.

### (4) [Break]

The detailed information on break functions is displayed and its configuration can be changed.

<b>First using type of breakpoint (except [Simulator])</b>  <b>[IECUBE]</b> <b>[IECUBE2]</b> <b>[MINICUBE]</b> <b>[E1/E20(LPD)]</b> <b>[E1/20(JTAG)]</b>	Select the type of the breakpoint to use with priority when setting it at the source line or the execution address with a one click operation of the mouse in the <a href="#">Editor panel/Disassemble panel</a> .  This property does not appear when the selected microcontroller supports only one breakpoint type.	
	Default	Software break
	Modifying	Select from the drop-down list.
	Available values	Software break Sets software breakpoint with priority.
		Hardware break Sets hardware breakpoint with priority.
	Select whether to terminate the peripheral emulation while stopping the program execution.	
	Default	No
	Modifying	Select from the drop-down list.
	Available values	Yes Terminates the peripheral emulation.
		No Does not terminate the peripheral emulation.

<b>Use open break function</b> <b>[IECUBE]</b> <b>[IECUBE2]</b> <b>[MINICUBE]</b> <b>[E1/E20(LPD)]</b> <b>[E1/E20(JTAG)]</b>	Select whether to use the open break function. This property appears only when the selected microcontroller supports the open break function.		
	Default	No(Output signal)	
	Modifying	Select from the drop-down list.	
	Available values	Yes(Hi-Z)	The open break target pin becomes the Hi-Z state after the CPU is stopped.
		No(Output signal)	The open break target pin outputs the signal even after the CPU is stopped.
	<b>Execute instruction at breakpoint when break</b> <b>[Simulator]</b>  Select the timing to stop the program execution by breakpoints either after or before the execution of the instruction at the breakpoint.		
<b>[Simulator]</b>  Select the timing to stop the program execution by breakpoints either after or before the execution of the instruction at the breakpoint.	Default	No	
	Modifying	Select from the drop-down list.	
	Available values	Yes	Breaks after executing the instruction <sup>Note</sup> .
		No	Breaks before executing the instruction.

**Note** When [Yes] is selected, all of the action events currently being set are handled as Hardware Break events (see "2.14 Set an Action into Programs").

#### (5) [Fail-safe Break] [IECUBE]

The detailed information on fail-safe break functions is displayed and its configuration can be changed.

<b>Stop when wrote to Internal ROM</b>	Select whether to stop the execution right after writing to the internal ROM <sup>Note</sup> . This property is invalid when the selected microcontroller is a ROMless product.		
	Default	Yes	
	Modifying	Select from the drop-down list.	
	Available values	Yes	Stops right after writing.
		No	Does not stop even after writing.
	<b>Stop when accessed to non-mapping Internal ROM</b> Select whether to stop the execution right after accessing to the non-mapping area of the internal ROM <sup>Note</sup> . This property is invalid when the selected microcontroller is a ROMless product.		
<b>Stop when accessed to non-mapping Internal ROM</b>	Default	Yes	
	Modifying	Select from the drop-down list.	
	Available values	Yes	Stops right after accessing.
		No	Does not stop even after accessing.
<b>Stop when accessed to non-mapping Internal RAM</b>	Select whether to stop the execution right after accessing to the non-mapping area of the internal RAM <sup>Note</sup> .		
	Default	Yes	
	Modifying	Select from the drop-down list.	
	Available values	Yes	Stops right after accessing.
		No	Does not stop even after accessing.

Verify when wrote to Read-only Internal RAM	Select whether to perform a verify check that detects a write operation to the write protected area in the internal RAM when the program execution is stopped <sup>Note</sup> .		
	Default	Yes	
	Modifying	Select from the drop-down list.	
	Available values	Yes	Outputs messages when write operations have been detected.
		No	Does not check a write operation.
Stop when read from read protected I/O Register	Select whether to stop the execution right after reading from the read protected area in the I/O register area.		
	Default	Yes	
	Modifying	Select from the drop-down list.	
	Available values	Yes	Stops right after reading.
		No	Does not stop even after reading.
Stop when wrote to write protected I/O Register	Select whether to stop the execution right after writing to the write protected area in the I/O register area.		
	Default	Yes	
	Modifying	Select from the drop-down list.	
	Available values	Yes	Stops right after writing.
		No	Does not stop even after writing.
Stop when accessed to non-mapping I/O Register	Select whether to stop the execution right after accessing to the non-mapping area in the I/O register area.		
	Default	Yes	
	Modifying	Select from the drop-down list.	
	Available values	Yes	Stops right after accessing.
		No	Does not stop even after accessing.
Stop when wrote to write protected External memory	Select whether to stop the execution right after writing to the write protected external memory.		
	Default	Yes	
	Modifying	Select from the drop-down list.	
	Available values	Yes	Stops right after writing.
		No	Does not stop even after writing.
Stop when accessed to non-mapping External Memory	Select whether to stop the execution right after accessing to the non-mapping area of the external memory.		
	Default	Yes	
	Modifying	Select from the drop-down list.	
	Available values	Yes	Stops right after accessing.
		No	Does not stop even after accessing.

**Note** CPU reset is generated automatically if you change the setting of the property.

**(6) [Trace] [IECUBE][IECUBE2][Simulator]**

The detailed information on trace functions is displayed and its configuration can be changed.

**Cautions 1. [IECUBE]**

**Some of the trace function, the real-time display update function (RRM function) and the coverage function are used on a mutually exclusive basis.**

**2. [IECUBE2]**

**Some of the trace function, the timer function (except for the Run-Break timer) and the coverage function are used on a mutually exclusive basis.**

**Note, however, that only the trace function can be used in this version.**

Use for trace data  [IECUBE]  [IECUBE2]	<b>[IECUBE]</b>  Some of the trace function, the real-time display update function (RRM function) and the coverage function are used on a mutually exclusive basis. Accordingly, specify a function used preferentially.  <b>[IECUBE2]</b>  Some of the trace function, the timer function (except for the Run-Break timer) and the coverage function are used on a mutually exclusive basis. Accordingly, specify a function used preferentially.  See " <a href="#">2.11.1 Configure the trace operation</a> " for details on this property.		
	Default	<b>[IECUBE]</b>  RRM  <b>[IECUBE2]</b>  Trace	Modifying
Select from the drop-down list.			Available values
Available values  [IECUBE]	Trace	Uses the trace function preferentially.	Trace
	RRM	Uses the real-time display update function (RRM function) preferentially.	RRM
	Coverage	Uses the coverage function preferentially.	Coverage
Available values  [IECUBE2]	Trace	Uses the trace function preferentially.	Trace
	Timer	Uses the timer function preferentially.	Timer
	Coverage	Uses the coverage function preferentially.	Coverage
Select trace data  [IECUBE]  [IECUBE2]	Select the type of the trace data to be acquired.  This property appears only when the [Use for trace data] property is set to [Trace].  See " <a href="#">2.11.1 Configure the trace operation</a> " for details on this property.		
Available values	Default	Branch PC + Access Data	
	Modifying	Select from the drop-down list.	
	Branch PC  All PC [IECUBE]  Access Data  Branch PC + Access Data  All PC + Access Data [IECUBE]  Access PC + Access Data  Branch PC + Access PC + Access Data	Branch PC	
		All PC [IECUBE]	
		Access Data	
		Branch PC + Access Data	
		All PC + Access Data [IECUBE]	
		Access PC + Access Data	
		Branch PC + Access PC + Access Data	

DMA is traced [IECUBE2]	Select whether to perform the DMA trace (Direct Memory Access Trace).				
	Default	No			
	Modifying	Select from the drop-down list.			
	Available values	Yes	Performs the DMA trace.		
		No	Does not perform the DMA trace.		
Select DMA trace data [IECUBE2]	Select the type of the DMA trace data to be acquired.				
	This property appears only when the [DMA is traced] property is set to [Yes].				
	See "2.11.1 Configure the trace operation" for details on this property.				
	Default	Access Type + Access Address + Data Size + Access Data			
	Modifying	Select from the drop-down list.			
	Available values	Access Type + Access Address + Data Size + Access Data			
		Access Type + Access Address + Data Size			
		Access Type + Channel Number			
		Access Type + Channel Number + Transfer Count			
		Access Type + Access Data + Channel Number + Transfer Count			
Trace priority [IECUBE] [IECUBE2]	Select which item should be given priority when collecting the trace data.				
	This property appears only when the [Use for trace data] property is set to [Trace].				
	Default	Speed priority			
	Modifying	Select from the drop-down list.			
	Available values	Speed priority	Traces giving priority to the real-time performance.		
		Data priority	Traces after stopping the execution pipeline of the CPU temporarily so that no data is missed.		
Use trace function [Simulator]	Select whether to use the trace function <sup>Note 1</sup> .				
	Default	No			
	Modifying	Select from the drop-down list.			
	Available values	Yes	Uses trace functions.		
		No	Does not use trace functions.		
Clear trace memory before running	Select whether to clear the trace memory before executing.				
	Default	Yes			
	Modifying	Select from the drop-down list.			
	Available values	Yes	Clears the trace memory.		
		No	Does not clear the trace memory.		

Operation after trace memory is full	Select the operation after the trace memory is full with the collected trace data.		
	Default	Non stop and overwrite to trace memory	
	Modifying	Select from the drop-down list.	
	Available values	Non stop and overwrite to trace memory	Continues overwriting trace data even after trace memory is used up.
		Stop trace	Stops overwriting trace data when trace memory is used up (the program execution will not be stopped).
		Stop	Stops running the program and overwriting trace data when trace memory is used up.
Accumulate trace time [Simulator]	Select whether to display the accumulated tracing time in the <a href="#">Trace panel [IECUBE][IECUBE2][Simulator]</a> .		
	Default	No	
	Modifying	Select from the drop-down list.	
	Available values	Yes	Displays the accumulated tracing time.
		No	Displays the trace time with differential value.
Rate of frequency division of trace time tag  [IECUBE]  [Simulator]	Select the frequency division ratio of the counter to be used for time tag display (the [Time] item in the <a href="#">Trace panel [IECUBE][IECUBE2][Simulator]</a> ).  Changing the frequency division ratio here changes the number of clocks necessary to count up a counter value which is displayed in the time tag.		
	Default	<b>[IECUBE]</b> 1/1(20ns/1.4min)  <b>[Simulator]</b> 1/1	
	Modifying	Select from the drop-down list.	
	Available values	<b>[IECUBE]</b> 1/1(20ns/1.4min), 1/2(40ns/2.8min), 1/4(80ns/5.7min), 1/8(160ns/11.4min), 1/16(320ns/22.8min), 1/32(640ns/45.6min), 1/64(1280ns/1.5h), 1/128(2560ns/3.0h), 1/256(5120ns/6.0h), 1/512(10240ns/12.2h), 1/1024(20480ns/24.4h), 1/2048(40960ns/48.8h), 1/4096(81920ns/97.6h)  (Values in "(" indicate the resolution, and the maximum measurement time when using a time tag counter of 32-bit and a external clock of 50 MHz).  <b>[Simulator]</b> 1/1, 1/2, 1/4, 1/8, 1/16, 1/32, 1/64, 1/128, 1/256, 1/512, 1/1K, 1/4K, 1/8K, 1/16K, 1/64K, 1/256K, 1/1M	

Trace memory size[frames]	Select the memory size for storing the trace data by the trace frame numbers <sup>Note 2</sup> .	
	Default	[IECUBE][IECUBE2] 8K [Simulator] 4K
Modifying	Select from the drop-down list.	
Available values	<b>[IECUBE]</b> 8K, 32K, 64K, 128K, 256K <b>[IECUBE2]</b> 8K, 32K, 64K, 128K, 256K, 512K <b>[Simulator]</b> 4K, 8K, 12K, 16K, 20K, 24K, 28K, 32K, 36K, 40K, 44K, 48K, 52K, 56K, 60K, 64K, 128K, 192K, 256K, 320K, 384K, 448K, 512K, 576K, 640K, 704K, 768K, 832K, 896K, 960K, 1M, 2M, 3M	
Enable trace data complement <b>[IECUBE]</b> <b>[IECUBE2]</b>	Select whether to perform complementary display when displaying the collected trace data <sup>Note 3</sup> .	
Default	Yes	
Modifying	Select from the drop-down list.	
Available values	Yes	Performs complementary display of trace data.
	No	Does not perform complementary display of trace data.

- Notes 1.** This property is automatically set to [Yes] when selecting [Start Tracing]/[Stop Tracing] from the context menu in the [Editor panel/Disassemble panel](#).
2. The trace frame is a unit of trace data. Each fetch/write/read uses one trace frame.
  3. Complement display of instructions between branch instructions that cannot be traced by hardware can be performed.
- The trace memory is cleared automatically if you change the setting of this property.

#### (7) [Timer] [IECUBE][IECUBE2][Simulator]

The detailed information on timer functions is displayed and its configuration can be changed.

**Caution [IECUBE2]**

All of the properties in this category become invalid if the [\[Use for trace data\]](#) property in the [\[Trace\]](#) category is not set to [\[Timer\]](#).

Rate of frequency division of timer <b>[IECUBE]</b> <b>[IECUBE2]</b>	<b>[IECUBE]</b> Select the frequency division ratio of the timer counter (32 bits, 50 MHz) used for timer measurement.				
	<b>[IECUBE2]</b> Select the frequency division ratio of the timer counter (33 bits, 200 MHz) used for timer measurement.				
	Default	<b>[IECUBE]</b> 1/1(20ns/1.4min) (Resolution/maximum measurement time are displayed in "()"). <b>[IECUBE2]</b> 1/1(5ns/42.9s) (Resolution/maximum measurement time are displayed in "()").			
	Modifying	Select from the drop-down list.			
Available values	<b>[IECUBE]</b> 1/1(20ns/1.4min), 1/2(40ns/2.8min), 1/4(80ns/5.7min), 1/8(160ns/11.4min), 1/16(320ns/22.8min), 1/32(640ns/45.6min), 1/64(1280ns/1.5h), 1/128(2560ns/3.0h), 1/256(5120ns/6.0h), 1/512(10240ns/12.2h), 1/1024(20480ns/24.4h), 1/2048(40960ns/48.8h), 1/4096(81920ns/97.6h) <b>[IECUBE2]</b> 1/1(5ns/42.9s), 1/2(10ns/1.4min), 1/4(20ns/2.8min), 1/8(40ns/5.71min), 1/16(80ns/11.42min), 1/32(160ns/22.8min), 1/64(320ns/45.6min), 1/128(640ns/1.5h), 1/256(1280ns/3.0h), 1/512(2560ns/6.0h), 1/1024(5120ns/12.2h), 1/2048(10240ns/24.4h), 1/4096(20480ns/48.8h), 1/8192(40960ns/97.6h), 1/16384(81920ns/195.2h)				
Use timer function <b>[Simulator]</b>	Select whether to use the timer function.				
Default	No				
Modifying	Select from the drop-down list.				
Available values	Yes	Uses timer functions.			
No	Does not use timer functions.				

#### (8) [Coverage] [IECUBE][IECUBE2][Simulator]

The detailed information on coverage functions is displayed and its configuration can be changed.

##### Cautions 1. [IECUBE]

All of the properties in this category become invalid in any one of the following conditions:

- When no coverage board is mounted on IECUBE used
- When the [Use for trace data] property in the [Trace] category is set to other than [Coverage]

##### 2. [IECUBE2]

All of the properties in this category become invalid when the [Use for trace data] property in the [Trace] category is set to other than [Coverage].

<b>Use coverage function [Simulator]</b>	Select whether to use the coverage function.				
	Default	No			
	Modifying	Select from the drop-down list.			
	Available values	Yes	Uses coverage functions		
		No	Does not use coverage functions		
<b>Reuse coverage result [IECUBE][IECUBE2]</b>  [Simulator]  This property appears only when the [Use coverage function] property is set to [Yes].	Select whether to load/save the coverage measurement result when connecting to or disconnecting from the debug tool.				
	Default	No			
	Modifying	Select from the drop-down list.			
	Available values	Yes	Loads/saves the coverage measurement result.		
		No	Does not load/save the coverage measurement result.		
<b>Coverage area of measurement(1MBytes) [IECUBE] [Simulator]</b>  [IECUBE]  This property appears only when the [Use for trace data] property is set to [Coverage].  [Simulator]  This property appears only when the [Use coverage function] property is set to [Yes].	Specify the area that performs coverage measurement.				
	Specify the start address of any 1 Mbyte space other than the internal ROM area.				
	[IECUBE]  This property appears only when the [Use for trace data] property is set to [Coverage].				
	[Simulator]  This property appears only when the [Use coverage function] property is set to [Yes].				
	Default	<i>The start address of internal RAM area</i>			
<b>Available values</b>	Modifying	Directly enter from the keyboard.			
	Address without the address range of the internal ROM area (symbols cannot be used).				

#### (9) [Mask for Input Signal] (except [Simulator])

The detailed information on the masking input signal is displayed and its configuration can be changed.

<b>Mask NMI/n signal [IECUBE] [MINICUBE] [E1/E20(LPD)] [E1/E20(JTAG)]</b>	Select whether to mask NMI/n signal to prevent the signal input to emulators.		
	Default	No	
	Modifying	Select from the drop-down list.	
	Available values	Yes	Masks NMI/n signal
		No	Does not mask NMI/n signal
<b>Mask HLDREQ signal [IECUBE] [IECUBE2] [MINICUBE] [E1/E20(LPD)] [E1/E20(JTAG)]</b>	Select whether to mask HLDREQ signal to prevent the signal input to emulators.		
	Default	No <sup>Note 1</sup>	
	Modifying	Select from the drop-down list.	
	Available values	Yes	Masks HLDREQ signal
		No	Does not mask HLDREQ signal

Mask RESET signal (except [IECUBE2])	Select whether to mask RESET signal to prevent the signal input to emulators.		
	Default	No	
	Modifying	Select from the drop-down list.	
	Available values	Yes	Masks RESET signal
		No	Does not mask RESET signal
Mask STOP signal [IECUBE] [IECUBE2] [MINICUBE] [E1/E20(LPD)] [E1/E20(JTAG)]	Select whether to mask STOP signal to prevent the signal input to emulators.		
	Default	No	
	Modifying	Select from the drop-down list.	
	Available values	Yes	Masks STOP signal
		No	Does not mask STOP signal
Mask WAIT signal [IECUBE] [IECUBE2] [MINICUBE] [E1/E20(LPD)] [E1/E20(JTAG)]	Select whether to mask WAIT signal to prevent the signal input to emulators.		
	Default	No <sup>Note 1</sup>	
	Modifying	Select from the drop-down list.	
	Available values	Yes	Masks WAIT signal.
		No	Does not mask WAIT signal.
Mask DBINT signal [V850E1][V850ES] [MINICUBE] [E1/E20(JTAG)]	Select whether to mask DBINT signal to prevent the signal input to emulators.		
	Default	No	
	Modifying	Select from the drop-down list.	
	Available values	Yes	Masks DBINT signal
		No	Does not mask DBINT signal
Mask of RESET signal [IECUBE2]	Select RESET signal to be masked.		
	Default	Mask TARGET RESET signal	
	Modifying	Select from the drop-down list.	
	Available values	Do not mask <sup>Note 2</sup>	Does not mask RESET signal.
		Mask TARGET RESET signal	Masks TARGET RESET signal.
		Mask TARGET RESET signal and INTERNAL RESET signal	Masks TARGET RESET signal and INTERNAL RESET signal.

**Notes 1. [IECUBE][IECUBE2]**

When the [Connecting with target board] property in the [Connection with Target Board] (except [MINICUBE][E20(LPD)/(JTAG)][Simulator]) category on the [Connect Settings] tab is set to [No], this property is fixed to [Yes] automatically after connecting to the debug tool (changes not allowed).

**2. [IECUBE2]**

When the [Connecting with target board] property in the [Connection with Target Board] (except [MINICUBE][E20(LPD)/(JTAG)][Simulator]) category on the [Connect Settings] tab is set to [No], this item does not appear.

**(10) [External Flash Memory Download] [IECUBE][IECUBE2][MINICUBE][E1/E20(LPD)/(JTAG)]**

The detailed information on downloading to an external flash memory is displayed and its configuration can be changed.

External Flash Memory Setting	Specify the external external flash memory information file (*.fdb) for downloading to the external flash memory and configure its download conditions.  The download conditions that correspond to the registered external flash memory information files are listed in the lower area, as the subproperty.  The names of files to be downloaded and their download conditions are listed in the lower area.	
	Default	[0]
	Modifying	Specify with the <a href="#">External Flash Memory Download dialog box</a> .  The Exterior Flash Memory Download dialog box is opened by clicking the [...] button that appears at right edge of this field when you select this property (you cannot specify the file to download on this panel).

**(11) [Simulator GUI] [Simulator]**

The detailed information on the Simulator GUI is displayed and its configuration can be changed.

**Caution After connecting to the debug tool, all the properties in this category will become invalid when a microcontroller whose Simulator does not support peripheral function simulations (instruction simulation version) is selected.**

Display Simulator GUI	Select whether to display the <a href="#">Simulator GUI window</a> to use the Simulator GUI.	
	Default	Yes
	Modifying	Select from the drop-down list.  (Changes not allowed during execution of a program.)
	Available values	Yes Uses the function of the Simulator GUI.
		No Does not use the function of the Simulator GUI.
Display Simulator GUI on top of other windows	Select whether to display the <a href="#">Simulator GUI window</a> in the forefront when program execution starts.  This property appears only when the [Display Simulator GUI] property is set to [Yes].	
	Default	Yes
	Modifying	Select from the drop-down list.
	Available values	Yes Displays it in the forefront.
		No Does not display it in the forefront.

### [Flash Self Emulation Settings] tab [IECUBE]


This tab is used to display the detailed information categorized by the following and the configuration can be changed.

Note that this tab appears only when the selected microcontroller incorporates the flash memory.

For the list of availability of emulation for flash function, and the cautions, see [\[Special notes on flash self programming emuration\]](#).

- (1) [Flash Self Emulation]
- (2) [Macro Service Error]
- (3) [Security Flag Emulation]
- (4) [Reset Vector/Boot Swap]

**Figure A-21. Property Panel: [Flash Self Emulation Settings] Tab**



### [Description of each category]

#### (1) [Flash Self Emulation]

The detailed information on flash self programming emulation functions is displayed and its configuration can be changed.

Flash self-programming	Select whether to use the flash self programming emulation function.	
	Default	No
	Modifying	Select from the drop-down list.
	Available values	Yes      Uses the flash self programming emulation function.
		No      Does not use the flash self programming emulation function.

Flash Macro service specification	Select the specification type of the flash macro service. This property appears only when the flash memory process is Type01 <sup>Note</sup> .		
	Default	Flash self programming Ver.2.00 or earlier	
	Modifying	Select from the drop-down list.	
	Available values	Flash self programming Ver.2.00 or earlier	Specifies Ver.2.00 or earlier for the specification type.
		Flash self programming Ver.3.00 or later	Specifies Ver.3.00 or later for the specification type.

**Note** The determination of the flash memory process is made when connected to the debug tool. Consequently, this will not be hidden when disconnected from the debug tool.

## (2) [Macro Service Error]

The detailed information on the flash macro service is displayed and its configuration can be changed.

The error returned when the flash memory is damaged will not be generated during normal emulation.

Generate FlashBlockErase error	Select whether to return error values in FlashBlockErase functions to emulate.		
	Default	No	
	Modifying	Select from the drop-down list.	
	Available values	Yes	Forcibly returns error values.
		No	Does not return error values.
Generate FlashBlockVerify error	Select whether to return error values in FlashBlockVerify functions to emulate.		
	Default	No	
	Modifying	Select from the drop-down list.	
	Available values	Yes	Forcibly returns error values.
		No	Does not return error values.
Generate FlashWordWrite error	Select whether to return error values in FlashWordWrite functions to emulate.		
	Default	No	
	Modifying	Select from the drop-down list.	
	Available values	Yes	Forcibly returns error values.
		No	Does not return error values.
Generate FlashBlockBlankCheck error	Select whether to return error values in FlashBlockBlankCheck functions to emulate.		
	Default	No	
	Modifying	Select from the drop-down list.	
	Available values	Yes	Forcibly returns error values.
		No	Does not return error values.
Generate FlashSetInfo error	Select whether to return error values in FlashSetInfo functions to emulate.		
	Default	No	
	Modifying	Select from the drop-down list.	
	Available values	Yes	Forcibly returns error values.
		No	Does not return error values.

Generate FlashFLMDCheck error	Select whether to return error values in FlashFLMDCheck functions to emulate.		
	Default	No	
	Modifying	Select from the drop-down list.	
	Available values	Yes	Forcibly returns error values.
		No	Does not return error values.

**(3) [Security Flag Emulation]**

The detailed information on the security flag emulation function is displayed and its configuration can be changed.

Disable flash ROM erase	Select whether to emulate to disable flash ROM erase. This property appears only when the flash memory used supports this function.		
	Default	No	
	Modifying	Select from the drop-down list.	
	Available values	Yes	Emulates to disable flash ROM erase.
		No	Does not emulate to disable flash ROM erase.
Disable block erase	Select whether to emulate to disable block erase.		
	Default	No	
	Modifying	Select from the drop-down list.	
	Available values	Yes	Emulates to disable block erase.
		No	Does not emulate to disable block erase.
Disable read	Select whether to emulate to disable reading. This property does not appear when the flash memory process is Type01 <sup>Note</sup> and the specification type of the flash self programming is Ver.2.00 or earlier.		
	Default	No	
	Modifying	Select from the drop-down list.	
	Available values	Yes	Emulates to disable reading.
		No	Does not emulate to disable reading.
Disable program	Select whether to emulate to disable writing.		
	Default	No	
	Modifying	Select from the drop-down list.	
	Available values	Yes	Emulates to disable writing.
		No	Does not emulate to disable writing.
Disable boot block cluster reprogram	Select whether to emulate to disable rewrite boot area. This property appears only when the flash memory process is Type02, Type03 or Type04 <sup>Note</sup> .		
	Default	No	
	Modifying	Select from the drop-down list.	
	Available values	Yes	Emulates to disable rewrite boot area.
		No	Does not emulate to disable rewrite boot area.

**Note** The determination of the flash memory process is made when connected to the debug tool.

**(4) [Reset Vector/Boot Swap]**

The detailed information on reset vector and boot swap functions is displayed and its configuration can be changed.

Reset vector address	Specify the reset vector address. This property appears only when the flash memory process is Type01 and the specification type of the flash self programming is Ver.3.00 or later <sup>Note 1</sup> .	
	Default	0
	Modifying	Directly enter from the keyboard.
	Available values	0x0 to 0xFFFFFFFF in hexadecimal number
Boot swap cluster	Specify the target area of boot swap clusters. The value set in this property is reflected to the target area in a boot block cluster <sup>Note 2</sup> . This property appears only when the flash memory process is Type04 <sup>Note 1</sup> .	
	Default	0
	Modifying	Directly enter from the keyboard.
	Available values	0 to 127 in decimal number

- Notes 1.** The determination of the flash memory process is made when connected to the debug tool. Consequently, this will not be hidden when disconnected from the debug tool.
- 2.** Prohibition of boot area rewriting can be set to the target area of boot swap clusters by using the microcontroller's security function.
- For the relationship between the value set in this property and the target area of boot block clusters, see "[Table 2-2. Relationship between Boot Swap Cluster and Boot Block Cluster](#)".

**[Special notes on flash self programming emuration]**

If you perform flash self programming on the IECUBE, check whether the flash functions shown below can be emulated, and check the related cautions.

**Table A-3. Flash Self Programming Type 01**

Flash Function	Functional Outline and Restriction	Availability of Emulation
FlashEnv	Flash environment initialization/end function	Emulated
FlashBlockErase	Block erasure function	Emulated
FlashWordWrite	One word writing function <b>Restriction:</b> If an address in the guard area is specified as the third argument, a fail-safe break occurs at an unexpected address.	Restricted
FlashBlockIVerify	Block internal verify processing function	Emulated
FlashBlockBlankCheck	Block blank check function	Emulated

Flash Function	Functional Outline and Restriction	Availability of Emulation
FlashGetInfo	Flash information acquisition function	
	Option = 2: CPU number and total number of blocks held by CPU <b>Restriction:</b> The device name (four-digit number) set in the Configuration dialog box is returned as the CPU number.	Restricted
	Option = 3: Security information	Emulated
	Option = 4: Acquisition of boot area swapping information <b>Restriction:</b> Boot area swapping information is not reflected.	Restricted
	Option = 5 + Block number: Acquisition of last address of block	Emulated
FlashSetInfo	Flash information setting function <b>Restriction:</b> The boot area swapping setting is ignored.	Restricted
FlashStatusCheck	Function for checking operation status of flash function that was executed most recently <b>Restriction:</b> For FlashBlockErase and FlashBlockBlankCheck, the timing at which the return value changes from FE_BUSY to FE_OK differs from that in the actual device.	Restricted
FlashBootSwap	Boot area block swapping function	Not emulated
FlashSetUserHandler	User interrupt handler registration function	Emulated
FlashFLMDCheck	FLMD0 pin status check function	Emulated
FlashSetInfoEx	Flash information setting function <b>Restriction:</b> The boot area swapping setting is ignored.	Restricted
FlashNWordRead	Function for reading N words <b>Restriction:</b> If an address in the guard area is specified as the third argument, a failsafe break occurs at an unexpected address.	Restricted

Table A-4. Flash Self Programming Type 02c

Flash Function	Functional Outline and Restriction	Availability of Emulation
FlashEnv	Flash environment initialization/end function	Emulated
FlashBlockErase	One block erasure function	Emulated
FlashWordWrite	One word writing function <b>Restriction:</b> If an address in the guard area is specified as the third argument, a failsafe break occurs at an unexpected address.	Restricted
FlashBlockIVerify	One block internal verify processing function	Emulated
FlashBlock-BlankCheck	One block blank check function	Emulated
FlashGetInfo	Flash information acquisition function	
	Option = 2 : CPU number and total number of blocks held by CPU <b>Restriction:</b> The device file name (four-digit number) is returned as the CPU number.	Restricted
	Option = 3 : Security information	Emulated
	Option = 4 : Acquisition of boot area swapping information <b>Restriction:</b> Boot area swapping information is not reflected.	Restricted
	Option = 5 + Block number : Acquisition of last address of block	Emulated

Flash Function	Functional Outline and Restriction	Availability of Emulation
FlashSetInfo	Flash information setting function <b>Restriction:</b> The boot area swapping setting is ignored.	Restricted
FlashBootSwap	Boot area block swapping function	Not emulated
FlashFLMDCheck	FLMD0 pin status check function	Emulated
FlashWordRead	Data reading function <b>Restriction:</b> If an address in the guard area is specified as the third argument, a fail-safe break occurs at an unexpected address.	Restricted

Table A-5. Flash Self Programming Type 03

Flash Function	Functional Outline and Restriction	Availability of Emulation
FlashEnv	Flash environment initialization/end function	Emulated
FlashBlockErase	Block erasure function	Emulated
FlashWordWrite	One word writing function <b>Restriction:</b> If an address in the guard area is specified as the third argument, a fail-safe break occurs at an unexpected address.	Restricted
FlashBlockIVerify	Block internal verify processing function	Emulated
FlashBlockBlankCheck	Block blank check function	Emulated
FlashGetInfo	Flash information acquisition function	
	Option = 2: CPU number and total number of blocks held by CPU <b>Restriction:</b> The device file name (four-digit number) is returned as the CPU number.	Restricted
	Option = 3: Security information	Emulated
	Option = 4: Acquisition of boot area swapping information <b>Restriction:</b> Boot area swapping information is not reflected.	Restricted
	Option = 5 + Block number: Acquisition of last address of block	Emulated
FlashSetInfo	Flash information setting function <b>Restriction:</b> The boot area swapping setting is ignored.	Restricted
FlashBootSwap	Boot area block swapping function	Not emulated
FlashFLMDCheck	FLMD0 pin status check function	Emulated
FlashWordRead	Data reading function <b>Restriction:</b> If an address in the guard area is specified as the third argument, a fail-safe break occurs at an unexpected address.	Restricted

Flash Function	Functional Outline and Restriction	Availability of Emulation
FlashVerify	Internal verify function (for EEPROM)	Not emulated
FlashBlankCheck	Blank check function (for EEPROM)	
EEPROM_Init	EEPROM area initialization function (for EEPROM)	
EEPROM_Write	EEPROM write function (for EEPROM)	
EEPROM_Read	EEPROM read function (for EEPROM)	
EEPROM_Copy	EEPROM copy function (for EEPROM)	
EEPROM_VChK	EEPROM valid area check function (for EEPROM)	
EEPROM_Erase	EEPROM erase function (for EEPROM)	

Table A-6. Flash Self Programming Type 04

Flash Function	Functional Outline and Restriction	Availability of Emulation
FlashInit	Self library initialization function	Emulated
FlashEnv	Flash environment initialization/end function	Emulated
FlashBlockErase	One block erasure function	Emulated
FlashWordWrite	One word writing function	Emulated
FlashBlockVerify	One block internal verify processing function	Emulated
FlashBlockBlankCheck	One block blank check function	Emulated
FlashGetInfo	Flash information acquisition function	
	Option = 2: Device information (total number of blocks and device number)	Emulated
	Option = 3: Security flag, last block number of boot block	Emulated
	Option = 4: Device information	Emulated
	Option = 5: Reset vector address	Emulated
	Option = 6 +block number <i>n</i> : Last address of block number <i>n</i>	Emulated
FlashSetInfo	Flash information setting function <b>Restriction:</b> Nothing but information setting is performed. The boot area swapping setting is ignored.	Restricted
FlashStatusCheck	Checking of flash function operation that was performed last <b>Restriction:</b> SELFLIB_BUSY is not returned.	Restricted
FlashBootSwap	Boot area block swapping function <b>Restriction:</b> Functions can be called but boot swapping is not executed.	Not emulated
FlashFLMDCheck	FLMD0 pin status check function	Emulated

**Table A-7. Cautions on Performing Flash Self Programming**

No.	Description
(1)	<p>Flash memory self programming emulation is not enabled in the following cases.</p> <ul style="list-style-type: none"> <li>- When the internal ROM size is not the default size [Workaround]: Restore the value of the [Size of internal ROM[KBytes]] property in the [Internal ROM/RAM] category on the <a href="#">[Debug Tool Settings] tab</a> to the default size.</li> <li>- When using two "break before execution" [Workaround]: Disable or delete one "break before execution".</li> </ul>
(2)	<p>When flash memory self programming emulation is enabled, the following restrictions apply to the debug function.</p> <ul style="list-style-type: none"> <li>- The internal ROM and internal RAM sizes cannot be changed.</li> <li>- The DMM and pseudo RRM functions are disabled.</li> <li>- An illegal break occurs in the program if the SP register value is 0 (not pointing to the internal RAM).</li> <li>- If a break such as an event occurs before the SP register value is initialized to point to a relevant location (such as internal RAM), then it causes an illegal break for the stack area. If there is a possibility that such a break will occur during this period, set a relevant value to SP before executing the program.</li> <li>- An illegal break may occur if the restriction shown below applies to the IECUBE used. Specify [No] in the [Stop when accessed to non-mapping Internal RAM] property in the [Fail-safe Break] category on the <a href="#">[Debug Tool Settings] tab</a>.</li> <li>- "An illegal break occurs during program execution in internal RAM"</li> </ul>
(3)	<p>When flash memory self programming emulation is enabled, the 4-byte area starting from address 0 is reserved, a 4-byte instruction <code>jr 0xffffd6</code> is written to address 0.</p> <p>Therefore, when using this function at a reset vector address 0, allocate a startup routine to the area starting from address 4.</p> <p>If flash memory self programming emulation is disabled, 0 is written to the four bytes area starting from address 0. Do not describe codes in which execution branches to address 0, even if this function is used as a reset vector address 0.</p> <p>It is recommended to perform description as shown below in order to operate the same program as the one generated by emulation, in the actual device.</p> <pre># RESET handler          -- in the case of address 0 .section    "RESET", text jr  __start            -- Overwritten by jr 0xffffd6 jr  __start</pre>
(4)	If address 0 is specified as the reset vector handling specification address, the reset vector is set to address 4. If an address other than address 0 is specified, then the specified address is set as the reset vector without incrementing the value by four.
(5)	Regarding the operation of <code>FlashStatusCheck()</code> after <code>FlashBlockErase()</code> and <code>FlashBlockBlankCheck()</code> during emulation, the timing at which the return value of <code>FlashStatusCheck()</code> changes from <code>FE_BUSY</code> to <code>FE_OK</code> differs from that in the actual device.
(6)	If the address specified as the third argument of <code>FlashWordWrite</code> , <code>FlashWordRead</code> , or <code>FlashNWordRead</code> is located in the guard area, then an illegal memory address is accessed, and a fail-safe break occurs at an unexpected address. Correct the address to a relevant one for <code>FlashWordWrite</code> , <code>FlashWordRead</code> , or <code>FlashNWordRead</code> .
(7)	To enable the settings made in the Flash Option dialog box, be sure to reset the CPU and reexecute the program; otherwise, the setting may not take effect.
(8)	Secure a stack area of at least 84 (54H) bytes for the debugger's workspace. The debugger consumes a stack area of at least 84 (54H) bytes when a break occurs or during emulation processing of flash memory writing. When interrupts are enabled, a stack area of another 84 (54H) bytes is required as the debugger's workspace. If multiple interrupts are enabled, a stack area of 84 (54H) bytes must be secured per stage.
(9)	The data in the internal RAM is corrupted after a CPU reset. Normally, the internal RAM data after reset is not guaranteed in the actual device, but note that the operation may vary.


No.	Description
(10)	If a flash function is not used in accordance with the specifications or an unsupported flash function is called, "1" is returned.
(11)	The following restrictions apply to emulation of Type4. <ul style="list-style-type: none"><li>- An area of 48 bytes from the internal RAM end address is reserved for use by the debugger.</li><li>- When using a device with a 1 MB internal flash memory, the internal flash area starting from address 0xFF300 or higher will be used by the debug tool.</li><li>- If a flash function is executed stepwise in instruction level, the debugger code for emulation will be executed, which is different from the code actually executed by the device. During debugging, therefore, perform stepwise execution in source level.</li></ul>

### [DataFlash Emulation Settings] tab [IECUBE]

This tab is used to display the detailed information categorized by the following and the configuration can be changed.  
Note that this tab appears only when the selected microcontroller incorporates the data flash memory.

- (1) [DataFlash Emulation]
- (2) [EEPROM Library Error]
- (3) [Writing Time/Erasing Time]

Figure A-22. Property Panel: [DataFlash Emulation Settings] Tab



### [Description of each category]

#### (1) [DataFlash Emulation]

The detailed information on the data flash emulation functions is displayed and its configuration can be changed.

DataFlash emulation	Select whether to use the data flash emulation function.	
	Default	No
	Modifying	Select from the drop-down list.
	Available values	Yes
		Uses data flash emulation functions.
	No	Does not use data flash emulation functions.

#### (2) [EEPROM Library Error]

The detailed information on EEPROM library error is displayed and its configuration can be changed.

The error values that are not returned during normal emulation can forcibly be returned by setting the properties of this category.

Generate WordWrite error	Select whether to return error values in WordWrite functions to emulate.			
	Default	No		
	Modifying	Select from the drop-down list.		
	Available values	Yes	Forcibly returns error values.	
		No	Does not return error values.	
Address generated WordWrite error	Specify an address in the data flash memory, at which a WordWrite function error is to be generated.  This property appears only when the [Generate WordWrite error] property is set to [Yes].			
	Default	0		
	Modifying	Directly enter from the keyboard.		
	Available values	0x0 to 0xFFFFFFFF in hexadecimal number		
	Select whether to return error values in BlockErase functions to emulate.			
Generate BlockErase error	Default	No		
	Modifying	Select from the drop-down list.		
	Available values	Yes	Forcibly returns error values.	
		No	Does not return error values.	
	Specify an address in the data flash memory, at which a BlockErase function error is to be generated.  This property appears only when the [Generate BlockErase error] property is set to [Yes].			
Address generated BlockErase error	Default	0		
	Modifying	Directly enter from the keyboard.		
	Available values	0x0 to 0xFFFFFFFF in hexadecimal number		
	Select whether to return error values in BlockIVerify functions to emulate.			
	Default	No		
Generate BlockIVerify error	Modifying	Select from the drop-down list.		
	Available values	Yes	Forcibly returns error values.	
		No	Does not return error values.	
	Specify an address in the data flash memory, at which a BlockIVerify function error is to be generated.  This property appears only when the [Generate BlockIVerify error] property is set to [Yes].			
	Default	0		
Address generated BlockIVerify error	Modifying	Directly enter from the keyboard.		
	Available values	0x0 to 0xFFFFFFFF in hexadecimal number		
	Select whether to return error values in BlockBlankCheck functions to emulate.			
	Default	No		
	Modifying	Select from the drop-down list.		
Generate BlockBlankCheck error	Available values	Yes	Forcibly returns error values.	
		No	Does not return error values.	

Address generated BlockBlankCheck error	Specify an address in the data flash memory, at which a BlockBlankCheck function error is to be generated.  This property appears only when the [Generate BlockBlankCheck error] property is set to [Yes].	
	Default	0
	Modifying	Directly enter from the keyboard.
	Available values	0x0 to 0xFFFFFFFF in hexadecimal number

**(3) [Writing Time/Erasing Time]**

The detailed information on the time for writing to and erasing the data flash memory is displayed and its configuration can be changed.


Writing time	Select the value to simulate the delay time for writing to the data flash memory.	
	Default	Typical number of times that is assumed by flash macro specifications
	Modifying	Select from the drop-down list.
	Available values	No retry  Specifies "0" as the number of times of retry. The delay time is 0 (the writing speed is fastest).
		Typical number of times that is assumed by flash macro specifications  Specifies the typical number of times that is assumed by flash macro specifications.
		Maximum number of times that is assumed by flash macro specifications  Specifies the maximum number of times that is assumed by flash macro specifications.
		Retries for the maximum number of times specified  Specifies the maximum number of times of retry. The delay time is maximum (the writing speed is longest).
Erasing time	Select the value to simulate the delay time for erasing the data flash memory.	
	Default	Typical number of times that is assumed by flash macro specifications
	Modifying	Select from the drop-down list.
	Available values	No retry  Specifies "0" as the number of times of retry. The delay time is 0 (the erasing speed is fastest).
		Typical number of times that is assumed by flash macro specifications  Specifies the typical number of times that is assumed by flash macro specifications.
		Maximum number of times that is assumed by flash macro specifications  Specifies the maximum number of times that is assumed by flash macro specifications.
		Retries for the maximum number of times specified  Specifies the maximum number of times of retry. The delay time is maximum (the erasing speed is longest).

### [Download File Settings] tab

This tab is used to display the detailed information categorized by the following and the configuration can be changed.  
For details on the download function, see "[2.5 Download/Upload Programs](#)".

- (1) [Download]
- (2) [Debug Information]

**Figure A-23. Property Panel: [Download File Settings] Tab**



- Notes 1.**
1. The [Download Mode] property appears only when the debug tool other than Simulator is used.
  2. The [Check reserved area overwriting when downloading] property appears only when MINICUBE2/E1(Serial)/E20(Serial)/EZ Emulator is used.

### [Description of each category]

#### (1) [Download]

The detailed information on download is displayed and its configuration can be changed.

Download files	Specify the file to download <sup>Note 1</sup> . The names of files to be downloaded and the download conditions are listed in the lower area.	
	Default	[Number of files to download]
	Modifying	Specify with the <a href="#">Download Files dialog box</a> . The Download Files dialog box is opened by clicking the [...] button that appears at right edge of this field when you select this property (you cannot specify the file to download on this panel).

CPU Reset after download	Select whether to reset the CPU after downloading.		
	Default	Yes	
	Modifying	Select from the drop-down list.	
	Available values	Yes	Resets the CPU after downloading.
		No	Does not reset the CPU after downloading.
Download Mode (except [Simulator])	Select the download mode for downloading to the flash ROM.		
	Default	Speed priority	
	Modifying	Select from the drop-down list.	
	Available values	Speed priority	Fills free space between the first data and the final data with FFH. Download speed will be faster because the writing data is reduced (default).
		Data priority	Retains the previous value in free space. Download speed will be very slow because data in free space are read once.
Erase flash ROM before download	Select whether to erase the flash ROM before downloading.		
	Default	No	
	Modifying	Select from the drop-down list. Note that changes cannot be made when the [Download Mode] property is set to [Data priority].	
	Available values	Yes	Erases the flash ROM before downloading.
		No	Does not erase the flash ROM before downloading.
Automatic change method of event setting position	Select how to perform the setting again if the file is downloaded again, and the location (address) set for the currently set event changes to midway in the instruction <sup>Note 2</sup> .		
	Default	Suspend event	
	Modifying	Select from the drop-down list.	
	Available values	Move to the head of instruction	Sets the event to the top address of the instruction.
		Suspend event	Disables the event (suspended state).
Check reserved area overwriting when downloading <b>[MINICUBE2]</b> <b>[E1/E20(Serial)]</b> <b>[EZ Emulator]</b>	Select whether to output a message when overwriting to an area reserved for use by the emulator is attempted at the time of downloading.		
	Default	Yes	
	Modifying	Select from the drop-down list.	
	Available values	Yes	Outputs a message when overwriting to an area reserved is attempted.
		No	Does not output a message when overwriting to an area reserved is attempted.

**Notes 1.** Files specified as build targets in a main project or sub-project cannot be deleted from the target files to download (These files are automatically registered as download files by default).

See "[Table 2-3. Type of Files That Can be Downloaded](#)" for downloadable file format.

2. This property setting works only for the location setting of events without the debug information. The location setting of events with the debug information is always moved to the beginning of the source text line.

**(2) [Debug Information]**

The detailed information on debugging is displayed and its configuration can be changed.

Execute to the specified symbol after CPU Reset	Select whether to execute the program to the specified symbol position after CPU reset.	
	Default Yes	
	Modifying Select from the drop-down list.	
	Available values	Yes Executes the program to the specified symbol position after CPU reset.
		No Does not execute the program after CPU reset.
Specified symbol	Specify the position at which the program is stop after CPU reset. This property appears only when the [ <a href="#">Execute to the specified symbol after CPU Reset</a> ] property is set to [Yes].	
	Default _main	
	Modifying Directly enter from the keyboard.	
	Available values	Address expression from 0 to the "end address of the address space".
Startup start symbol	Specify the start symbol of the text area of the startup routine.	
	Default __start	
	Modifying Directly enter from the keyboard.	
	Available values	Address expression from 0 to the "end address of the address space".
Startup end symbol	Specify the end symbol of the text area of the startup routine.	
	Default __startend	
	Modifying Directly enter from the keyboard.	
	Available values	Address expression from 0 to the "end address of the address space".

**[Flash Options Settings] tab [V850E2]**

This tab is used to configure options for the flash memory incorporated in the V850E2 microcontroller.

Note that this tab appears only when the selected V850E2 microcontroller supports the flash options.

To configure options, specify with the corresponding items on the [Flash Options Setting dialog box \[V850E2\]](#) that is opened by clicking the [...] button that appears at the right of the field by selecting the [Flash options] property in the [Flash Options] category on this tab (you cannot directly specify options on this tab).

- Cautions 1.** You can configure options only while connected to the debug tool.  
2. CPU reset may be generated automatically depending on the selected microcontroller when you change the configuration on this tab.

Figure A-24. Property Panel: [Flash Options Settings] Tab

**[Description of each category]****(1) [Flash Options]**

The detailed information on the flash options is displayed and its configuration can be changed.


Flash options	Click the [...] button that appears at the right of the field by selecting this property, to open the <a href="#">Flash Options Setting dialog box [V850E2]</a> .
---------------	---

### [Hook Transaction Settings] tab

This tab is used to display the detailed information categorized by the following and the configuration can be changed.  
For details on the hook transaction, see "[2.16 Use Hook Function](#)".

#### (1) [Hook Transaction Settings]

**Figure A-25. Property Panel: [Hook Transaction Settings] Tab**



### [Description of each category]

#### (1) [Hook Transaction Settings]

The detailed information on the hook transaction is displayed and its configuration can be changed.

Note that the properties on this tab can be specified via the [Text Edit dialog box](#), which is opened by clicking the [...] button that appears at right edge of a field when you select each property (you cannot specify the process directly on this panel).

**Caution** Up to 64 characters for one process, and up to 128 processes for each property can be set (one line in the [Text] area in the [Text Edit dialog box](#) is equivalent to one processing).

Before download	Specify the process to proceed right before downloading the load module file.	
	Default	Before download[0] ("[] is the current number of specified processes.)
	Modifying	Specify with the <a href="#">Text Edit dialog box</a> .
	Format	Either one of the following - I/O register <i>name</i> + space + <i>Value</i> <b>[Process]</b> Automatically overwrites the value of I/O register with <i>Value</i> . - CPU register <i>name</i> + space + <i>Value</i> <b>[Process]</b> Automatically overwrites the value of CPU register with <i>Value</i> . - Source Python script path <b>[Process]</b> Automatically executes a script file specified with Python script path.

After download	Specify the process to proceed right after downloading the load module file.	
	Default	After download[0] ("[] is the current number of specified processes.)
	Modifying	Specify with the <a href="#">Text Edit dialog box</a> .
	Format	<p>Either one of the following</p> <ul style="list-style-type: none"> <li>- I/O register <i>name</i> + space + <i>Value</i></li> <li><b>[Process]</b> Automatically overwrites the value of I/O register with <i>Value</i>.</li> <li>- CPU register <i>name</i> + space + <i>Value</i></li> <li><b>[Process]</b> Automatically overwrites the value of CPU register with <i>Value</i>.</li> <li>- Source <i>Python script path</i></li> <li><b>[Process]</b> Automatically executes a script file specified with <i>Python script path</i>.</li> </ul>
After CPU reset under breaking	Specify the process to proceed right after CPU reset during break.	
	Default	After CPU reset under breaking[0] ("[] is the current number of specified processes.)
	Modifying	Specify with the <a href="#">Text Edit dialog box</a> .
	Format	<p>Either one of the following</p> <ul style="list-style-type: none"> <li>- I/O register <i>name</i> + space + <i>Value</i></li> <li><b>[Process]</b> Automatically overwrites the value of I/O register with <i>Value</i>.</li> <li>- CPU register <i>name</i> + space + <i>Value</i></li> <li><b>[Process]</b> Automatically overwrites the value of CPU register with <i>Value</i>.</li> <li>- Source <i>Python script path</i></li> <li><b>[Process]</b> Automatically executes a script file specified with <i>Python script path</i>.</li> </ul>
Before running	Specify the process to proceed right before the execution of the program.	
	Default	Before running[0] ("[] is the current number of specified processes.)
	Modifying	Specify with the <a href="#">Text Edit dialog box</a> .
	Format	<p>Either one of the following</p> <ul style="list-style-type: none"> <li>- I/O register <i>name</i> + space + <i>Value</i></li> <li><b>[Process]</b> Automatically overwrites the value of I/O register with <i>Value</i>.</li> <li>- CPU register <i>name</i> + space + <i>Value</i></li> <li><b>[Process]</b> Automatically overwrites the value of CPU register with <i>Value</i>.</li> <li>- Source <i>Python script path</i></li> <li><b>[Process]</b> Automatically executes a script file specified with <i>Python script path</i>.</li> </ul>
After breaking	Specify the process to proceed right after the program break.	
	Default	After breaking[0] ("[] is the current number of specified processes.)
	Modifying	Specify with the <a href="#">Text Edit dialog box</a> .
	Format	<p>Either one of the following</p> <ul style="list-style-type: none"> <li>- I/O register <i>name</i> + space + <i>Value</i></li> <li><b>[Process]</b> Automatically overwrites the value of I/O register with <i>Value</i>.</li> <li>- CPU register <i>name</i> + space + <i>Value</i></li> <li><b>[Process]</b> Automatically overwrites the value of CPU register with <i>Value</i>.</li> <li>- Source <i>Python script path</i></li> <li><b>[Process]</b> Automatically executes a script file specified with <i>Python script path</i>.</li> </ul>

### Editor panel

This panel is used to display and edit files.

Furthermore, the source level debugging/instruction level debugging (see "2.7.3 Execute programs in steps") and the code coverage measurement result display [IECUBE][IECUBE2][Simulator] (see "2.13 Measure Coverage [IECUBE][IECUBE2][Simulator]") can be performed when connected to the debug tool and the downloaded source file is opened in this panel.

The code data, label and disassembled text can be displayed combined with the source code by selecting the mixed display mode (see "(1) Change display mode").

When opened the file encoding and newline code is automatically detected and retained when it is saved. You can open a file with a specific encoding selected in the [Encoding dialog box](#). If the encoding and newline code is specified in the [Save Settings dialog box](#) then the file is saved with those settings.

This panel can be opened multiple times (up to 100 panels).

**Remarks 1.** When a project is closed, all of the Editor panels displaying a file being registered in the project are closed.

2. When a file is excluded from a project, the Editor panel displaying the file is closed.
3. A message is shown when the downloaded load module file is older than the source file to be opened. This is due to the debug information not matching the source code being viewed.

Figure A-26. Editor Panel




Figure A-27. Editor Panel (When Code Coverage Measurement Result Is Displayed)





Figure A-28. Editor Panel (When Mixed Display Mode Is Selected)



This section describes the following.

- [How to open]
- [Description of each area]
- [Toolbar]
- [[File] menu (Editor panel-dedicated items)]

- [[Edit] menu (Editor panel-dedicated items)]
- [[Window] menu (Editor panel-dedicated items)]
- [Context menu]

### [How to open]

- On the [Project Tree panel](#), double click a file.
- Automatically opens after downloading the load module file with debug information.
- On the [Project Tree panel](#), select a source file, and then select [Open] from the context menu.
- On the [Project Tree panel](#), select [Add] >> [Add New File...] from the context menu, and then create a text file or source file.
- On the [Disassemble panel](#), [Call Stack panel](#), [Trace panel \[IECUBE\]\[IECUBE2\]\[Simulator\]](#), or [Events panel](#), select [Jump to Source] from the context menu.
- Automatically opens if there is a source text line corresponding to the current PC value when the current PC value is forcibly changed or the program stops executing.

### [Description of each area]

#### (1) Title bar

The name of the opened text file or source file is displayed.

Marks displayed at the end of the file name indicate the following:

Mark	Description
*	The text file has been modified since being opened.
!	Update time and date of the source file opened are later than the one of the downloaded load module file. Note that this mark is valid only when connected to the debug tool and the downloaded source file is opened.
[RECYCLE]	The recycle mode (see " <a href="#">(3) Display multiple source files in a single panel</a> ") is valid. Note that this mark is valid only when connected to the debug tool and the downloaded source file is opened.
(Read only)	The opened text file is read only.

#### (2) Column header

The title of each column on the Editor panel is displayed (hovering the mouse cursor over this area displays the title name).

Display	Title Name	Description
Line	Line	Displays line numbers (see " <a href="#">(4) Line number area</a> ").
(No display)	Selection	The display is colored to reflect the state in terms of saving of the state of editing (see " <a href="#">(4) Line number area</a> "). However, this column is not displayed in the mixed display mode.
(No display)	Out of Date Module Indicator	The display is colored to reflect cases where a source file has been updated more recently than the corresponding load module file (see " <a href="#">(4) Line number area</a> "). However, this column is not displayed when disconnected from the debug tool or in the mixed display mode.
	Coverage	Displays the coverage information (see " <a href="#">(5) Coverage area</a> "). However, this column is not displayed when disconnected from the debug tool.

Display	Title Name	Description
Address	Address	Displays addresses (see "(6) Address area"). However, this column is not displayed when disconnected from the debug tool.
Op code	Op code	Displays instruction codes (see "(7) Code area"). However, this column is displayed only in the mixed display mode.
Label	Label	Displays labels (see "(8) Label area"). However, this column is displayed only in the mixed display mode.
	Event	Sets events (see "(9) Event area"). However, this column is not displayed when disconnected from the debug tool.
	Main	Sets breakpoints (see "(10) Main area"). However, this column is not displayed when disconnected from the debug tool.

**Remark** Show/hide of the column header can be switched by the setting of the toolbar.


### (3) Splitter bars

You can split the Editor panel by using the horizontal and vertical splitter bars within the view. This panel can be split up to two times vertically, and two times horizontally.

- To split this panel, drag the splitter bar down or to the right to the desired position, or double-click any part of the splitter bar.
- To remove the split, double-click any part of the splitter bar.

**Caution** The split is enabled only when this panel is in the normal display mode (setting to the mixed display mode removes the split).

Figure A-29. Editor Panel (Vertical/Horizontal Two-way Split View)



### (4) Line number area

This area displays the line number of the opened text file or source file.

On each line there is an indicator that shows the line modification status.

```

(1) 88 void main(void)
89 {
90     /* Start user code.
91
92     TMPO_Start();
93     TMP1_Start();
94     AD_Start();
95
96     while (1U)
97 {

```

Furthermore, when connected to the debug tool and the downloaded source file is opened, the following mark will be displayed if the update time and date of the source file opened are later than the one of the downloaded load module file (the color of the mark depends on the "Warning" color of the [\[General - Font and Color\] category](#) of the [Option dialog box](#)).

```

(3) 88
89 0000065c void main(void)
90
91 0000065e /* Start user c
92
         TMPO_Start();

```

(1)		This means new or modified line but unsaved.
(2)		This means new or modified line and saved. To erase this mark, close the panel, and then open this source file again.
(3)		This means that the downloaded load module file is out of date. To erase this mark, run a build and then download the load module file again

## (5) Coverage area

This area is valid only when connected to the debug tool and the downloaded source file is opened.

When the coverage function is valid, lines corresponding to the specified coverage measurement area are shown highlighted based on the code coverage measurement result that is acquired by executing the program (the color depends on the configuration in the [\[General - Font and Color\] category](#) of the [Option dialog box](#)).

See "[2.13 Measure Coverage \[IECUBE\]\[IECUBE2\]\[Simulator\]](#)" for details on the coverage measurement.

Hovering the mouse cursor over this area displays the area title "Coverage".

This area is provided with the following function.

### (a) Clearing the coverage information via the menu

When you right-click in this area, the following menu below is displayed:

Clear Coverage Information	Clears all the coverage measurement results currently being stored in the debug tool. Note that this item appears only when the debug tool used supports the coverage function.
----------------------------	--

## (6) Address area

This area is valid only when connected to the debug tool and the downloaded source file is opened.

This area shows the address corresponding to where the instruction is located in the memory space of the selected microcontroller.

The format of this area is fixed as hexadecimal number notation.

The address width corresponds to the one in memory space of the selected microcontroller in the project.

#### (7) Code area

This area is valid only when connected to the debug tool and the downloaded source file is opened in the mixed display mode.

This area shows the code corresponding to the source code.

Hovering the mouse cursor over this area (but not over a specific code) displays the area title "OpCode".

#### (8) Label area

This area is valid only when connected to the debug tool and the downloaded source file is opened in the mixed display mode.

This area shows the label name when a label is defined for the address.

Hovering the mouse cursor over this area (but not over a specific label) displays the area title "Label".

#### (9) Event area

This area is valid only when connected to the debug tool and the downloaded source file is opened.

Trace or timer events can be set at lines that have valid addresses.

In addition, the [Event mark](#) corresponding to an event that has been currently set is displayed.

Hovering the mouse cursor over this area (but not over a specific event mark) displays the area title "Event".

This area is provided with the following functions.

##### (a) Configuring events via the menu

When you right-click in this area, the following menu below is displayed.

Set Timer Start Event	Sets a timer start event to start measuring the execution time of the program when the line at caret is executed (see " <a href="#">2.12.2 Measure execution time in the arbitrary section</a> ").
Set Timer End Event	Sets a timer end event to stop measuring the execution time of the program when the line at caret is executed (see " <a href="#">2.12.2 Measure execution time in the arbitrary section</a> ").
Set Trace Start Event	Sets a trace start event to start collecting the trace data when the line at the caret is executed (see " <a href="#">2.11.3 Collect execution history in the arbitrary section</a> ").
Set Trace End Event	Sets a trace end event to stop collecting the trace data when the line at the caret is executed (see " <a href="#">2.11.3 Collect execution history in the arbitrary section</a> ").
Register Action Event...	Opens the <a href="#">Action Events dialog box</a> to set an action event to the corresponding address of the line at the caret position (see " <a href="#">2.14.1 Insert printf</a> ").

##### (b) Changing the status of events via the menu

The events status can be changed from the following menu displayed by right-clicking the [Event mark](#).

Enable Event(s)	Changes all events state to a <a href="#">Valid state</a> . When an event is enabled and its condition is met, the event occurs. If the event mark (  ) which indicates that multiple events have been set is selected, all of the events that have been set are enabled.
Disable Events(s)	Changes all events state to an <a href="#">Invalid state</a> . When an event is disabled and its condition is met, the event will not occur. If the event mark (  ) which indicates that multiple events have been set is selected, all of the events that have been set are disabled.
Delete Event(s)	Deletes all events. If the event mark (  ) which indicates that multiple events have been set is selected, all of the events that have been set are deleted.

View Details in Event Panel	Opens the <a href="#">Events panel</a> to display the detailed information of the selected event.
-----------------------------	---

### (c) Pop-up display

By hovering the mouse cursor over the [Event mark](#), the name of the event, the detailed information for the event and the comments added to the event are a pop-up displayed.

When multiple events have been set in the applicable place, information for each event, up to a maximum of three events, is listed and displayed.

**Remark** The detailed information about the set event is reflected in the [Events panel](#).

## (10) Main area

This area is valid only when the user is connected to the debug tool and the downloaded source file is opened.

Breakpoints can be set at lines that have valid addresses.

In addition, the [Event mark](#) corresponding to a breakpoint that has been currently set is displayed.

The current PC mark ( ) that corresponds to the current PC position (PC register value) is displayed.

Note that the current PC mark is only displayed if the current PC value corresponds to the source text line, when the current PC position is modified or the state of the debug tool is changed from execution to stop.

Hovering the mouse cursor over this area (but not over a specific event mark) will display the area title "Main".

This area is provided with the following functions.

### (a) Setting/deleting breakpoints

By clicking where you want to set a breakpoint with mouse, the breakpoints can be set easily.

The breakpoint is set to the instruction at the start address corresponding to the clicked line.

Once a breakpoint is set, an [Event mark](#) is displayed at the line that is set. In addition, the detailed information about the set breakpoint is reflected in the [Events panel](#).

When this operation is performed at a place where any one of the event marks is already being displayed, that event is deleted and the setting of breakpoints cannot be done.

See "[2.8.2 Stop the program at the arbitrary position \(breakpoint\)](#)" for details on how to set the breakpoint.

### (b) Configuring breakpoints via the menu

When you right-click in this area, the following menu below is displayed.

Set Breakpoint	Sets a breakpoint to the line at the caret position (see " <a href="#">2.8.2 Stop the program at the arbitrary position (breakpoint)</a> ").  Except [ <a href="#">Simulator</a> ]  By default the debug tool will set a hardware break when resources are available. This behavior can be customized by using the " <a href="#">Hardware Break First</a> " or " <a href="#">Software Break First</a> " menu items.
Set Hardware Breakpoint (except [ <a href="#">Simulator</a> ])	Sets a breakpoint (Hardware Break event) to the line at the caret position.
Set Software Breakpoint (except [ <a href="#">Simulator</a> ])	Sets a breakpoint (Software Break event) to the line at the caret position.
Hardware Break First (except [ <a href="#">Simulator</a> ])	The type of break that can be set by a one click operation of the mouse is set as a hardware breakpoint (this is reflected in the setting of the [First using type of breakpoint] property in the [Break] category from the <a href="#">[Debug Tool Settings] tab</a> on the <a href="#">Property panel</a> ).

Software Break First (except [Simulator])	The type of break that can be set by a one click operation of the mouse is set as a software breakpoint (this is reflected in the setting of the [First using type of breakpoint] property in the [Break] category from the [Debug Tool Settings] tab on the <a href="#">Property panel</a> ).
--	--

**(c) Changing the status of breakpoints via the menu**

The events status can be changed from the following menu displayed by right-clicking the [Event mark](#).

Enable Breakpoint	Changes the selected breakpoint state to a <a href="#">Valid state</a> . When the specified condition is met, execution of the program will be stopped. If the event mark (  ) which indicates that multiple events have been set is selected, all of the breakpoints that have been set are enabled.
Disable Breakpoint	Changes the selected breakpoint state to an <a href="#">Invalid state</a> . When the specified condition is met, execution of the program will not be stopped. If the event mark (  ) which indicates that multiple events have been set is selected, all of the breakpoints that have been set are disabled.
Delete Breakpoint	Deletes the selected breakpoint. If the event mark (  ) which indicates that multiple events have been set is selected, all of the breakpoints that have been set are deleted.
View Details in Event Panel	Opens the <a href="#">Events panel</a> to display the detailed information of the selected event.

**(d) Pop-up display**

By hovering the mouse cursor over the [Event mark](#), the name of the event, the detailed information for the event and the comments added to the event are a pop-up displayed.

When multiple events have been set in the applicable place, information for each event, up to a maximum of three events, is listed and displayed.

**Remark** The detailed information about the set event is reflected in the [Events panel](#).

**(11) Characters area**

This area displays character strings of text files and source files and you can edit it.

This area has the following functions.

**(a) Code outlining**

This allows you to expand and collapse source code blocks so that you can concentrate on the areas of code which you are currently modifying or debugging. This is only available for only C/C++ source file types.

This is achieved by clicking the plus and minus symbols to the left of the Characters area.

Types of source code blocks that can be expanded or collapsed are:

Open and close braces ('{' and '}')	
Multi-line comments ('/*' and '*/')	
Pre-processor statements ('if', 'elif', 'else', 'endif')	   

**Caution** This will be disabled for source files larger than 1MB.

**(b) Characters editing**

Characters can be entered from the keyboard.

Various shortcut keys can be used to enhance the edit function.

**(c) Tag jump**

If the information of a file name, a line number and a column number exists in the line at the caret position, selecting [Tag Jump] from the context menu opens the file in the Editor panel and jumps to the corresponding line and the corresponding column (if the target file is already opened in the Editor panel, you can jump to the panel).

See "[Table 2-6. Operation of Tag Jump](#)" for details on the operation of the tag jump.

**(d) Current PC line display**

When the current PC position (PC register value) corresponds to the source text lines, those lines are shown highlighted (the highlighting color depends on the configuration in the [\[General - Font and Color\] category](#) of the [Option dialog box](#)).

This function is only enabled when connected to the debug tool and the source file is opened.

**(e) Lines with breakpoints display**

Lines where the breakpoints are set are shown highlighted (the highlighting color depends on the configuration in the [\[General - Font and Color\] category](#) of the [Option dialog box](#)).

This function is only enabled when connected to the debug tool and the source file is opened.

**(f) Code coverage measurement result display [IECUBE][Simulator]**

When the coverage function is valid, lines corresponding to the specified coverage measurement area are shown highlighted based on the code coverage measurement result that is acquired by executing the program (the highlighting color depends on the configuration in the [\[General - Font and Color\] category](#) of the [Option dialog box](#)).

See "[2.13 Measure Coverage \[IECUBE\]\[IECUBE2\]\[Simulator\]](#)" for details on the coverage measurement.

This function is only enabled when connected to the debug tool and the source file is opened.

**(g) Pop-up display of variables**

When hovering the mouse cursor over a variable in the source text, a pop-up that shows the name and value of the variable is displayed ("<variable name>=<variable value>").

The display format of the variable value is same as "[Table A-17. Display Format of Watch-Expressions \(Default\)](#)" depending on the type of the variable.

This function is only enabled when connected to the debug tool and the source file is opened.

**(h) Setting of various events**

Various events can be set to the addresses or lines where the caret currently exists by selecting [Break Settings], [Trace Settings] or [Timer Settings] from the context menu.

The corresponding [Event mark](#) is displayed in the [Event area](#) or [Main area](#) by setting the event. In addition, the detailed information about the set event is reflected in the [Events panel](#).

This function is only enabled when connected to the debug tool and the source file is opened.

See the following for details on how to set events.

- [2.8.4 Stop the program with the access to variables/I/O registers](#)
- [2.11.3 Collect execution history in the arbitrary section](#)
- [2.11.4 Collect execution history only when the condition is met](#)
- [2.12.2 Measure execution time in the arbitrary section](#)

**Remark** A breakpoint can be set or deleted easily in the Main area as well (see "(a) Setting/deleting breakpoints").

#### (i) Registering watch expressions

C language variable, CPU registers, I/O registers, and assembler symbols can be registered in the Watch panel as watch expressions.

See "(1) Register a watch-expression" for details on how to operate it.

This function is only enabled when connected to the debug tool and the source file is opened.

#### (j) File monitor

The following function for monitoring is provided to manage source files.

- A message is displayed when the downloaded load module file is older than the source file to open.
- If the contents of the currently displayed file is changed (including renaming or deleting) without using CubeSuite+, a message will appear asking you whether you wish to update the file or not.
- If the contents of the currently displayed file have been changed without using CubeSuite+, a message will appear asking you whether you wish to save the file or not.


#### (k) Smart edit function [V850E2]

The smart edit function is used to complement the names of functions, variables and the arguments of functions during input and offer them as candidates.

The smart edit function complements the information listed below.

- Global functions in the C language
- Global variables in the C language

Figure A-30. Display Example of Smart Edit Function (Candidates of Function and Variables)



- Cautions 1.** The smart edit function is supported only when CX is used as the build tool.  
 2. The smart edit function cannot be used when the mixed display mode (see "Change display mode") is selected in the Editor panel.

Follow the procedure below to enable the smart edit function.

- Select the [Smart edit] check box in the [General - Text Editor] category of the Option dialog box (default).
- Candidates are displayed by using the cross reference information that is generated by the build tool. Therefore, set the build tool's Property panel<sup>Note</sup> so that the cross reference information is output, and then run and complete a build.
- If an error in building occurs, the cross reference information before the error occurred is used if any exists.

**Note** [Common Options] tab >> [Output File Type and Path] category >> [Output cross reference information] property >> [Yes(-Xref)]

If this setting is invalid, the smart edit function cannot be used since the output will be empty of the cross reference information.

#### <1> Display of candidates for functions and variables

##### - How to display

Candidates for functions and variables can be displayed by any one of the following methods:

- In the C language, when "." or "->" is input if there is a relevant member for the left side

- When the [Ctrl] + [Space] key on the keyboard is pressed (all candidates are displayed)


However, if there is only one candidate, the relevant character string is inserted at this time without displaying the candidate.

##### - How to insert character strings

Select a character string from the candidates list by using the [Up]/[Down] key or the mouse, then press the [Enter] key or the [TAB] key.

##### - Description of each area

Figure A-31. Display of Candidates for Functions and Variables



##### - Candidates list

Displays candidates for functions and variables in alphabetical order.

If there are character strings that match to the character strings at the caret position, they are highlighted (case insensitive).

The following icons are displayed as labels for the list of candidates.

Icon	Description
	Shows that the candidate is for a typedef.
	Shows that the candidate is for a function.
	Shows that the candidate is for a variable.
	Shows that the candidate is for a structure or an union.

- Toolbar

Switches whether candidates for functions and variables are displayed or not.

Button	Description
	Displays candidates for functions.
	Displays candidates for variables.

- Tab

Switches the members to be displayed.

Tab Name	Description
All members	Displays all candidates.
Public members	Displays only the candidates with the public attribute. Note, however, that this tab has no effect.

- Detailed display

Displays details of candidates for functions or variables currently being selected.

Item	Description
(1) Kind	Shows whether the selected item is a function or a variable. - (function) : Shows the selected item is a function. - (variable) : Shows the selected item is a variable.
(2) Type	Shows the type of the function or the variable.
(3) Name	Shows the name of the function or the variable.
(4) Name and argument	Shows the name of the function or the variable. When the item is a function, its arguments are also shown.

## <2> Display of candidates for arguments


- How to display

Candidates for arguments can be displayed by any one of the following methods:

- In a function name, when "(" is input if there is a relevant function on the left side of "("
- When the [Ctrl] + [Shift] + [Space] key on the keyboard is pressed while the text cursor is at the location of an argument for a function

- Description of each area

Figure A-32. Display of Candidates for Arguments



Item	Description
(1) Type	Shows the type of the function or the variable.
(2) Name and argument	Shows the name of the function and its arguments. The argument at the current caret position is highlighted.
(3) Name and argument	Shows the name of the function and its arguments.

### <3> Termination of the candidates display

The candidates display disappears by any one of the following methods:

- Press the [ESC] key
- Enter a key other than an alphanumeric character
- When nothing is selected from the candidates list: This operation has no effect.
- When an item is selected in the candidates list: The selected character strings are inserted.

### <4> Notes for displaying of candidates list


- The following items are not the subject of the candidates display.
- Macro definitions
- Local variables
- Typedef statements
- When a structure or union is declared within a function, candidates are not displayed within the function after its own declaration.
- In some cases the type of variables to be displayed differs from that actually declared when a compiler option which affects the size of variables is set.

**Remark** When the mouse cursor is hovered over a function name or a variable name on the source text, the information about that function or variable appears in a pop-up.

Note the following, however, when using this function.

- This function cannot be used when connected to the debug tool.
- When an union is declared, a pop-up does not appear even if the mouse cursor is hovered over the tag name of the unions.
- Structures and unions declared in header files cannot be displayed in a pop-up.
- const, static, and volatile attributes cannot be displayed in a pop-up.

**Figure A-33. Pop-up Display of Smart Edit Function**



#### (I) Selecting blocks

You can select a block that consists of multiple lines by any one of the following methods:

- Drag the left-mouse button while holding down the [Alt] key
- Press the [Right], [Left], [Up], or [Down] key while holding down the [Alt] + [Shift] key

```

void main(void)
{
    /* Start user code.

    TMP0_Start();
    TMP1_Start();
    AD_Start(); */

    while (1U)
    {
    }
}

```

**Remark** Editing of the selected block can be done by using [Cut], [Copy], [Paste], or [Delete] from the [Edit] menu.

#### (m) Zoom in or out on a view

You can zoom in and out of the editor view by using the [Ctrl] key + mouse-wheel combination.

- Using the [Ctrl] key + mouse-wheel forward will zoom into the view, making the contents larger and easier to see (max. 300%).
- Using the [Ctrl] key + mouse-wheel backward will zoom out of the view, making the contents smaller (min. 50%).

**Remark** The following items can be customized by setting the [Option dialog box](#).

- Display fonts
- Tab interval
- Show or hide white space marks (blank symbols)
- Colors of reserved words and comments

### [Toolbar]

	Toggles between normal (default) and mixed display mode, as the display mode of this panel (see " <a href="#">(1) Change display mode</a> "). Clicking this button sets to the mixed display mode. Note that this item is enabled only when connected to the debug tool and the downloaded source file is opened in this panel.
	Toggles between source (default) and instruction level, as the unit in which the program is step-executed (see " <a href="#">2.7.3 Execute programs in steps</a> "). Clicking this button sets the unit of a step execution to instruction level (the current PC mark will be moved to a disassembled text line). Note that this item is enabled only when connected to the debug tool and the mixed display mode is selected.
	Displays the current PC position. Note that this item is enabled only when connected to the debug tool.
	Forwards to the position before operating <a href="#">[Context menu] &gt;&gt; [Back To Last Cursor Position]</a> . Note that this item is disabled when connected to the debug tool and the mixed display mode is selected.
	Goes back to the position before operating <a href="#">[Context menu] &gt;&gt; [Jump to Function]</a> . Note that this item is disabled when connected to the debug tool and the mixed display mode is selected.

Columns	The following items are displayed to show or hide the columns or marks on all of the Editor panels. Remove the check to hide the items (all the items are checked by default).
Line Number	Shows the line number, in the line number area.
Selection	Shows the mark that indicates the line modification status, in the line number area.
Out of date module indicator	Shows the mark that indicates the update status of the downloaded load module file, in the line number area. Note that this item is enabled only when connected to the debug tool.
Coverage	Shows the coverage area. Note that this item is enabled only when connected to the debug tool.
Address	Shows the address area. Note that this item is enabled only when connected to the debug tool.
Op Code	Shows the code area. Note that this item is enabled only when connected to the debug tool and the mixed display mode is selected.
Label	Shows the label area. Note that this item is enabled only when connected to the debug tool and the mixed display mode is selected.
Event	Shows the event area. Note that this item is enabled only when connected to the debug tool.
Main	Shows the main area. Note that this item is enabled only when connected to the debug tool.
Column Header	Shows the column header.

#### [[File] menu (Editor panel-dedicated items)]

The following items are exclusive for the [File] menu in the Editor panel (other items are common to all the panels).

Close <i>file name</i>	Closes the currently editing Editor panel. When the contents of the panel have not been saved, a confirmation message is shown.
Save <i>file name</i>	Overwrites the contents of the currently editing Editor panel. When the file has never been saved or the file is read only, the same operation is applied as the selection in [Save <i>file name As...</i> ]. Note that this item is disabled when this panel is in the mixed display mode.
Save <i>file name As...</i>	Opens the <a href="#">Save As dialog box</a> to newly save the contents of the currently editing Editor panel. Note that this item is disabled when this panel is in the mixed display mode.
<i>File name</i> Save Settings...	Opens the <a href="#">Save Settings dialog box</a> to change the encoding and newline code of the file being opened in the currently editing Editor panel.
Print...	Opens the Windows dialog box for printing the contents of the currently editing Editor panel.
Print Preview	Opens the <a href="#">Print Preview window</a> to preview the file contents to be printed.

**[[Edit] menu (Editor panel-dedicated items)]**

The following items are exclusive for [Edit] menu in the Editor panel (all other items are disabled).

Undo	Cancels the previous operation and restores the characters and the caret position (up to 100 times). Note that this item is disabled when this panel is in the mixed display mode.
Redo	Cancels the previous [Undo] operation and restores the characters and the caret position. Note that this item is disabled when this panel is in the mixed display mode.
Cut	Cuts the selected character string and copies it to the clipboard. If there is no selection, the entire line is cut. Note that this item is disabled when this panel is in the mixed display mode.
Copy	Copies the contents of the selected range to the clipboard as character string(s). If there is no selection, the entire line is copied.
Paste	Inserts (insert mode) or overwrites (overwrite mode) the characters that are copied on the clipboard into the caret position. Note that this item is disabled when the contents of the clipboard are not recognized as characters or this panel is in the mixed display mode.
Delete	Deletes one character at the caret position. When there is a selection area, all the characters in the area are deleted. Note that this item is disabled when this panel is in the mixed display mode.
Select All	Selects all the characters from beginning to the end in the currently editing text file. Note that this item is disabled when this panel is in the mixed display mode.
Find...	Opens the Find and Replace dialog box with selecting [Quick Find] tab.
Replace...	Opens the Find and Replace dialog box with selecting [Quick Replace] tab. Note that this item is disabled when this panel is in the mixed display mode.
Go To...	Opens the <a href="#">Go to Line dialog box</a> to move the caret to the specified line.
Outlining	Displays a cascading menu for controlling expand and collapse states of source file outlining (see "(a) <a href="#">Code outlining</a> "). Note that these items are disabled when this panel is in the mixed display mode.
Collapse to Definitions	Collapses all nodes that are marked as implementation blocks (e.g. function definitions).
Toggle Outlining Expansion	Toggles the current state of the innermost outlining section in which the cursor lies when you are in a nested collapsed section.
Toggle All Outlining	Toggles the collapsed state of all outlining nodes, setting them all to the same expanded or collapsed state. If there is a mixture of collapsed and expanded nodes, all nodes will be expanded.
Stop Outlining	Stops code outlining and remove all outlining information from source files.
Start Automatic Outlining	Starts automatic code outlining and automatically displayed in supported source files.

Advanced	Displays a cascading menu for performing an advanced operation for the Editor panel. Note that these items are disabled when this panel is in the mixed display mode.
Increase Line Indent	Increases the indentation of the current cursor line by one tab.
Decrease Line Indent	Decreases the indentation of the current cursor line by one tab.
Uncomment Lines	Removes the first set of line-comment delimiters from the start of the current cursor line, appropriate to the current language (e.g. C++). This operation will only be available when the language of the current source file has line-comment delimiters specified (e.g. C++).
Comment Lines	Places line-comment delimiters at the start of the current cursor line, appropriate to the current language (e.g. C++). This operation will only be available when the language of the current source file has line-comment delimiters specified (e.g. C++).
Convert Tabs to Spaces	Converts all tabs on the current cursor line into spaces.
Convert Spaces to Tabs	Converts each set of consecutive space characters on the current line to tab characters, but only for those sets of spaces that are at least equal to one tab size.
Tabify Selected Lines	Tabifies the current line, causing all spaces at the start of the line (prior to any text) to be converted to tabs where possible.
Untabify Selected Lines	Untabifies the current line, causing all tabs at the start of the line (prior to any text) to be converted to spaces.
Make Uppercase	Converts all letters within the selection to uppercase.
Make Lowercase	Converts all letters within the selection to lowercase.
Toggle Character Casing	Toggles the character cases (uppercase / lowercase) of all letters within the selection.
Capitalize	Capitalizes the first character of every word within the selection.
Delete Horizontal Whitespace	Deletes any excess white space either side of the cursor position, leaving only one whitespace character remaining. If there the cursor is within a word or not surrounded by whitespace, this operation will have no effect.
Trim Trailing Whitespace	Deletes any trailing whitespace that appears after the last non-whitespace character on the cursor line.
Delete Line	Completely delete the current cursor line.
Duplicate Line	Duplicates the cursor line, inserting a copy of the line immediately after the cursor line.
Delete Blank Lines	Deletes the line at the cursor if it is empty or contains only whitespace.

**[[Window] menu (Editor panel-dedicated items)]**

The following items are exclusive for the [Window] menu in the Editor panel (other items are common to all the panels).

Split	Splits the active Editor panel horizontally. Only the active Editor panel can be split. Other panels will not be split. A panel can be split up to two times.
Remove Split	Removes the split view of the Editor panel.

**[Context menu]****[Titlebar area]**

Close Panel	Closes the currently selected panel.
Close All but This	Closes all other panels being displayed in the same panel display area as the selected panel, except for the currently selected panel.

Save file name	Saves the contents of the opened text file.
Copy Full Path	Copies the full path of the opened text file to the clipboard.
Open Containing Folder	Opens the folder where the text file is saved in Explorer.
New Horizontal Tab Group	<p>The area for the display of active panels is evenly divided into two areas in the horizontal direction, and the panels are displayed as a new group of tabbed pages. Only one panel is active in the new group. The area may be divided into up to four panels.</p> <p>This item is not displayed in the following cases.</p> <ul style="list-style-type: none"> <li>- Only one panel is open.</li> <li>- The group has already been divided in the vertical direction.</li> <li>- The group has already been divided into four panels.</li> </ul>
New Vertical Tab Group	<p>The area for the display of active panels is evenly divided into two areas in the vertical direction, and the panels are displayed as a new group of tabbed pages. Only one panel is active in the new group. The area may be divided into up to four panels.</p> <p>This item is not displayed in the following cases.</p> <ul style="list-style-type: none"> <li>- Only one panel is open.</li> <li>- The group has already been divided in the horizontal direction.</li> <li>- The group has already been divided into four panels.</li> </ul>
Go to Next Tab Group	<p>When the display area is divided in the horizontal direction, this moves the displayed panel to the group under that displaying the selected panel.</p> <p>When the display area is divided in the vertical direction, this moves the displayed panel to the group to the right of that displaying the selected panel.</p> <p>This item is not displayed if there is no group in the given direction.</p>
Go to Previous Tab Group	<p>When the display area is divided in the horizontal direction, this moves the displayed panel to the group over that displaying the selected panel.</p> <p>When the display area is divided in the vertical direction, this moves the displayed panel to the group to the left of that displaying the selected panel.</p> <p>This item is not displayed if there is no group in the given direction.</p>

[Characters area (when disconnected from the debug tool)]

Cut	Cuts the selected character string and copies it to the clipboard. If there is no selection, the entire line is cut.
Copy	Copies the contents of the selected range to the clipboard as character string(s). If there is no selection, the entire line is copied.
Paste	Inserts (insert mode) or overwrites (overwrite mode) the characters that are copied on the clipboard into the caret position. When the contents of the clipboard are not recognized as characters, the operation is invalid.
Find...	Opens the Find and Replace dialog box with selecting [Quick Find] tab.
Go To...	Opens the <a href="#">Go to Line dialog box</a> to move the caret to the specified line.
Forward To Next Cursor Position	Forwards to the position before operating [ <a href="#">Back To Last Cursor Position</a> ]. Note that this item is disabled when this panel is in the mixed display mode.
Back To Last Cursor Position	Goes back to the position before operating [ <a href="#">Jump to Function</a> ]. Note that this item is disabled when this panel is in the mixed display mode.
Jump to Function	Jumps to the function that is selected or at the caret position regarding the selected characters and the words at the caret position as functions (see " <a href="#">(7) Jump to functions</a> ").

Tag Jump	Jumps to the corresponding line and column in the corresponding file if the information of a file name, a line number and a column number exists in the line at the caret position (see " <a href="#">(c) Tag jump</a> ").
Advanced	Displays a cascading menu for performing an advanced operation for the Editor panel.
Increase Line Indent	Increases the indentation of the current cursor line by one tab.
Decrease Line Indent	Decreases the indentation of the current cursor line by one tab.
Uncomment Lines	Removes the first set of line-comment delimiters from the start of the current cursor line, appropriate to the current language (e.g. C++). This operation will only be available when the language of the current source file has line-comment delimiters specified (e.g. C++).
Comment Lines	Places line-comment delimiters at the start of the current cursor line, appropriate to the current language (e.g. C++). This operation will only be available when the language of the current source file has line-comment delimiters specified (e.g. C++).
Convert Tabs to Spaces	Converts all tabs on the current cursor line into spaces.
Convert Spaces to Tabs	Converts each set of consecutive space characters on the current line to tab characters, but only for those sets of spaces that are at least equal to one tab size.
Tabify Selected Lines	Tabifies the current line, causing all spaces at the start of the line (prior to any text) to be converted to tabs where possible.
Untabify Selected Lines	Untabifies the current line, causing all tabs at the start of the line (prior to any text) to be converted to spaces.
Make Uppercase	Converts all letters within the selection to uppercase.
Make Lowercase	Converts all letters within the selection to lowercase.
Toggle Character Casing	Toggles the character cases (uppercase / lowercase) of all letters within the selection.
Capitalize	Capitalizes the first character of every word within the selection.
Delete Horizontal Whitespace	Deletes any excess white space either side of the cursor position, leaving only one whitespace character remaining. If there the cursor is within a word or not surrounded by whitespace, this operation will have no effect.
Trim Trailing Whitespace	Deletes any trailing whitespace that appears after the last non-whitespace character on the cursor line.
Delete Line	Completely delete the current cursor line.
Duplicate Line	Duplicates the cursor line, inserting a copy of the line immediately after the cursor line.
Delete Blank Lines	Deletes the line at the cursor if it is empty or contains only whitespace.

[Characters area (while connected to the debug tool)]

Register to Watch1	Registers a selected character string or a word at the caret position to the <a href="#">Watch panel</a> (Watch1) as a watch-expression (the judgment of the word depends on current build tool). Note that this item is disabled when no corresponding address exists in the line at caret.
Register to Analysis Chart	Registers a selected character string or a word at the caret position to the Analysis Chart panel of the analyze tool (Program Analyzer) as a variable. If variables have been already registered to all channels, a message is displayed and this operation will have no effect. Note that this item is disabled when the active project does not support a plug-in of the analyze tool.
Register Action Event...	Opens the <a href="#">Action Events dialog box</a> to set an action event to the corresponding address of the line at the caret position <sup>Note 1</sup> . Note that this item is disabled when no corresponding address exists in the line at caret.
Cut	Deletes the selected character string(s) and copies them to the clipboard. If there is no selection, the entire line is cut. Note that this item is disabled when this panel is in the mixed display mode.
Copy	Copies the contents of the selected range to the clipboard as character string(s). If there is no selection, the entire line is copied.
Paste	Inserts (insert mode) or overwrites (overwrite mode) the characters that are copied on the clipboard into the caret position. Note that this item is disabled when the contents of the clipboard are not recognized as characters or this panel is in the mixed display mode.
Find...	Opens the Find and Replace dialog box with selecting [Quick Find] tab.
Go To...	Opens the <a href="#">Go to Line dialog box</a> to move the caret to the specified line.
Forward To Next Cursor Position	Forwards to the position before operating [ <a href="#">Back To Last Cursor Position</a> ]. Note that this item is disabled when this panel is in the mixed display mode.
Back To Last Cursor Position	Goes back to the position before operating [ <a href="#">Jump to Function</a> ]. Note that this item is disabled when this panel is in the mixed display mode.
Go to Here	Executes the program from the address indicated by the current PC value to the address corresponding to the line at the caret position <sup>Note 1</sup> . If the corresponding address of the line at the caret position does not exist, the program is executed to the corresponding address of the lower valid line. Note that this item is disabled during execution of a program or [ <a href="#">Build &amp; Download</a> ].
Set PC to Here	Sets the address of the line at the current caret position to the current PC value <sup>Note 1</sup> . Note that this item is disabled when no corresponding address exists in the line at caret, or during execution of a program or [ <a href="#">Build &amp; Download</a> ].
Jump to Function	Jumps to the function that is selected or at the caret position regarding the selected characters and the words at the caret position as functions (see " <a href="#">(7) Jump to functions</a> ").
Tag Jump	Jumps to the corresponding line and column in the corresponding file if the information of a file name, a line number and a column number exists in the line at the caret position (see " <a href="#">(c) Tag jump</a> ").
Jump to Disassemble	Opens the <a href="#">Disassemble panel</a> and jumps to the address corresponding to the line at the caret <sup>Note 1</sup> . Note that this item is disabled when no corresponding address exists in the line at caret.

Advanced	Displays a cascading menu for performing an advanced operation for the Editor panel. Note that these items are disabled when this panel is in the mixed display mode.
Increase Line Indent	Increases the indentation of the current cursor line by one tab.
Decrease Line Indent	Decreases the indentation of the current cursor line by one tab.
Uncomment Lines	Removes the first set of line-comment delimiters from the start of the current cursor line, appropriate to the current language (e.g. C++). This operation will only be available when the language of the current source file has line-comment delimiters specified (e.g. C++).
Comment Lines	Places line-comment delimiters at the start of the current cursor line, appropriate to the current language (e.g. C++). This operation will only be available when the language of the current source file has line-comment delimiters specified (e.g. C++).
Convert Tabs to Spaces	Converts all tabs on the current cursor line into spaces.
Convert Spaces to Tabs	Converts each set of consecutive space characters on the current line to tab characters, but only for those sets of spaces that are at least equal to one tab size.
Tabify Selected Lines	Tabifies the current line, causing all spaces at the start of the line (prior to any text) to be converted to tabs where possible.
Untabify Selected Lines	Untabifies the current line, causing all tabs at the start of the line (prior to any text) to be converted to spaces.
Make Uppercase	Converts all letters within the selection to uppercase.
Make Lowercase	Converts all letters within the selection to lowercase.
Toggle Character Casing	Toggles the character cases (uppercase / lowercase) of all letters within the selection.
Capitalize	Capitalizes the first character of every word within the selection.
Delete Horizontal Whitespace	Deletes any excess white space either side of the cursor position, leaving only one whitespace character remaining. If there the cursor is within a word or not surrounded by whitespace, this operation will have no effect.
Trim Trailing Whitespace	Deletes any trailing whitespace that appears after the last non-whitespace character on the cursor line.
Delete Line	Completely delete the current cursor line.
Duplicate Line	Duplicates the cursor line, inserting a copy of the line immediately after the cursor line.
Delete Blank Lines	Deletes the line at the cursor if it is empty or contains only whitespace.

Break Settings	The following cascade menus are displayed to set the break-related event. Note that events can be set only for lines for which events can be set (see " <a href="#">(9) Event area</a> ").
Set Hardware Break	Sets a breakpoint (Hardware Break event) to the line at the caret position (see " <a href="#">(1) Set a break event (execution type)</a> ") <sup>Note 1</sup> .
Set Software Break (except [Simulator])	Sets a breakpoint (Software Break event) to the line at the caret position (see " <a href="#">(1) Set a break event (execution type)</a> ") <sup>Note 1</sup> .
Set Combination Break	In this product version, this item is not supported.
Set Read Break to	Sets a break event with read access condition to the line at the caret or the selected variable (global variable, static variable inside functions, or file-internal static variable)/I/O register (see " <a href="#">(1) Set a break event (access type)</a> ").
Set Write Break to	Sets a break event with write access condition to the line at the caret or the selected variable (global variable, static variable inside functions, or file-internal static variable)/I/O register (see " <a href="#">(1) Set a break event (access type)</a> ").
Set R/W Break to	Sets a break event with read/write access condition to the line at the caret or the selected variable (global variable, static variable inside functions, file-internal static variable)/I/O register (see " <a href="#">(1) Set a break event (access type)</a> ").
Set Read Combination Break to	In this product version, this item is not supported.
Set Write Combination Break to	In this product version, this item is not supported.
Set R/W Combination Break to	In this product version, this item is not supported.
Break Option	Opens the <a href="#">Property panel</a> to set the break function.

Trace Settings [IECUBE][IECUBE2] [Simulator]	The following cascade menus are displayed to set the trace-related event. Note that events can be set only for lines for which events can be set (see "(9) Event area").
Start Tracing	Sets a trace start event to start collecting the trace data when the line at the caret is executed (see "(1) Set a Trace event") <sup>Note 1</sup> .  [Simulator] In addition, the selecting of the [Use trace function] property in the [Trace] [IECUBE][IECUBE2][Simulator] category on the <a href="#">Property panel</a> is automatically set to [Yes].
Stop Tracing	Sets a trace end event to stop collecting the trace data when the line at the caret is executed (see "(1) Set a Trace event") <sup>Note 1</sup> .  [Simulator] In addition, the selecting of the [Use trace function] property in the [Trace] [IECUBE][IECUBE2][Simulator] category on the <a href="#">Property panel</a> is automatically set to [Yes].
Record Reading Value	Sets a Point Trace event to record the access value as the trace data when a variable at the caret or the selected variable (global variable, static variable inside functions, file-internal static variable) /I/O register is read accessed (see "(1) Set a Point Trace event").
Record Writing Value	Sets a Point Trace event to record the access value as the trace data when a variable at the caret or the selected variable (global variable, static variable inside functions, file-internal static variable) /I/O register is write accessed (see "(1) Set a Point Trace event").
Record R/W Value	Sets a Point Trace event to record the access value as the trace data when a variable at the caret or the selected variable (global variable, static variable inside functions, file-internal static variable) /I/O register is read/ write accessed (see "(1) Set a Point Trace event").
Record Start R/W Value	In this product version, this item is not supported.
Record End R/W Value	In this product version, this item is not supported.
Show Trace Result	Opens the [Trace] [IECUBE][IECUBE2][Simulator] and displays the acquired trace data.
Trace Settings	Opens the <a href="#">Property panel</a> to set the trace function.
Timer Settings	The following cascade menus are displayed to set the timer-related event <sup>Note 2</sup> (see "2.12.2 Measure execution time in the arbitrary section"). Note that events can be set only for lines for which events can be set (see "(9) Event area").
Start timer	Sets a timer start event to start measuring the execution time of the program when the line at caret is executed <sup>Note 1</sup> .  [Simulator] In addition, the selecting of the [Use timer function] property in the [Timer] [IECUBE][IECUBE2][Simulator] category on the <a href="#">Property panel</a> is automatically set to [Yes].
Stop timer	Sets a timer end event to stop measuring the execution time of the program when the line at caret is executed <sup>Note 1</sup> .  [Simulator] In addition, the selecting of the [Use timer function] property in the [Timer] [IECUBE][IECUBE2][Simulator] category on the <a href="#">Property panel</a> is automatically set to [Yes].
View Result of Timer	Opens the <a href="#">Events panel</a> and displays only timer-related events.
Clear Coverage Information	Clears all the coverage measurement results currently being stored in the debug tool. Note that this item appears only when the debug tool used supports the coverage function.

**Notes 1.** A message is displayed if these items are selected when the downloaded load module file is older than the opened source file.

**2. [V850E1][V850ES]: [MINICUBE2][E1][E20][EZ Emulator]**

Because the Timer Result event is not supported, this item is disabled.

### Memory panel

This panel is used to display the contents of the memory and change the memory value (see "[2.9.1 Display/change the memory](#)").

Furthermore, the contents of data flash memory (including ID tag) can be displayed and changed when the selected microcontroller incorporates the data flash memory.

Up to a maximum of four of these panels can be opened. Each panel is identified by the names "Memory1", "Memory2", "Memory3", and "Memory4" on the titlebar.

The display contents are automatically updated when the value of the memory changes after a program is executed (when the execution is done in steps, the display is updated after each step).

In addition, by enabling the [Real-time display update function](#), it is also possible to update the display contents in real-time even while a program is being executed.


This panel appears only when connected to the debug tool.

**Caution [V850E2]**


**CPU reset may be generated depending on the selected microcontroller if you change the memory value in the data flash area.**

- Remarks 1.** You can set the scroll range of the vertical scroll bar on this panel via the [Scroll Range Settings dialog box](#) which is opened by clicking the  button from [View] on the toolbar.
2. This panel can be zoomed in and out by  in the tool bar, or by moving the mouse wheel forward or backward while holding down the [Ctrl] key.


**Figure A-34. Memory Panel (When Microcontroller without Data Flash Memory)**



**Figure A-35. Memory Panel: [CPU Memory] Tab (When Microcontroller with Data Flash Memory)**



**Figure A-36. Memory Panel: [ID Tag] Tab (When Microcontroller with Data Flash Memory)**



This section describes the following.

- [How to open]
  - [Description of each area]
  - [Toolbar]
  - [[File] menu (Memory panel-dedicated items)]
  - [[Edit] menu (Memory panel-dedicated items)]
  - [Context menu]

## [How to open]

- From the [View] menu, select [Memory] >> [Memory 1-4].

### [Description of each area]

#### (1) Display position specification area

It is possible to specify the display start position of the memory contents by specifying an address expression.

Specify the following items.

##### (a) Specify an address expression

Directly input the address expression of the memory value address to display in the text box. You can specify an input expression with up to 1024 characters. The result of the expression is treated as the display start position address.

Note that an address value greater than the microcontroller address space cannot be specified.

In addition, an address value greater than the value expressed within 32 bits cannot be specified.

**Remarks 1.** A symbol name at the current caret position can be complemented by pressing the [Ctrl] + [Space] key in this text box (see "2.18.2 Symbol name completion function").

2. If the specified address expression is the symbol and its size can be recognized, everything from the start address to the end address of that symbol is displayed selected.

##### (b) Specify automatic/manual evaluation of the address expression

The timing to change the display start position can be determined by specifying in the [Move when Stop] check box and the [Move] button.

[Move when Stop]	<input checked="" type="checkbox"/>	The caret is moved to the address which is automatically calculated from the address expression after the program is stopped.
	<input type="checkbox"/>	The address expression is not automatically evaluated after the program is stopped. Click the [Move] button to manually evaluate the address expression.
[Move] button		When the [Move when Stop] check box is not checked, click this button to evaluate the address expression and move the caret to the result address of the evaluation.

#### (2) Address area

The address of the memory is displayed (hexadecimal number notation fixing).

The display starts from address 0x0 by default. However, an offset value of the start address can be set via the [Address Offset Settings dialog box](#) that is opened by selecting [Address Offset Value Settings...] from the context menu.

The address width corresponds to the one in memory space of the specified microcontroller in the project.

This area cannot be edited.

**Caution** The offset value that have been set is automatically changed in accordance with the number of view columns in the [Memory value area](#).

#### (3) Memory value area

The value of the memory is displayed and changed.

Specification of the display notation, display width of memory values or the number of view columns is performed by selecting the buttons on the toolbar or [Notation]/[Size Notation]/[View] from the context menu (see "(2) Change display format of values").

The meanings of the marks and colors displayed as memory values are as follows (character colors and background colors depend on the configuration in the [\[General - Font and Color\] category](#) of the [Option dialog box](#)):

Display Example (Default)			Description		
<b>00</b>	Character color	Blue	Memory value that the user is changing Press the [Enter] key to write to the target memory.		
	Background color	Standard color			
<b><u>00</u></b> (Under line)	Character color	Standard color	Memory value of the address whose symbol has been defined ( <a href="#">Registering watch-expression</a> can be performed).		
	Background color	Standard color			
<b>00</b>	Character color	Brown	Memory value that has been changed because of the execution of a program <small>Note</small> To reset the highlighting, select the  button on the toolbar.		
	Background color	Cream			
<b>00</b>	Character color	Pink	Memory value for which the <a href="#">Real-time display update function</a> is being operated		
	Background color	Standard color			
<b>00</b>	Character color	Standard color	Read/Fetch	Current access condition of the memory value when the <a href="#">Real-time display update function</a> is being operated	
	Background color	Palegreen			
<b>00</b>	Character color	Standard color	Write		
	Background color	Orange			
<b>00</b>	Character color	Standard color	Read and Write		
	Background color	Paleturquoise			
<b>00</b>	Character color	Gray	Memory value of the read-protected area		
	Background color	Standard color			
<b>??</b>	Character color	Gray	Areas not memory-mapped		
	Background color	Standard color			
<b>--</b>	Character color	Gray	Areas not rewritable (e.g. I/O register area/I/O protection area) or when acquisition of memory values failed		
	Background color	Standard color			
<b>**</b>	Character color	Standard color	When display is specified for other than the real-time display update area during program execution or when acquisition of memory values failed		
	Background color	Standard color			

**Note** Just before execution of a program, only the memory value in the address range for which the Memory panel had been displayed becomes the target.

In addition, the value is not highlighted if it is same for before and after the execution of the program.


**Caution** The number of view columns is automatically changed in accordance with the set value of [Size Notation] of the context menu.

This area is provided with the following functions.

#### (a) Pop-up display

The following contents are pop-up displayed based on the nearest existing symbol forward from the address the mouse is designating when hovering the mouse cursor over the memory value.

Note that if there is no symbol information (the underlining is non-display), no pop-up display is done.



Symbol name	Indicates the name of the symbol.
Offset value	When a symbol has not been defined for the addresses, the offset value from the nearest symbol exists forward is displayed (hexadecimal number notation fixing).

**(b) Real-time display update function**

Using the real-time display update function allows you to display/modify the value of the memory contents not only while the program is stopped, but also in execution.

See "[\(4\) Display/modify the memory contents during program execution](#)" for details on the real-time display update function.

**(c) Changing memory values**

Directly edit from the keyboard after moving the caret to the memory value to be edited.

The color of the memory value changes when it is in editing. Press the [Enter] key to write the edited value to the target memory (if the [Esc] key is pressed before the [Enter] key is pressed, the editing is cancelled).

See "[\(3\) Modify the memory contents](#)" for details on the method for changing the memory value.

**(d) Searching/initializing memory value**

The [Memory Search dialog box](#) is opened to search the memory contents in the specified address range by selecting [Find...] from the context menu (see "[\(5\) Search the memory contents](#)").

In addition, the [Memory Initialize dialog box](#) is opened to change the memory contents collectively in the specified address range by selecting [Fill...] from the context menu (see "[\(6\) Modify the memory contents in batch \(initialize\)](#)").

**(e) Copying and pasting**

By selecting a range of memory values with the mouse, the contents of the range can be copied to the clipboard as a character string, and these contents can be pasted to the caret position.

These operations are performed by selecting from the context menu or selecting from the [Edit] menu.

However, the paste operation is possible only when the character string to be pasted and the display notation (radix and size) of the area match.

If the display notation does not match, a message is displayed.

The character codes and character strings that can be handled by this area are as follows.

If character strings other than these are pasted, a message is displayed.

Character code	ASCII
Character string	0, 1, 2, 3, 4, 5, 6, 7, 8, 9, a, b, c, d, e, f, A, B, C, D, E, F

**(f) Registering watch-expression**

A memory value with underline indicates that a symbol has been defined in the address, and its symbol can be registered as a watch-expression.

After selecting the memory value or placing the caret on the memory value, the symbol name of the address is registered in the [Watch panel](#) (Watch1) as a watch-expression by selecting [Register to Watch1] from the context menu.

**Caution A memory value without underline cannot be registered as a watch-expression.**

### (g) Saving the contents of memory values

The [Data Save dialog box](#) can be opened by selecting the [File] menu >> [Save Memory Data As...], and the contents of this panel can be saved in a text file (\*.txt) or CSV file (\*.csv).

See "[\(7\) Save the memory contents](#)" for details on the method for saving the contents of memory values.

### (4) Character strings area

Memory values converted into character code are displayed.

The character code can be specified by selecting [Encoding] from the toolbar or context menu (ASCII code is selected by default).

Furthermore, in this area, memory values converted into a floating-point value can be displayed as character strings. To do this, select the following item from [Encoding] of the context menu.

Item	Display Format		Size
Float	Single-precision floating-point value		32-bit
	Numeric value	<sign><mantissa>e<sign><exponent>	
	Infinite number	Inf, and -Inf	
	Not a number	NaN	
	Example	+ 1.234567e+123	
Double	Double-precision floating-point value		64-bit
	Numeric value	<sign><mantissa>e<sign><exponent>	
	Infinite number	Inf, and -Inf	
	Not a number	NaN	
	Example	+ 1.2345678901234e+123	
Float Complex	Complex number of single-precision floating-point		64-bit
	<Single-precision floating-point value> <Single-precision floating-point value> * i		
Double Complex	Complex number of double-precision floating-point		128-bit
	<Double-precision floating-point value> <Double-precision floating-point value> * i		
Float Imaginary	Imaginary number of single-precision floating-point		32-bit
	<Single-precision floating-point value> * i		
Double Imaginary	Imaginary number of double-precision floating-point		64-bit
	<Double-precision floating-point value> * i		

**Caution** Nothing is displayed when the minimum size of a character code or a floating-point value is greater than "the number of bytes of display width of memory values" x "the number of bytes of the number of view columns".

This area is provided with the following functions.

#### (a) Changing character strings

Directly edit from the keyboard after moving the caret to the character string to be edited.

The color of the character string changes when it is in editing. Press the [Enter] key to write the edited value to the target memory (if the [Esc] key is pressed before the [Enter] key is pressed, the editing is cancelled).

**Caution** Character strings displayed as floating-point values cannot be searched.

**(b) Searching character strings**

The [Memory Search dialog box](#) is opened to search for character strings by selecting [Find...] from the context menu (see "[\(5\) Search the memory contents](#)").

**(c) Copying and pasting**

By selecting a range of character strings with the mouse, the contents of the range can be copied to the clipboard as a character string, and these contents can be pasted to the caret position.

These operations are performed by the selecting from the context menu or selecting from the [Edit] menu.

However, the paste operation is possible only when [ASCII] has been selected as the character code. If other than [ASCII] is selected, a message is displayed.

**(5) Tab selection area (except [Simulator])**

This area appears only when the selected microcontroller incorporates the data flash memory.

Select the tab that indicates the memory type.

The following tabs are displayed.

Tab Name	Description
CPU Memory	Displays the value of the memory mapped to the microcontroller.
ID Tag	Displays the value of the ID tag for the data flash memory.

**(6) ID Tag area (except [Simulator])**

This area appears only when the selected microcontroller incorporates the data flash memory.

The value of the ID tag for the data flash memory is displayed.

The ID tag is a bit assigned to the data flash memory and is used to detect power failure. When it is "0", it means that the data has been written normally.

The setting for this area can be changed only between "0" and "1".

**[Toolbar]**

	Acquires the latest data from the debug tool, and updates the contents of this panel.
	Resets highlighting of values that have been changed by executing a program. This item is disabled during execution of a program.
Notation	The following buttons to change the notation of memory values are displayed. The items below is disabled during execution of a program.
	Displays memory values in hexadecimal number (default).
	Displays memory values in signed decimal number.
	Displays memory values in unsigned decimal number.
	Displays memory values in octal number.
	Displays memory values in binary number.

Size Notation	The following buttons to change the notation of sizes of memory values are displayed. The items below is disabled during execution of a program.
	Displays memory values in 4-bit width.
	Displays memory values in 8-bit width (default).
	Displays memory values in 16-bit width. Values are converted depending on the endian of the target memory area.
	Displays memory values in 32-bit width. Values are converted depending on the endian of the target memory area.
	Displays memory values in 64-bit width. Values are converted depending on the endian of the target memory area.
Encoding	The following buttons to change the encoding of character strings are displayed. The items below is disabled during execution of a program.
	Displays character strings in ASCII code (default).
	Displays character strings in Shift_JIS code.
	Displays character strings in EUC-JP code.
	Displays character strings in UTF-8 code.
	Displays character strings in UTF-16 code.
	Displays character strings as a single-precision floating-point value.
	Displays character strings as a double-precision floating-point value.
	Displays character strings as a complex number of single-precision floating-point.
	Displays character strings as a complex number of double-precision floating-point.
	Displays character strings as an imaginary number of single-precision floating-point.
	Displays character strings as an imaginary number of double-precision floating-point.
View	The following buttons to change the display format are displayed.
	Opens the <a href="#">Scroll Range Settings dialog box</a> to set the scroll range for this panel.
Column Number Settings...	Opens the <a href="#">Column Number Settings dialog box</a> to set the number of view columns in the <a href="#">Memory value area</a> .
Address Offset Value Settings...	Opens the <a href="#">Address Offset Settings dialog box</a> to set an offset value for addresses displayed in the <a href="#">Address area</a> .

### [[File] menu (Memory panel-dedicated items)]

The following items are exclusive for the [File] menu in the Memory panel (other items are common to all the panels). Note that all these items are disabled during execution of a program.

Save Memory Data	Overwrites the contents of this panel to the previously saved text file (*.txt)/CSV file (*.csv) (see " <a href="#">(g) Saving the contents of memory values</a> "). Note that when the file has never been saved or the file is write disabled, the same operation is applied as the selection in [Save Memory Data As...].
Save Memory Data As...	Opens the <a href="#">Data Save dialog box</a> to newly save the contents of this panel to the specified text file (*.txt)/CSV file (*.csv) (see " <a href="#">(g) Saving the contents of memory values</a> ").

**[Edit] menu (Memory panel-dedicated items)**

The following items are exclusive for [Edit] menu in the Memory panel (all other items are disabled).

Note that all these items are disabled during execution of a program.

Copy	Copies the contents of the selected range to the clipboard as character string(s).
Paste	Pastes the character string(s) copied in the clipboard to the caret position. - To the memory value area: See "(e) Copying and pasting". - To the character strings area: See "(c) Copying and pasting".
Find...	Opens the <a href="#">Memory Search dialog box</a> . The search is operated either in the <a href="#">Memory value area</a> or the <a href="#">Character strings area</a> , in which a caret is.

**[Context menu]**

Register to Watch1	Registers the symbol at the caret to the <a href="#">Watch panel</a> (Watch1). At this time, since it is registered as a variable name, the symbol name that is displayed changes depending on the scope. Note that this item is disabled when no symbol has been defined in the address corresponding to the memory value at the caret position (see "(f) Registering watch-expression").
Find...	Opens the <a href="#">Memory Search dialog box</a> . The search is operated either in the <a href="#">Memory value area</a> or the <a href="#">Character strings area</a> (unless the floating-point value display is selected), in which a caret is. This item is disabled during execution of a program.
Fill...	Opens the <a href="#">Memory Initialize dialog box</a> .
Refresh	Acquires the latest data from the debug tool, and updates the contents of this panel.
Copy	Copies the contents of the selected range to the clipboard as character string(s). This item is disabled during execution of a program.
Paste	Pastes the character string(s) copied in the clipboard to the caret position. This item is disabled during execution of a program. - To the memory value area: See "(e) Copying and pasting". - To the character strings area: See "(c) Copying and pasting".
Notation	The following cascade menus are displayed to specify the notation of memory values. The items below is disabled during execution of a program.
Hexadecimal	Displays memory values in hexadecimal number (default).
Signed Decimal	Displays memory values in signed decimal number.
Unsigned Decimal	Displays memory values in unsigned decimal number.
Octal	Displays memory values in octal number.
Binary	Displays memory values in binary number.

Size Notation	The following cascade menus are displayed to specify the notation of sizes of memory values. The items below is disabled during execution of a program.
4 Bits	Displays memory values in 4-bit width.
1 Byte	Displays memory values in 8-bit width (default).
2 Bytes	Displays memory values in 16-bit width. Values are converted depending on the endian of the target memory area.
4 Bytes	Displays memory values in 32-bit width. Values are converted depending on the endian of the target memory area.
8 Bytes	Displays memory values in 64-bit width. Values are converted depending on the endian of the target memory area.
Encoding	The following cascade menus are displayed to specify the display format in the character strings area. The items below is disabled during execution of a program.
ASCII	Displays character strings in ASCII code (default).
Shift_JIS	Displays character strings in Shift_JIS code.
EUC-JP	Displays character strings in EUC-JP code.
UTF-8	Displays character strings in UTF-8 code.
UTF-16	Displays character strings in UTF-16 code.
Float	Displays character strings as a single-precision floating-point value.
Double	Displays character strings as a double-precision floating-point value.
Float Complex	Displays character strings as a complex number of single-precision floating-point.
Double Complex	Displays character strings as a complex number of double-precision floating-point.
Float Imaginary	Displays character strings as an imaginary number of single-precision floating-point.
Double Imaginary	Displays character strings as an imaginary number of double-precision floating-point.
View	The following cascade menus are displayed to specify the display format.
Settings Scroll Range...	Opens the <a href="#">Scroll Range Settings dialog box</a> to set the scroll range for this panel.
Column Number Settings...	Opens the <a href="#">Column Number Settings dialog box</a> to set the number of view columns in the <a href="#">Memory value area</a> .
Address Offset Value Settings...	Opens the <a href="#">Address Offset Settings dialog box</a> to set an offset value for addresses displayed in the <a href="#">Address area</a> .
Highlight Accessed	Highlights memory values that have changed by execution of a program if this item is checked (default). This item is disabled during execution of a program.
Periodic Updating	The following cascade menus are displayed to set for the real-time display update function (see "(b) <a href="#">Real-time display update function</a> ").
Periodic Updating Options	Opens the <a href="#">Property panel</a> to set for the real-time display update function.

### Disassemble panel

This panel is used to display the results of disassembling the contents of the memory (disassembled text), and execute line assembly (see "2.6.4 Perform line assembly").

Furthermore, the instruction level debugging (see "2.7.3 Execute programs in steps") and the code coverage measurement result display [IECUBE][IECUBE2][Simulator] (see "2.13 Measure Coverage [IECUBE][IECUBE2][Simulator]") can be performed in this panel.

Up to a maximum of four of these panels can be opened. Each panel is identified by the names "Disassemble1", "Disassemble2", "Disassemble3" and "Disassemble4" on the titlebar.

The source text in the source file corresponding to the code data can also be displayed by setting to the mixed display mode (default).

This panel appears only when connected to the debug tool.

**Caution** A step execution is performed in instruction level units when the focus is in this panel (see "2.7.3 Execute programs in steps").

- Remarks 1.** You can set the scroll range of the vertical scroll bar on this panel via the [Scroll Range Settings dialog box](#) which is opened by clicking the  button from [View] on the toolbar.
2. You can print the current screen image of this panel by selecting [Print...] from the [File] menu.
  3. This panel can be zoomed in and out by [100%](#) in the tool bar, or by moving the mouse wheel forward or backward while holding down the [Ctrl] key.

**Figure A-37. Disassemble Panel (When Mixed Display Mode Is Selected)**




Figure A-38. Disassemble Panel (When Mixed Display Mode Is Not Selected)





Figure A-39. Disassemble Panel (When Code Coverage Measurement Result Is Displayed)



This section describes the following.

- [How to open]
- [Description of each area]
- [Toolbar]
- [[File] menu (Disassemble panel-dedicated items)]
- [[Edit] menu (Disassemble panel-dedicated items)]
- [Context menu]

**[How to open]**

- From the [View] menu, select [Disassemble] >> [Disassemble 1 - 4].

**[Description of each area]****(1) Event area**

The lines for which events can be set are shown with the background color in white (this mean that events cannot be set for those lines whose background color in gray).

In addition, the [Event mark](#) corresponding to an event that has been currently set is displayed.

This area is provided with the following functions.

**(a) Setting/deleting breakpoints**

By clicking where you want to set a breakpoint with the mouse, the breakpoint can be set easily.

The breakpoint is set to the instruction at the start address of the clicked line.

Once the breakpoint is set, the [Event mark](#) is displayed at the line that is set. In addition, the detailed information about the set breakpoint is reflected in the [Events panel](#).

When this operation is performed at a place where any one of the event marks is already being displayed, that event is deleted and the setting of breakpoints cannot be done.

Note that the setting of events can be done only for those lines where the background color is shown in white.

See "[2.8.2 Stop the program at the arbitrary position \(breakpoint\)](#)" for details on how to set the breakpoint.

**(b) Changes event status**

Event status can be changed from the following menu displayed by right-clicking the event mark.

Enable Event	Changes the selected event state to a <a href="#">Valid state</a> . Event occurs when the specified condition is met. When the event mark (■) which indicates that multiple events have been set is selected, all of the events that have been set are enabled.
Disable Event	Changes the selected event state to an <a href="#">Invalid state</a> . Event does not occur when the specified condition is met. When the event mark (■) which indicates that multiple events have been set is selected, all of the events that have been set are disabled.
Delete Event	Deletes the selected event. When the event mark (■) which indicates that multiple events have been set is selected, all of the events that have been set are deleted.
View Event Detailed Setup	Opens the <a href="#">Events panel</a> to display the detailed information of the selected event.

**(c) Pop-up display**

By hovering the mouse cursor over the [Event mark](#), the name of the event, the detailed information for the event and the comments added to the event are pop-up displayed.

When multiple events have been set in the applicable place, information for each event, up to a maximum of three events, is listed and displayed.

**(2) Address area**

The address per line to start disassembling is displayed (hexadecimal number notation fixing).

In addition, the current PC mark (■) that corresponds to the current PC position (PC register value) is displayed.

The address width corresponds to the one in memory space of the specified microcontroller in the project.

For the source text line in the mixed display mode, line numbers (xxx) in the source file correspond to the start address are displayed.

This area is provided with the following functions.

#### (a) Pop-up display

By hovering the mouse cursor over a address or line number, the following information is pop-up displayed.


Address	Format: <Label name> + <Offset value> Example1: main + 0x10 Example2: sub function + 0x20
Source line number	Format: <Load module name> <sup>Note\$</sup> <File name> # <Line number> Example1: test1.out\$main.c#40 Example2: main.c#100

**Note** <Load module name> is displayed only when multiple load modules have been downloaded to the debug tool.

#### (3) Disassemble area

The results of disassembling are displayed next to the corresponding source text as follows.

Figure A-40. Display Contents of Disassemble Area (In Case of Mixed Display Mode)



Label line	The label is displayed when a label is defined for the address, and its corresponding line is shown highlighted in lightgreen.	
PC line	A line corresponding to an address of the current PC (PC register value) is shown highlighted <sup>Note 1</sup> .	
Breakpoint line	A line at which a breakpoint is set is shown highlighted <sup>Note 1</sup> .	
Source text line	The source text corresponding to the code data is displayed <sup>Note 2</sup> .	
Disassemble results	Offset value	The offset value from the nearest label is displayed when a label is defined for the address <sup>Note 3</sup> .
	Code	The code that is the target of disassembly is displayed in hexadecimal number.
	Instruction	Instruction is displayed as the result of disassembling. The mnemonics are shown highlighted in blue.

- Notes**
1. The highlighting color depends on the configuration in the [General - Font and Color] category of the [Option dialog box](#).
  2. The source text can be set to non-display by clicking the  button (toggle) on the toolbar or removing the check for [Mixed Display] from the context menu (this option is checked by default).
  3. Offset values are not displayed by default. They can be displayed by clicking the  button on the toolbar or selecting [Show Offset] from the context menu.

This area is provided with the following functions.

#### (a) Line assembly

Instructions and code displayed in this panel can be edited (line assembly).

See "[2.6.4 Perform line assembly](#)" for details on how to operate it.

#### (b) Program execution by instruction level

Execution can be controlled at the instruction level unit by step executing a program in a state where there is a focus on this panel.

See "[2.7.3 Execute programs in steps](#)" for details on how to operate it.

#### (c) Setting of various events

Various events can be set to the addresses/lines where the caret currently exists by selecting [Break Settings], [Trace Settings] or [Timer Settings] from the context menu.

The corresponding [Event mark](#) is displayed in the [Event area](#) when an event is set. In addition, the detailed information about the set event is reflected in the [Events panel](#).

+Note, however, that the setting of events can be done only for those lines where the background color is shown in white in the event area.

See the following for details on how to set events.

- "[2.8.4 Stop the program with the access to variables/I/O registers](#)"
- "[2.11.3 Collect execution history in the arbitrary section](#)"
- "[2.11.4 Collect execution history only when the condition is met](#)"
- "[2.12.2 Measure execution time in the arbitrary section](#)"

**Remark** A breakpoint can be set or deleted easily in the [Event area](#) as well (see "[\(a\) Setting/deleting breakpoints](#)").

#### (d) Registering watch-expression

Variable names of C language, CPU registers, I/O registers, and assembler symbols can be registered in the [Watch panel](#) as watch-expressions.

See "[\(1\) Register a watch-expression](#)" for details on how to operate it.

#### (e) Moving to symbol definition place

By clicking the  button on the toolbar or selecting [Go to Symbol] from the context menu in a state where the caret has been moved to a instruction that has referenced a symbol, the caret position is moved to the address where the symbol at the caret position has been defined.

In addition, when following on this operation you click on the  button on the toolbar or select [Back to Address] from the context menu, the caret position is returned to the instruction that has referenced a symbol before the caret was moved (the address value of the instruction that has referenced a symbol is displayed in [Address](#)).

**(f) Jump to source line and memory**

Selecting [Jump to Source] from the context menu will open the [Editor panel](#) with the caret moved to the source line corresponding to the address at the current caret position (if the Editor panel is already open, the screen will jump to the panel).

In addition, similarly, selecting [Jump to Memory] will open the [Memory panel](#) (Memory1) with the caret moved to the memory value corresponding to the address at the current caret position (if the Memory panel (Memory1) is already open, the screen will jump to the panel).

**(g) Code coverage measurement result display [IECUBE][IECUBE2][Simulator]**

When the coverage function is valid, lines corresponding to the specified coverage measurement area are shown highlighted based on the code coverage measurement result that is acquired by executing the program. See "[2.13 Measure Coverage \[IECUBE\]\[IECUBE2\]\[Simulator\]](#)" for details on the coverage measurement.

**(h) Saving the contents of disassembled data**

The [Data Save dialog box](#) can be opened by selecting the [File] menu >> [Save Disassemble Data As...], and the contents of this panel can be saved in a text file (\*.txt) or CSV file (\*.csv).

See "[\(5\) Save the disassembled text contents](#)" for details on the method for saving the contents of disassembled data.

**[Toolbar]**

	Acquires the latest data from the debug tool, and updates the contents of this panel.
	Sets to the mixed display mode and displays the correspondence between the disassembled data and the source text (default).
	Specifies the caret position so that it follows the current PC value.
	Moves the caret to the define position of the selected symbol.
	Moves the caret to the position (address) immediately before it is moved with the  button.
View	The following buttons to set the display contents in the disassemble area are displayed.
	Displays the offset value of the label. The offset value from the nearest label is displayed when a label is defined for the address.
	Displays the address value in the format "symbol + offset value" (default). Note that when a symbol has been defined as the address value, only the symbol is displayed.
	Displays the name of the register by its function name (default).
	Displays the name of the register by its absolute name.
	Opens the <a href="#">Scroll Range Settings dialog box</a> to set the scroll range for this panel.

**[File] menu (Disassemble panel-dedicated items)**

The following items are exclusive for the [File] menu in the Disassemble panel (other items are common to all the panels).

Note that all these items are disabled during execution of a program.

Save Disassemble Data	Overwrites the contents of the disassembling to the previously saved text file (*.txt)/CSV file (*.csv) (see " <a href="#">(h) Saving the contents of disassembled data</a> "). Note that when the file has never been saved or the file is write disabled, the same operation is applied as the selection in [Save Disassemble Data As...].
Save Disassemble Data As...	Opens the <a href="#">Data Save dialog box</a> to newly save the contents of the disassembling to the specified text file (*.txt)/CSV file (*.csv) (see " <a href="#">(h) Saving the contents of disassembled data</a> ").
Print...	Opens the <a href="#">Print Address Range Settings dialog box</a> for printing the contents of this panel.

**[Edit] menu (Disassemble panel-dedicated items)**

The following items are exclusive for the [Edit] menu in the Disassemble panel (all other items are disabled).

Copy	When a line is selected, copies the contents of the selected line to the clipboard as a character string. In the case of the edit mode, copies the selected character string to the clipboard.
Rename	Changes to the edit mode to edit the instruction/code at the caret position (see " <a href="#">2.6.4 Perform line assembly</a> "). This item is disabled during execution of a program.
Find...	Opens the Find and Replace dialog box with selecting the [Find in Files] tab.
Replace...	Opens the Find and Replace dialog box with selecting the [Replace in Files] tab.
Move...	Opens the <a href="#">Go to the Location dialog box</a> to move the caret to the specified address.

**[Context menu]**

[Disassemble area and Address area]

Register to Watch1	Registers the selected character string or the word at the caret position to the <a href="#">Watch panel</a> (Watch1) as a watch-expression (the judgment of the word depends on current build tool). At this time, since it is registered as a variable name, the symbol name that is displayed changes depending on the scope.
Register Action Event...	Opens the <a href="#">Action Events dialog box</a> to set an action event to the address at the caret position.
Go to Here	Executes the program from the address indicated by the current PC value to the address corresponding to the line at the caret position. This item is disabled during execution of a program/[Build & Download].
Set PC to Here	Sets the address of the line at the current caret position to the current PC value. This item is disabled during execution of a program/[Build & Download].
Move...	Opens the <a href="#">Go to the Location dialog box</a> to move the caret to the specified address.
Go to Symbol	Moves the caret to the define position of the selected symbol.
Back to Address	Moves the caret to the position (address) immediately before it is moved by [Go to Symbol]. Note that this item is disabled when no symbol name is displayed in the address.

Break Settings	The following cascade menus are displayed to set the break-related event. Note that breakpoints can be set only for lines for which events can be set (see " <a href="#">(1) Event area</a> ").
Set Hardware Break	Sets a breakpoint (Hardware Break event to the address at the caret position (see " <a href="#">2.8.2 Stop the program at the arbitrary position (breakpoint)</a> ").
Set Software Break (except [Simulator])	Sets a breakpoint (Software Break event) to the address at the caret position (see " <a href="#">2.8.2 Stop the program at the arbitrary position (breakpoint)</a> ").
Set Combination Break	In this product version, this item is not supported.
Set Read Break to	Sets a break event with read access condition to a variable at the caret or a selected variable (global variable/static variable inside functions/file-internal static variable)/I/O register (see " <a href="#">(1) Set a break event (access type)</a> ").
Set Write Break to	Sets a break event with write access condition to a variable at the caret or a selected variable (global variable/static variable inside functions/file-internal static variable)/I/O register (see " <a href="#">(1) Set a break event (access type)</a> ").
Set R/W Break to	Sets a break event with read/write access condition to a variable at the caret or a selected variable (global variable/static variable inside functions/file-internal static variable)/I/O register (see " <a href="#">(1) Set a break event (access type)</a> ").
Set Read Combination Break to	In this product version, this item is not supported.
Set Write Combination Break to	In this product version, this item is not supported.
Set R/W Combination Break to	In this product version, this item is not supported.
Break Option	Opens the <a href="#">Property panel</a> to set the break function.

Trace Settings [IECUBE][IECUBE2] [Simulator]	The following cascade menus are displayed to set the trace-related event.  Note that events can be set only for lines for which events can be set (see " <a href="#">(1) Event area</a> ").
Start Tracing	Sets a trace start event to start collecting the trace data when an instruction of an address at the caret position is executed (see " <a href="#">(1) Set a Trace event</a> ").  [Simulator]  In addition, the selecting of the [Use trace function] property in the [Trace] [IECUBE][IECUBE2][Simulator] category on the <a href="#">Property panel</a> is automatically set to [Yes].
Stop Tracing	Sets a trace end event to stop collecting the trace data when an instruction of an address at the caret position is executed (see " <a href="#">(1) Set a Trace event</a> ").  [Simulator]  In addition, the selecting of the [Use trace function] property in the [Trace] [IECUBE][IECUBE2][Simulator] category on the <a href="#">Property panel</a> is automatically set to [Yes].
Record Reading Value	Sets a Point Trace event to record the access value as the trace data when a variable at the caret or the selected variable (global variable, static variable inside functions, file-internal static variable) or I/O register is read accessed (see " <a href="#">(1) Set a Point Trace event</a> ").
Record Writing Value	Sets a Point Trace event to record the access value as the trace data when a variable at the caret or the selected variable (global variable, static variable inside functions, file-internal static variable) or I/O register is write accessed (see " <a href="#">(1) Set a Point Trace event</a> ").
Record R/W Value	Sets a Point Trace event to record the access value as the trace data when a variable at the caret or a selected variable (global variable/static variable inside functions/file-internal static variable)/I/O register is read/write accessed (see " <a href="#">(1) Set a Point Trace event</a> ").
Record Start R/W Value	In this product version, this item is not supported.
Record End R/W Value	In this product version, this item is not supported.
Show Trace Result	Opens the <a href="#">Trace panel</a> [IECUBE][IECUBE2][Simulator] and displays the acquired trace data.
Trace Settings	Opens the <a href="#">Property panel</a> to set the trace function.
Timer Settings	The following cascade menus are displayed to set the timer-related event <sup>Note</sup> (see " <a href="#">2.12.2 Measure execution time in the arbitrary section</a> ").  Note that events can be set only for lines for which events can be set (see " <a href="#">(1) Event area</a> ").
Start timer	Sets a timer start event to start measuring the execution time of the program when an instruction of an address at the caret position is executed.  [Simulator]  In addition, the selecting of the [Use timer function] property in the [Timer] [IECUBE][IECUBE2][Simulator] category on the <a href="#">Property panel</a> is automatically set to [Yes].
Stop timer	Sets a timer end event to stop measuring the execution time of the program when an instruction of an address at the caret position is executed.  [Simulator]  In addition, the selecting of the [Use timer function] property in the [Timer] [IECUBE][IECUBE2][Simulator] category on the <a href="#">Property panel</a> is automatically set to [Yes].
View Result of Timer	Opens the <a href="#">Events panel</a> and displays only timer-related events.
Clear Coverage Information	Clears all the coverage measurement results currently being stored in the debug tool.  Note that this item appears only when the debug tool used supports the coverage function.
Edit Disassemble	Changes to the edit mode to edit the instruction of the line at the caret position (see " <a href="#">2.6.4 Perform line assembly</a> ").  This item is disabled during execution of a program.

Edit Code	Changes to the edit mode to edit the code of the line at the caret position (see "2.6.4 Perform line assembly"). This item is disabled during execution of a program.
View	The following cascade menus to set the display contents in the disassemble area are displayed.
Show Offset	Displays the offset value of the label. The offset value from the nearest label is displayed when a label is defined for the address.
Show Symbol	Displays the address value in the format "symbol + offset value" (default). Note that when a symbol has been defined as the address value, only the symbol is displayed.
Show Function Name	Displays the name of the register by its function name (default).
Show Absolute Name	Displays the name of the register by its absolute name.
Settings Scroll Range...	Opens the <a href="#">Scroll Range Settings dialog box</a> to set the scroll range for this panel.
Mixed Display	Sets to the mixed display mode and displays the correspondence between the disassembled data and the source text (default).
Jump to Source	Opens the <a href="#">Editor panel</a> and jumps to the source line corresponding to the address at the caret position in this panel.
Jump to Memory	Opens the <a href="#">Memory panel</a> (Memory1) and jumps to the memory value corresponding to the address at the caret position in this panel.

**Note [V850E1][V850ES]: [MINICUBE2][E1][E20][EZ Emulator]**

Because the Timer Result event is not supported, this item is disabled.

**[Event area] (except [Simulator])**

Hardware Break First	The type of break that can be set by a one click operation of the mouse is set as a hardware breakpoint (this is reflected in the setting of the [First using type of breakpoint] property in the <a href="#">[Break] category</a> on the <a href="#">Property panel</a> ).
Software Break First	The type of break that can be set by a one click operation of the mouse is set as a software breakpoint (this is reflected in the setting of the [First using type of breakpoint] property in the <a href="#">[Break] category</a> on the <a href="#">Property panel</a> ).


### CPU Register panel

This panel is used to display the contents of the CPU register (general-purpose registers and system registers) and change the CPU register values (see "2.9.2 Display/change the CPU register").

This panel appears only when connected to the debug tool.

- Remarks 1.** This panel can be zoomed in and out by  in the tool bar, or by moving the mouse wheel forward or backward while holding down the [Ctrl] key.
- 2.** When the separator line of each area in this panel is double-clicked, the width of the area changes to the shortest possible size that can display the contents of the area.

Figure A-41. CPU Register Panel



This section describes the following.

- [\[How to open\]](#)
- [\[Description of each area\]](#)
- [\[Toolbar\]](#)
- [\[\[File\] menu \(CPU Register panel-dedicated items\)\]](#)
- [\[\[Edit\] menu \(CPU Register panel-dedicated items\)\]](#)
- [\[Context menu\]](#)

#### [How to open]

- From the [View] menu, select [CPU Register].

#### [Description of each area]

##### (1) [Register Name] area

The types of register are classified as categories (folders), and a list of the respective register names is displayed. Note that neither category names nor register names can be edited and deleted.

The meanings of the icons are as follows:



Indicates that the register name belonging to this category is displayed. When you double-click on the icon, or click on the "-" mark, the category is closed and the register name is hidden.

	Indicates that the register name belonging to this category is hidden. When you double-click on the icon, or click on the "+" mark, the category is opened and the register name is displayed.
	Indicates the name of the register. When you double-click on the icon, or click on the "+" or "-" marks, the name of the register part is displayed or hidden.
	Indicates the name of the register part.

Category names and register names displayed are as follows (number of "+" marks before register names indicates the depth of the display level):

**Table A-8. Register Names in [General Registers] Category [V850E1][V850ES]**

Register Name (Alias)	Bit Width	Register Name (Alias)	Bit Width
+ r0	32	+ r5(TP)	32
+ r1	32	+ r6 to + r29	32
+ r2	32	+ r30(EP)	32
+ r3(SP)	32	+ r31(LP)	32
+ r4(GP)	32		

**Table A-9. Register Names in [General Registers] Category [V850E2]**

Register Name (Alias)	Bit Width	Register Name (Alias)	Bit Width
+ Integer	-	+ Single Precision Floating Point	-
++ r0	32	++ fp1 to + fp30	32
++ r1	32	++ fp31	32
++ r2	32	+ Double Precision Floating Point	-
++ r3(SP)	32	++ dp2	64
++ r4(GP)	32	++ dp2 to + dp28	64
++ r5(TP)	32	++ dp30	64
+ r6 to + r29	32		
++ r30(EP)	32		
++ r31(LP)	32		

**Table A-10. Register Names in [System Registers] Category [V850E1][V850ES]**

Register Name	Bit Width	Register Name	Bit Width
+ PC	32	+ CTPC	32
+ EIPC	32	+ CTPSW	32
+ EIPSW	32	++ NP	1
++ NP	1	++ EP	1
++ EP	1	++ ID	1
++ ID	1	++ SAT	1
++ SAT	1	++ CY	1
++ CY	1	++ OV	1

Register Name	Bit Width	Register Name	Bit Width
++ OV	1	++ S	1
++ S	1	++ Z	1
++ Z	1	+ DBPC	32
+ FEPC	32	+ DBPSW	32
+ FEPSW	32	++ NP	1
++ NP	1	++ EP	1
++ EP	1	++ ID	1
++ ID	1	++ SAT	1
++ SAT	1	++ CY	1
++ CY	1	++ OV	1
++ OV	1	++ S	1
++ S	1	++ Z	1
++ Z	1	+ CTBP	32
+ ECR	32		
+ PSW	32		
++ NP	1		
++ EP	1		
++ ID	1		
++ SAT	1		
++ CY	1		
++ OV	1		
++ S	1		
++ Z	1		

Table A-11. Register Names in [System Registers] Category [V850E2]

Register Name	Bit Width	Register Name	Bit Width
+ PC	32	++ Software Paging Bank	-
+ CPU Function Group	-	+++ MPM	32
++ Main Banks	-	+++ MPC	32
+++ EIPC	32	+++ TID	32
+++ EIPSW	32	+++ VMECR	32
+++ FEPC	32	+++ VMTID	32
+++ FEPSW	32	+++ VMADR	32
+++ ECR	32	+++ IPA0L	32
+++ PSW	32	+++ IPA0U	32
++++ PP	1	+++ IPA1L	32
++++ NPV	1	+++ IPA1U	32
++++ DMP	1	+++ IPA2L	32

Register Name	Bit Width	Register Name	Bit Width
++++ IMP	1	+++ IPA2U	32
++++ NP	1	+++ IPA3L	32
++++ EP	1	+++ IPA3U	32
++++ ID	1	+++ IPA4L	32
++++ SAT	1	+++ IPA4U	32
++++ CY	1	+++ DPA0L	32
++++ OV	1	+++ DPA0U	32
++++ S	1	+++ DPA1L	32
++++ Z	1	+++ DPA1U	32
+++ SCCFG	32	+++ DPA2L	32
+++ SCBP	32	+++ DPA2U	32
+++ EIIC	32	+++ DPA3L	32
+++ FEIC	32	+++ DPA3U	32
+++ CTPC	32	+++ DPA4L	32
+++ CTPSW	32	+++ DPA4U	32
+++ CTBP	32	+++ DPA5L	32
++ Exception Handler Switch Function Bank 0	-	+++ DPA5U	32
+++ SW_CTL	32	+ FPU Function Group	-
+++ SW_CFG	32	++ FPU Status Bank	-
+++ SW_BASE	32	+++ FPSR	32
++ Exception Handler Switch Function Bank 1	-	+++ FPEPC	32
+++ EH_CFG	32	+++ FPST	32
+++ EH_RESET	32	+++ FPCC	32
+++ EH_BASE	32	+++ FPCFG	32
+ Processor Protection Function Group	-	+++ FPEC	32
++ Processor Protection Violation Bank	-	+ User Group	-
+++ VSECR	32	++ User 0 Banks	-
+++ VSTID	32	+++ PSW	32
+++ VSADR	32	++++ PP	1
+++ VMECR	32	++++ NPV	1
+++ VMTID	32	++++ DMP	1
+++ VMADR	32	++++ IMP	1
+++ MCA	32	++++ NP	1
+++ MCS	32	++++ EP	1
+++ MCC	32	++++ ID	1
+++ MCR	32	++++ SAT	1

Register Name	Bit Width	Register Name	Bit Width
++ Processor Protection Setting Bank	-	++++ CY	1
+++ MPM	32	++++ OV	1
+++ MPC	32	++++ S	1
+++ TID	32	++++ Z	1
+++ IPA0L	32	+++ FPST	32
+++ IPA0U	32	+++ FPCC	32
+++ IPA1L	32	+++ FPCFG	32
+++ IPA1U	32	+++ CTPC	32
+++ IPA2L	32	+++ CTPSW	32
+++ IPA2U	32	++++ PP	1
+++ IPA3L	32	++++ NPV	1
+++ IPA3U	32	++++ DMP	1
+++ IPA4L	32	++++ IMP	1
+++ IPA4U	32	++++ NP	1
+++ DPA0L	32	++++ EP	1
+++ DPA0U	32	++++ ID	1
+++ DPA1L	32	++++ SAT	1
+++ DPA1U	32	++++ CY	1
+++ DPA2L	32	++++ OV	1
+++ DPA2U	32	++++ S	1
+++ DPA3L	32	++++ Z	1
+++ DPA3U	32	+++ CTBP	32
+++ DPA4L	32	+ Common Group	-
+++ DPA4U	32	++ EIWR	32
+++ DPA5L	32	++ FEWR	32
+++ DPA5U	32	++ BSEL	32
		+++ BNK	8
		+++ GRP	8

This area is provided with the following functions.

#### (a) Registering watch-expression

CPU registers/categories can be registered in the [Watch panel](#) as watch-expressions.

See "[\(1\) Register a watch-expression](#)" for details on how to operate it.

- Remarks 1.** When you have registered a watch-expression with a category as the object, all of the CPU registers belonging to that category are registered as watch-expressions.
- 2.** A scope specification is automatically added to a registered watch-expression.

**(2) [Value] area**

The values of each CPU register are displayed and changed.

The radix of a data value can be selected by the button on the toolbar or the context menu item. In addition, a display format adding the value in hexadecimal number constantly can also be selected as well.

The meanings of the colors of the CPU register values are as follows (character colors and background colors depend on the configuration in the [\[General - Font and Color\] category](#) of the [Option dialog box](#)):

Display Example (Default)			Description
0x0	Character color	Blue	The value of the CPU register that the user is changing Press the [Enter] key to write to the target memory.
	Background color	Standard color	
0x0	Character color	Brown	The value of the CPU register that has been changed because of the execution of a program.
	Background color	Cream	The highlighting is rest by executing again the program.

This area is provided with the following functions.

**(a) Changing the CPU register value**

To edit the CPU register value, select the value to edit, then change the value directly from the keyboard after clicking again on it (press the [Esc] key to cancel the edit mode).

After you edit the value of the CPU register, it is written to the target memory of the debug tool by pressing the [Enter] key or moving the focus to outside the edit region.

**(b) Saving the contents of the CPU register**

The [Save As dialog box](#) can be opened by selecting the [File] menu >> [Save CPU Register Data As...], and all the contents of this panel can be saved in a text file (\*.txt) or CSV file (\*.csv).

See "[\(4\) Save the CPU register contents](#)" for details on the method for saving the contents of the CPU register.

**[Toolbar]**

	Acquires the latest data from the debug tool, and updates the contents of this panel. This item is disabled during execution of a program.
Notation	The following buttons to change the notation of a data value are displayed.
	Displays the value of the selected item (including sub-items) in the default notation (default).
	Displays the value of the selected item (including sub-items) in hexadecimal number.
	Displays the value of the selected item (including sub-items) in signed decimal number.
	Displays the value of the selected item (including sub-items) in unsigned decimal number.
	Displays the value of the selected item (including sub-items) in octal number.
	Displays the value of the selected item (including sub-items) in binary number.
	Displays the character string of the selected item (including sub-items) in ASCII code. If the character size is 2 bytes and above, it is displayed with the characters for each 1 byte arranged side-by-side.
	Displays the value of the selected item in Float. Note that when the value is not 4-byte data, displays it in the default notation.
	Displays the value of the selected item in Double. Note that when the value is not 8-byte data, displays it in the default notation.
	Adds the value in hexadecimal number enclosing with "(" at the end of the value.

**[File] menu (CPU Register panel-dedicated items)**

The following items are exclusive for the [File] menu in the CPU Register panel (other items are common to all the panels).

Note that all these items are disabled during execution of a program.

Save CPU Register Data	Overwrites the contents of this panel to the previously saved text file (*.txt)/CSV file (*.csv) (see "(b) Saving the contents of the CPU register"). Note that when the file has never been saved or the file is write disabled, the same operation is applied as the selection in [Save CPU Register Data As...].
Save CPU Register Data As...	Opens the <a href="#">Save As dialog box</a> to newly save the contents of this panel to the specified text file (*.txt)/CSV file (*.csv) (see "(b) Saving the contents of the CPU register").

**[Edit] menu (CPU Register panel-dedicated items)**

The following items are exclusive for [Edit] menu in the CPU Register panel (all other items are disabled).

Cut	Deletes the selected character string and copies it to the clipboard. This item becomes valid only when the character string is being edited.
Copy	Copies the selected character string to the clipboard during editing. If a line is selected, copies the register or the category to the clipboard. The copied item can be pasted to the <a href="#">Watch panel</a> .
Paste	Pastes the character string copied in the clipboard to the caret position. This item becomes valid only when the character string is being edited.
Select All	Selects all the items of this panel.
Find...	Opens the Find and Replace dialog box with selecting the [Find in Files] tab.
Replace...	Opens the Find and Replace dialog box with selecting the [Replace in Files] tab.

**[Context menu]**

Register to Watch1	Registers the selected register or category to the <a href="#">Watch panel</a> (Watch1).
Copy	Copies the selected character string to the clipboard during editing. If a line is selected, copies the register or the category to the clipboard. The copied item can be pasted to the <a href="#">Watch panel</a> .

Notation	The following cascade menus to specify the notation of a data value are displayed.
AutoSelect	Displays the value of the selected item (including sub-items) in the default notation (default).
Hexadecimal	Displays the value of the selected item (including sub-items) in hexadecimal number.
Signed Decimal	Displays the value of the selected item (including sub-items) in signed decimal number.
Unsigned Decimal	Displays the value of the selected item (including sub-items) in unsigned decimal number.
Octal	Displays the value of the selected item (including sub-items) in octal number.
Binary	Displays the value of the selected item (including sub-items) in binary number.
ASCII	Displays the character string of the selected item (including sub-items) in ASCII code. If the character size is 2 bytes and above, it is displayed with the characters for each 1 byte arranged side-by-side.
Float	Displays the value of the selected item in Float. Note that when the value is not 4-byte data, displays it in the default notation.
Double	Displays the value of the selected item in Double. Note that when the value is not 8-byte data, displays it in the default notation.
Include Hexadecimal Value	Adds the value in hexadecimal number enclosing with "(" at the end of the value.

### IOR panel

This panel is used to display the contents of the I/O register and change the I/O register values (see "2.9.3 Display/change the I/O register").


This panel appears only when connected to the debug tool.

**Caution** The I/O register that cause the microcontroller to operate when it is read is read-protected and therefore cannot be read ("?" is displayed in the value).

To read the value of read-protected I/O register, select [Force Read Value] from the context menu.

- Remarks 1.** This panel can be zoomed in and out by  in the tool bar, or by moving the mouse wheel forward or backward while holding down the [Ctrl] key.
2. When the separator line of each area in this panel is double-clicked, the width of the area changes to the shortest possible size that can display the contents of the area.

Figure A-42. IOR Panel



This section describes the following.

- [How to open]
- [Description of each area]
- [Toolbar]
- [[File] menu (IOR panel-dedicated items)]
- [[Edit] menu (IOR panel-dedicated items)]
- [Context menu]

#### [How to open]

- From the [View] menu, select [IOR].

### [Description of each area]

#### (1) Search area

This area is used to search for the I/O register name.

	Specifies the character strings to search (case-insensitive). You can either type character strings directly from the key board (up to 512 characters), or select one from the input history via the drop-down list (up to 10 items).
	Searches up for the I/O register name containing the string specified in the text box, and selects the I/O register that is found.
	Searches down for the I/O register name containing the string specified in the text box, and selects the I/O register that is found.

- Remarks**
1. A hidden I/O register name being classified with a category can be searched (the category is opened and the I/O register is selected).
  2. After typing character strings to search, to press the [Enter] key is the same function as clicking the button, and to press the [Shift] + [Enter] key is the same function as clicking the button.

#### (2) [IOR] area

The types of I/O register are classified as categories (folders), and a list of the respective I/O register name is displayed.

The meanings of the icons are as follows:

	Indicates that the I/O register name belonging to this category is displayed. When you double-click on the icon, or click on the "-" mark, the category is closed and the I/O register name is hidden. Note that no categories exist by default. Perform <a href="#">Tree editing</a> if you need a category.
	Indicates that the I/O register name belonging to this category is hidden. When you double-click on the icon, or click on the "+" mark, the category is opened and the I/O register name is displayed. Note that no categories exist by default. Perform <a href="#">Tree editing</a> if you need a category.
	Indicates the name of the I/O register.

**Remark** The category names are sorted in character code order by clicking on the header part of this area (the I/O register names in the category are also similarly sorted).

This area is provided with the following functions.

##### (a) Tree editing

The each I/O register can be categorized (by folders) and displayed in the tree view.

To create a category, Click the button on the toolbar or select [Create Category] from the context menu after moving the caret to a I/O register name to create a category, and then input a desired name from the keyboard (up to 1024 characters).

To delete a category, select the category then click the button on the toolbar or select [Delete] from the context menu. However, the categories that can be deleted are only the empty categories.

To rename the created category, select the category then do either one of the following.

- Click the name again, then directly rename the category name.
- Select the [Edit] menu >> [Rename], then directly rename the category name.
- Press the [F2] key, then directly rename the category name.

By directly dragging and dropping the I/O register in the created category, each I/O register is displayed in the categorized tree view.

Also, the display order of the categories and the I/O register names (upper or lower position) can be changed easily by drag and drop operation.

**Cautions 1. Categories cannot be created within categories.**

2. I/O registers cannot be added or deleted.

**(b) Registering a watch-expression**

Variable names of C language, CPU registers, I/O registers, and assembler symbols can be registered in the [Watch panel](#) as watch-expressions.

See "[\(1\) Register a watch-expression](#)" for details on how to operate it.

**Remarks 1.** When you have registered a watch-expression with a category as the object, all of I/O registers belonging to that category are registered as watch-expressions.

2. A scope specification is automatically added to a registered watch-expression.

**(3) [Value] area**

The value of I/O register is displayed and changed.

The radix of a data value can be selected by the button on the toolbar or the context menu item. In addition, a display format adding the value in hexadecimal number constantly can also be selected as well.

The meanings of the marks and colors displayed as I/O register values are as follows (character colors and background colors depend on the configuration in the [\[General - Font and Color\] category](#) of the [Option dialog box](#)):

Display Example (Default)			Description
<b>0x0</b>	Character color	Blue	The value of the I/O register that the user is changing (press the [Enter] key to write to the target memory).
	Background color	Standard color	
<b>0x0</b>	Character color	Brown	The value of the I/O register that has been changed because of the execution of a program To reset the highlighting, select the  button on the toolbar or [Reset Color] from the context menu.
	Background color	Cream	
?	Character color	Gray	The value of the I/O register that is a read-protected object <sup>Note</sup>
	Background color	Standard color	

**Note** An I/O register for which the microcontroller ends up being activated by a read operation is shown.

To read the value of read-protected I/O register, select [Force Read Value] from the context menu.

**Caution** The timing for acquiring the values differs in the case of a 1 byte/2 bytes I/O register and that of 1 bit I/O registers that have been allocated to a 1 byte/2 bytes I/O register. Owing to this, there are also cases where the values differ even if the value of the same I/O register is displayed.

**Remark** The values are sorted in ascending order of the numerical values by clicking on the header part of this area.

This area is provided with the following functions.

#### (a) Changing I/O register values

To edit the I/O register value, select the value to edit, then change the value directly from the keyboard after clicking again on it (press the [Esc] key to cancel the edit mode).

After you edit the value of the I/O register, it is written to the register of the debug tool by pressing the [Enter] key, or moving the focus to outside the edit region.

See "[\(4\) Modify the I/O register contents](#)" for details on the method for changing the I/O register value.

#### (b) Saving the contents of the I/O register

The [Save As dialog box](#) can be opened by selecting the [File] menu >> [Save IOR Data As...], and all the contents of the I/O register can be saved in a text file (\*.txt) or CSV file (\*.csv).

See "[\(6\) Save the I/O register contents](#)" for details on the method for saving the contents of the I/O register.

### (4) [Type (Byte Size)] area

The type information of each I/O register is displayed in the following formats.

- <Type of I/O register> [<Access attribute> <All accessible sizes>](<Size>)

Access attribute	One of the following is displayed as the access attribute.	
	R	Read only
	W	Write only
	R/W	Read/Write
All accessible sizes	All accessible sizes are demarcated by a comma and listed in order of the smallest size in bit units.	
Size	The size of the I/O register is displayed. It is displayed by supplying the unit, in byte units in the event that it can be displayed in byte units, and in bit units in the event that it can be displayed on in bit units.	

#### Examples 1. "The case of "IOR [R/W 1.8] (1 byte)"

An I/O register that is readable/writable and 1 bit accessible/8 bit accessible, and whose size is 1 byte

#### 2. "The case of "IOR [R/W 1] (1 bit)"

An I/O register that is readable/writable and 1 bit accessible, and whose size is 1 byte

**Remark** The type information is sorted in the character code order by clicking on the header part of this area.

### (5) [Address] area

The address that each I/O register is mapped is displayed (hexadecimal number notation fixing).

However, in the case of the bit register, it is displayed by providing a bit offset value like the following examples.

#### Examples 1. The case of "0xFF40"

This is allocated to the address "0xFF40"

#### 2. The case of "0xFF40.4"

This is allocated to bit 4 of the address "0xFF40.4" (bit register)

**Remark** The addresses are sorted in ascending order of numerical values by clicking on the header part of this area.

**[Toolbar]**

	Acquires the latest data from the debug tool, and updates the contents of this panel. Note that the values of read-protected I/O register are not re-read. This item is disabled during execution of a program.
	Resets highlighting of the selected I/O register whose value has been changed by executing a program. Note that this item is disabled during execution of a program.
	Adds a new category (folder). Directly input the category name in the text box. There are no restrictions on the number of categories that can be created anew (however, it is not possible to create a category inside a category). Note that this item is disabled during execution of a program.
	Deletes the selected character string(s). If an empty category is in a select state, its category is deleted (it is not possible to delete I/O registers).
Notation	The following buttons to change the notation of a data value are displayed.
	Displays the value of the selected item in hexadecimal number (default).
	Displays the value of the selected item in signed decimal number.
	Displays the value of the selected item in unsigned decimal number.
	Displays the value of the selected item in octal number.
	Displays the value of the selected item in binary number.
	Displays the value of the selected item in ASCII code.
	Adds the value in hexadecimal number enclosing with "()" at the end of the value of the selected item.

**[[File] menu (IOR panel-dedicated items)]**

The following items are exclusive for the [File] menu in the IOR panel (other items are common to all the panels). Note that all these items are disabled during execution of a program.

Save IOR Data	Overwrites the contents of this panel to the previously saved text file (*.txt)/CSV file (*.csv) (see " <a href="#">(b) Saving the contents of the I/O register</a> "). Note that when the file has never been saved or the file is write disabled, the same operation is applied as the selection in [Save IOR Data As...].
Save IOR Data As...	Opens the <a href="#">Save As dialog box</a> to newly save the contents of this panel to the specified text file (*.txt)/CSV file (*.csv) (see " <a href="#">(b) Saving the contents of the I/O register</a> ").

**[[Edit] menu (IOR panel-dedicated items)]**

The following items are exclusive for [Edit] menu in the IOR panel (all other items are disabled).

Cut	Deletes the selected character string(s) and copies them to the clipboard (it is not possible to cut I/O registers/categories).
Copy	Copies the contents of the selected range to the clipboard as character string(s). If the I/O register(s)/category(s) are selected, copies them to the clipboard. The copied item can be pasted to the <a href="#">Watch panel</a> .
Paste	If texts are in editing, pastes the contents of the clipboard to the caret position (it is not possible to paste I/O registers/categories).

Delete	Deletes the selected character string(s). If an empty category is in a select state, its category is deleted (it is not possible to delete I/O registers).
Select All	If texts are in editing, selects all the character strings. If texts are not in editing, selects all the I/O registers/categories.
Rename	Edits the name of the selected category.
Find...	Moves the focus to the text box in the <a href="#">Search area</a> .
Move...	Opens the <a href="#">Go to the Location dialog box</a> to move the caret to the specified I/O register.

**[Context menu]**

Register to Watch1	Registers the selected I/O register or category to the <a href="#">Watch panel</a> (Watch1).
Refresh	Acquires the latest data from the debug tool, and updates the contents of this panel. Note that the values of read-protected I/O register are not re-read. This item is disabled during execution of a program.
Force Read Value	Forcibly reads once the value of the read-protected I/O register.
Move...	Opens the <a href="#">Go to the Location dialog box</a> .
Create Category	Adds a new category (folder). Directly input the category name in the text box. There are no restrictions on the number of categories that can be created anew (however, it is not possible to create a category inside a category). Note that this item is disabled during execution of a program.
Copy	Copies the contents of the selected range to the clipboard as character string(s). If the I/O register(s)/category(s) are selected, copies them to the clipboard. The copied item can be pasted to the <a href="#">Watch panel</a> .
Delete	Deletes the selected character string(s). If an empty category is in a select state, its category is deleted (it is not possible to delete I/O registers).
Notation	The following cascade menus are displayed to specify the notation.
Hexadecimal number	Displays the value of the selected item in hexadecimal number (default).
Signed Decimal	Displays the value of the selected item in signed decimal number.
Unsigned decimal number	Displays the value of the selected item in unsigned decimal number.
Octal	Displays the value of the selected item in octal number.
Binary	Displays the value of the selected item in binary number.
ASCII	Displays the value of the selected item in ASCII code.
Include Hexadecimal Value	Adds the value in hexadecimal number enclosing with "(" at the end of the value of the selected item.
Reset Color	Resets highlighting of the selected I/O register whose value has been changed by executing a program.

### Local Variables panel


This panel is used to display the contents of the local variable and change the local variable values (see "[2.9.5 Display/change local variables](#)").

This panel appears only when connected to the debug tool.

- Cautions 1.** **Nothing is displayed on this panel during execution of a program. When the execution of a program is stopped, items in each area are displayed.**
- 2.** **Due to compiler optimization, the data for the target variable may not be on the stack or in a register in blocks where that variable is not used. In this case, the target variable will not be displayed.**

- Remarks 1.** This panel can be zoomed in and out by **100%** in the tool bar, or by moving the mouse wheel forward or backward while holding down the [Ctrl] key.
2. When the separator line of each area in this panel is double-clicked, the width of the area changes to the shortest possible size that can display the contents of the area.

**Figure A-43. Local Variables Panel**



This section describes the following.

- [\[How to open\]](#)
- [\[Description of each area\]](#)
- [\[Toolbar\]](#)
- [\[\[File\] menu \(Local Variables panel-dedicated items\)\]](#)
- [\[\[Edit\] menu \(Local Variables panel-dedicated items\)\]](#)
- [\[Context menu\]](#)

#### [How to open]

- From the [View] menu, select [Local Variable].

#### [Description of each area]

##### (1) Scope area

Select the scope of the local variable to be displayed from the following drop-down list.

Item	Operation
Current	Displays local variables in the scope of the current PC value.
<Depth> <Function name() [file name#line number]> <sup>Note</sup>	Displays local variables in the scope of the calling function. After the program is executed, the scope that is selected is maintained as long as the selected scope exists.

**Note** The calling functions displayed in the [Call Stack panel](#) are displayed.

## (2) [Name] area

The local variable name or function name is displayed.

The argument of the function is also displayed as the local variable.

In addition, the hierarchical structure is displayed in tree format for arrays, pointer variables, and structures or unions.

This area cannot be edited.

The meanings of the icons are as follows:

	Indicates the variable. Auto, Internal Static, and Register variables are also displayed <sup>Note</sup> . In addition, the hierarchical structure is displayed in tree format for arrays, pointer variables, and structures or unions. If "+" mark exist at the top of the name, the next structure is expanded by clicking it (the mark changes to "-" after the expansion).
Array	All elements in the array
Pointer variables	Variables that the pointer designates If the pointer designates a pointer, add "+" mark and expand it by clicking the mark. Note that if the pointer designates an unknown, "?" mark is displayed.
Structures/Unions	All the member of structures/unions
	Indicates the argument.
	Indicates the function.

**Note** When Auto variables are used to display local variables, accurate values cannot be displayed at a prologue ("{"}) or epilogue ("}") of a function. The Auto variable addresses are the relative addresses from the address pointed to by the stack pointer (SP), so their addresses are not determined until the SP value is determined in the function. The SP is manipulated via prologues or epilogues, so the accurate value cannot be displayed.

This area is provided with the following functions.

### (a) Registering watch-expression

Variable names of C language can be registered in the [Watch panel](#) as watch-expressions.

See "[\(1\) Register a watch-expression](#)" for details on how to operate it.

**Remark** A scope specification is automatically added to a registered watch-expression.

**(b) Jump to memory**

By selecting [Jump to Memory] from the context menu, the [Memory panel](#) (Memory1) opens with moving the caret to the source line corresponding to the address where the selected local variable is disposed (if the Memory panel (Memory1) is already open, the screen will jump to the panel).

**(3) [Value] area**

The value of the local variable is displayed and changed.

The notation of a data value can be selected by the button on the toolbar or the context menu item. In addition, a display format adding the value in hexadecimal number constantly can also be selected as well.

The meanings of the marks and colors displayed as the values of the local variables are as follows (character colors and background colors depend on the configuration in the [\[General - Font and Color\] category](#) of the [Option dialog box](#)):

Display Example (Default)			Description
<b>0x0</b>	Character color	Blue	The value of the local variable that the user is changing Press the [Enter] key to write to the target memory.
	Background color	Standard color	
<b>0x0</b>	Character color	Brown	The value of the local variable that have been changed because of the execution of a program <sup>Note</sup> . The highlighting is rest by executing again the program.
	Background color	Cream	
?	Character color	Gray	When the value of the local variable cannot be acquired
	Background color	Standard color	

**Note** Variables that the name stays same from the start point where the program started executing to the breakpoint and their values are changed are the target.

This area is provided with the following functions.

**(a) Changing the local variable/argument value**

To edit the local variable value or the argument value, select the value to edit, then change the value directly from the keyboard after clicking again on it (press the [Esc] key to cancel the edit mode).

After you edit the value of the local variable or the argument, it is written to the target memory of the debug tool by pressing the [Enter] key or moving the focus to outside the edit region.

See "[\(2\) Modify the contents of local variables](#)" for details on the method for changing the local variable/argument value.

**(b) Saving the contents of the local variable**

The [Save As dialog box](#) can be opened by selecting the [File] menu >> [Save Local Variables Data As...], and all the contents of this panel can be saved in a text file (\*.txt) or CSV file (\*.csv).

See "[\(3\) Save the contents of local variables](#)" for details on the method for saving the contents of the local variable.

**(4) [Type (Byte Size)] area**

The type name of the local variable is displayed. The notation accords with the description of C language.

For an array, an element number is displayed in "[]". For a function, its size (number of bytes) is displayed in "()".

This area cannot be edited.

**(5) [Address] area**

The address of the local variable is displayed. When a variable is assigned to the register, the name of the register is displayed.

This area cannot be edited.

**[Toolbar]**

These buttons below are disabled during execution of a program.

	Acquires the latest data from the debug tool, and updates the contents of this panel.
Notation	The following buttons to specify the notation of values are displayed.
	Displays values on this panel in the default notation according to the type of variable (default).
	Displays values on this panel in hexadecimal number.
	Displays values on this panel in decimal number.
	Displays values on this panel in octal number.
	Displays values on this panel in binary number.
	Displays array indexes on this panel in decimal number (default).
	Displays array indexes on this panel in hexadecimal number.
	Displays values on this panel in Float. Note that when the value is not 4-byte data, or has the type information, displays it in the default notation.
	Displays values on this panel in Double. Note that when the value is not 4-byte data, or has the type information, displays it in the default notation.
	Adds the value in hexadecimal number enclosing with "(" at the end of the value.
Encoding	The following buttons to specify the encoding of character variables are displayed.
	Displays character variables in ASCII code (default).
	Displays character variables in Shift_JIS code.
	Displays character variables in EUC-JP code.
	Displays character variables in UTF-8 code.
	Displays character variables in UTF-16 code.

**[[File] menu (Local Variables panel-dedicated items)]**

The following items are exclusive for the [File] menu in the Local Variables panel (other items are common to all the panels).

Note that all these items are disabled during execution of a program.

Save Local Variables Data	Overwrites the contents of this panel to the previously saved text file (*.txt)/CSV file (*.csv) (see " <a href="#">(b) Saving the contents of the local variable</a> ").  Note that when the file has never been saved or the file is write disabled, the same operation is applied as the selection in [Save Local Variables Data As...].
Save Local Variables Data As...	Opens the <a href="#">Save As dialog box</a> to newly save the contents of this panel to the specified text file (*.txt)/CSV file (*.csv) (see " <a href="#">(b) Saving the contents of the local variable</a> ").

**[Edit] menu (Local Variables panel-dedicated items)**

The following items are exclusive for [Edit] menu in the Local Variables panel (all other items are disabled).

Copy	Copies the contents of the selected line or the character string to the clipboard.
Select All	Selects all the items of this panel.
Rename	Changes to the edit mode to edit the selected local variable value (see " <a href="#">(2) Modify the contents of local variables</a> "). This item is disabled during execution of a program.
Find...	Opens the Find and Replace dialog box with selecting the [Find in Files] tab.
Replace...	Opens the Find and Replace dialog box with selecting the [Replace in Files] tab.

**[Context menu]**

All the items from the context menu are disabled during execution of a program.

Register to Watch1	Registers the selected local variable to the <a href="#">Watch panel</a> (Watch1).
Copy	Copies the contents of the selected line or the character string to the clipboard.
Notation	The following cascade menus to specify the notation of values are displayed.
AutoSelect	Displays values on this panel in the default notation according to the type of variable (default).
Hexadecimal	Displays values on this panel in hexadecimal number.
Decimal	Displays values on this panel in decimal number.
Octal	Displays values on this panel in octal number.
Binary	Displays values on this panel in binary number.
Decimal Notation for Array Index	Displays array indexes on this panel in decimal number (default).
Hexadecimal Notation for Array Index	Displays array indexes on this panel in hexadecimal number.
Float	Displays values on this panel in Float. Note that when the value is not 4-byte data, or has the type information, displays it in the default notation.
Double	Displays values on this panel in Double. Note that when the value is not 4-byte data, or has the type information, displays it in the default notation.
Include Hexadecimal Value	Adds the value in hexadecimal number enclosing with "(" at the end of the value.
Encoding	The following cascade menus to specify the encoding of character variables are displayed.
ASCII	Displays character variables in ASCII code (default).
Shift_JIS	Displays character variables in Shift_JIS code.
EUC-JP	Displays character variables in EUC-JP code.
UTF-8	Displays character variables in UTF-8 code.
UTF-16	Displays character variables in UTF-16 code.
Jump to Memory	Opens the <a href="#">Memory panel</a> (Memory1) and jumps to the memory value corresponding to the address of the selected line in this panel.

### Watch panel

This panel is used to display the contents of the registered watch-expressions and change their values (see "[2.9.6 Display/change watch-expressions](#)").

Up to a maximum of four of these panels can be opened. Each panel is identified by the names "Watch1", "Watch2", "Watch3", and "Watch4" on the titlebar, and the watch-expressions can be registered/deleted/moved individually.

Watch-expressions can be registered in this panel as well as in the [Editor panel](#), [Disassemble panel](#), [Memory panel](#), [CPU Register panel](#), [Local Variables panel](#) or [IOR panel](#).

When the panel is closed with registered watch-expressions, the panel closes but the information on the registered watch-expressions is retained. Therefore, if the same panel is opened again, it is opened with the watch-expressions registered.


The display contents are automatically updated when the value of the watch-expression changes after a program is executed (when the execution is done in steps, the display is updated after each step).

In addition, by enabling the [Real-time display update function](#), it is also possible to update the display contents in real-time even while a program is being executed.

This panel appears only when connected to the debug tool.

- Remarks 1.** This panel can be zoomed in and out by [100%](#) in the tool bar, or by moving the mouse wheel forward or backward while holding down the [Ctrl] key.
- 2.** When the separator line of each area in this panel is double-clicked, the width of the area changes to the shortest possible size that can display the contents of the area.

**Figure A-44. Watch Panel**



This section describes the following.

- [\[How to open\]](#)
- [\[Description of each area\]](#)
- [\[Toolbar\]](#)
- [\[\[File\] menu \(Watch panel-dedicated items\)\]](#)
- [\[\[Edit\] menu \(Watch panel-dedicated items\)\]](#)
- [\[Context menu\]](#)

#### [How to open]

- From the [View] menu, select [Watch] >> [Watch 1 - 4].

**[Description of each area]**

**(1) [Watch] area**

All the registered watch-expressions are displayed in a list.

Clicking the title of the list in this area sorts the watch-expressions in the list in alphabetical order.

Categories (folders) can be created to categorize the watch-expressions and display them in the tree view (see "[\(a\) Tree editing](#)").

The meanings of the icons are as follows:

	Indicates that the watch-expression belonging to this category is displayed. When you double-click on the icon, or click on the "-" mark, the category is closed and the watch-expression is hidden.
	Indicates that the watch-expression belonging to this category is hidden. When you double-click on the icon, or click on the "+" mark, the category is opened and the watch-expression is displayed.
	Indicates that the watch-expression is a variable. At the top of the watch-expression represents arrays, pointer type variables, and structures/unions, "+"/ "-" mark is displayed. Click the mark to <a href="#">Expand/shrink display</a> .
	Indicates that the watch-expression is a function.
	Indicates that the watch-expression is an immediate value.
	Indicates that the watch-expression is an expression.
	Indicates that the watch-expression is I/O register.
	Indicates that the watch-expression is CPU register. At the top of the watch-expression that has the lower level register (part of the register), "+"/ "-" mark is displayed. Click the mark to <a href="#">Expand/shrink display</a> .

This area is provided with the following functions.

**(a) Tree editing**

Watch-expressions can be categorized (by folders) and displayed in the tree view.

To create a category, click the button on the toolbar or select [Create Category] from the context menu after moving the caret to the position to create a category, and then input a desired name from the keyboard.

To delete a category, select the category then click the button on the toolbar or select [Delete] from the context menu.

To rename the created category, select the category then do either one of the following.

- Click the name again, then directly rename the category name.
- Select the [Edit] menu >> [Rename], then directly rename the category name.
- Press the [F2] key, then directly rename the category name.

By directly dragging and dropping the registered watch-expression in the created category, each category is displayed in the categorized tree view.

Also, the display order of the categories and the watch-expressions (upper or lower position) can be changed easily by drag and drop operation.

**Cautions 1. Categories cannot be created within categories.**

2. Up to 64 categories can be created in one watch panel (if this restriction is violated, a message appears).

**Remark** Drag and drop the watch-expressions/categories in other watch panel (Watch1 to Watch4) to copy them.

**(b) Expand/shrink display**

At the top of the watch-expression represents arrays, pointer type variables, structures/unions, and registers (with the name of the part), "+"/-" mark is displayed. Click the mark to expand the contents ("+" mark is changed to "-" after the expansion).

Watch-Expression	Contents When Expanded
Array	All elements in the array Select [Encoding] >> [ASCII] from the context menu to display the value as a string (up to 256 characters). Note, however, that any characters that cannot be displayed in the encoding will be shown as periods "." or "?".
Pointer type variable	Variables that the pointer designates
Structure/Union	All the member of structure/union
Register	Name of the bit/bit string that constructs register Example) ECR register FECC register EICC register

**(c) Registering new watch-expression**

There are three ways as follows to register new watch-expressions.

**<1> Register from other panels**

Do either one of the following to register watch-expressions in other panels.

- Drag and drop the target character string onto this area in the desired watch panel (Watch1 to Watch4).
- Select [Register to Watch1] from the context menu after selecting the target character string or place the caret on either of the target character string (the target is automatically determined).
- Select the [Edit] menu >> [Paste] in this area in the desired watch panel (Watch1 to Watch4) after selecting the [Edit] menu >> [Copy] for the target character string.

The relationship between panels that can use this operation and targets that can be registered as watch-expressions is as follows:

**Table A-12. Relationship between Panels and Targets That Can be Registered as Watch-Expressions**

Panel Name	Targets That can be Registered as Watch-Expressions
Editor panel	Variable names of C language, CPU registers, I/O registers, and assembler symbols
Disassemble panel	Variable names of C language, CPU registers, I/O registers, and assembler symbols
CPU Register panel	CPU registers <sup>Note</sup>
Local Variables panel	Variable names of C language (local variables)
IOR panel	I/O registers <sup>Note</sup>

**Note** The scope-specification is automatically added to the registered watch-expression.

<2> Directly register in the Watch panel

Click the  button on the toolbar or select [Add New Watch] from the context menu in the desired watch panel (Watch1 to Watch4) to display an entry box for a new watch-expression in the bottom of this area.

Directly input a watch-expression from the keyboard in the [Watch] area in the entry box then press the [Enter] key.

The input format of the watch-expression is as follows:

**Table A-13. Input Format of Watch-Expression**

Watch-Expression	Value to Display
Variable name of C language	Value of C language variable
<i>Watch-expression</i> [ <i>Watch-expression</i> ]	Element of array
<i>Watch-expression</i> Member name	Member of structures/unions
<i>Watch-expression</i> -> Member name	Member of structures/unions that pointer designates
* <i>Watch-Expression</i>	Value of pointer variable
CPU register name	Value of the CPU register
I/O register name	I/O register value
Label, EQU symbol and immediate address	Values of label, EQU symbol and immediate address
Bit symbol	Bit symbol value

Watch-expressions can be registered with specifying the scope. The scope specifications with watch-expression registration are as follows:

**Table A-14. Scope Specification of C language Used with Watch-Expression Registration**

Scope Specification	Load Module File Name	Source File Name	Function Name	Variable Name
prog\$file#func#var	prog	file	func	var
prog\$file#var	prog	file	global	var
prog\$var	prog	global	global	var
file#func#var	current	file	func	var
file#var	current	file	global	var
var	current	current	current	var

**Table A-15. Scope Specification of CPU Register with Watch-Expression Registration**

Scope Specification	Register Bank	Name of CPU Register
r10:REG	-	r10

**Table A-16. Scope Specification of I/O register with Watch-Expression Registration**

Scope Specification	Name of I/O register
P0:IOR	P0
P0	P0

**Remarks 1.** A symbol name at the current caret position can be complemented by pressing the [Ctrl] + [Space] key in this area (see "[2.18.2 Symbol name completion function](#)").

2. An immediate value is treated as an address. Note, however, that an immediate value with operators cannot be used.
3. An arithmetic expression with symbols cannot be used for a watch-expression.
4. If the same name exists either in C language variables, CPU registers or I/O registers, and it is registered without specifying scopes, then its value will be displayed after the symbol is determined in the following order.

Variable of C language > CPU registers > I/O register

If "\$" is specified at the top of a watch-expression, then its value will be displayed after the symbol is determined in the following order.

CPU registers > I/O register > Variable of C language

5. If a local variable and a global variable exist with the same name, and its symbol name is registered without specifying scopes, then its value will be displayed after the symbol is determined based on the scope of the current PC value.

#### 6. **[V850E2]**

System registers with the same name can be distinguished by the following scope specification.

Scope Specification	System Register Bank	System Register Name
PSW:SRBff00	CPU function group (0xff) / User 0 banks (0x00)	PSW
PSW:SRB0000	User group (0x00) / Main banks (0x00)	PSW

7. When watch-expressions are registered from the [IOR panel](#) or the [CPU Register panel](#), the scope specification is automatically added.

#### <3> Register from other application

Select a character string of a variable of C language, CPU register, I/O register or assembler symbol from a external editor then do either one of the following.

- Drag and drop the target character string in this area in the desired watch panel (Watch1 to Watch4).
- Select the [Edit] menu >> [Paste] in this area in the desired watch panel (Watch1 to Watch4) after copying the target character string.

**Cautions 1.** Up to 128 watch-expressions can be registered in one watch panel (if this restriction is violated, a message appears).

2. Due to compiler optimization, the data for the target variable may not be on the stack or in a register in blocks where that variable is not used. In this case, the target watch-expression value is displayed as "?".

**Remarks 1.** Each watch-expression registered in each watch panel (Watch1 to Watch4) is managed in each panel and saved as the user information of the project.

2. More than one watch-expression with the same name can be registered.

**(d) Editing watch-expression**

To edit the registered watch-expression, double-click the watch-expression to be edited to change the watch-expression to edit mode then directly edit from the keyboard (press the [Esc] key to cancel the edit mode).

After editing the watch-expression, press the [Enter] key to complete the editing.

**(e) Deleting watch-expression**

To delete the registered watch-expression, select the watch-expression(s) to be deleted then click the  button on the toolbar or select [Delete] from the context menu.

**(f) Setting of various events**

Various events can be set to the selected watch-expression by selecting [Access Break] or [Trace Output] from the context menu.

If an access event is set, the mark of the watch-expression is changed (the event mark of a break event is displayed under the icon of the watch-expression in layers).

When an event is set, the detailed information about the set event is reflected in the [Events panel](#).

Note that events are only set to the watch-expressions that are global variables, static variables inside functions, or file-internal static variables.

See the following for details on how to set events.

- ["2.8.4 Stop the program with the access to variables/I/O registers"](#)
- ["2.11.4 Collect execution history only when the condition is met"](#)

**(g) Jump to the address with memory definition**

By selecting [Jump to Memory] from the context menu, the [Memory panel](#) (Memory1) opens with moving the caret to the address in which the selected watch-expression is defined (if the Memory panel (Memory1) is already open, the screen will jump to the panel).

Note that this operation is disabled when more than one watch-expression is selected at the same time or the CPU register/I/O register is selected.

**(2) [Value] area**

The value of the registered watch-expression is displayed and changed (if the watch-expression is a function pointer, the function name is displayed in this area).

Notations and encodes can be selected by the button on the toolbar or the context menu item. In addition, a display format adding the value in hexadecimal number constantly can also be selected as well.

The default display format of the values is automatically decided depending on the type of the watch-expression.

**Table A-17. Display Format of Watch-Expressions (Default)**

Type of Watch-Expression	Display Format
char, signed char, unsigned char	ASCII code with hexadecimal number
short, signed short, short int, signed short int, int, signed, signed int, long, signed long, long int, signed long int	Signed decimal number with hexadecimal number
unsigned short, unsigned short int, unsigned, unsigned int, unsigned long, unsigned long int	Unsigned decimal number with hexadecimal number
float	Float (when the size is 4-byte) with hexadecimal number
double, long double	Double (when the size is 8-byte) with hexadecimal number

Type of Watch-Expression	Display Format
Pointers to char, signed char, unsigned char	Characters Encoding: ASCII
Pointers to other than char, signed char, unsigned char	Hexadecimal number
Arrays of char, signed char, unsigned char types	Characters Encoding: ASCII
bit, boolean, _boolean	Unsigned decimal number with hexadecimal number
Enumeration type	Enumeration constant value with hexadecimal number
Label, address of immediate value, EQU symbol	Signed decimal number with hexadecimal number
bit symbol	Unsigned decimal number with hexadecimal number
Others	Hexadecimal number

The meanings of the marks and colors displayed as the values of watch-expressions are as follows (character colors and background colors depend on the configuration in the [General - Font and Color] category of the Option dialog box):

Display Example (Default)			Description
<b>0x0</b>	Character color	Blue	The value of the watch-expression that the user is changing Press the [Enter] key to write to the target memory.
	Background color	Standard color	
<b>0x0</b>	Character color	Pink	The value of the watch-expression that is displayed with the <a href="#">Real-time display update function</a>
	Background color	Standard color	
<b>0x0</b>	Character color	Brown	The value of the watch-expression that has been changed because of the execution of a program To reset the highlighting, select the  button on the toolbar or [Reset Color] from the context menu.
	Background color	Cream	
?	Character color	Gray	Variable that does not exist is registered as a watch-expression or the value of the watch-expression cannot be retrieved (variable is out of the scope)
	Background color	Standard color	

- Remarks 1.** The I/O register that cause the microcontroller to operate when it is read is read-protected and therefore cannot be read. To read the value of read-protected I/O register, select [Force Read Value] from the context menu.
2. Each watch-expression acquires the value in the order it was registered.  
As the timing to acquire a value is different, the values displayed may be different if the same I/O register is registered more than once.
3. When a hexadecimal value is also given, then values in the specified notation and hexadecimal values are read separately. For this reason, the values with the specified notion and the hexadecimal values may differ due to the time lag between being read.

This area is provided with the following functions.

#### (a) Real-time display update function

Using the real-time display update function allows you to display/modify the value of the watch-expression not only while the program is stopped, but also in execution.

See "[\(4\) Display/modify the memory contents during program execution](#)" for details on the real-time display update function.

#### (b) Changing values of watch-expressions

To edit the value of the watch-expression, change the value directly from the keyboard after double-clicking on the value to be edited (press the [Esc] key to cancel the edit mode).

After you edit the value of the watch-expression, it is written to the target memory of the debug tool by pressing the [Enter] key, or moving the focus to outside the edit region.

See "[\(6\) Modify the contents of watch-expressions](#)" for detail on how to change values of watch-expressions.

#### (c) Saving the contents of watch-expressions

By selecting the [File] menu >> [Save Watch Data As...], the [Save As dialog box](#) can be opened, and all the contents of this panel can be saved in a text file (\*.txt) or CSV file (\*.csv).

See "[\(9\) Save the contents of watch-expressions](#)" for details on the method for saving the contents of watch-expressions.

### (3) [Type (Byte Size)] area

The type information of watch-expressions with the following format is displayed.

Watch-Expression	Display Format	
Single CPU register	<Types of CPU register> (<Size <sup>Note 1</sup> >)	
Single I/O register	<I/O register type> (<Access attribute> <Access type><Size <sup>Note 1</sup> >)	
	Access attribute	R: Read only W: Write only R/W: Read/Write only
	Access type	1: Bit accessible 8: Byte accessible 16: Half word accessible 32: Word accessible
Unknown	?	
Others	<Watch-expression type that follow the C compiler's determination <sup>Note 2</sup> > (<Size <sup>Note 1</sup> >)	

**Notes 1.** The size of the watch-expression is displayed in bytes.

However, for bit I/O register or C language bit field, the size is displayed in bits and "bits" is added to the end of the number.

**2.** Types to be treated are displayed when compiling the watch-expression.

### (4) [Address] area

The address that each watch-expression is mapped is displayed (hexadecimal number notation fixing).

If the watch-expression is single CPU register or is unknown, "-" or "?" is displayed instead.

**Remark** When the watch-expression is the bit I/O register, the bit-offset value is also displayed.

**Example** When the bit register is allocated to bit 4 of the address "0xFF40"  
Display example:0xFF40.4

**(5) [Memo] area**

The user can write comments for the watch-expressions/categories.

Each comment for a watch-expression/category written in this area is saved individually as the user information of the project. Therefore, when any of the watch-expression/category is deleted, the comment corresponding to it is also deleted.

Note that when arrays or register are displayed expanded, the comment cannot be input for each element.

To edit the comment, input the character strings directly from the keyboard after double-clicking on the item to be edited (press the [Esc] key to cancel the edit mode).

Up to 256 character strings can be input (line feed code is ignored).

After editing the character strings, complete the editing by pressing the [Enter] key or moving the focus to outside the edit region.

**[Toolbar]**

	Reacquires all the values of the registered watch-expression and updates the display. Note that read-protected I/O register values are not re-read.
	Resets highlighting of the selected watch-expression whose value has been changed by executing a program. This item is disabled during execution of a program.
	Registers a new watch-expression. Directly input the watch-expression in the text box (see "(c) Registering new watch-expression") Note that up to 128 watch-expressions can be registered in one watch panel.
	Adds a new category (folder). Directly input the category name in the text box. Note that up to 64 categories can be created in one watch panel (categories cannot be created in categories).
	Deletes the selected character string(s). If the watch-expression(s)/category(s) are selected, deletes them (except when the expanded item of the watch-expression is selected).
Notation	The following buttons to change the notation of a data value are displayed.
	Displays the value of the selected watch-expression in the default notation (see "Table A-17. Display Format of Watch-Expressions (Default)") according to the type of variable (default).
	Displays the value of the selected item in hexadecimal number.
	Displays the value of the selected item in signed decimal number.
	Displays the value of the selected item in unsigned decimal number.
	Displays the value of the selected item in octal number.
	Displays the value of the selected item in binary number.
	Displays the value of the selected item in ASCII code.
	Displays the value of the selected item in Float. Note that this item becomes valid only when the selected watch-expression value is 4-byte data.
	Displays the value of the selected item in Double. Note that this item becomes valid only when the selected watch-expression value is 8-byte data.
	Adds the value in hexadecimal number enclosing with "(" at the end of the value of the selected item (except the item displayed in hexadecimal number).

**[[File] menu (Watch panel-dedicated items)]**

The following items are exclusive for the [File] menu in the Watch panel (other items are common to all the panels).

Note that all these items are disabled during execution of a program.

Save Watch Data	Overwrites the contents of this panel to the previously saved text file (*.txt)/CSV file (*.csv) (see " <a href="#">(c) Saving the contents of watch-expressions</a> "). Note that when the file has never been saved or the file is write disabled, the same operation is applied as the selection in [Save Watch Data As...].
Save Watch Data As...	Opens the <a href="#">Save As dialog box</a> to newly save the contents of this panel to the specified text file (*.txt)/CSV file (*.csv) (see " <a href="#">(c) Saving the contents of watch-expressions</a> ").

**[[Edit] menu (Watch panel-dedicated items)]**

The following items are exclusive for [Edit] menu in the Watch panel (all other items are disabled).

Cut	Deletes the selected character string(s) and copies them to the clipboard. If the watch-expression(s)/category(s) are selected, deletes them (except when the expanded item of the watch-expression is selected).
Copy	Copies the contents of the selected range to the clipboard as character string(s). If the watch-expression(s)/category(s) are selected, copies them to the clipboard (except when the expanded item of the watch-expression is selected).
Paste	If texts are in editing, pastes the contents of the clipboard to the caret position. If texts are not in editing and the watch-expression(s) are copied in the clipboard, registers them to the caret position.
Delete	Deletes the selected character string(s). If the watch-expression(s)/category(s) are selected, deletes them (except when the expanded item of the watch-expression is selected).
Select All	If texts are in editing, selects all the character strings. If texts are not in editing, selects all the watch-expressions/categories.
Rename	Renames the selected watch-expression/category.
Find...	Opens the Find and Replace dialog box with selecting the [Find in Files] tab.
Replace...	Opens the Find and Replace dialog box with selecting the [Replace in Files] tab.

**[Context menu]**

Access Break	This item becomes valid only when the selected watch-expression is the global variable, the static variable inside functions, the file-internal static variable, or I/O register (multiple selections not allowed). The following cascade menus are displayed to set the access break event (see " <a href="#">(1) Set a break event (access type)</a> ").
Set Read Break to	Sets a break event with read access condition to the selected watch-expression.
Set Write Break to	Sets a break event with write access condition to the selected watch-expression.
Set R/W Break to	Sets a break event with read/write access condition to the selected watch-expression.
Set Read Combination Break to	In this product version, this item is not supported.
Set Write Combination Break to	In this product version, this item is not supported.
Set R/W Combination Break to	In this product version, this item is not supported.
Trace Output <b>[IECUBE][IECUBE2] [Simulator]</b>	This item becomes valid only when the selected watch-expression is a global variable, static variable inside functions, file-internal static variable, or I/O register (multiple selections not allowed). The following cascade menus are displayed to set the trace-related event (see " <a href="#">(1) Set a Point Trace event</a> ").
Record Reading Value	Sets a Point Trace event to record the values in the trace memory when the selected watch-expression is accessed for read.
Record Writing Value	Sets a Point Trace event to record the values in the trace memory when the selected watch-expression is accessed for write.
Record R/W Value	Sets a Point Trace event to record the values in the trace memory when the selected watch-expression is accessed for read/write.
Record Start R/W Value	In this product version, this item is not supported.
Record End R/W Value	In this product version, this item is not supported.
Trace	Opens the <a href="#">Trace panel [IECUBE][IECUBE2][Simulator]</a> and displays the acquired trace data.
Periodic Updating	The following cascade menus are displayed to set for the real-time display update function (see " <a href="#">(a) Real-time display update function</a> ").
Periodic Updating Options	Opens the <a href="#">Property panel</a> to set for the real-time display update function.
Refresh	Reacquires all the values of the registered watch-expression and updates the display. Note that the values of read-protected I/O register are not re-read.
Force Read Value	Forcibly reads once the values of the read-protected I/O register. This item is disabled during execution of a program.
Add New Watch	Registers a new watch-expression. Directly input the watch-expression in the text box (see " <a href="#">(c) Registering new watch-expression</a> ") Note that up to 128 watch-expressions can be registered in one watch panel.
Create Category	Adds a new category (folder). Directly input the category name in the text box. Note that up to 64 categories can be created in one watch panel (categories cannot be created in categories).

Delete	Deletes the selected character string(s). If the watch-expression(s)/category(s) are selected, deletes them (except when the expanded item of the watch-expression is selected).
Cut	Deletes the selected character string(s) and copies them to the clipboard. If the watch-expression(s)/category(s) are selected, deletes them (except when the expanded item of the watch-expression is selected).
Copy	Copies the contents of the selected range to the clipboard as character string(s). If the watch-expression(s)/category(s) are selected, copies them to the clipboard (except when the expanded item of the watch-expression is selected).
Paste	If texts are in editing, pastes the contents of the clipboard to the caret position. If texts are not in editing and the watch-expression(s) are copied in the clipboard, registers them to the caret position.
Rename	Renames the selected watch-expression/category.
Import Watch Expression...	Opens the <a href="#">Open Watch Expression Data File dialog box</a> to import watch-expressions (see " <a href="#">(8) Export/import watch-expressions</a> ").
Notation	The following cascade menus are displayed to specify the notation.
AutoSelect	Displays the value of the selected watch-expression in the default notation (see " <a href="#">Table A-17. Display Format of Watch-Expressions (Default)</a> " according to the type of variable (default)).
Hexadecimal number	Displays the value of the selected item in hexadecimal number.
Signed Decimal	Displays the value of the selected item in signed decimal number.
Unsigned decimal number	Displays the value of the selected item in unsigned decimal number.
Octal	Displays the value of the selected item in octal number.
Binary	Displays the value of the selected item in binary number.
ASCII	Displays the value of the selected item in ASCII code.
Include Hexadecimal Value	Adds the value in hexadecimal number enclosing with "(" at the end of the value of the selected item (except the item displayed in hexadecimal number).
Float	Displays the value of the selected item in Float. Note that when the selected watch-expression value is not 4-byte data, or has the type information, displays it in the default notation (see " <a href="#">Table A-17. Display Format of Watch-Expressions (Default)</a> ").
Double	Displays the value of the selected item in Double. Note that when the selected watch-expression value is not 8-byte data, or has the type information, displays it in the default notation (see " <a href="#">Table A-17. Display Format of Watch-Expressions (Default)</a> ").
Decimal Notation for Array Index	Displays array indexes on this panel in decimal number (default).
Hexadecimal Notation for Array Index	Displays array indexes on this panel in hexadecimal number.

Encoding	The following cascade menus are displayed to specify the character code.
ASCII	Displays the value of the selected item in ASCII code (default).
Shift_JIS	Displays the value of the selected item in Shift_JIS code.
EUC-JP	Displays the value of the selected item in EUC-JP code.
UTF-8	Displays the value of the selected item in UTF-8 code.
UTF-16	Displays the value of the selected item in UTF-16 code.
Size Notation	The following cascade menus are displayed to specify the size notation.
1 Bytes	Displays the value of the selected item as 8-bit data.
2 Bytes	Displays the value of the selected item as 16-bit data.
4 Bytes	Displays the value of the selected item as 32-bit data.
8 Bytes	Displays the value of the selected item as 64-bit data.
Jump to Memory	Opens the <a href="#">Memory panel</a> (Memory1) and jumps to the address which the selected watch-expression is defined (see " <a href="#">(g) Jump to the address with memory definition</a> ").
Reset Color	Resets highlighting of the selected watch-expression whose value has been changed by executing a program. This item is disabled during execution of a program.

### Call Stack panel


This panel is used to display the call stack information for the function call (see "2.10.1 Display call stack information"). This panel appears only when connected to the debug tool.

**Caution** Nothing is displayed on this panel during execution of a program.

When the execution of a program is stopped, items in each area are displayed.

**Remark** This panel can be zoomed in and out by  in the tool bar, or by moving the mouse wheel forward or backward while holding down the [Ctrl] key.

Figure A-45. Call Stack Panel



This section describes the following.

- [\[How to open\]](#)
- [\[Description of each area\]](#)
- [\[Toolbar\]](#)
- [\[\[File\] menu \(Call Stack panel-dedicated items\)\]](#)
- [\[\[Edit\] menu \(Call Stack panel-dedicated items\)\]](#)
- [\[Context menu\]](#)

#### [How to open]

- From the [View] menu, select [Call Stack].

#### [Description of each area]

##### (1) [Depth] area

The depth of the call is displayed.

The line at the current PC position becomes 0 and incremented numbers from 1 is added to the calling function in the order.

##### (2) [Call Stack] area

The current source position and the call stack information pushed on the stack (position of the calling function and arguments of a each function, etc.) are displayed.

The display format in this area differs depending on the selection condition of the  button on the toolbar, or of [Show Parameter]/[Show Module File Name] from the context menu.

Condition	Display Format
- Display arguments - Display module file name	$<\text{Function}>(<\text{Argument}>=<\text{Argument Value}^{\text{Note}}>, \dots)[<\text{Module file name}>\$<\text{File name}>\#<\text{Line number}>]$ (default)
- Display arguments - Do not display module file name	$<\text{Function}>(<\text{Argument}>=<\text{Argument value}^{\text{Note}}>, \dots)[<\text{File Name}>\#<\text{Line number}>]$
- Do not display arguments - Display module file name	$<\text{Function}>()[<\text{Module file name}>\$<\text{File name}>\#<\text{Line number}>]$
- Do not display arguments - Do not display module file name	$<\text{Function}>()[<\text{File name}>\#<\text{Line number}>]$

**Note** When the argument value is character string, up to 20 characters can be displayed.

**Remark** Array arguments are passed as pointers rather than arrays (C language specification). For this reason, if the argument is an array, it is displayed as a pointer.

This area is provided with the following functions.

#### (a) Jump to source line and disassemble

By selecting [Jump to Source] from the context menu, the [Editor panel](#) is opened with moving the caret to the source line corresponding to the calling function at the current caret position (if the Editor panel is already open, the screen will jump to the panel).

In addition, similarly by selecting [Jump to Disassemble], the [Disassemble panel](#) (Disasembble1) is opened with moving the caret to the address corresponding to the calling function at the current caret position (if the Disassemble panel is already open, the screen will jump to the panel (Disassemble1)).

**Remark** It is possible to jump to the target source line by double-clicking on that line as well.

#### (b) Saving the contents of call stack information

By selecting the [File] menu >> [Save Call Stack Data As...], the [Save As dialog box](#) can be opened, and all the contents of this panel can be saved in a text file (\*.txt) or CSV file (\*.csv).

See "[\(4\) Save the contents of call stack information](#)" for details on the method for saving the contents of call stack information.

**[Toolbar]**

The buttons below are disabled during execution of a program.

	Acquires the latest data from the debug tool, and updates the contents of this panel.
Notation	The following buttons to specify the notation of values are displayed.
	Displays values on this panel in the default notation according to the type of variable (default).
	Displays values on this panel in hexadecimal number.
	Displays values on this panel in decimal number.
	Displays values on this panel in octal number.
	Displays values on this panel in binary number.
Encoding	The following buttons to specify the encoding of character variables are displayed.
	Displays character variables in ASCII code (default).
	Displays character variables in Shift_JIS code.
	Displays character variables in EUC-JP code.
	Displays character variables in UTF-8 code.
	Displays character variables in UTF-16 code.
	Displays the call stack information with the module file name (default).
	Displays the call stack information with the parameters (arguments) of the function call (default).

**[[File] menu (Call Stack panel-dedicated items)]**

The following items are exclusive for the [File] menu in the Call Stack panel (other items are common to all the panels). Note that all these items are disabled during execution of a program.

Save Call Stack Data	Overwrites the contents of this panel to the previously saved text file (*.txt)/CSV file (*.csv) (see " <a href="#">(b) Saving the contents of call stack information</a> "). Note that when the file has never been saved or the file is write disabled, the same operation is applied as the selection in [Save Call Stack Data As...].
Save Call Stack Data As...	Opens the <a href="#">Save As dialog box</a> to newly save the contents of this panel to the specified text file (*.txt)/CSV file (*.csv) (see " <a href="#">(b) Saving the contents of call stack information</a> ").

**[[Edit] menu (Call Stack panel-dedicated items)]**

The following items are exclusive for [Edit] menu in the Call Stack panel (all other items are disabled).

Copy	Copies the contents of the selected line to the clipboard.
Select All	Selects all the items of this panel.
Find...	Opens the Find and Replace dialog box with selecting the [Find in Files] tab.
Replace...	Opens the Find and Replace dialog box with selecting the [Replace in Files] tab.

**[Context menu]**

All the items from the context menu are disabled during execution of a program.

Copy	Copies the contents of the selected line to the clipboard.
Show Module File Name	Displays the call stack information with the module file name (default).
Show Parameter	Displays the call stack information with the parameters (arguments) of the function call (default).
Notation	The following cascade menus to specify the notation of values are displayed.
AutoSelect	Displays values on this panel in the default notation according to the type of variable (default).
Hexadecimal	Displays values on this panel in hexadecimal number.
Decimal	Displays values on this panel in decimal number.
Octal	Displays values on this panel in octal number.
Binary	Displays values on this panel in binary number.
Encoding	The following cascade menus to specify the encoding of character variables are displayed.
ASCII	Displays character variables in ASCII code (default).
Shift_JIS	Displays character variables in Shift_JIS code.
EUC-JP	Displays character variables in EUC-JP code.
UTF-8	Displays character variables in UTF-8 code.
UTF-16	Displays character variables in UTF-16 code.
Jump to Disassemble	Opens the <a href="#">Disassemble panel</a> (Disassemble1) and jumps to the address corresponding to the calling function of the selected line in this panel.
Jump to Source	Opens the <a href="#">Editor panel</a> and jumps to the source line corresponding to the calling function of the selected line in this panel.
Jump to Local Variable at This Time	Opens the <a href="#">Local Variables panel</a> to display the local variable corresponding to the selected line.

### Trace panel [IECUBE][IECUBE2][Simulator]

This panel is used to display trace data recording the execution history of the program (see "2.11 Collect Execution History of Programs [IECUBE][IECUBE2][Simulator]").

The trace data displays by mixing the disassembled text and source text by default, but it is also possible to display either one of these by selecting the **Display mode**.

After the execution of the program is stopped, the display position is automatically updated such that the latest trace data is displayed.

This panel appears only when connected to the debug tool.

#### Cautions 1. [IECUBE]


**Some of the trace function, the real-time display update function (RRM function) and the coverage function are used on a mutually exclusive basis.**

#### 2. [IECUBE2]

**Some of the trace function, the timer function (except for the Run-Break timer) and the coverage function are used on a mutually exclusive basis.**

- Remarks 1.**
1. When the separator line of each area in this panel is double-clicked, the width of the area changes to the shortest possible size that can display the contents of the area.
  2. This panel can be zoomed in and out by **100%** in the tool bar, or by moving the mouse wheel forward or backward while holding down the [Ctrl] key.

Figure A-46. Trace Panel



This section describes the following.

- [\[How to open\]](#)
- [\[Description of each area\]](#)
- [\[Toolbar\]](#)
- [\[\[File\] menu \(Trace panel-dedicated items\)\]](#)
- [\[\[Edit\] menu \(Trace panel-dedicated items\)\]](#)
- [\[Context menu\]](#)

**[How to open]**

- From the [View] menu, select [Trace].
- On the [Editor panel/Disassemble panel](#), select [Trace Settings] >> [Show Trace Result] from the context menu.

**[Description of each area]****(1) [Number] area**

The trace number corresponding to the trace frame is displayed.

**(2) [Time (h:min:s,ms,μs,ns)] area**

This area displays the time required from the execution start of the program to the execution start of an instruction of each frame or generation of memory access cause.

The time is displayed in units of "hours, minutes, seconds, milliseconds, microseconds and nanoseconds".

If overflow occurs, this area is displayed in invalid color (gray).

**Remarks 1. [IECUBE][IECUBE2]**

The precision of the time depends on the setting of the [Rate of frequency division of trace time tag] property on the [Trace] category on the [\[Debug Tool Settings\] tab](#) of the [Property panel](#).

**2. [Simulator]**

The question of whether to set the time display as an integrated value or differential value depends on the setting of the [Accumulate trace time] property on the [Trace] category on the [\[Debug Tool Settings\] tab](#) of the [Property panel](#).

**(3) [Line/Address] area**

The address of the assemble code or the line number of a source file is displayed.

The notation of a data value can be selected by the button on the toolbar or the context menu item.

The display formats are as follows:

Type of Display Line	Display Format
Instruction (disassemble results)	<Address>
Source text	<File name>#<Line number>
Other than above	-

**Remark** Since the following execution histories are not displayed, the line numbers displayed are not consecutive numbers.


- CPU register access
- Operand access
- Invalid fetch

**(4) [Source/Disassemble] area**

The collected trace data is displayed as follows.

The items displayed in this area differ depending on the selection of the display mode (see "(a) [Display mode](#)").

Figure A-47. Display Contents of [Source/Disassemble] Area (Default)



Label	The label is displayed when a label is defined for the address.
Offset value	The offset value from the nearest label is displayed when a label is defined for the address.
Source text	<p>The corresponding source text is displayed when the <a href="#">Mixed display mode</a> or <a href="#">Source display mode</a> is selected.</p> <p>However, when a place where no debugging information is present is executed, "&lt;No Debug Information&gt;" is displayed.</p> <p>In addition, when the value of a variable<sup>Note 1</sup> or an I/O register that is accessed during execution of a source line can be analyzed, that value is displayed in the following format at the end of the source line.</p> <ul style="list-style-type: none"> <li>- &lt;&lt;&lt;Variable name = Variable value&gt;&gt;&gt;</li> <li>- &lt;&lt;&lt;I/O register name = I/O register value&gt;&gt;&gt;</li> </ul> <p>Example: a=b; &lt;&lt;&lt;a=5&gt;&gt;&gt;</p> <p>The results of the <a href="#">Point Trace</a> are displayed as same as format above.</p>
Instruction (disassemble results)	<p>The corresponding instructions are displayed as the result of disassembling when the <a href="#">Mixed display mode</a> or <a href="#">Disassemble display mode</a> is selected<sup>Note 2</sup>.</p> <p>The mnemonics are shown highlighted.</p>
Break cause [Simulator]	The reason why the program has broken down is displayed.

- Notes 1.** When there is a memory access, a symbol will be interpreted as a variable and displayed only if a symbol is assigned to the accessed address. Note, however, that only variables of up to 4 bytes are supported. If multiplication or other code is processed by the standard libraries, the label of the SADDR area used by the standard library may be shown.
- 2.** At a frame for which not all the trace data was fetched, "(LOST)" is displayed. In this case, the corresponding line is shown in error color (the error color depends on the configuration in the [\[General - Font and Color\] category](#) of the Option dialog box).

This area is provided with the following functions.

#### (a) Display mode

It is possible to select the following three display modes by selection of a button on the toolbar or the context menu.

Display Mode	Displayed Content
Mixed display mode	Displays the instruction (disassemble results), labels, source text (corresponding source line), point trace results, and break causes (default).
Disassemble display mode	Displays the instruction (disassemble results), labels, point trace results, and break causes.
Source display mode	Displays the source text (corresponding source line) and break causes. However, when a place where no debugging information is present is executed, "<No Debug Information>" is displayed.

#### (b) Jumping to source line or disassemble

By selecting [Jump to Source] from the context menu, the [Editor panel](#) opens with moving the caret to the source line corresponding to the line at the current caret position (if the Editor panel is already open, the screen will jump to the panel).

In addition, similarly by selecting [Jump to Disassemble], the [Disassemble panel](#) (Disasembble1) is opened with moving the caret to the address corresponding to the fetch address of the line at the current caret position (if the Disassemble panel is already open, the screen will jump to the panel (Disassemble1)).

#### (c) Linking with other panels

By clicking the  /  button on the toolbar, or selecting [Window Connecting] >> [Connect Source Window]/[Connect Disassemble Window] from the context menu, it is possible to link and display the corresponding places on the [Editor panel](#)/[Disassemble panel](#), with the address of the caret position on this panel used as the pointer (no movement of the focus is done).

#### (d) Pop-up display

By hovering the mouse cursor over a line, all the area (item) data corresponding to that line is pop-up displayed in tandem shape.

#### (e) Saving trace data

The [Data Save dialog box](#) can be opened by selecting the [File] menu >> [Save Trace Data As...], and the contents of this panel can be saved in a text file (\*.txt) or CSV file (\*.csv).

See "[2.11.9 Save the contents of execution history](#)" for details on the method for saving trace data.

### (5) [Address] area

The target address of memory access is displayed.

However, in the event of access to I/O register, the I/O register name is displayed instead of the address (when a plurality is accessed these are displayed in the following lines).

The radix of a data value can be selected by the button on the toolbar or the context menu item.

#### Remark [IECUBE2]

To display the target address of memory access via DMA, select [Yes] with the [DMA is traced] property in the [Trace] category on the [\[Debug Tool Settings\] tab](#) of the [Property panel](#).

**(6) [Data] area**

The accessed data value and the access type at that time are displayed.

However, CPU register access is not displayed.

The notation of a data value can be selected by the button on the toolbar or the context menu item.

The display format of the data value and the access type are as follows (character colors and background colors depend on the configuration in the [\[General - Font and Color\] category](#) of the [Option dialog box](#)):

Display Example (Default)			Memory Access Type
RData value	Character color	Standard color	Read access
	Background color	Palegreen	
WData value	Character color	Standard color	Write access
	Background color	Orange	
RWData value	Character color	Standard color	Read and write access
	Background color	Paleturquoise	
VECTData value	Character color	Standard color	Vector read access
	Background color	Palegreen	

**Remarks 1. [IECUBE]**

If an I/O register access or a memory access is generated via DMA, "DMA" will be shown immediately after the data value of the frame where the access started/ended.

**2. [IECUBE2]**

To display the data value that is accessed via DMA, select [Yes] with the [DMA is traced] property in the [Trace] category on the [\[Debug Tool Settings\] tab](#) of the [Property panel](#). In this case, the DMA trace data specified with the [Select DMA trace data] property in the same category will be displayed in the following format:

<Access type><Data value><DMA Channel number=DMA Channel number><Size=Data size><Transfer Count=Transfer count number>

**[Toolbar]**

	Acquires the latest data from the debug tool, and updates the contents of this panel. This item is disabled while the tracer is running.
	Clears the trace memory and the display of this panel (initialized). This item is disabled while the tracer is running.
	Starts the tracer operation. The content currently being displayed in this panel is cleared. This item is disabled while the tracer is running.
	Stops the tracer operation. The contents of trace data newly acquired are displayed. This item is disabled while the tracer is stopped.
	Opens the <a href="#">Trace Search dialog box [IECUBE][IECUBE2][Simulator]</a> .

Notation	The following buttons to change the notation of a data value are displayed. This item is disabled while the tracer is running.
 Hex	Displays values on this panel in hexadecimal number (default).
 Dec	Displays values on this panel in decimal number.
 Oct	Displays values on this panel in octal number.
 Bin	Displays values on this panel in binary number.
 Editor	Links with the <a href="#">Editor panel</a> .
 Disassemble	Links with the <a href="#">Disassemble panel</a> .
 Mixed	Sets to the <a href="#">Mixed display mode</a> as the display mode (default). This item is disabled while the tracer is running.
 Disassemble	Sets to the <a href="#">Disassemble display mode</a> as the display mode. This item is disabled while the tracer is running.
 Source	Sets to the <a href="#">Source display mode</a> as the display mode. This item is disabled while the tracer is running.

**[File] menu (Trace panel-dedicated items)**

The following items are exclusive for the [File] menu in the Trace panel (other items are common to all the panels). Note that all these items are disabled during execution of a program.

Save Trace Data	Overwrites the contents of this panel to the previously saved text file (*.txt)/CSV file (*.csv) (see " <a href="#">(e) Saving trace data</a> ").  Note that when the file has never been saved or the file is write disabled, the same operation is applied as the selection in [Save Trace Data As...].  This item is disabled while the tracer is running.
Save Trace Data As...	Opens the <a href="#">Data Save dialog box</a> to newly save the contents of this panel to the specified text file (*.txt)/CSV file (*.csv) (see " <a href="#">(e) Saving trace data</a> ").  This item is disabled while the tracer is running.

**[Edit] menu (Trace panel-dedicated items)**

The following items are exclusive for [Edit] menu in the Trace panel (all other items are disabled).

Copy	Copies the contents of the selected line to the clipboard (multiple line selections impossible).  This item is disabled while the tracer is running.
Find...	Opens the <a href="#">Trace Search dialog box [IECUBE][IECUBE2][Simulator]</a> .

**[Context menu]**

Clear Trace	Clears the trace memory and the display of this panel (initialized).  This item is disabled while the tracer is running.
Start Trace	Starts the tracer operation.  The content currently being displayed in this panel is cleared.  This item is disabled while the tracer is running.

Stop Trace	Stops the tracer operation. The contents of trace data newly acquired are displayed. This item is disabled while the tracer is stopped.
Find...	Opens the <a href="#">Trace Search dialog box [IECUBE][IECUBE2][Simulator]</a> . This item is disabled while the tracer is running.
Copy	Copies the contents of the selected line to the clipboard (multiple line selections impossible). This item is disabled while the tracer is running.
Mixed Display	Sets to the <a href="#">Mixed display mode</a> as the display mode. This item is disabled while the tracer is running.
Disassemble View	Sets to the <a href="#">Disassemble display mode</a> as the display mode. This item is disabled while the tracer is running.
Source View	Sets to the <a href="#">Source display mode</a> as the display mode. This item is disabled while the tracer is running.
Notation	The following cascade menus are displayed to specify the notation. This item is disabled while the tracer is running.
Hexadecimal number	Displays values on this panel in hexadecimal number (default).
Decimal	Displays values on this panel in decimal number.
Octal	Displays values on this panel in octal number.
Binary	Displays values on this panel in binary number.
Window Connecting	The following cascade menus are displayed to link with other panels (see " <a href="#">(c) Linking with other panels</a> ").
Connect Source Window	Links with the <a href="#">Editor panel</a> .
Connect Disassemble Window	Links with the <a href="#">Disassemble panel</a> .
Jump to Disassemble	Opens the <a href="#">Disassemble panel</a> (Disassemble1) and jumps to the fetch address corresponding to the line at the caret position in this panel.
Jump to Source	Opens the <a href="#">Editor panel</a> and jumps to the source line corresponding to the line at the caret position in this panel.
Jump to Memory	Opens the <a href="#">Memory panel</a> and jumps to the memory value corresponding to the line at the caret position in this panel.


### Events panel

This panel is used to display the detailed information about the events that are set on the [Editor panel/Disassemble panel/Watch panel](#). On this panel, you can change the setting state of the event between valid/invalid and delete the event (see "[2.15 Manage Events](#)").

This panel appears only when connected to the debug tool.

- Remarks 1.** The available event types depend on the type of the selected microcontroller and of the debug tool in use. Refer to the descriptions under "See ..." sentences in the category "Description" in "[Table A-19. Event Type](#)". Alternatively, see "[\(1\) Maximum number of enabled events](#)".
2. The events that have been set on the Function List panel or Variable List panel of the analyze tool (Program Analyzer) are also managed on this panel.
  3. This panel can be zoomed in and out by  in the tool bar, or by moving the mouse wheel forward or backward while holding down the [Ctrl] key.
  4. When the separator line of each area in this panel is double-clicked, the width of the area changes to the shortest possible size that can display the contents of the area.

**Figure A-48. Events Panel**



This section describes the following.

- [\[How to open\]](#)
- [\[Description of each area\]](#)
- [\[Toolbar\]](#)
- [\[\[Edit\] menu \(Events panel-dedicated items\)\]](#)
- [\[Context menu\]](#)


#### [How to open]

- From the [View] menu, select [Event].
- **[IECUBE][IECUBE2][Simulator]**

On the [Editor panel/Disassemble panel](#), select [Timer Settings] >> [View Result of Timer] from the context menu.

**[Description of each area]****(1) [Name] area**

A list of the event names that have currently been set is displayed in the following format.



**Remark** It is possible to limit the event to be displayed by clicking the button on the toolbar (see "[Toolbar]").

**(a) Check box**

The setting state of the event is displayed/changed.

Note that the [Event mark](#) is changed depending on the setting state of the event.

<input checked="" type="checkbox"/>	Valid state	Event occurs when the specified condition is met. It is possible to set the event to an invalid state by removing the check.
<input type="checkbox"/>	Invalid state	Event does not occur when the specified condition is met. It is possible to set the event to a valid state by removing the check.
<input type="checkbox"/>	Suspended state	The conditions that have been specified cannot be set with the program of the debugging target. It is not possible to operate the check box.

**Remarks 1.** Both of the Timer Start event and Timer Stop event is must be set for the Timer Result event.

Therefore, it is not possible to set a particular event to a valid state by only the setting of one of these (at the same time as both events are set, they are treated as grouped events as a Timer Result).

2. It is not possible to set the Run-Break Timer event to an invalid/suspended state.
3. The setting of the Unconditional Trace event and the Trace event to valid or invalid state is exclusively controlled. Therefore, the Unconditional Trace event, which is a built-in event, is valid state by default, but if either a trace start event/trace end event is set, it automatically becomes invalid state, and the Trace event, which is a event name that is collectively called with a trace start event and a trace end event, becomes valid state. Conversely, if the set Trace event is invalid state, the Unconditional Trace event automatically becomes valid state.

**(b) Event mark**

The event mark shows the type of event, and in addition shows the current setting state.

The meanings of the marks displayed are as follows:

**Table A-18. Event Mark**

Event Type	Valid State	Invalid State	Suspended State	Note
Hardware Break				-
Software Break				-
Break at start of function				A break event that can be set via the analyze tool.
Access break to variable				
Unconditional Trace			None	-
Run-Break Timer		None	None	-
Trace				Displayed on only the <a href="#">Events panel</a>
Trace start				Displayed on only the <a href="#">Editor panel</a> / <a href="#">Disassemble panel</a>
Trace end				
Timer Result				Displayed on only the <a href="#">Events panel</a>
Timer start				Displayed on only the <a href="#">Editor panel</a> / <a href="#">Disassemble panel</a>
Timer end				
Point Trace				-
Printf (Action event)				-
Setting of two or more events	Note 1	Note 2	Note 3	Displayed on only the <a href="#">Editor panel</a> / <a href="#">Disassemble panel</a>

**Notes 1.** There is one or more event with valid state.

2. There is no event with valid state and at least one event with invalid state.
3. All the set events are suspended state.

**(c) Event name**

The event type and ID number are displayed as the event name.

A number from 0001 is automatically provided as the ID number for each event (no renumbering of the ID number is done even in the event that an event that has been set once is deleted).

Event types that are displayed are as follows:

**Table A-19. Event Type**

Event Type	Description
Hardware Break (Break <sup>Note 1</sup> )	Breaks the program when the condition is met while the debug tool monitors the break condition all the time during program execution. -> See " <a href="#">2.8.2 Stop the program at the arbitrary position (breakpoint)</a> " -> See " <a href="#">2.8.3 Stop the program at the arbitrary position (break event)</a> " -> See " <a href="#">2.8.4 Stop the program with the access to variables/I/O registers</a> "
Software Break (Break <sup>Note 1</sup> )	Breaks the program when the instruction, which an address code to break is rewritten for the break instruction, is executed. -> See " <a href="#">2.8.2 Stop the program at the arbitrary position (breakpoint)</a> "

Event Type	Description
Break at start of function	This event type is a <a href="#">Hardware Break</a> (execution type) that is set in the Function panel of the analyze tool (Program Analyzer).
Access break to variable	This event type is a <a href="#">Hardware Break</a> (access type) that is set in the Variable panel of the analyze tool (Program Analyzer).
Unconditional Trace	Automatically collects the trace data with start of a program execution, and stops collecting the trace data with stop of the program execution. This event cannot be deleted because of the built-in event <sup>Note 2</sup> (this event is set to a <a href="#">Valid state</a> by default). -> See " <a href="#">2.11.2 Collect execution history until stop of the execution</a> "
Run-Break Timer	Automatically measures the execution time of a program with start of the program execution, and stops the measurement with stop of the program execution. This event cannot be deleted because of the built-in event <sup>Note 2</sup> (this event is set to a <a href="#">Valid state</a> by default). -> See " <a href="#">2.12.1 Measure execution time until stop of the execution</a> "
Trace	Starts/stops collecting the trace data when the condition specified with a trace start event and a trace end event is met (this event is displayed when either a trace start event or a trace end event is set). -> See " <a href="#">2.11.3 Collect execution history in the arbitrary section</a> "
Timer Result	Starts/stops measuring the execution time of a program when the condition specified with a timer start event and a timer end event is met (this event is displayed when either a timer start event or a timer end event is set). -> See " <a href="#">2.12.2 Measure execution time in the arbitrary section</a> "
Point Trace	Records the information as the trace data only when accessing the specified variable or I/O register during execution of a program. -> See " <a href="#">2.11.4 Collect execution history only when the condition is met</a> "
Printf	Executes printf command in software processing after temporary stopping a program in execution at an arbitrary position (action event). -> See " <a href="#">2.14.1 Insert printf</a> "

- Notes 1.** A breakpoint that is set by a one click operation of the mouse is displayed "Break" (see "[\(2\) Set a breakpoint](#)").
- 2.** This is set in the debug tool by default.

## (2) [Detail Information] area

Detailed information about each event is displayed.

The contents of the information that is displayed differ depending on the event type as follows:

**Table A-20.** Detailed Information with Event Type

Event Type	Displayed Content <sup>Note 1</sup>			
Hardware Break (Condition: execution)	Format1	<Condition to occur> <File name#Line number> <Address>		
	Example	Before Execution main.c#39 0x100		
		After Execution sub.c#100 0x200		
		Before Execution - 0x300		
		Execution main.c#39 0x300 [Simulator]		
	Format2	<Condition to occur> <Symbol + Offset> <Address>		
	Example	Before Execution funcA + 0x10 0x100		
		After Execution funcB + 0x20 0x200		
		Before Execution - 0x300		
Hardware Break (Condition: access)	Format1	<Condition to occur> <File name#Variable name> <Address(range)> <Comparison condition> <Comparison value>		
	Example	Read main.c#variable1 0x100 - 0x101 == 0x5		
		Write sub.c#variable2 0x200 - 0x200 == 0x7		
		Read/Write sub2.c#variable3 0x300 - 0x303 == 0x8		
	Format2	<Condition to occur> <File name#Function name#Variable name> <Address(range)> <Comparison condition> <Comparison value>		
	Example	Read main.c#func1#variable1 0x100 - 0x101 == 0x10		
	Format3	<Condition to occur> <Variable name> <Address(range)> <Comparison condition> <Comparison value>		
Software Break	Example	Write variable1 0x100 - 0x101 == 0x10		
	Format1	<Condition to occur> <File name#Line number> <Address>		
	Example	Before Execution main.c#40 0x102		
		Before Execution sub.c#101 0x204		
	Format2	<Condition to occur> <Symbol + Offset> <Address>		
Unconditional Trace	Example	Before Execution funcA + 0x120x102		
	Format	-		
	Example	-		
Run-Break Timer	Format	Total: <Total execution time>		
	Example	Total: 1000ms		
		Total: OVERFLOW		
Trace (Condition: execution)	Format	Total of Start/End: <Total number of trace start/trace end events> <sup>Note 2</sup> <Start/End> <Detailed information of trace start/trace end event>		
	Example	Total of Start/End: 4 - Start After Execution main.c#1000x300 - Start After Execution funcA + 0x1000x300 - End After Execution main.c#2000x100 - End After Execution funcA + 0x100x100		

Event Type	Displayed Content <sup>Note 1</sup>	
Timer Result (Condition: execution)	Format	Total:<Total execution time> Total of Start/End: <Total number of timer start event/timer end event> <sup>Note 2</sup> - <Total execution time> <Pass Count> <Average> <Max> <Min> - <Start/End> <Detailed information of timer start event/timer end event>
	Example	Total: 10ms Total of Start/End: 4 - Total: 10ms Pass Count: 5 Average: 2ms Max: 4ms Min: 1ms - Start After Execution main.c#1000x300 - Start After Execution funcA + 0x300x100 - End After Execution main.c#1000x300 - End After Execution funcA + 0x500x100
Point Trace (Condition: access)	Format1	<Condition to occur> <Variable name> <Variable address>
	Example	Read variable1 0x100
	Format2	<Condition to occur> <File name# Variable name> <Variable address>
	Example	Write sub.c#variable2 0x200
	Format3	<Condition to occur> <File name#Function name# Variable name> <Variable address>
	Example	Read/Write sub.c#func1#variabl3 0x300
Printf (Action event)	Format	<Condition to occur> <File name#Line number> <Address> <Setting of Printf event>
	Example	Before Execution main.c#39 0x100 aaa, bbb, ccc
		After Execution sub.c#100 0x200 Result of aaa : aaa

**Notes 1.** Following are the details on the display format.

<Condition to occur>	Displays one of the following conditions. <b>For other than [Simulator]</b> Execution: Before Execution or After Execution Access: Read, Write, Read/Write <b>[Simulator]</b> Execution: Execution Access: Read, Write, Read/Write
<File name#Line number>	Shows the line number of the source. Display format is the same as the watch type scope specification expression. When multiple load module files are downloaded, <Load module file name\$File name#Line number> is displayed. For those events set in the <a href="#">Disassemble panel</a> , display <Line number> in the format <Symbol + offset> in the condition below. - Line information exists and the specified position that the event is set not the top of the line information - Line information does not exist and symbol information exists. Show <Line number> in "-" in the following condition. - Line information and symbol information does not exist.
<Variable name>	Shows the variable name in the source file. Display format is the same as the watch type scope specification expression.
<Comparison condition>	Condition to compare (==) is shown. If the comparison value is not specified, comparison condition is not shown.

<Comparison value>	Comparison value is shown. If the comparison value is not specified, comparison condition is not shown.
<Address>	Address in the memory area is shown (only in hex number).
<Start/End>	Shows whether the contents of the detailed information is start event or the stop event.
<Pass Count>	Shows the measurement result of the pass count of the timer. If a timer overflow occurs (see " <a href="#">2.12.3 Measurable time ranges</a> "), or if the illegal value was acquired, "OVERFLOW" is displayed. If measurements have not been performed yet, "Not measured" is displayed.
<Total>	Shows the measurement result of the timer total execution time. The unit is either of ns/μs/ms/s/min/clock (if, however, the unit is in "min", a value in "s" unit also appears). If a timer overflow occurs (see " <a href="#">2.12.3 Measurable time ranges</a> "), or if the illegal value was acquired, "OVERFLOW" is displayed. If measurements have not been performed yet, "Not measured" is displayed.
<Average>	Shows the measurement result of average execution of the timer. The unit is either of ns/μs/ms/s/min/clock (if, however, the unit is in "min", a value in "s" unit also appears). If a timer overflow occurs (see " <a href="#">2.12.3 Measurable time ranges</a> "), or if the illegal value was acquired, "OVERFLOW" is displayed. If measurements have not been performed yet, "Not measured" is displayed.
<Max>	Shows the measurement result of the maximum execution time of the timer. The unit is either of ns/μs/ms/s/min/clock (if, however, the unit is in "min", a value in "s" unit also appears). If a timer overflow occurs (see " <a href="#">2.12.3 Measurable time ranges</a> "), or if the illegal value was acquired, "OVERFLOW" is displayed. If measurements have not been performed yet, "Not measured" is displayed.
<Min>	Shows the measurement result of the minimum execution time of the timer. The unit is either of ns/μs/ms/s/min/clock (if, however, the unit is in "min", a value in "s" unit also appears). If a timer overflow occurs (see " <a href="#">2.12.3 Measurable time ranges</a> "), or if the illegal value was acquired, "OVERFLOW" is displayed. If measurements have not been performed yet, "Not measured" is displayed.
<Set print event>	Shows the variable expression and the character strings specified in the <a href="#">Action Events dialog box</a> .

2. Click this line to display the detailed information of the lower lines.

### (3) [Comment] area

The user can write comments for each event that has been set.

To input comments, click on this area, or select [Edit Comment] from the context menu after selecting the event in which you want to input comments, and then input directly the desired text from the keyboard (the edit mode is cancelled by pressing down the [Esc] key).

After editing the comments, complete the editing by pressing the [Enter] key or moving the focus to outside the edit region. Up to a maximum of 256 characters can be inputted for the comments, and this is saved as the settings of the user during use.

**[Toolbar]**

	Deletes the selected event and event condition. Note that it is not possible to delete the built-in events (Unconditional Trace event and Run-Break Timer event).
	Displays events related to Hardware Break (default).
 (except [Simulator])	Displays events related to Software Break (default).
 [IECUBE][IECUBE2] [Simulator]	Displays events related to the trace (default).
	Displays events related to the timer (default) <sup>Note 1</sup> .
	Displays events related to the action event (Printf event) (default).
	Displays events related to the built-in event (Unconditional Trace event/Run-Break Timer event) (default).
	Opens the <a href="#">Editor panel</a> and jumps to the source line corresponding to the address where the selected event <sup>Note 2</sup> is being set.
	Opens the <a href="#">Disassemble panel</a> and jumps to the disassemble results corresponding to the address where the selected event <sup>Note 2</sup> is being set.
	Opens the <a href="#">Memory panel</a> and jumps to the memory corresponding to the address where the selected event <sup>Note 2</sup> is being set.

**Notes 1. [V850E1][V850ES]: [MINICUBE2][E1][E20][EZ Emulator]**

This button is disabled.

2. Events other than Trace events, Timer Result events and built-in events (Unconditional Trace events/Run-Break Timer events) can be objects of this button.

**[[Edit] menu (Events panel-dedicated items)]**

The following items are exclusive for [Edit] menu in the Events panel (all other items are disabled).

Delete	Deletes the selected event and event condition. Note that it is not possible to delete the built-in events (Unconditional Trace event and Run-Break Timer event).
Select All	Selects all the events displayed on the panel.
Find...	Opens the Find and Replace dialog box with selecting [Find in Files] tab.
Replace...	Opens the Find and Replace dialog box with selecting [Replace in Files] tab.

**[Context menu]**

Enable Event	Enables the selected event (valid state). Note that this item is disabled if the selected event is a valid state.
Disable Event	Disables the selected event (invalid state). Note that this item is disabled if the selected event is an invalid state.

Delete	Deletes the selected event. Note that it is not possible to delete the built-in events (Unconditional Trace event and Run-Break Timer event).
Select All	Selects all the events of this panel.
View Select	The following cascade menus are displayed to limit the event type to be displayed. All of the items have been selected by default.
Hardware Break	Displays events related to Hardware Break.
Software Break	Displays events related to Software Break.
Timer Event	Displays events related to the timer.
Trace Event <b>[IECUBE][IECUBE2] [Simulator]</b>	Displays events related to the trace.
Action Event	Displays events related to action events (Printf events).
Built-in Event	Displays events related to built-in events (Unconditional Trace event or Run-Break Timer event).
Timer Settings	The following cascade menus are displayed to do the settings related to the timer. Note that this item is enabled only when a timer-related event has been selected.
Init Timer	Initializes the timer used by the selected event (except for Run-Break Timer).
Nanosecond	Displays the result of a selected event measured by a timer in nanosecond (ns) units.
Microsecond	Displays the result of a selected event measured by a timer in microsecond ( $\mu$ s) units.
Millisecond	Displays the result of a selected event measured by a timer in millisecond (ms) units.
Second	Displays the result of a selected event measured by a timer in second (s) units.
Minute	Displays the result of a selected event measured by a timer in minute (min) units.
Clock	Displays the result of a selected event measured by a timer in clock units.
Jump to Memory	Opens the <a href="#">Memory panel</a> (Memory1) and jumps to the memory corresponding to the address where the selected event <sup>Note</sup> is being set.
Jump to Disassemble	Opens the <a href="#">Disassemble panel</a> (Disassemble1) and jumps to the disassemble results corresponding to the address where the selected event <sup>Note</sup> is being set.
Jump to Source	Opens the <a href="#">Editor panel</a> and jumps to the source line corresponding to the address where the selected event <sup>Note</sup> is being set.
Edit Condition...	Opens one of the following dialog box to edit the selected event - For an action event (Printf event) <a href="#">Action Events dialog box</a>
Edit Comment	Sets to the edit mode to input comments for the selected event. When comments are already present, all of that character string is set to a select state.

**Note** Events other than Trace events, Timer Result events and built-in events (Unconditional Trace events/Run-Break Timer events) can be objects of this item.


## Output panel

This panel is used to display operation logs for various components (debug tool, design tool, build tool, etc.) provided by CubeSuite+, in addition to results of batch searches by the Find and Replace dialog box and a Printf event (see "2.14.1 Inset printf").

The messages are classified by the message origination tool and displayed on the individual tabs.

**Remark** This panel can be zoomed in and out by  in the tool bar, or by moving the mouse wheel forward or backward while holding down the [Ctrl] key.

Figure A-49. Output Panel



This section describes the following.

- [\[How to open\]](#)
- [\[Description of each area\]](#)
- [\[\[File\] menu \(Output panel-dedicated items\)\]](#)
- [\[\[Edit\] menu \(Output panel-dedicated items\)\]](#)
- [\[Context menu\]](#)

### [How to open]

- From the [View] menu, select [Output].

### [Description of each area]

#### (1) Message area

The output messages of each tool, search results and results by a Printf event are displayed.

In the case of search results (batch search), every time a search is performed, a new message will be displayed after the previous message is cleared (except for the [All Messages] tab).

The colors of message display differ with the type of message as shown below (character colors and background colors depend on the configuration in the [\[General - Font and Color\] category](#) of the [Option dialog box](#)).

Message Type	Display Example (Default)		Description	
Normal message		Character color	Black	Displayed with information notices
		Background color	White	
Warning message		Character color	Blue	Displayed with warnings about operations
		Background color	Standard color	

Message Type	Display Example (Default)			Description
Error message	<b>AaBbCc</b>	Character color	Red	Displayed when there is a critical error, or when execution is not possible due to a operational mistake
		Background color	Light gray	

This area is provided with the following functions.

#### (a) Tag jump

By double-clicking on the output message, the [Editor panel](#) is opened and the number of the corresponding line in the corresponding file is displayed.

This allows you to jump from error messages that are output when building, etc. to the corresponding error line in the source file.

#### (b) Help display

If there is a caret on the line where a warning message or error message is being displayed, you can select [Help for Message] from the context menu. You can also display help for that line's message by pressing the [F1] key.

#### (c) Saving a log

The [Save As dialog box](#) can be opened by selecting the [File] menu >> [Save Output-tab name As...], and the contents that are displayed on the currently selected tab can be saved in a text file (\*.txt) (messages on deselected tabs will not be saved).

### (2) Tab selection area

Select the tab that indicates the origin of message.

The following tabs are available for the debug tool.

Tab Name	Description
All Messages	Displays operation logs for all components (debug tool, design tool, build tool, etc.) provided by CubeSuite+ in order of output.
Debug Tool	Displays messages output from the debug tool. Display only operation logs for the debug tool out of those for various components (debug tool, design tool, build tool, etc.) provided by CubeSuite+.
Find and Replace	Displays the batch search results from the Find and Replace dialog box.

**Caution** Even if a new message is output on a deselected tab, tab selection will not automatically switch. In this case, "\*" mark will be added in front of the tab name, indicating that a new message has been output.

### [[File] menu (Output panel-dedicated items)]

The following items are exclusive for the [File] menu in the Output panel (other items are common to all the panels). Note that all these items are disabled during execution of a program.

Save Output-tab name	Overwrites the contents that are displayed on the currently selected tab to the previously saved text file (see "(c) Saving a log").  Note that when the file has never been saved or the file is write disabled, the same operation is applied as the selection in [Save Output-tab name As...].  This item is disabled while building.
----------------------	--

Save Output- <i>file name</i> As...	Opens the <a href="#">Save As dialog box</a> to newly save the contents that are displayed on the currently selected tab to the specified text file (*.txt) (see "(c) Saving a log").
--	---

**[Edit] menu (Output panel-dedicated items)**

The following items are exclusive for [Edit] menu in the Output panel (all other items are disabled).

Copy	Copies the contents of the selected range to the clipboard as character string(s).
Select All	Selects all the messages displayed on the currently selected tab.
Find...	Opens the Find and Replace dialog box with selecting [Quick Find] tab.
Replace...	Opens the Find and Replace dialog box with selecting [Replace in Files] tab.

**[Context menu]**

Copy	Copies the contents of the selected range to the clipboard as character string(s).
Select All	Selects all the messages displayed on the currently selected tab.
Clear	Deletes all the messages displayed on the currently selected tab.
Tag Jump	Opens the <a href="#">Editor panel</a> and jumps to the number of the corresponding line in the corresponding file of the message at the caret position.
Stop Searching	Cancels the search currently being executed. This item is disabled when a search is not being executed.
Help for Message	Displays help for the message on the current caret position. This item only applies to warning messages and error messages.

### Memory Mapping dialog box

This dialog box is used to set the memory mapping for each type of memory.

**Caution** If you are not connected to a debug tool, then only memory mapping areas added by user is displayed.

Connecting to a debug tool (see "2.4.1 Connect to the debug tool") will display details for each memory type.

Figure A-50. Memory Mapping Dialog Box (for Other Than [IECUBE[V850ES]][Simulator])




Figure A-51. Memory Mapping Dialog Box [IECUBE[V850E1]]





Figure A-52. Memory Mapping Dialog Box [Simulator]



This section describes the following.

- [\[How to open\]](#)
- [\[Description of each area\]](#)
- [\[Function buttons\]](#)

#### [How to open]

- On the [\[Debug Tool Settings\]](#) tab of the [Property panel](#), click the [...] button displayed by selecting one of the values of the [Memory mappings] property in the [Memory] category.

**Caution** This dialog box cannot be opened during execution of a program.

#### [Description of each area]

##### (1) Added memory mapping specification area

Specify the information for a memory mapping newly added.

###### (a) [Memory type]

Select the memory type for the memory mapping to be added from the following drop-down list.

The item selected by default differs depending on the debug tool to use.

Emulation ROM area [IECUBE[V850E1][V850ES]] [Simulator]	Adds the Emulation ROM area. [IECUBE]: The IECUBE alternate ROM is used. [Simulator]: The simulator alternate ROM is used.
Emulation RAM area [IECUBE[V850E1][V850ES]] [Simulator]	Adds the Emulation RAM area. [IECUBE]: The IECUBE alternate RAM is used. [Simulator]: The simulator alternate RAM is used.
Target memory area	Adds the target memory area.
Target ROM area [IECUBE[V850E1][V850ES]]	Adds the target ROM area. Areas specified as target ROM are subject to write protect for the fail-safe break.

I/O protection area	Adds the I/O protection area <sup>Note</sup> .
---------------------	--

**Note** The I/O protected area is an area protected from access by the debug function.

The address range set to I/O protected area cannot be accessed from the [Memory panel](#) (i.e., it can only be accessed via executing the load module). I/O protected area mapping is only possible within the target memory area.

**Remark** External memory area and guarded areas (areas where access is prohibited) are treated as non-mapped areas. For this reason, if a mapping overlaps a guarded area, then a message will inform the user that the mapping overlaps a non-mapped area.

See the manual of our microcontroller for details onfor details onfor details on the mapping information of external memory areas and guarded areas.

Mapping attributes and their sizes that can be set are as follows:

**Table A-21. Settable Mapping Attribute**

Attribute	Debug Tool				
	IECUBE	IECUBE2	MINICUBE E1/E20(LPD) E1/E20(JTAG)	[MINICUBE2 E1/E20(Serial) EZ Emulator]	Simulator
Emulation ROM area	✓ <sup>Note</sup>	-	-	-	✓
Emulation RAM area	✓ <sup>Note</sup>	-	-	-	✓
Target memory area	✓	✓	✓	✓	✓
Target ROM area	✓	-	-	-	-
I/O protection area	✓	✓	✓	✓	✓

✓ : Valid (Mapping unit: 1 Mbyte for Emulator, 64Kbytes for Simulator))

- : Invalid

**Note** Valid only with the option board.

The emulation ROM/RAM area are composed of 16 Mbytes.

#### (b) [Address range]

Specify the start address and end address for the memory mapping to be added.

Directly input a hexadecimal number into the text box for each.

In the case of the following settings, however, new memory mappings cannot be added. Clicking the [Add] button in this area causes an error message to be displayed.

- If the specified address range duplicates a separate memory area when [Target memory area] is selected as the memory type
- If the specified address range cannot be put into a single target memory area when [I/O protection area] is selected as the memory type

#### (c) [Chip select] [IECUBE[V850E1]]

This item is only valid when using V850E1 Core and when [\[Memory type\]](#) is set to [\[Emulation ROM\]](#) or [\[Emulation RAM\]](#).

Select from the drop-down list the chip select corresponding to the address specified with [\[Address range\]](#).

**(d) [Access width] (except [Simulator])**

Select the access width of the memory mapping to be added from the following drop-down list (direct input is not possible).

In the case where [I/O protection area] is selected as the memory type, the access width must be set to the same value as the access width of the target memory area.

8bits	Sets the access width of the memory mapping to be added to 8 bits (default).
16bits	Sets the access width of the memory mapping to be added to 16 bits <sup>Note</sup> .
32bits	Sets the access width of the memory mapping to be added to 32 bits <sup>Note</sup> .

**Note** When being added to memory mapping, fractions in the address value specified as the ending address are automatically rounded up to multiples of 2 if [16bits] is selected, or multiples of 4 if [32bits] is specified.

**(e) Button**

Button	Function
Add	Adds the content specified in this area to memory mapping. The added memory mapping is displayed in the <a href="#">[Memory mapped list]</a> area. The changes will not take effect until the [OK] button is clicked.

**(2) [Memory mapped list] area****(a) List display**

Information about the memory mapping added in the [Added memory mapping specification area](#) and the microcontroller's internal memory mapping is displayed. This area cannot be edited.

Memory type	<p>Displays the following memory types.</p> <p><b>[V850E1][V850ES]</b></p> <ul style="list-style-type: none"> <li>- Internal ROM area<sup>Note 1</sup></li> <li>- Internal RAM area</li> <li>- DataFlash area<sup>Note 2</sup> (except [<b>Simulator</b>])</li> <li>- I/O register area</li> <li>- Target memory area</li> <li>- Target ROM area [<b>IECUBE</b>]</li> <li>- Emulation ROM area [<b>IECUBE</b>][<b>Simulator</b>]</li> <li>- Emulation RAM area [<b>IECUBE</b>][<b>Simulator</b>]</li> <li>- Non-map area</li> <li>- I/O protection area</li> </ul> <p><b>[V850E2]</b></p> <ul style="list-style-type: none"> <li>- Internal ROM area<sup>Note 1</sup></li> <li>- Internal RAM area</li> <li>- DataFlash area<sup>Note 2</sup> (except [<b>Simulator</b>])</li> <li>- PBUS peripheral I/O area</li> <li>- CPU peripheral I/O area</li> <li>- Internal peripheral I/O area</li> <li>- HBUS peripheral I/O area</li> <li>- HBUS shared memory area</li> <li>- Back-up RAM area</li> <li>- Target memory area</li> <li>- Emulation ROM area [<b>Simulator</b>]</li> <li>- Emulation RAM area [<b>Simulator</b>]</li> <li>- Non-map area</li> <li>- I/O protection area</li> </ul>
Address range	Displays the address range as <Start address> - <End address>. Display is fixed as "0x"-prefixed hexadecimal numbers.
Size	Displays size as a decimal number (unit: bytes/Kbytes <sup>Note 3</sup> ).
Access width	Displays the access width (unit: bits).

- Notes 1.** This item does not appear when the selected microcontroller is a ROMless product.  
 In the case that internal emulation ROM area exists in the emulator, however, "Internal ROM area" will be displayed only when the [Size of internal ROM [KBytes]] property of the [Internal ROM/RAM] category is set to a value greater than "0" in the [\[Connect Settings\] tab of the Property panel](#).
- 2.** This item appears only when the selected microcontroller incorporates the data flash memory.
- 3.** Only in the case of multiple of 1024, displays in kilobyte units.

**(b) Button**

Button	Function
Remove	<p>Deletes the memory mapping selected in this area.</p> <p>The memory areas that can be deleted are the Target memory area, I/O protection area, Emulation ROM area [<b>IECUBE][Simulator</b>], or the Emulation RAM area [<b>IECUBE][Simulator</b>] (the microcontroller's internal memory mapping cannot be deleted).</p> <p>In the case where you have attempted to delete a target memory area that is specified as an I/O protection area, however, a message will be displayed. The selected target memory area and the I/O protection area mapped to that area will both be deleted only if you click the [OK] button.</p>

**[Function buttons]**

Button	Function
OK	Sets the currently specified memory mapping to the debug tool and closes this dialog box.
Cancel	Cancels memory mapping changes and closes this dialog box.
Help	Displays the help for this dialog box.


### Download Files dialog box

This dialog box is used to select files for downloading and configure download conditions (see "2.5 Download/Upload Programs").

Note that files specified as build targets in a project (main project or sub-project) are automatically registered as download targets (they can be unregistered).

**Caution** This dialog box cannot be opened during execution of a program.

Figure A-53. Download Files Dialog Box



This section describes the following.

- [How to open]
- [Description of each area]
- [Function buttons]

#### [How to open]

- On the [Download File Settings] tab of the Property panel, click the [...] button displayed by selecting the [Download files] property in the [Download] category.

#### [Description of each area]

##### (1) [Download file list] area

###### (a) List display

Displays a list of files to download. The names of files specified as build targets in a project (main project or sub-project) are displayed by default (they can be removed).

Files are downloaded in the order that they are displayed here.

To add a new file to be downloaded, click the [Add] button in this area, then in the [Download file property] area, specify the download conditions of the file to add.

## (b) Button

Button	Function
Up	Moves the selected file up one row in the list. Clicking this for the top file in the list has no effect.
Down	Moves the selected file down one row in the list. Clicking this for the bottom file in the list has no effect.
Add	Adds an empty item "-" to the list, and selects it. Specify the download conditions of the file to add in the [Download file property] area. Note that this button will be disabled if 20 files have already been registered.
Remove	Removes the selected file from the list. Note, however, that this button is disabled if the selected file is a project build target.

- Remarks 1.** By hovering the mouse cursor over a file name, the pass information of the file is pop-up displayed.
- 2.** By dragging a file name with the mouse, the display order in the list can be changed.  
Note, however, that the order of a project build target cannot be changed.

## (2) [Download file property] area

## (a) [Download file information]

This area is used to display or edit the download conditions of the file selected in the [Download file list] area.  
It can also be used to specify the download conditions of new download files added via the [Add] button.

File	Specify the name of the file to download.	
	Default	<i>File name</i> (but it will be blank for newly added files)
	Modifying	Directly enter from the keyboard, or specify with the <a href="#">Select Download File dialog box</a> opened by clicking the [...] button <sup>Note 1</sup> appears at right by selecting this item.
	Available values	See " <a href="#">Table 2-3. Type of Files That Can be Downloaded</a> " Up to 259 characters
File type	Specify the type of the file to download.	
	Default	Load module file
	Modifying	Select from the drop-down list.
	Available values	Either of the following - Load module file - Hex file - Hex file with ID Tag <sup>Note 2</sup> - Hex file with ID Tag (Flash Programmer) <sup>Note 2</sup> - Binary data file
Offset	Specify the offset from the address at which the file's download is to start. Note that this item appears only when [File type] is set to [Hex file].	
	Default	0
	Modifying	Directly enter from the keyboard.
	Available values	0x0 to 0xFFFFFFFF in hexadecimal number

Start address	Specify the address at which to start the file's download. Note that this item appears only when [File type] is set to [Binary data file].	
	Default	0
	Modifying	Directly enter from the keyboard.
	Available values	0x0 to 0xFFFFFFFF in hexadecimal number
Download object	Specify whether to download the object information from the specified file. Note that this item appears only when [File type] is set to [Load module file].	
	Default	Yes
	Modifying	Select from the drop-down list.
	Available values	Yes      Downloads object information. No      Does not download object information.
Download symbol information	Specify whether to download the symbol information from the specified file <sup>Note 3</sup> . Note that this item appears only when [File type] is set to [Load module file].	
	Default	Yes
	Modifying	Select from the drop-down list.
	Available values	Yes      Downloads symbol information. No      Does not download symbol information.

- Notes**
- When a file specified as build target in the project is selected in the [\[Download file list\]](#) area, or when the program is executing, the [...] button does not appear.
  - For other than [Simulator]**  
This item appears only when the selected microcontroller incorporates the data flash memory with ID tag and the data flash memory function is valid (i.e. when the [Use DataFlash memory area] property in the [DataFlash] category on the [\[Connect Settings\]](#) tab of the [Property panel](#) is set to [Yes]).
  - If the symbol information have not been downloaded, the source level debugging cannot be performed.

### [Function buttons]


Button	Function
OK	Finishes configuring the download files, and closes this dialog box.
Cancel	Cancels any changes to the download files, and closes this dialog box.
Help	Displays the help for this dialog box.

### External Flash Memory Download dialog box

This dialog box is used to select the external flash memory information file (\*.fdb) for downloading to the external flash memory and configure its download conditions (see "(5) Download to external flash memory [IECUBE][IECUBE2][MINICUBE][E1/E20(LPD)/(JTAG)]").

**Caution** This dialog box cannot be opened during execution of a program.

Figure A-54. Exterior Flash Memory Download Dialog Box



This section describes the following.

- [\[How to open\]](#)
- [\[Description of each area\]](#)
- [\[Function buttons\]](#)

#### [How to open]

- On the [\[Debug Tool Settings\] tab](#) of the [Property panel](#), click the [...] button displayed by selecting the [\[External Flash Memory Setting\]](#) property in the [\[External Flash Memory Download\]](#) category.

#### [Description of each area]

##### (1) [External Flash Setting list] area

###### (a) List display

This area displays a list of the registered external flash memory information files in the format "*Start address*, *Data width*, *Number of parallel*, *Number of serial*" that is being set for them.

Files are downloaded in the order that they are displayed here.

To add a new external flash memory information file, click the [Add] button in this area, then in the [\[External Flash Setting property\]](#) area, specify the download conditions for the file to be added.

**(b) Button**

Button	Function
Up	Moves the selected file up one row in the list. Clicking this for the top file in the list has no effect.
Down	Moves the selected file down one row in the list. Clicking this for the bottom file in the list has no effect.
Add	Adds an empty item "-" to the list, and selects it. Specify the download conditions of the file to add in the [External Flash Setting property] area. Note that this button will be disabled if 10 files have already been registered.
Remove	Removes the selected file from the list.

- Remarks 1.** By hovering the mouse cursor over a file, the pass information of the file is pop-up displayed.
- 2.** By dragging a file with the mouse, the display order in the list can be changed.

**(2) [External Flash Setting property] area****(a) [External Flash Memory Download]**

This area displays download conditions (i.e. settings for the external flash memory) or changes of settings made for a file selected in the [External Flash Setting list] area.

Also, if a new external flash memory information file is added using the [Add] button, this area may be used to specify download conditions for the file added.

File name	Specify the name of the external flash memory information file.	
	Default	Blank
	Modifying	Directly enter from the keyboard, or specify with the <a href="#">Select Flash Memory Information File dialog box</a> opened by clicking the [...] button <sup>Note</sup> appears at right by selecting this item.
Start address	Specify the start address of the external flash memory.	
	Default	Blank
	Modifying	Directly enter from the keyboard.
	Available values	0x0 to 0xFFFFFFFF in hexadecimal number
Data width [Bits]	Specify the data width (access size) of the external flash memory.	
	Default	8
	Modifying	Select from the drop-down list.
	Available values	8, 16, 32
Number of parallel	Specify the number of external flash memories in parallel.	
	Default	1
	Modifying	Select from the drop-down list or directly enter from the keyboard.
	Available values	<ul style="list-style-type: none"> <li>- Either one of the following from the drop-down list 1, 2, 4</li> <li>- Directly enter the numbers ranged below Integer number between 1 and 99</li> </ul>

Number of serial	Specify the number of external flash memories in serial.	
	Default	1
	Modifying	Select from the drop-down list or directly enter from the keyboard.
	Available values	<ul style="list-style-type: none"><li>- Either one of the following from the drop-down list<ul style="list-style-type: none"><li>1, 2</li></ul></li><li>- Directly enter the numbers ranged below<ul style="list-style-type: none"><li>Integer number between 1 and 99</li></ul></li></ul>

**Note** The [...] button does not appear while executing a program.

#### [Function buttons]

Button	Function
OK	Finishes configuring the external flash memory information files, and closes this dialog box.
Cancel	Cancels any changes to the download files, and closes this dialog box.
Help	Displays the help for this dialog box.

### Flash Options Setting dialog box [V850E2]

This dialog box is used to configure options for the flash memory incorporated in the V850E2 microcontroller. This dialog box appears only when connected to the debug tool.

**Caution** CPU reset may be generated automatically depending on the selected microcontroller when you click the [Write] button after changing the configuration of this dialog box.

Figure A-55. Flash Options Setting Dialog Box [IECUBE2]




Figure A-56. Flash Options Setting Dialog Box [MINICUBE][MINICUBE2][E1]E20]





Figure A-57. Flash Options Setting Dialog Box [Simulator]



This section describes the following.

- [How to open]
- [Description of each area]
- [Function buttons]

#### [How to open]

- On the [Flash Options Settings] tab [V850E2] tab of the **Property panel**, click the [...] button displayed by selecting the [Flash options] property in the [Flash Options] category.

**[Description of each area]****(1) [Flash option property] area**

**Caution** The items displayed in this area differ depending on the type of the selected microcontroller.

**(a) [Option Bytes Setting]**

You can configure the option bytes for the flash memory.

OPBT0 - 8	Specify the option bytes.	
	Default	<i>The value before shipment of the microcontroller</i>
	Modifying	Directly enter from the keyboard.
	Available values	0x0 to 0xFFFFFFFF in hexadecimal number

**Caution** Bit 31/30 of OPBT0 is fixed to 0 or 1 depending on the debug tool used.

Debug Tool	Bit 31	Bit 30
IECUBE2	-	-
MINICUBE E1/E20(JTAG)	1 <sup>Note</sup>	-
MINICUBE2 E1/E20(Serial)	0	1
E1/E20(LPD)	-	-

**Note** Use a flash programmer if you wish to write "0" to it.

**(b) [On-chip Debug Security ID Setting] [MINICUBE][MINICUBE2][E1]E20]**

Specify the on-chip debug security ID.

For details on the on-chip debug security ID, see User's Manual of the debug tool used.

Security ID	Specify the on-chip debug security ID.	
	Default	FFFFFFFFFFFFFFFFFFFF
	Modifying	Directly enter from the keyboard.
	Available values	24 digits hexadecimal number (12 bytes)

**Cautions 1. Bit 95 is fixed to "1".**

**Use a flash programmer if you wish to write "0" to it.**

**2. A clicking of the [Read] button will have no effect to this item.**

**(c) [Emulation Setting] [IECUBE2]**

Specify whether to use the security emulation function.

Use security flag emulation	Specify whether to use the security emulation function.	
	Default	Yes
	Modifying	Select from the drop-down list.
	Available values	Yes
		Uses the security flag emulation function.
	No	Does not use the security flag emulation function.

**(d) [Security Setting] [IECUBE2]**

You can configure the security emulation function.

Note that this category appears only when the [[Use security flag emulation](#)] property is set to [Yes].

**Caution** If the [Write] button is clicked after setting this category's property to [Yes], then it cannot be returned to [No]. If you want to return it to [No], select the [[Flash ROM erase when writing](#)] check box, and then click the [Write] button.

Disable read	Specify whether to emulate to disable reading.	
	Default	No
	Modifying	Select from the drop-down list.
	Available values	Yes
		Emulates to disable reading.
	No	Does not emulate to disable reading.
Disable program	Specify whether to emulate to disable writing.	
	Default	No
	Modifying	Select from the drop-down list.
	Available values	Yes
		Emulates to disable writing.
No	Does not emulate to disable writing.	
Disable flash ROM erase	Specify whether to emulate to disable flash ROM erase.	
	Note that this property appears only when the selected microcontroller supports this function.	
	Default	No
	Modifying	Select from the drop-down list.
	Available values	Yes
Emulates to disable flash ROM erase.		
No	Does not emulate to disable flash ROM erase.	
Disable block erase	Specify whether to emulate to disable block erase.	
	Default	No
	Modifying	Select from the drop-down list.
	Available values	Yes
		Emulates to disable block erase.
No	Does not emulate to disable block erase.	

Disable program boot block	Specify whether to emulate to disable rewrite boot area.	
	Default	No
	Modifying	Select from the drop-down list.
	Available values	Yes Emulates to disable rewrite boot area <sup>Note</sup> . No Does not emulate to disable rewrite boot area.

**Note** If this property is set to [Yes], the [[Boot block last number](#)] property should be outside the range of the [[Start block number](#)] and [[End block number](#)] properties in the [[Flash Shield Window Function Setting](#)] category.

#### (e) [[Boot Block Cluster Setting](#)] [[IECUBE2](#)]

You can configure the boot swap function.

Note that this category appears only when the [[Use security flag emulation](#)] property is set to [Yes].

Boot block last number	Specify the last block number of the boot area.	
	Default	0
	Modifying	Directly enter from the keyboard. Note that changes can be made only when the [ <a href="#">Disable program boot block</a> ] property is set to [No].
	Available values	hexadecimal number

#### (f) [[Flash Shield Window Function Setting](#)] (except [[Simulator](#)])

You can configure the flash shield window function.

Start block number	Specify the number of the first block of the flash shield window.	
	Default	0
	Modifying	Directly enter from the keyboard.
	Available values	0x0 to 0x7FF in hexadecimal number
End block number	Specify the number of the last block of the flash shield window.	
	Default	<i>The number of the last block of the selected microcontroller</i>
	Modifying	Directly enter from the keyboard.
	Available values	0x0 to 0x7FF in hexadecimal number

#### (2) [[Flash ROM erase when writing](#)]

<input checked="" type="checkbox"/>	Executes the flash ROM erase when clicking the [ <a href="#">Write</a> ] button.
<input type="checkbox"/>	Does not execute the flash ROM erase when clicking the [ <a href="#">Write</a> ] button (default).


**[Function buttons]**

Button	Function
Read	Reads the values currently specified in the debug tool, and reflects them in this dialog box.
Write	Writes the currently set values in this dialog box to the debug tool, and reflects them in the <a href="#">Property panel</a> and the project. Then, closes this dialog box. Note at this time that CPU reset may be generated automatically depending on the selected microcontroller.
Close	Specifies the currently set values in this dialog box to the project and closes this dialog box.
Cancel	Closes this dialog box without setting.
Help	Displays the help for this dialog box.

### Text Edit dialog box

This dialog box is used to input/modify character strings.

**Figure A-58. Text Edit Dialog Box**



This section describes the following.

- [How to open]
- [Description of each area]
- [Function buttons]

#### [How to open]

- On the [\[Hook Transaction Settings\] tab](#) of the [Property panel](#), click the [...] button displayed by selecting one of the property in the [Hook Transaction Settings] category.

#### [Description of each area]

##### (1) [Text] area

Input/modify character strings in this area.

#### [Function buttons]

Button	Function
OK	Sets the input character strings to the caller panel/dialog box and closes this dialog box.
Cancel	Closes this dialog box.
Help	Displays the help for this dialog box.


### Action Events dialog box

This tab is used to configure action events (see "2.14 Set an Action into Programs").

This dialog box appears only when connected to the debug tool.

**Caution** Also see "2.15.6 Notes for setting events" for details on Printf events (e.g. limits on the number of enabled events).

Figure A-59. Action Events Dialog Box



This section describes the following.

- [\[How to open\]](#)
- [\[Description of each area\]](#)
- [\[Function buttons\]](#)

#### [How to open]

- On the [Editor panel](#), move the caret to the line where you wish to set an action event, then select [\[Register Action Event...\]](#) from the context menu.
- On the [Disassemble panel](#), move the caret to the address where you wish to set an action event, then select [\[Register Action Event...\]](#) from the context menu.
- On the [Events panel](#), select an action event, then select [\[Edit Condition...\]](#) from the context menu.

**[Description of each area]****(1) Tab selection area**

Select a tab to switch the type of an action event to be set.

This dialog box has the following two tabs.

- [\[Printf event\] tab](#)

**Caution** If this dialog box is opened by selecting [Edit Condition...] from the context menu, this area does not appear.

**(2) Event condition setting area**

Use this area to configure detailed condition of an action event.

For details on how to setup an action event, see the section explaining the corresponding tab.

**[Function buttons]**

Button	Function
OK	Finishes configuring the action event, and sets it at the position specified in this dialog box.
Cancel	Cancels the action event settings and closes this dialog box.
Help	Displays the help for this dialog box.


### [Printf event] tab

Use this tab to configure Printf events as action events (see "2.14 Set an Action into Programs").

A Printf event momentarily stops the execution of the program at a specified location, and executes the printf command via software processing. When a Printf event is set, the program momentarily stops immediately before executing the command at the location where this event is set, and the value of the variable expression specified in this dialog box is output to the [Output panel](#).

This dialog box appears only when connected to the debug tool.

**Figure A-60. Action Events Dialog Box: [Printf event] Tab**



This section describes the following.

- [\[How to open\]](#)
- [\[Description of each area\]](#)
- [\[Function buttons\]](#)

#### [How to open]

- On the [Editor panel](#), move the caret to the line where you wish to set a Printf event, then select [Register Action Event...] from the context menu.
- On the [Disassemble panel](#), move the caret to the address where you wish to set a Printf event, then select [Register Action Event...] from the context menu.
- On the [Events panel](#), select a Printf event, then select [Edit Condition...] from the context menu.

**[Description of each area]****(1) [Output string] area**

Type in the string to add to the [Output panel](#) directly via the keyboard (up to 1024 characters).

Note that the output string can only be one line (spaces allowed).

**(2) [Variable expression] area**

Specify the variable expression(s) for the Printf event.

Type a variable expression directly into the text box (up to 1024 characters).

You can specify up to 10 variable expressions for a single Printf event by separating them with commas (",").

If this dialog box opens with a variable expression selected in the [Editor panel /Disassemble panel](#), the selected variable expression appears as the default.

The basic input format that can be specified as variable expressions and the values output by Printf event are as follows:

**Table A-22. Relationship between Variable Expressions and Output Value (Printf Event)**

Variable Expression	Output Value
Variable name of C language	Value of C language variable
<i>Variable expression</i> [ <i>Variable expression</i> ]	Element of array
<i>Variable expression</i> .Member name	Member of structure/union
<i>Variable expression</i> -> Member name	Member of structure/union that pointer designates
* <i>Variable expression</i>	Value of pointer variable
CPU register name	Value of the CPU register
I/O register name	I/O register value
Label name, EQU symbol name and immediate address	Values of label, EQU symbol and immediate address
Bit symbol	Bit symbol value

**Caution** A variable expression including an arithmetic expression (e.g. "+"/"-") cannot be specified.

**Remark** A symbol name at the current caret position can be complemented by pressing the [Ctrl] + [Space] key in this text box (see "2.18.2 Symbol name completion function").

**(3) [Address] area**

Specify the address at which to set the Printf event.

You can either type an address expression directly into the text box (up to 1024 characters), or select them from the input history via the drop-down list (up to 10 items). The address of the location currently being specified is displayed by default.

**Remark** A symbol name at the current caret position can be complemented by pressing the [Ctrl] + [Space] key in this text box (see "2.18.2 Symbol name completion function").

Note that the output result format by the Printf event in the [Output panel](#) are as follows:

**Figure A-61. Output Result Format of Printf Event**

<i>Specified-characters</i>	<i>Variable-expression-1 = Value-1, Variable-expression-2 = Value-2, ...</i>
-----------------------------	--

<i>Specified characters</i>	Characters specified with [Output string]
<i>Variable expression 1 - 10</i>	Characters specified with [Variable expression]
<i>Value 1 - 10</i>	<p>Value of variable corresponds to " <i>Variable expression 1 - 10</i> ".</p> <p>The value is displayed in the default notation (see "<a href="#">Table A-17. Display Format of Watch-Expressions (Default)</a>") according to the type of the variable (note, however, that "?" will be displayed if the specified variable expression cannot be obtained). Moreover, the value in hexadecimal number enclosing with "()" is also displayed (note, however, that "-" will be displayed if the value cannot be displayed in that notation).</p>


**[Function buttons]**

Button	Function
OK	Finishes configuring the Printf event, and sets it at the caret position in the <a href="#">Editor panel</a> / <a href="#">Disassemble panel</a> .
Cancel	Cancels the Printf event settings and closes this dialog box.
Help	Displays the help for this dialog box.

### Encoding dialog box

This dialog box is used to select a file-encoding.

**Figure A-62. Encoding Dialog Box**



This section describes the following.

- [\[How to open\]](#)
- [\[Description of each area\]](#)
- [\[Function buttons\]](#)

#### [How to open]

- From the [File] menu, open the [Open File dialog box](#) by selecting [Open with Encoding...], and then click the [Open] button in the dialog box.

#### [Description of each area]

##### (1) [Available encodings]

Select the encoding to be set from the drop-down list.

The encoding of the selected file is selected by default.

#### [Function buttons]


Button	Function
OK	Opens the selected file in the <a href="#">Open File dialog box</a> using a selected file encoding.
Cancel	Not open the selected file in the <a href="#">Open File dialog box</a> and closes this dialog box.
Help	Displays the help for this dialog box.

### Save Settings dialog box

This dialog box is used to specify the encoding and the new line code of the file being edited in the [Editor panel](#).

**Remark** The target file name is displayed on the title bar.

**Figure A-63. Save Settings Dialog Box**



This section describes the following.

- [\[How to open\]](#)
- [\[Description of each area\]](#)
- [\[Function buttons\]](#)

#### [How to open]

- With the [Editor panel](#) in focus, select [*File name* Save Settings...] from the [File] menu.

#### [Description of each area]

##### (1) [Encode] area

Select the encoding to be set from the drop-down list.

The items of the drop-down list are displayed according to the following sequence.

Note that the same encoding and encoding which are not supported by the current OS will not be displayed.

- *Current encoding of the file* (default)
- *Default encoding of the current OS*
- *Most recently used encodings* (maximum 4)
- *Popular encodings for current locale*  
(e.g. for United States locale it will be:
  - Western European (Windows)
  - Unicode (UTF-8)
- *All other encodings supported by the OS* (*in alphabetical order*)

**(2) [New line code] area**

Specify the new line code to be set from the drop-down list.

Either of the following can be selected.

- Windows (CR LF)
- Macintosh (CR)
- Unix (LF)

An active newline entry is selected by default.

**(3) [Reload the file with these settings]**

<input checked="" type="checkbox"/>	Reloads the file with the specified encoding and new line code when the [OK] button is clicked.
<input type="checkbox"/>	Does not reload the file when the [OK] button is clicked (default).


**[Function buttons]**

Button	Function
OK	Sets the selected encoding and newline code to the target file and closes this dialog box. If [Reload the file with these settings] is selected, sets the selected encoding and newline code to the target file and reloads the file. And then closes this dialog box.
Cancel	Cancels the setting and closes this dialog box.
Help	Displays the help for this dialog box.

### Bookmarks dialog box

This dialog box is used to display the position where a bookmark is to be set or to delete a bookmark.

**Figure A-64. Bookmarks Dialog Box**



The following items are explained here.

- [\[How to open\]](#)
- [\[Description of each area\]](#)
- [\[Function buttons\]](#)

#### [How to open]

- From the [Edit] menu, select [Bookmark] >> [List Bookmarks...].

#### [Description of each area]

##### (1) Bookmark list area

Display a list of bookmarks that have been registered.

The bookmarks are listed alphabetically by file name for [Bookmark]. Bookmarks in the same file are listed in line number order.

When a bookmark is added to the [Editor panel](#), a bookmark function is added.

In the bookmark list area, double-clicking on a line moves a caret to the corresponding position for the bookmark.

###### (a) [File]

Display a file name (without any path) registered as a bookmark.

###### (b) [Line Number]

Display a line number registered as a bookmark.

###### (c) [Path]

Display a file path registered as a bookmark.

**Caution** If the [Editor panel](#) is closed, bookmarks registered on the [Editor panel](#) will be removed.


### [Function buttons]

Button	Function
View	Moves a caret to the selected position for the bookmark. However, this button is disabled when no bookmark is selected, two or more bookmarks are selected, or no bookmark is registered.
Remove	Removes a selected bookmark. When two or more bookmarks are selected, all of those selected are removed. However, this button is disabled when no bookmark is selected or no bookmark is registered.
Remove All	Removes all the registered bookmarks. This button is disabled when no bookmark is registered.
Next	Moves a caret to the position of the bookmark next to the selected bookmark. This button is disabled in the following cases. <ul style="list-style-type: none"> <li>- A bookmark shown in the last line has been selected.</li> <li>- No bookmark is selected.</li> <li>- Two or more bookmarks are selected.</li> <li>- No bookmark is registered.</li> <li>- Only one bookmark is registered.</li> </ul>
Previous	Moves a caret to the position of the bookmark previous to the selected bookmark. This button is disabled in the following cases. <ul style="list-style-type: none"> <li>- A bookmark shown in the first line has been selected.</li> <li>- No bookmark is selected.</li> <li>- Two or more bookmarks are selected.</li> <li>- No bookmark is registered.</li> <li>- Only one bookmark is registered.</li> </ul>
Help	Displays the help for this dialog box.
Close	Closes this dialog box.

### Column Number Settings dialog box

This dialog box is used to set the number of view columns of memory values on the [Memory panel](#).

**Figure A-65. Column Number Settings Dialog Box**



This section describes the following.

- [\[How to open\]](#)
- [\[Description of each area\]](#)
- [\[Function buttons\]](#)

#### [How to open]

- On the [Memory panel](#), select [View] >> [Column Number Settings...] from the context menu.

#### [Description of each area]

##### (1) [Column Number] area

Directly enter a decimal value as the number of columns you want to display.

The settable range depends on [Size Notation] currently being set on the [Memory panel](#), as follows:

Size Notation	Settable Range
4 Bits	2 - 512 <sup>Note</sup>
1 Byte	1 - 256
2 Bytes	1 - 128
4 Bytes	1 - 64
8 Bytes	1 - 32

**Note** Only an even number is specifiable (if an odd number is specified, then it will be changed to a value one greater than such odd number).

#### [Function buttons]

Button	Function
OK	Displays memory values in the specified number of columns.
Cancel	Cancels the settings and closes this dialog box.
Help	Displays the help for this dialog box.

### Address Offset Settings dialog box

This dialog box is used to set an offset value of the start address in the address area on the [Memory panel](#).

**Figure A-66. Address Offset Settings Dialog Box**



This section describes the following.

- [\[How to open\]](#)
- [\[Description of each area\]](#)
- [\[Function buttons\]](#)

#### [How to open]

- On the [Memory panel](#), select [View] > [Address Offset Value Settings...] from the context menu.

#### [Description of each area]

##### (1) [Address Offset Value] area

Directly enter a hexadecimal value as an offset value for the address display.

The settable range depends on the number of bytes of the memory currently being displayed in a line on the [Memory panel](#), as follows:

- Settable range:  $0x0 - ("Set value of [Size Notation]" \times "The number of view columns") - 1$

**Example** When "Set value of [Size Notation]" is 1 byte and "The number of view columns" is 16 columns:

Offset Value	Displayed Content of Address Area
0x0 (default)	0000 0010 0020
0x1	0001 0011 0021
0x2	0002 0012 0022

#### [Function buttons]

Button	Function
OK	Displays memory addresses with the specified offset value.
Cancel	Cancels the settings and closes this dialog box.


Button	Function
Help	Displays the help for this dialog box.

### Memory Initialize dialog box

This dialog box is used to initialize memory (see "(6) Modify the memory contents in batch (initialize)"). The memory area in the specified address range is repeatedly overwritten with the specified initial data pattern.

**Caution Initialization of memory cannot be performed for values of the ID tag for the data flash memory.**

Figure A-67. Memory Initialize Dialog Box



This section describes the following.

- [How to open]
- [Description of each area]
- [Function buttons]

#### [How to open]

- On the [Memory panel](#), select [Fill...] from the context menu.

#### [Description of each area]

##### (1) Range specification area

Specify the range of memory address to initialize via the [Start address/symbol] and [End address/symbol]. You can either type address expressions directly into the text boxes (up to 1024 characters), or select them from the input history via the drop-down list (up to 10 items).

The results of calculating the address expressions you have entered are treated as start and end addresses, respectively.

Note that address values greater than the microcontroller address space cannot be specified.

**Caution You cannot specify the range of address aligned across the different endian area.**

**Remark** A symbol name at the current caret position can be complemented by pressing the [Ctrl] + [Space] key in each text box (see "2.18.2 Symbol name completion function").

##### (2) [Initialize data] area

Specify the initial value(s) with which to overwrite the memory.

You can either type the initial value into the text box directly in hexadecimal number (the value need not start with "0x"), or select one from the input history via the drop-down list (up to 10 items).

You can specify more than one initial value. Specify up to 16 values of up to 4 bytes (8 characters) each, separated by spaces.

Each initial value is parsed from the end of the string, with each two characters interpreted as a byte.

If the string has an odd number of characters, then the first character is interpreted as one byte.

Note that if a initial value consists of more than one byte, then the target memory is overwritten with the value converted into an array of bytes of the specified address range's endian, as follows.

Input Character Strings (Initial Value)	How Data is Overwritten (in Bytes)	
	Little Endian	Big Endian
1	01	01
0 12	00 12	00 12
00 012 345	00 12 00 45 03	00 00 12 03 45
000 12 000345	00 00 12 45 03 00	00 00 12 00 03 45

#### [Function buttons]

Button	Function
OK	The memory area in the specified address range is repeatedly overwritten with the specified initial data pattern. If the end address is reached in the middle of the pattern, then writing ends at that point.
Cancel	Cancels the memory initialization and closes this dialog box.
Help	Displays the help for this dialog box.

### Memory Search dialog box

This dialog box is used to search memory (see "(5) Search the memory contents").

Search in either the [Memory value area](#) or [Character strings area](#) where the caret was located in the [Memory panel](#) immediately before this dialog box opened.

**Caution** **Search cannot be performed in the program space (the mirror area and ID tag for the data flash memory, etc. cannot be searched).**

Figure A-68. Memory Search Dialog Box



This section describes the following.

- [\[How to open\]](#)
- [\[Description of each area\]](#)
- [\[Function buttons\]](#)

#### [How to open]

- On the [Memory panel](#), select [Find...] from the context menu.

#### [Description of each area]

##### (1) [Search Data] area

Specify data to search.

You can either type a value directly into the text box (up to 256 bytes), or select one from the input history via the drop-down list (up to 10 items).

If the search is performed in the [Memory value area](#) of the [Memory panel](#), the value must be entered in the same display format (notation and size) as that area.

If the search is performed in the [Character strings area](#), then the target of the search must be a string. The specified string is converted into the encoding format displayed in that area, and searched for.

If a memory value was selected immediately prior to opening this dialog box, then that value will appear as default.

##### (2) [Search Range] area

Select the range to search from the following drop-down list.

Specify address range	Searches in the address range specified in the [Address] area.
Memory mapping	Searches within the selected memory mapping range. This list item displays the memory mappings set in the <a href="#">Memory Mapping dialog box</a> (except the non-mapped area). Display format: <memory type> <address range> <size>

**(3) [Address] area**

This item is only enabled if [Specify address range] is selected in the [\[Search Range\] area](#).

Specify the range of memory address to search via the start and end addresses. You can either type address expressions directly into the text boxes (up to 1024 characters), or select them from the input history via the drop-down list (up to 10 items).

The results of calculating the address expressions you have entered are treated as start and end addresses, respectively.

Note, however, that the largest address that can be searched is the maximum address of the program space (0x03FFFFFF) (the mirror area cannot be searched).

In addition, an address value greater than the value expressed within 32 bits cannot be specified.

- Remarks 1.** A symbol name at the current caret position can be complemented by pressing the [Ctrl] + [Space] key in each text box (see "[2.18.2 Symbol name completion function](#)").
2. If the start address field is left blank, it is treated as if "0x0" were specified.
  3. If the end address field is left blank, then it is treated as if the maximum value in the microcontroller's address space were specified.


**[Function buttons]**

Button	Function
Search Backward	<p>Searches upward within the range specified in the <a href="#">[Address] area</a> or the <a href="#">[Search Range] area</a>. The location found by the search is selected in the <a href="#">Memory panel</a>.</p> <p>Note that if an illegal value is specified or while the program is being executed, a message will appear, and the memory search will not be performed.</p> <p>If focus moves to this dialog box while the memory panel is hidden or another panel has focus, then this button will be disabled.</p>
Search Forward	<p>Searches downward within the range specified in the <a href="#">[Address] area</a> or the <a href="#">[Search Range] area</a>. The location found by the search is selected in the <a href="#">Memory panel</a>.</p> <p>Note that if an illegal value is specified or while the program is being executed, a message will appear, and the memory search will not be performed.</p> <p>If focus moves to this dialog box while the memory panel is hidden or another panel has focus, then this button will be disabled.</p>
Cancel	Cancels the memory search and closes this dialog box.
Help	Displays the help for this dialog box.

### Print Address Range Settings dialog box

This dialog box is used to specify the address range to print the contents of the [Disassemble panel](#).

**Figure A-69. Print Address Range Settings Dialog Box**



This section describes the following.

- [\[How to open\]](#)
- [\[Description of each area\]](#)
- [\[Function buttons\]](#)

#### [How to open]

- On the [Disassemble panel](#), select [Print...] from the [File] menu.

#### [Description of each area]

##### (1) Range specification area

Select a range to print from the following option buttons.

###### (a) [Current display area] (default)

Prints only the contents of the [Disassemble panel](#) currently being displayed.

###### (b) [Current selected area]

Prints only the range currently being selected in the [Disassemble panel](#).

Note, however, that this option button will be disabled when nothing is selected in the Disassemble panel.

###### (c) [Range of specified]

Specify the range of address to print via [Start address] and [End address]. You can either type address expressions directly into the text boxes (up to 1024 characters), or select them from the input history via the drop-down list (up to 10 items).

**Remark** A symbol name at the current caret position can be complemented by pressing the [Ctrl] + [Space] key in each text box (see "2.18.2 Symbol name completion function").

**[Function buttons]**


Button	Function
OK	Closes this dialog box and opens the Windows dialog box to print the contents of the specified range of the <a href="#">Disassemble panel</a> .
Cancel	Cancels the range specification and closes this dialog box.
Help	Displays the help for this dialog box.

### Print Preview window

This window is used to preview the file currently being displayed in the [Editor panel](#) before printing.

**Remark** This window can be zoomed in and out by moving the mouse wheel forward or backward while holding down the [Ctrl] key.

**Figure A-70. Print Preview Window**



The following items are explained here.

- [\[How to open\]](#)
- [\[Description of each area\]](#)
- [\[Toolbar\]](#)
- [\[Context menu\]](#)

#### [How to open]

- Focus the [Editor panel](#), and then select [Print Preview] from the [File] menu.

#### [Description of each area]

##### (1) Preview area

This window displays a form showing a preview of how and what is printed.

The file name (fully qualified path) and the page number are displayed at the page header and page footer.

The display differs according to whether the debug tool is or is not connected, and when it is connected, to whether the display is in normal display mode or mixed display mode. Note, however, that columns that are hidden on the [Editor panel](#) are not displayed (these columns are not printed).

When the outline setting is in used and the collapsed section mark of an outline (see "(a) [Code outlining](#)") is displayed in a print preview, the lines in the collapsed section are also displayed.

**[Toolbar]**

	Opens the Print dialog box provided by Windows to print the current <a href="#">Editor panel</a> as shown by the print preview form.
	Copies the selection into the clipboard.
	Increases the size of the content.
	Decreases the size of the content.
	Displays the preview at 100-percent zoom (default).
	Fits the preview to the width of this window.
	Displays the whole page.
	Displays facing pages.

**[Context menu]**


Increase Zoom	Increases the size of the content.
Decrease Zoom	Decreases the size of the content.

### Trace Search dialog box [IECUBE][IECUBE2][Simulator]

This dialog box is used to search trace data (see "2.11.8 Search the trace data").

The search can be performed at the instruction or source level.

**Figure A-71. Trace Search Dialog Box**



This section describes the following.

- [\[How to open\]](#)
- [\[Description of each area\]](#)
- [\[Function buttons\]](#)

#### [How to open]

- On the [Trace panel \[IECUBE\]\[IECUBE2\]\[Simulator\]](#), select  button on the toolbar.
- On the [Trace panel \[IECUBE\]\[IECUBE2\]\[Simulator\]](#), select [Find...] from the context menu.

#### [Description of each area]

##### (1) Tab selection area

Select a tab to switch the level of the search.

This dialog box has the following two tabs.

- [\[Instruction Level\] tab](#)
- [\[Source Level\] tab](#)

**(2) Search parameter setup area**

Use this area to configure detailed search parameters.

For details on the window elements and how to configure the parameters for a particular tab, see the section for the tab in question.

**[Function buttons]**


Button	Function
Search Backward	<p>Searches upward (in the direction of larger to smaller numbers) within the specified range. Search matches are selected in the Trace panel [<b>I</b>ECUBE]<b>[I</b>ECUBE2]<b>[S</b>imulator].</p> <p>Note that if an illegal value is specified or while the program is being executed, a message will appear, and the trace data search will not be performed.</p> <p>If focus moves to this dialog box while the Trace panel is hidden or another panel has focus, then this button will be disabled.</p>
Search Forward	<p>Searches forward (in the direction of smaller to larger numbers) within the specified range. Search matches are selected in the Trace panel [<b>I</b>ECUBE]<b>[I</b>ECUBE2]<b>[S</b>imulator].</p> <p>Note that if an illegal value is specified or while the program is being executed, a message will appear, and the trace data search will not be performed.</p> <p>If focus moves to this dialog box while the Trace panel is hidden or another panel has focus, then this button will be disabled.</p>
Cancel	Cancels the trace data search and closes this dialog box.
Help	Displays the help for this dialog box.

### [Instruction Level] tab

Use this tab to search the acquired trace data at the instruction level.

**Caution** If the [Trace panel \[IECUBE\]\[IECUBE2\]\[Simulator\]](#) is set to [Source display mode](#), then performing an instruction level search via this tab will not perform the target search correctly. In order to perform an instruction level search, set the mode to [Mixed display mode](#) or [Disassemble display mode](#).

Figure A-72. Trace Search Dialog Box: [Instruction Level] Tab



This section describes the following.

- [\[How to open\]](#)
- [\[Description of each area\]](#)
- [\[Function buttons\]](#)

#### [How to open]

- On the [Trace panel \[IECUBE\]\[IECUBE2\]\[Simulator\]](#), select  button on the toolbar.
- On the [Trace panel \[IECUBE\]\[IECUBE2\]\[Simulator\]](#), select [\[Find...\]](#) from the context menu.

**[Description of each area]****(1) [Search condition] area****(a) [Fetch Address]**

Specify the fetch address if it is a required search parameter.

You can either type address expressions directly into the text boxes, or select them from the input history via the drop-down lists (up to 10 items).

The fetch address can also be specified as a range. In this case, specify a range by specifying address expressions in both the left and right text boxes.

If the right-hand text box is blank or contains the text [(Input value when range is specified)], then the fixed address specified in the left-hand text box will be searched.

Note that if an address value greater than the microcontroller address space is specified, the upper address value is masked.

In addition, an address value greater than the value expressed within 32 bits cannot be specified.

**(b) [Mnemonic]**

Specify the mnemonic if it is a required search parameter.

The specified character strings in this area are searched within the [\[Source/Disassemble\]](#) area of the Trace panel [[IECUBE](#)][[IECUBE2](#)][[Simulator](#)].

You can either type a mnemonic directly into the text boxes, or select one from the input history via the drop-down list (up to 10 items).

Searches are case-insensitive, and partial matches are also allowed.

**(c) [Access Address]**

Specify the access address if it is a required search parameter.

You can either type address expressions directly into the text boxes, or select them from the input history via the drop-down lists (up to 10 items).

The access address can also be specified as a range. In this case, specify a range by specifying address expressions in both the left and right text boxes.

If the right-hand text box is blank or contains the text [(Input value when range is specified)], then the fixed address specified in the left-hand text box will be searched.

Note that if an address value greater than the microcontroller address space is specified, the upper address value is masked.

In addition, an address value greater than the value expressed within 32 bits cannot be specified.

**(d) [Access Status]**

This item is only enabled if a value for [\[Access Address\]](#) is specified.

Select the access type from the following drop-down list.

Select [No Specification] if you do not wish to limit access types.

(No Specification)
Read/Write
Read
Write
Vector Read
DMA

**(e) [Data]**

This item is only enabled if a value for [\[Access Address\]](#) is specified.

Specify the access data.

You can either type the data directly into the text boxes (in hexadecimal number), or select it from the input history via the drop-down list (up to 10 items).

The data can also be specified as a range. In this case, specify a range by specifying data in both the left and right text boxes.

If the right-hand text box is blank or contains the text [(Input value when range is specified)], then the fixed data specified in the left-hand text box will be searched.

**(2) [Search range] area****(a) [Number]**

Specify the range within the trace data to search via the number displayed in the [\[Number\] area](#) of the [Trace panel](#) [[IECUBE](#)][[IECUBE2](#)][[Simulator](#)].

Specify the starting number in the left text box, and the ending number in the right text box ("0" to "last number" are specified by default).

You can either type the numbers directly into the text boxes (in base-10 format), or select them from the input history via the drop-down lists (up to 10 items).

If the left-hand text box is left blank, it is treated as if "0" were specified.

If the right-hand text box is left blank, it is treated as if the last number were specified.

**[Function buttons]**


Button	Function
Search Backward	<p>Searches upward (in the direction of larger to smaller numbers) within the specified range.            Search matches are selected in the <a href="#">Trace panel</a> [<a href="#">IECUBE</a>][<a href="#">IECUBE2</a>][<a href="#">Simulator</a>].            Note that if an illegal value is specified, a message will appear, and the trace data search will not be performed.            If focus moves to this dialog box while the Trace panel is hidden or another panel has focus, then this button will be disabled.</p>
Search Forward	<p>Searches forward (in the direction of smaller to larger numbers) within the specified range.            Search matches are selected in the <a href="#">Trace panel</a> [<a href="#">IECUBE</a>][<a href="#">IECUBE2</a>][<a href="#">Simulator</a>].            Note that if an illegal value is specified, a message will appear, and the trace data search will not be performed.            If focus moves to this dialog box while the Trace panel is hidden or another panel has focus, then this button will be disabled.</p>
Cancel	Cancels the trace data search and closes this dialog box.
Help	Displays the help for this dialog box.

### [Source Level] tab

Use this tab to search the acquired trace data at the source level.

**Caution** If the Trace panel [IECUBE][IECUBE2][Simulator] is set to **Disassemble display mode**, then performing an source level search via this tab will not perform the target search correctly. In order to perform an source level search, set the mode to **Mixed display mode** or **Source display mode**.

Figure A-73. Trace Search Dialog Box: [Source Level] Tab



This section describes the following.

- [\[How to open\]](#)
- [\[Description of each area\]](#)
- [\[Function buttons\]](#)

#### [How to open]

- On the Trace panel [IECUBE][IECUBE2][Simulator], select  button on the toolbar.
- On the Trace panel [IECUBE][IECUBE2][Simulator], select [Find...] from the context menu.

**[Description of each area]****(1) [Search object] area**

Select the search object from the following option buttons.

The execution part is retrieved specifying the source line	Finds the execution location in the specified source line (default). Only <a href="#">[Source and Line]</a> will be enabled as a search parameter.
The execution part is retrieved specifying the function	Finds the execution location in the specified function. Only <a href="#">[Function Name]</a> will be enabled as a search parameter.
The execution part is retrieved specifying the global variable	Finds the location at which the specified global variable was accessed. Only <a href="#">[Variable Name]</a> , <a href="#">[Kind]</a> and <a href="#">[Value]</a> will be enabled as a search parameters.

**(2) [Search condition] area****(a) [Source and Line]**

This item is only enabled if [\[The execution part is retrieved specifying the source line\]](#) is selected.

The specified character strings in this area are searched within the [\[Line/Address\] area](#) of the [Trace panel](#) [\[IECUBE\]\[IECUBE2\]\[Simulator\]](#).

You can either type the character strings of the source line to be find directly into the text box, or select them from the input history via the drop-down list (up to 10 items).

Searches are case-insensitive, and only complete matches are retrieved.

- Examples 1.**
- 1. main.c#40
  - 2. main.c
  - 3. main

**(b) [Function Name]**

This item is only enabled if [\[The execution part is retrieved specifying the function\]](#) is selected.

You can either type the function name to be find directly into the text box, or select it from the input history via the drop-down list (up to 10 items).

Searches are case-insensitive, and only complete matches are retrieved.

**(c) [Variable Name]**

This item is only enabled if [\[The execution part is retrieved specifying the global variable\]](#) is selected.

You can either type the variable name to be find directly into the text box, or select it from the input history via the drop-down list (up to 10 items).

Searches are case-insensitive, and only complete matches are retrieved.

**(d) [Kind]**

This item is only enabled if [\[The execution part is retrieved specifying the global variable\]](#) is selected.

Select the access type ([Reference/Substitution], [Reference], or [Substitution]) from the drop-down list.

**(e) [Value]**

This item is only enabled if [\[The execution part is retrieved specifying the global variable\]](#) is selected.

Specify the accessed variable value in hexadecimal number.

You can either type a variable value directly into the text box, or select one from the input history via the drop-down list (up to 10 items).

The variable value can also be specified as a range. In this case, specify a range by specifying variable values in both the left and right text boxes.

If the right-hand text box is blank, then access locations with the fixed variable values specified in the left-hand text box will be searched for.

### (3) [Search range] area

#### (a) [Number]

Specify the range within the trace data to search via the number displayed in the [Number] area of the Trace panel [**I**ECUBE][**I**ECUBE2][Simulator].

Specify the starting number in the left text box, and the ending number in the right text box ("0" to "last number" are specified by default).

You can either type the numbers directly into the text boxes (in base-10 format), or select them from the input history via the drop-down lists (up to 10 items).

If the left-hand text box is left blank, it is treated as if "0" were specified.

If the right-hand text box is left blank, it is treated as if the last number were specified.

#### [Function buttons]

Button	Function
Search Backward	<p>Searches upward (in the direction of larger to smaller numbers) within the specified range.            Search matches are selected in the Trace panel [<b>I</b>ECUBE][<b>I</b>ECUBE2][Simulator].</p> <p>Note that if an illegal value is specified, a message will appear, and the trace data search will not be performed.</p> <p>If focus moves to this dialog box while the Trace panel is hidden or another panel has focus, then this button will be disabled.</p>
Search Forward	<p>Searches forward (in the direction of smaller to larger numbers) within the specified range.            Search matches are selected in the Trace panel [<b>I</b>ECUBE][<b>I</b>ECUBE2][Simulator].</p> <p>Note that if an illegal value is specified, a message will appear, and the trace data search will not be performed.</p> <p>If focus moves to this dialog box while the Trace panel is hidden or another panel has focus, then this button will be disabled.</p>
Cancel	Cancels the trace data search and closes this dialog box.
Help	Displays the help for this dialog box.

### Scroll Range Settings dialog box


This dialog box is used to set the scroll range of the vertical scroll bar on the [Memory panel/Disassemble panel](#).

By setting the appropriate range, it is possible to improve the operability of a mouse (e.g. dragging) because the size of the vertical scroll bar on the panel is changed suitably.

**Caution** After setting a scroll range via this dialog box, the scroll range is not updated automatically even if the address evaluated by the address expression is changed because of such as a line assembly.

**Remark** It is possible to move outside the scroll range by using the [Page Up]/[Page Down]/[Up]/[Down] key, a button at either end of the scroll bar or a menu item related to the jump function.

Figure A-74. Scroll Range Setting Dialog Box



This section describes the following.

- [\[How to open\]](#)
- [\[Description of each area\]](#)
- [\[Function buttons\]](#)

#### [How to open]

- On the [Memory panel](#), click the  button from [View] on the toolbar.
- On the [Memory panel](#), select the [View] menu >> [Settings Scroll Range...] from the context menu.
- On the [Disassemble panel](#), click the  button from [View] on the toolbar.
- On the [Disassemble panel](#), select the [View] menu >> [Settings Scroll Range...] from the context menu.

#### [Description of each area]

##### (1) [Start address] area

Specify the start address of the range of scrolling.

You can either type an address expression directly into the text box (up to 1024 characters), or select it from the input history via the drop-down list (up to 10 items).

Note that the setting of the scroll range is not performed if "All" is selected in the drop-down list at this time (the scroll range is not limited).

**Remark** A symbol name at the current caret position can be complemented by pressing the [Ctrl] + [Space] key in this text box (see "[2.18.2 Symbol name completion function](#)").

##### (2) [End address] area

Specify the end address of the range of scrolling.

You can either type an address expression directly into the text box (up to 1024 characters), or select it from the input history via the drop-down list (up to 10 items).

Note that this area becomes invalid if [Start address] is specified with [All].

**Remark** A symbol name at the current caret position can be complemented by pressing the [Ctrl] + [Space] key in this text box (see "[2.18.2 Symbol name completion function](#)").


#### [Function buttons]

Button	Function
OK	Sets the specified scroll range for the target panel. Moves the caret to the start address, from the beginning of the area displayed in the target panel.
Cancel	Cancels the jump and closes this dialog box.
Help	Displays the help for this dialog box.

### Go to Line dialog box

This dialog box is used to move the caret to a specified source line.

**Figure A-75. Go to Line Dialog Box**



This section describes the following.

- [How to open]
- [Description of each area]
- [Function buttons]

#### [How to open]

- From the [Edit] menu, select [Go to...].
- On the [Editor panel](#), select [Go to...] from the context menu.

#### [Description of each area]

##### (1) [Line number (*valid line range*)] area

"(*valid line range*)" shows the range of valid lines in the current file.

Directly enter a decimal value as the number of the line you want to move the caret to.

You can also enter a symbol in this area.

By default, the number of the line where the caret is currently located in the [Editor panel](#) is displayed.


#### [Function buttons]

Button	Function
OK	Places the caret at the start of the specified source line.
Cancel	Cancels the jump and closes this dialog box.
Help	Displays the help for this dialog box.

### Go to the Location dialog box

This dialog box is used to move the caret to a specified position.

**Figure A-76. Go to the Location Dialog Box**



This section describes the following.

- [\[How to open\]](#)
- [\[Description of each area\]](#)
- [\[Function buttons\]](#)

#### [How to open]

- From the [Edit] menu, select [Go to...].
- On the [Disassemble panel](#), select [Go to...] from the context menu.
- On the [IOR panel](#), select [Go to...] from the context menu.

#### [Description of each area]

##### (1) [Address/Symbol], or [IOR] area

Specify the location to which the caret jumps.

You can either type a location directly into the text box (up to 1024 characters), or select one from the input history via the drop-down list (up to 10 items).

The data to specify varies depending on the target panel, as follows:

Target Panel	Data Specified
Disassemble panel	Address expression
IOR panel	I/O register name

**Remark** If this dialog box is opened from the [Disassemble panel](#), a symbol name at the current caret position can be complemented by pressing the [Ctrl] + [Space] key in this text box (see "[2.18.2 Symbol name completion function](#)").

#### [Function buttons]


Button	Function
OK	Moves the caret to the specified location, from the beginning of the area displayed in the target panel.
Cancel	Cancels the jump and closes this dialog box.
Help	Displays the help for this dialog box.

### Data Save dialog box

This dialog box is used to save data displayed in the [Disassemble panel](#), [Memory panel](#), or [Trace panel](#) [[IECUBE](#)][[IECUBE2](#)][[Simulator](#)], and save uploaded data (see "[2.5.3 Execute uploading](#)").

This dialog box appears only when connected to the debug tool.

**Figure A-77. Data Save Dialog Box**



This section describes the following.

- [\[How to open\]](#)
- [\[Description of each area\]](#)
- [\[Function buttons\]](#)

#### [How to open]

- With the [Disassemble panel](#) in focus, select [Save Disassemble Data As...] from the [File] menu.
- With the [Memory panel](#) in focus, select [Save Memory Data As...] from the [File] menu.
- With the [Trace panel](#) [[IECUBE](#)][[IECUBE2](#)][[Simulator](#)] in focus, select [Save Trace Data As...] from the [File] menu.
- From the [Debug] menu, select [Upload...].

#### [Description of each area]

##### (1) [File Name] area

Specify the name of the file to save.

You can either type a filename directly into the text box (up to 259 characters), or select one from the input history via the drop-down list (up to 10 items).

You can also specify the file by clicking the [...] button, and selecting a file via the [Select Data Save File dialog box](#).

##### (2) [File Type] area

Select the format in which to save the file from the following drop-down list.

The available file formats will differ as follows depending on the type of data being saved.

##### (a) Saving the data displayed in a panel

Text files (*.txt)	Text format (default)
CSV (Comma-Separated Variables) (*.csv)	CSV format <sup>Note</sup>

**Note** The data is saved with entries separated by commas (,).

If the data contains commas, each entry is surrounded by double quotes ("") in order to avoid illegal formatting.

#### (b) Saving upload data

See "[Table 2-5. Type of Files That Can be Uploaded](#)".

#### (3) [Save Range xxx] area

Specify the range of data to save.

You can either type ranges directly into the text boxes, or select them from the input history via the drop-down lists (up to 10 items).

The method of specifying the ranges will differ as follows depending on the type of data to be saved.

Type of Data	Description
Disassemble panel	Specify the range of addresses to save via the start and end addresses. Ranges can be entered as base-16 numbers or as address expressions. When a range is selected in the panel, that range is specified by default. When there is no selection, then the range currently visible in the panel is specified.
Memory panel	Specify the range of memory to save via the start and end addresses. Ranges can be entered as base-16 numbers or as address expressions. When a range is selected in the panel, that range is specified by default. When there is no selection, then the range currently visible in the panel is specified.
Trace panel [IECUBE][IECUBE2][Simulator]	- Specifying a range to save Specify the trace range to save via the start and end trace numbers <sup>Note</sup> . Ranges can only be entered as base-10 numbers. - Saving all trace data From the drop-down list to the left, select [All Trace Data]. The text box to the right is disabled. All currently acquired trace data will be saved. The range currently visible in the panel is specified by default.
Upload data	Specify the range of memory to save via the start and end addresses. Ranges can be entered as base-16 numbers or as address expressions.

**Note** These are the numbers shown in the [\[Number\]](#) area of the Trace panel.

**Remark** A symbol name at the current caret position can be complemented by pressing the [Ctrl] + [Space] key in each text box (see "[2.18.2 Symbol name completion function](#)").

#### [Function buttons]


Button	Function
Save	Saves the data to a file with the specified filename, in the specified format.
Cancel	Cancels the save and closes this dialog box.
Help	Displays the help for this dialog box.

### Progress Status dialog box

This dialog box is used to display the progress of long processes.

This dialog box closes automatically when the currently executing process completes.

Figure A-78. Progress Status Dialog Box



This section describes the following.

- [\[How to open\]](#)
- [\[Description of each area\]](#)
- [\[Function buttons\]](#)

#### [How to open]

- This dialog box appears automatically when a message is displayed during a long process.

#### [Description of each area]

##### (1) Message display area

Displays messages during processing (cannot be edited).

##### (2) Progress bar

The amount of progress made toward completing the current progress is indicated by the length of the bar.

The dialog box will automatically close when the progress reaches 100% (the length of the bar reaches the right end).

#### [Function buttons]


Button	Function
Cancel	Cancels the currently executing process, and closes this dialog box. Note that this button will be disabled if the currently executing process cannot be interrupted.

### Option dialog box

This dialog box is used to configure the CubeSuite+ environment.

All settings made via this dialog box are saved as preferences for the current user.

**Figure A-79. Option Dialog Box**



This section describes the following.

- [\[How to open\]](#)
- [\[Description of each area\]](#)
- [\[Function buttons\]](#)

#### [How to open]

- From the [Tool] menu, select [Options...].

#### [Description of each area]

##### (1) Category selection area

Select the items to configure from the following categories.

Category	Description
[General - Startup and Exit] category	Configure startup and shutdown.
[General - Display] category	Configure messages from the application.
[General - External Text Editor] category	Configure the external text editor.
[General - Font and Color] category	Configure the fonts and colors shown on each panel.
[General - External Tools] category	Configure the startup of external tools.
[General - Build/Debug] category	Configure building and debugging.
[General - PythonConsole] category	Configure the python console.
[General - Text Editor] category	Configure the text editor.

Category	Description
[General - Update] category	Configure updating.
[Others - User Information] category	Configure user information.

**Remark** See "CubeSuite+ Integrated Development Environment User's Manual: Start" for details on the categories other than [General - Font and color]/[General - Build/Debug].

## (2) Setting area

This area is used to configure the various options for the selected category.

For details about configuration for a particular category, see the section for the category in question.


### [Function buttons]

Button	Function
Initialize All Settings	Restores all settings on this dialog box to their default values. Note, however, that newly added items in the [General - External Tools] category will not be removed.
OK	Applies all setting and closes this dialog box.
Cancel	Ignores the setting and closes this dialog box.
Apply	Applies all setting (does not close this dialog box).
Help	Displays the help for this dialog box.

### [General - Font and Color] category

Use this category to configure general settings relating to fonts and colors on each panel.

**Figure A-80. Option Dialog Box ([General - Font and Color] Category)**



The following items are explained here.

- [How to open]
- [Description of each area]
- [Function buttons]

#### [How to open]

- From the [Tool] menu, select [Options...].

#### [Description of each area]

##### (1) Color options area

Use this area to configure the colors.

###### (a) [Setting place] area

Select a location from the list for which the color will be specified.

The relationships between the list items and default color settings are as follows:

Item	Example			Description
Default <sup>Note</sup>	<b>AaBbCc</b>	Font color	Black	Standard display colors on all windows and panels
		Background color	White	
Warning	<b>AaBbCc</b>	Font color	Blue	Display colors of warning messages on the <a href="#">Output panel</a> , as well as display colors for file names with "warnings included" on the <a href="#">Project Tree panel</a>
		Background color	Default color	

Item	Example			Description
Error		Font color	Red	Display colors of warning messages on the <a href="#">Output panel</a> , as well as display colors for file names with "errors included" on the <a href="#">Project Tree panel</a>
		Background color	Whitesmoke	
Reserved word		Font color	Maroon	Display colors of reserved words on the <a href="#">Editor panel</a> for compilers/assemblers used
		Background color	Default color	
Comment		Font color	Green	Display colors of comment parts (for C source files, /* to */ ) on the <a href="#">Editor panel</a>
		Background color	Default color	
String literal		Font color	Gray	Display colors of string literals on the <a href="#">Editor panel</a>
		Background color	Default color	
Control code		Font color	Darkcyan	Display colors of control characters on the <a href="#">Output panel</a>
		Background color	Default color	
Highlight		Font color	White	Display colors of highlighted spots in plug-in products, etc.
		Background color	Mediumvioletred	
Changed value		Font color	Sienna	Display colors on the <a href="#">Memory panel</a> , <a href="#">CPU Register panel</a> , <a href="#">Local Variables panel</a> , <a href="#">IOR panel</a> and <a href="#">Watch panel</a> of spots whose values have been changed by program execution
		Background color	Lightyellow	
Edit value		Font color	Blue	Display colors on the <a href="#">Memory panel</a> , <a href="#">CPU Register panel</a> , <a href="#">Local Variables panel</a> , <a href="#">IOR panel</a> and <a href="#">Watch panel</a> of spots whose values have been forcibly changed by user
		Background color	Default color	
Current PC		Font color	Black	Display colors on the <a href="#">Editor panel</a> and <a href="#">Disassemble panel</a> of a line where the current PC position exists
		Background color	Gold	
Breakpoint		Font color	Black	Display colors on the <a href="#">Editor panel</a> and <a href="#">Disassemble panel</a> of a line where breakpoints are set
		Background color	Lightsalmon	
Update periodic		Font color	Deeppink	Display colors on the <a href="#">Memory panel</a> and <a href="#">Watch panel</a> of areas whose display is set to be updated in real time
		Background color	Default color	
Read or fetch		Font color	Default color	Display colors on the <a href="#">Memory panel</a> and <a href="#">Trace panel</a> [ <a href="#">IECUBE</a> ][ <a href="#">IECUBE2</a> ][ <a href="#">Simulator</a> ] of spots that have been read or fetched
		Background color	Palegreen	
Write		Font color	Default color	Display colors on the <a href="#">Memory panel</a> and <a href="#">Trace panel</a> [ <a href="#">IECUBE</a> ][ <a href="#">IECUBE2</a> ][ <a href="#">Simulator</a> ] of spots that have been written
		Background color	Orange	

Item	Example			Description
Read and write		Font color	Default color	Display colors on the <a href="#">Memory panel</a> and <a href="#">Trace panel</a> [ <a href="#">IECUBE</a> ][ <a href="#">IECUBE2</a> ][ <a href="#">Simulator</a> ] of spots that have been read and written
		Background color	Paletur-quoise	
Lost		Font color	White	Display colors on the Analysis Chart panel of the analyze tool (Program Analyzer) of sections where acquisition of graph data has failed
		Background color	Lightgray	
Coverage 100%		Font color	Default color	Display colors on the <a href="#">Editor panel</a> and <a href="#">Disassemble panel</a> of lines whoes code caverage rates are 100 %
		Background color	Lightgreen	
Coverage 1 - 99%		Font color	Default color	Display colors on the <a href="#">Editor panel</a> and <a href="#">Disassemble panel</a> of lines whoes code caverage rates are 1 to 99 %
		Background color	Lightpink	
Coverage 0%		Font color	Default color	Display colors on the <a href="#">Editor panel</a> and <a href="#">Disassemble panel</a> of lines whoes code caverage rates are 0 % (unexecuted)
		Background color	Lightgray	
Invalid		Font color	Gray	Display colors on the <a href="#">Memory panel</a> of areas that are not memory-mapped, and of file names that are not actually present on the <a href="#">Project Tree panel</a>
		Background color	Default color	

**Note** The [Default] text and background colors depends on the Windows settings of the host computer. Here, we use the Windows defaults, which are black text and white background.

#### (b) [Use default color]

<input checked="" type="checkbox"/>	Display items selected via the <a href="#">[Setting place] area</a> using the standard text color.
<input type="checkbox"/>	Display items selected via the <a href="#">[Setting place] area</a> with a user-defined text color. The <a href="#">[Font color...]</a> button is enabled.

#### (c) [Use default background color]

<input checked="" type="checkbox"/>	Display items selected via the <a href="#">[Setting place] area</a> using the standard background color.
<input type="checkbox"/>	Display items selected via the <a href="#">[Setting place] area</a> with a user-defined background color. The <a href="#">[Background Color...]</a> button is enabled.

#### (d) Buttons

Font Color...	The <a href="#">Edit Colors Dialog Box</a> opens. Specify the text color of the item selected via the <a href="#">[Setting place] area</a> . Note, however, that this button will be disabled if the <a href="#">[Use default color]</a> check box is selected.
---------------	--

Background Color...	The <a href="#">Edit Colors Dialog Box</a> opens. Specify the background color of the item selected via the <a href="#">[Setting place]</a> area. Note, however, that this button will be disabled if the <a href="#">[Use default background color]</a> check box is selected.
Reset Selected Item Colors	Reset the color information for the item selected via the <a href="#">[Setting place]</a> area to the defaults.

Figure A-81. Edit Colors Dialog Box

**(2) [Display example] area**


Display sample text using the color and font settings from the [Color options area](#).

By default the string "AaBbCc" is shown, but you can type an arbitrary string directly into the text box.

**(3) [Font settings for text editor] area**

Click the [\[Font...\]](#) button to open the [Font Dialog Box](#) and configure the fonts for your text editor.

Figure A-82. Font Dialog Box



**(4) Buttons**

Import...	Opens the <a href="#">Open Option Setting File dialog box</a> to reflect the set contents that were saved in a file to this category.
Export...	Opens the <a href="#">Save Option Setting File dialog box</a> to save the set contents of this category to a file.
Initialize Settings	Returns all currently displayed setting to their default values.


**[Function buttons]**

Button	Function
Initialize All Settings	Restores all settings on this dialog box to their default values. Note, however, that newly added items in the [General - External Tools] category will not be removed.
OK	Applies all setting and closes this dialog box.
Cancel	Ignores the setting and closes this dialog box.
Apply	Applies all setting (does not close this dialog box).
Help	Displays the help for this dialog box.

### [General - Build/Debug] category

Use this category to configure general setting relating to building and debugging.

**Figure A-83. Option Dialog Box ([General - Build/Debug] Category)**



The following items are explained here.

- [How to open]
- [Description of each area]
- [Function buttons]

#### [How to open]

- From the [Tool] menu, select [Options...].

#### [Description of each area]

##### (1) [Enable Rapid Build]

<input checked="" type="checkbox"/>	Enable the rapid build <small>Note</small> feature (default).
<input type="checkbox"/>	Do not use the rapid build feature.

**Note** This feature automatically begins a build when the source file being edited is saved.

Enabling this feature makes it possible to perform builds while editing source files.

If this feature is used, we recommend saving frequently after editing source files.

## (2) [Observe registered files changing]

<input checked="" type="checkbox"/>	Start a rapid build when a source file registered in the project is edited or saved by an external text editor or the like.
<input type="checkbox"/>	Do not start a rapid build when a source file registered in the project is edited or saved by an external text editor or the like (default).

**Remark** This item is only enabled if the [Enable Rapid Build] check box is selected.

- Cautions**
1. The rapid build will not finish if this item is selected, and the files to be built have been registered for automatic editing or overwriting (e.g. by commands executed before or after the build). If the rapid build does not finish, unselect this item, and stop the rapid build.
  2. If this item is selected, a file that is registered in the project but does not exist (a file grayed out) will not be observed even if it is registered again by the Explorer, etc.  
To observe the file, reload the project file, or select this item again after unselecting this item and closing this dialog box.

## (3) [Show dependency files in project tree]

<input checked="" type="checkbox"/>	Displays the group of files on which the source file depends as a project tree.
<input type="checkbox"/>	Does not display the group of files on which the source file depends as a project tree (default).

## (4) [Output quality record file when build is successful]

<input checked="" type="checkbox"/>	Outputs a quality record file if the build is successful.
<input type="checkbox"/>	Does not output a quality record file if the build is successful (default).

- Remarks**
1. The quality report file is not output when a rapid build is executed, a debug-dedicated project is built, and compiling or assembling is executed in file units.
  2. The following information item is output to the quality report file.
    - Time and date on which the file is created
    - Log of the build results
    - Information on the command file which is used during building
    - Information on the detailed version of this product or the current project
  3. The quality report file is output with the file name "QuarityReport(project-name.build-mode-name).text" to the project folder of each project.  
If a file having the same name exists, it will be overwritten.  
It is also shown on the project tree, under the Build tool generated files node.

## (5) [Enable Break Sound]

<input checked="" type="checkbox"/>	Beeps when the execution of a program is halted due to a break event (Hardware or Software break).
<input type="checkbox"/>	Does not beep when the execution of a program is halted due to a break event (Hardware or Software break) (default).

## (6) [Observe downloaded load module files changing]

<input checked="" type="checkbox"/>	Watches changes made to the load module files downloaded to the debug tool, so that when changes are made, a message dialog box is displayed for confirmation of whether or not to execute a download.
<input type="checkbox"/>	Does not watch changes made to the load module files downloaded to the debug tool (default).

## (7) [Add source files automatically (for the "Debug Only" project only)]

<input checked="" type="checkbox"/>	Automatically adds the source files to the project tree when the load-module files are downloaded to the debug tool in the debug-dedicated project (default).
<input type="checkbox"/>	Does not automatically add the source files to the project tree when the load-module files are downloaded to the debug tool in the debug-dedicated project

**Caution** This function is valid only when the load module files have been added to the Download files node of the project tree. If the load module files have been added via the [Download File Settings] tab in the Property panel of the debug tool, then the source files will not be added to the project tree.

## (8) Buttons

Initialize Settings	Returns all currently displayed setting to their default values.
---------------------	--


## [Function buttons]

Button	Function
Initialize All Settings	Restores all settings on this dialog box to their default values. Note, however, that newly added items in the [General - External Tools] category will not be removed.
OK	Applies all setting and closes this dialog box.
Cancel	Ignores the setting and closes this dialog box.
Apply	Applies all setting (does not close this dialog box).
Help	Displays the help for this dialog box.

### Select Download File dialog box

This dialog box is used to select a downloaded file.

**Figure A-84. Select Download File Dialog Box**



This section describes the following.

- [\[How to open\]](#)
- [\[Description of each area\]](#)
- [\[Function buttons\]](#)

#### [How to open]

- On the [Download file property] area in the [Download Files dialog box](#), click the [...] button on the [File] property.

#### [Description of each area]

##### (1) [Look in] area

Select the folder which contains the file you want to download.

##### (2) List of files area

This area displays a list of files matching the conditions selected in the [Look in] and [Files of type] areas.

##### (3) [File name] area

Specify the name of a file you want to download.

**(4) [Files of type] area**

Select the type of a file to download (file type).

Load module file (*.lmf, *.out)	Load module format <sup>Note 1</sup> (default)
Hex file (*.hex)	Hex format <sup>Note 2</sup>
Binary data file (*.bin)	Binary format
All files (*.*)	All file formats

**Notes 1. [V850E2]**

Usable extension for load module files is only "\*.lmf" ("\*.out" does not shown in this item).

**2. For other than [Simulator]**

To use the format with ID tag, select [Hex file with ID Tag] in [File type] on the [Select Download File dialog box](#).


**[Function buttons]**

Button	Function
Open	Adds the specified file to the <a href="#">Download Files dialog box</a> .
Cancel	Closes the dialog box.

### Open Watch Expression Data File dialog box

This dialog box is used to select a file that imports watch-expressions to the [Watch panel](#).

**Figure A-85. Open Watch Expression Data File Dialog Box**



This section describes the following.

- [\[How to open\]](#)
- [\[Description of each area\]](#)
- [\[Function buttons\]](#)

#### [How to open]

- On the [Watch panel](#), select [Import Watch Expression...] from the context menu.

#### [Description of each area]

##### (1) [Look in] area

Select the folder which contains the file you want to import.

##### (2) List of files area

This area displays a list of files matching the conditions selected in the [Look in] and [Files of type] areas.

##### (3) [File name] area

Specify the name of a file you want to import.

##### (4) [Files of type] area

The following type of the file (file type) is shown.

Importable CSV(Comma-Separated Variables) (*.csv)	CSV format to enable import
---	-----------------------------


**[Function buttons]**

Button	Function
Open	Imports the specified file to the <a href="#">Watch panel</a> .
Cancel	Closes the dialog box.

### Select Flash Memory Information File dialog box

This dialog box is used to select the external flash memory information file (\*.fdb) for downloading to the external flash memory.

**Figure A-86. Select Flash Memory Information File Dialog Box**



This section describes the following.

- [\[How to open\]](#)
- [\[Description of each area\]](#)
- [\[Function buttons\]](#)

#### [How to open]

- On the [Exterior Flash Setting property] area in the [External Flash Memory Download dialog box](#), click the [...] button on the [File name] property.

#### [Description of each area]

##### (1) [Look in] area

Select the folder which contains the external flash memory information file.

##### (2) List of files area

This area displays a list of files matching the conditions selected in the [Look in] and [Files of type] areas.

##### (3) [File name] area

Specify the name of the external flash memory information file.

**(4) [Files of type] area**

Select the type of the external flash memory information file (file type).

File Information of the External Flash Memory (*.fdb)	External flash memory information file format
All files (*.*)	All file formats


**[Function buttons]**

Button	Function
Open	Adds the specified file to the <a href="#">External Flash Memory Download dialog box</a> .
Cancel	Closes the dialog box.

### Open File dialog box

This dialog box is used to open a file.

**Figure A-87. Open File Dialog Box**



The following items are explained here.

- [\[How to open\]](#)
- [\[Description of each area\]](#)
- [\[Function buttons\]](#)

#### [How to open]

- From the [File] menu, select [Open File...] or [Open with Encoding...].

#### [Description of each area]

##### (1) [Look in] area

Select the folder which contains the file you want to open.

When you first open this dialog box, the folder is set to "C:\Documents and Settings \user-name\My Documents".

The second and subsequent times, this defaults to the last folder that was selected.

##### (2) List of files area

This area displays a list of files matching the conditions selected in the [Look in] and [Files of type] areas.

##### (3) [File name] area

Specify the name of a file you want to open.

## (4) [Files of type] area

Select the type of the file you want to open (file type).

All files (*.*)	All formats
Project File(*.mtpj)	Project file
Project File for CubeSuite(*.cspj)	Project file for CubeSuite
Workspace File for HEW(*.hws)	Workspace file for HEW
Project File for HEW(*.hwp)	Project file for HEW
Workspace File for PM+(*.prw)	Workspace file for PM+
Project File for PM+(*.prj)	Project file for PM+
C source file (*.c)	C language source file
Header file (*.h; *.inc)	Header file
Assemble file (*.s) [CA850]	Assembler source file
Assemble file (*.asm; *.s) [CX]	Assembler source file
Link directive file (*.dir; *.dr)	Link directive file
Section file (*.sf) [CA850]	Section file
Symbol information file (*.sfg) [CX]	Symbol information file
Map file (*.map)	Map file
Hex file (.hex)	Hex file
Python script file (*.py)	Python script file
Text file (*.txt)	Text format


## [Function buttons]

Button	Function
Open	<ul style="list-style-type: none"> <li>- When this dialog box is opened by [Open File...] from the [File] menu Opens the specified file.</li> <li>- When this dialog box is opened by [Open with Encoding...] from the [File] menu Opens the <a href="#">Encoding dialog box</a>.</li> </ul>
Cancel	Closes this dialog box.

### Save As dialog box

This dialog box is used to save the contents of the panel into a specified file.

**Figure A-88. Save As Dialog Box**



This section describes the following.

- [\[How to open\]](#)
- [\[Description of each area\]](#)
- [\[Function buttons\]](#)

#### [How to open]

- With the [Editor panel](#) in focus, select [Save file name As...] from the [File] menu.
- With the [CPU Register panel](#) in focus, select [Save CPU Register Data As...] from the [File] menu.
- With the [Watch panel](#) in focus, select [Save Watch Data As...] from the [File] menu.
- With the [IOR panel](#) in focus, select [Save IOR Data As...]. from the [File] menu.
- With the [Call Stack panel](#) in focus, select [Save Call Stack Data As...] from the [File] menu.
- With the [Local Variables panel](#) in focus, select [Save Local Variable Data As...] from the [File] menu.
- With the [Output panel](#) in focus, select [Save tab name As...] from the [File] menu.

#### [Description of each area]

##### (1) [Save in] area

Select the folder in which you want to save the file, from the drop-down list.

##### (2) List of files area

This area displays a list of files matching the conditions selected in the [Save in] and [Save as type] areas.

##### (3) [File name] area

Specify a file name under which you want to save.

## (4) [Save as type] area

## (a) In the Editor panel

The following file types are displayed depending on the file being edited.

Text file (*.txt)	Text format
C source file (*.c)	C language source file
Header file (*.h;*.inc)	Header file
Assemble file (*.asm) [CX]	Assembly language source file
Assemble file (*.s)	Assembly language source file
Link directive file (*.dir;*.dr)	Link directive file
Link order specification file (*.mtls)	Link order specification file
Section file (*.sf) [CA850]	Section file
Symbol information file (*.sfg) [CX]	Symbol information file
Map file (*.map)	Map file
Hex file (*.hex)	Hex file

## (b) In the CPU Register panel/Watch panel/IOR panel/Call Stack panel/Local Variables panel

The following file types are displayed.

Select the format in which to save the file from the drop-down list.

Text file (*.txt)	Text format (default)
CSV (Comma-Separated Variables)(*.csv)	CSV format <sup>Note 1</sup>
Importable CSV (Comma-Separated Variables)(*.csv) <sup>Note 2</sup>	CSV format <sup>Note 1</sup> to enable import

**Notes 1.** The data is saved with entries separated by commas (,).

If the data contains commas, each entry is surrounded by double quotes (" ") in order to avoid illegal formatting.

**2.** This item appears only when this dialog box was opened from the [Watch panel](#).

## (c) In the Output panel

The following file types are displayed.

The contents can be saved only in text format.

Text file (*.txt)	Text format (default)
-------------------	-----------------------


## [Function buttons]

Button	Function
Save	Saves the file with the specified name.
Cancel	Closes the dialog box.

### Select Data Save File dialog box

This dialog box is used to select a file in which to save the data.

Figure A-89. Select Data Save File Dialog Box



This section describes the following.

- [\[How to open\]](#)
- [\[Description of each area\]](#)
- [\[Function buttons\]](#)

#### [How to open]

- On the [File Name] area in the [Data Save dialog box](#), click the [...] button.

#### [Description of each area]

##### (1) [Look in] area

Select the folder which contains the file you want to save.

##### (2) List of files area

This area displays a list of files matching the conditions selected in the [Look in] and [Files of type] areas.

##### (3) [File name] area

Specify the name of a file you want to save.

**(4) [Files of type] area**

Select the type of the file (file type).

The available file formats will differ as follows depending on the type of data being saved.

**(a) Saving the data displayed in a panel**

Text files (*.txt)	Text format (default)
CSV (Comma-Separated Variables)(*.csv)	CSV format <sup>Note</sup>

**Note** The data is saved with entries separated by commas (,).

If the data contains commas, each entry is surrounded by double quotes (" ") in order to avoid illegal formatting.

**(b) Saving upload data**

See "[Table 2-5. Type of Files That Can be Uploaded](#)".


**[Function buttons]**

Button	Function
Open	Specifies the specified file in the <a href="#">Data Save dialog box</a> .
Cancel	Closes the dialog box.

### Open Option Setting File dialog box

This dialog box is used to select a option setting file to import to the [General - Font and Color] category of the Option dialog box.

**Figure A-90. Open Option Setting File Dialog Box**



The following items are explained here.

- [\[How to open\]](#)
- [\[Description of each area\]](#)
- [\[Function buttons\]](#)

#### [How to open]

- On the [General - Font and Color] category of the [Option dialog box](#), click the [Import...] button.

#### [Description of each area]

##### (1) [Look in] area

Select the folder which contains the option setting file you want to open.

When you first open this dialog box, the folder is set to "C:\Documents and Settings \user-name\My Documents".

The second and subsequent times, this defaults to the last folder that was selected.

##### (2) List of files area

This area displays a list of files matching the conditions selected in the [Look in] and [Files of type] areas.

##### (3) [File name] area

Specify the name of a option setting file you want to open.

**(4) [Files of type] area**

The following type of the file (file type) is shown.

Option Setting File (*.mtpu)	Option setting file
------------------------------	---------------------


**[Function buttons]**

Button	Function
Open	Imports the specified file to the the <a href="#">[General - Font and Color] category</a> of the <a href="#">Option dialog box</a> .
Cancel	Closes this dialog box.

### Save Option Setting File dialog box

This dialog box is used to save the set contents of the [General - Font and Color] category of the Option dialog box to a option setting file.

**Figure A-91. Save Option Setting File Dialog Box**



This section describes the following.

- [\[How to open\]](#)
- [\[Description of each area\]](#)
- [\[Function buttons\]](#)

#### [How to open]

- On the [General - Font and Color] category of the Option dialog box, click the [Export...] button.

#### [Description of each area]

##### (1) [Save in] area

Select the folder in which you want to save the option setting file.

When you first open this dialog box, the folder is set to "C:\Documents and Settings \user-name\My Documents".

The second and subsequent times, this defaults to the last folder that was selected.

##### (2) List of files area

This area displays a list of files matching the conditions selected in the [Save in] and [Save as type] areas.

##### (3) [File name] area

Specify the name of a option setting file under which you want to save.

**(4) [Save as type] area**

The following type of the file (file type) is shown.

Option Setting File (*.mtpu)	Option setting file
------------------------------	---------------------


**[Function buttons]**

Button	Function
Save	Saves the option setting file with the specified name.
Cancel	Closes the dialog box.

### Select Simulator Configuration File dialog box [Simulator]

This dialog box is used to select the simulator configuration file to perform use customization (adding of user models) of the simulator.

**Figure A-92. Select Simulator Configuration File Dialog Box**



This section describes the following.

- [\[How to open\]](#)
- [\[Description of each area\]](#)
- [\[Function buttons\]](#)

#### [How to open]

- On the [\[Connect Settings\] tab](#) of the [Property panel](#), click the [...] button displayed by selecting the [Simulator configuration file] property in the [Configuration] category.

#### [Description of each area]

##### (1) [Look in] area

Select the folder which contains the simulator configuration file.

##### (2) List of files area

This area displays a list of files matching the conditions selected in the [Look in] and [Files of type] areas.

##### (3) [File name] area

Specify the name of the simulator configuration file to be used.

##### (4) [Files of type] area

Select the type of the file (file type).

Note that it is fixed to "Simulator Configuration File(\*.cfg)".

**[Function buttons]**

Button	Function
Open	Uses the specified simulator configuration file.
Cancel	Closes the dialog box.

### Simulator GUI window

This window appears automatically by default after connecting to the debug tool when a microcontroller whose Simulator supports peripheral function simulations is selected and [Simulator] is selected as the debug tool to use (see "2.17 Use the Simulator GUI [Simulator]").

In Simulator GUI, other windows (Signal Data Editor window, Timing Chart window, I/O Panel window, and Serial window) are manipulated from this window.

- Cautions**
1. When a microcontroller whose Simulator does not support peripheral function simulations (instruction simulation version) is selected, this window cannot be opened.
  2. This window and windows opened from it cannot be docked to the CubeSuite+ Main window.
  3. The help for this window will not be displayed even if the [F1] key on the keyboard is pressed when no window opened from this window is opened.  
To open the help for this window, select the [Help] menu >> [Main Window] on this window.
  4. The [x] button on this window's titlebar is invalid (it is invalid even if using the Aero function of Windows Vista). If you wish to close this window, perform the configuration of the Property panel (see "2.17 Use the Simulator GUI [Simulator]").  
In addition, do not use the [Alt] + [F4] key to close this window.

**Remark** The language of titlebar/menubar of this window and windows opened from it depends on the setting of [Regional and Language Options] in [Control Panel] of the host machine used (if this setting is set to [Japan]/[Japanese], their titlebar/menubar are displayed in Japanese).

Figure A-93. Simulator GUI Window



This section describes the following.

- [Menubar]
- [Toolbar]
- [Window display area]

**[Menubar]**

- (1) [File] menu
- (2) [Edit] menu
- (3) [View] menu
- (4) [Parts] menu
- (5) [Figure] menu
- (6) [Option] menu
- (7) [Simulator] menu
- (8) [Window] menu
- (9) [Help] menu

**(1) [File] menu**

New File...	Opens a new window for the Simulator GUI window. Same operation as the  button.
Open...	Opens the files handled in the Simulator GUI window. Same operation as the  button.
Close	Closes the window currently having the focus.
Save	Overwrites the contents of the window currently having the focus to the file handled in the Simulator GUI window. Same operation as the  button.
Save As...	Saves the contents of the window currently having the focus to the specified file.

**(2) [Edit] menu**

This menu varies depending on the window currently having the focus.

For details on this menu items, see "[Dedicated menu]" section in the [Signal Data Editor window](#), [Timing Chart window](#), [I/O Panel window](#), or [Serial window](#).

**(3) [View] menu**

This menu varies depending on the window currently having the focus.

For details on this menu items, see "[Dedicated menu]" section in the [Signal Data Editor window](#), [Timing Chart window](#), [I/O Panel window](#), or [Serial window](#).

**(4) [Parts] menu**

This menu is added when the [I/O Panel window](#) is opened.

For details on this menu items, see the [\[Parts\] menu/\[Parts\] toolbar](#).

**(5) [Figure] menu**

This menu is added when the [I/O Panel window](#) is opened.

For details on this menu items, see the [\[Figure\] menu/\[Figure\] toolbar](#).

## (6) [Option] menu

ToolBar	Switches on/off display of the toolbar corresponding to the cascade menu.
Simulator Standard	Selects whether the [Simulator Standard] toolbar is displayed or not.
Simulator Tools	Selects whether the [Simulator Tool] toolbar is displayed or not.
Signal Data Editor	Selects whether the [Signal Data Editor] toolbar is displayed or not.
Timing Chart	Selects whether the [Timing Chart] toolbar is displayed or not.
Parts	Selects whether the [Parts] toolbar is displayed or not.
Figure	Selects whether the [Figure] toolbar is displayed or not.
Customize...	Opens the <a href="#">Customize</a> dialog box.

## (7) [Simulator] menu

Signal Data Editor	Opens the <a href="#">Signal Data Editor window</a> . Same operation as the  button.
Timing Chart	Opens the <a href="#">Timing Chart window</a> . Same operation as the  button.
I/O Panel	Opens the <a href="#">I/O Panel window</a> . Same operation as the  button.
Serial	Opens the <a href="#">Serial window</a> . Same operation as the  button.

## (8) [Window] menu

Close All	Closes all windows, except this window.
Cascade	Cascade display of the windows in this window.
Tile	Cascade display of the windows in this window.
Arrange Icons	Rearranges the icons in this window.

## (9) [Help] menu

Main Window	Displays the help for this window.
Current Window	Displays the help for the current window.

**[Toolbar]**

- (1) [Simulator Standard] toolbar
- (2) [Simulator Tool] toolbar
- (3) [Signal Data Editor] toolbar
- (4) [Timing Chart] toolbar
- (5) [Parts] toolbar
- (6) [Figure] toolbar

**(1) [Simulator Standard] toolbar**

	Opens a new window for the Simulator GUI window.
	Opens the files handled in the Simulator GUI window.
	Overwrites the contents of the window currently having the focus to the file handled in the Simulator GUI window.
	Undoes the immediately preceding operation.
	Restores the status undone by the  button.
	Cuts the selected range and saves it to the clipboard.
	Copies the selected range and saves it to the clipboard.
	Pastes the clipboard contents.
	Opens the <a href="#">Search Data dialog box</a> .
	Displays the contents of the help.

**(2) [Simulator Tool] toolbar**

	Opens the <a href="#">Signal Data Editor window</a> .
	Opens the <a href="#">Timing Chart window</a> .
	Opens the <a href="#">Serial window</a> .
	Opens the <a href="#">I/O Panel window</a> .

**(3) [Signal Data Editor] toolbar**

This toolbar can be used when the [Signal Data Editor window](#) has the focus.

For details on this toolbar, see the [\[Signal Data Editor toolbar\]](#).

**(4) [Timing Chart] toolbar**

This toolbar can be used when the [Timing Chart window](#) has the focus.

For details on this toolbar, see the [\[Timing Chart toolbar\]](#).

**(5) [Parts] toolbar**

This toolbar can be used when the [I/O Panel window](#) has the focus.

For details on this toolbar, see the [\[Parts\] menu/\[Parts\] toolbar](#).

**(6) [Figure] toolbar**

This toolbar can be used when the [I/O Panel window](#) has the focus.

For details on this toolbar, see the [\[Figure\] menu/\[Figure\] toolbar](#).

**[Window display area]**

This area is used to display various windows ([Signal Data Editor window](#), [Timing Chart window](#), [I/O Panel window](#), or [Serial window](#)).

The displayed window can be changed in size or an icon can be created in this area.

**Customize dialog box**

This dialog box is used to set or change the color and fonts for the [Signal Data Editor window](#), [Timing Chart window](#) or [Serial window](#).

Figure A-94. Customize Dialog Box: [Color] Tab (For Timing Chart Window)



Figure A-95. Customize Dialog Box: [Font] Tab



This section describes the following.

- [\[How to open\]](#)
- [\[\[Color\] tab\]](#)
- [\[\[Font\] tab\]](#)
- [\[Function buttons\]](#)

**[How to open]**

- With the [Signal Data Editor window](#), [Timing Chart window](#) or [Serial window](#) in focus, select [Customize...] from the [Option] menu.

**[[Color] tab]****(1) Color setting area**

Set and change the color of each part in the window.

List	The parts for which color change is possible are displayed in list form. The parts displayed differ depending on the target window.
Color	The currently set color of the part is displayed when that part is selected from the list.
[Change...] button	The color currently set for the relevant part of each listed item can be changed.

**[[Font] tab]****(1) Font setting area**

Set and change the text font of each part in the window.

List	The parts for which font change is possible are displayed in list form.
Font	The current font name of the part is displayed, when that part is selected from the list.
Size	The current font size of the part is displayed, when that part is selected from the list.
[Change...] button	The font currently set for the relevant part of each listed item can be changed.

**[Function buttons]**

Button	Function
OK	Validates the settings and closes this dialog box.
Cancel	Cancels the settings and closes this dialog box.
Apply	Cannot be selected.
Help	Displays the help for this dialog box.

### Signal Data Editor window

This window is used to create and edit the signal data that is input to input pins.

The created signal data can be input to the input pin during simulation by selecting the [Edit] menu >> [Signal Input].

This data can also be saved to the signal data file (\*.wvi) by selecting the [File] menu >> [Save]/[Save As...] or by saving the project file.

The saved file contents can be restored by selecting the [File] menu >> [Open...] or by loading the project file.

- Cautions**
1. If the saved signal data file is opened or the project file is opened while Simulator GUI is running with a microcontroller different from the one used when the signal data file was created, the settings of pins that are not provided in the microcontroller will not be restored.
  2. The main clock and sub clock cannot be input from this window. Set the main clock/sub clock oscillation frequency on the **[Connect Settings]** tab in the **Property panel**.
  3. If inputting of signals is started during program break, the signals will actually be input when the program is resumed from the break.

**Remarks**

1. The following data can be displayed or edited in this window:
  - Newly created signal data
  - Previously created signal data files
  - File of signal data previously obtained by performing simulation and saving the results as output signal data
2. On the titlebar of this window, "Project file name + Serial number (from 0).wvi" is displayed when the project file has been loaded. However, after having loaded a project file of PM+, then if you save a file as the project file of CubeSuite+, "Project file name + CS+ Serial number (from 0).wvi" is displayed on the titlebar.

Figure A-96. Signal Data Editor Window

	Mark	Wait	P00	P01	P02	ANIO	AVREF
1	F	100	0	0	0	0	5000
2		100	0	0	1	500	5000
3		100	0	1	0	1000	5000
4		100	0	1	1	1500	5000
5		100	1	0	0	2000	5000
6		100	1	0	1	2500	5000
7		100	1	1	1	3000	5000
8		100	0	0	0	3500	5000
9		100	0	0	1	4000	5000
11		100	0	1	0	4500	5000
12		100	1	0	1	3000	5000

This section describes the following.

- [How to open]
- [Description of each area]
- [Dedicated menu (Signal Data Editor window)]
- [Signal Data Editor toolbar]
- [Context menu]
- [Operation]

### [How to open]

- Click the  button
- Select [Signal Data Editor] from the [Simulator] menu.


### [Description of each area]

#### (1) Information bar

It can be specified whether this area is displayed or not, by selecting the [View] menu >> [Information Bar].

 MainClk	Select the unit of the wait time from the drop-down list. The wait time unit can be changed by selecting the [Edit] menu >> [Time unit].
	If this button is clicked while the program is running, signal input starts. If this button is clicked while the program is stopped, signal input starts automatically the next time the program execution is started.
	If this button is clicked while the program is running, signal input is stopped. If this button is clicked while the program is stopped, signal input does not start automatically even if the program execution is started.
	The current signal input line (line highlighted with yellow) is returned to the beginning.

#### (2) Client area



Pin area	Displays the input pin names. The input pin to be used is selected via the <a href="#">Select Pin dialog box</a> opened by clicking the  button on the toolbar or selecting the [Edit] menu >> [Select Pin...]. Data input to pins can be enabled/disabled by selecting the [Edit] menu >> [Pin Status].
----------	---

Line number area	Displays line number. This area is used when performing editing in line units. Note that up to 1,048,576 (= 1M) lines can be specified as the signal data.	
Mark area	Displays the loop information for the specified input value. The loop information is specified by selecting from the context menu or the [Edit] menu >> [Mark] in the relevant field. The following marks are displayed after the loop information has been specified.	
		Loop start location (endless loop)
		Loop start location (with loop count)
		Loop end location
Wait area	Displays as "wait time" the timing at which the specified input value is input to the pins. The wait time is specified by directly writing numeric values in the relevant field. Note that numeric values (decimal code) from 0 to 4,294,967,295 can be specified (values that exceed 4,294,967,295 can be set by using one more line). The wait time unit can be changed by selecting the [Edit] menu >> [Time unit].	
Data area	Displays the input value input to the pins. The input value is specified by directly writing numeric value in the relevant field. Note that the input rules differ as follows according to the pin type.	
	Digital pins	Any one of the following one character
	0	LOW signal
	1	HIGH signal
	Z	Hi-Z signal (case insensitive)
	Analog pins	A decimal value from 0 to 5000 (unit: mV)

**[Dedicated menu (Signal Data Editor window)]****(1) [Edit] menu**

Undo	Cannot be selected.
Redo	Cannot be selected.
Cut	Cuts the selected range and saves it to the clipboard.
Copy	Copies the selected range and copies it to the clipboard.
Paste	Pastes the contents of the clipboard to the selected location.
Delete	Deletes the selected range.
Select All	Selects all display data.
Find	Cannot be selected.
Select Pin...	Opens the <a href="#">Select Pin dialog box</a> . The pin(s) for which input signal data is to be created or edited is (are) selected in this dialog box.
Time unit	Selects the wait time unit.
main clock	Main clock (default)
usec	Microsecond
msec	Millisecond

Pin Status	Selects the input status of the selected pin.
Valid	Enables data input to the pin (default).
Invalid	Disables data input to the pin.
Mark	Sets a mark to the selected <a href="#">Mark area</a> .
Loop Start	Sets the loop start mark.
Loop End	Sets the loop end mark.
Loop Dialog	Opens the <a href="#">Loop dialog box</a> . Sets the details of loop information.
Signal Input	Inputs signal data to the simulator.
Start	Starts signal input.
Stop	Stops signal input.
Reset	Returns the current signal input line to the beginning.

## (2) [View] menu

Information Bar	Selects whether the information bar is displayed or not.
-----------------	--

## (3) [Option] menu

Customize...	Opens the <a href="#">Customize dialog box</a> .
--------------	--

## [Signal Data Editor toolbar]

	Opens the <a href="#">Select Pin dialog box</a> . The pin(s) for which input signal data is to be created or edited is (are) selected in this dialog box.
	If this button is clicked while the program is running, signal input starts. If this button is clicked while the program is stopped, signal input starts automatically the next time the program execution is started.
	If this button is clicked while the program is running, signal input is stopped. If this button is clicked while the program is stopped, signal input does not start automatically even if the program execution is started.
	The current signal input line (line highlighted with yellow) is returned to the beginning.

## [Context menu]

The following context menus are available at each area in the [Client area](#).

## (1) Pin area

Valid	Enables data input to the pin (default).
Invalid	Disables data input to the pin.
Select Pin...	Opens the <a href="#">Select Pin dialog box</a> . The pin(s) for which input signal data is to be created or edited is (are) selected in this dialog box.

**(2) Line number**

Cut	Cuts the selected range and saves it to the clipboard.
Copy	Copies the selected range and copies it to the clipboard.
Paste	Pastes the contents of the clipboard to the selected location.
Delete	Deletes the selected range.

**(3) Mark area**

Cut	Cuts the selected cell and saves it to the clipboard.
Copy	Copies the selected cell and copies it to the clipboard.
Paste	Pastes the contents of the clipboard to the selected location.
Delete	Deletes the selected cell.
Loop Start	Sets the loop start mark.
Loop End	Sets the loop end mark.
Loop Dialog	Opens the <a href="#">Loop dialog box</a> . Sets the details of loop information.

**(4) Wait area**

Cut	Cuts the data in the selected cell and saves it to the clipboard. The data in the selected cell becomes 0.
Copy	Copies the data in the selected cell and copies it to the clipboard.
Paste	Pastes the contents of the clipboard to the selected location.
Delete	Deletes the data in the selected cell. The data in the selected cell becomes 0.

**(5) Data area**

Cut	Cuts the data in the selected cell and saves it to the clipboard. The data in the selected cell becomes "Z" (Hi-Z).
Copy	Copies the data in the selected cell and copies it to the clipboard.
Paste	Pastes the contents of the clipboard to the selected location.
Delete	Deletes the data in the selected cell. The data in the selected cell becomes "Z" (Hi-Z).
Start Signal Input	Starts signal input.
Stop Signal Input	Stops signal input.
Reset Signal Input	Returns the current signal input line to the beginning.

**[Operation]**

- (1) Pin selection
- (2) Creating signal data
- (3) Data copy and paste
- (4) Single-line editing
- (5) Signal input
- (6) Operation at CPU reset

**(1) Pin selection**

To create the signal data, it is first necessary to select the pin to be used.

Open the [Select Pin dialog box](#) by clicking the  button on the toolbar or selecting the [Edit] menu >> [Select Pin...], and select the pin to be used. Once a pin is selected, its name is displayed in [Pin area](#).

**(2) Creating signal data**

Create the signal data input to each pin.

**(a) Setting of input value**

In the Data area, specify the value that is input to each pin (see "[Data area](#)").

**(b) Setting of input timing**

In the Wait area, specify the timing at which the input value is input to each pin as "wait time" (see "[Wait area](#)").

**(c) Setting of the loop information**

When loop processing for the signal data specified in step (a) and (b) is needed, specify the loop information.

To specify the loop information, select [Loop Start] from the context menu on the loop start position in the Mark area, and select [Loop End] on the loop stop position.

At this time, the loop count can be specified. In this case, specify the loop count via the [Loop dialog box](#) opened by selecting [Loop Dialog...] from the context menu.

The corresponding loop information marks are displayed if the setting of the loop information is completed (see "[Mark area](#)").

**(3) Data copy and paste**

The setting values in [Mark area](#)/[Wait area](#)/[Data area](#) can be copied and pasted.

However, copied data can be pasted only in the same area.

Copy	When one or more (a range of) cells are selected, these cells can be copied by selecting the [Edit] menu >> [Copy] (or pressing the [Ctrl] + [C] key).
Paste	When one or more (a range of) cells are selected, these cells can be pasted by selecting the [Edit] menu >> [Paste] (or pressing the [Ctrl] + [V] key). When multiple (a range of) cells are selected, the copied data is pasted to the cells repeatedly.

**(4) Single-line editing**

Single lines can be edited by selecting [Line number area](#).

The method is the same as that described in "[\(3\) Data copy and paste](#)".

Data pasted during line paste (insertion) is inserted immediately before the selected line.

**(5) Signal input**

Input the created signal data to the input pins of the simulator while simulation is executed.

At this time, the line whose signal is currently being input (current line) is highlighted in yellow during program breaks (this can be changed via [Inputted current line] item in the [Customize dialog box](#)), in order to display signal input progress.

There are the following types of signal data input operations:

Signal input start	Click the  button, or select the [Edit] menu >> [Signal Input] >> [Start]. As a result, signal input starts from the current signal input line (highlighted line).
Signal input stop	Click the  button, or select the [Edit] menu >> [Signal Input] >> [Stop]. This stops signal input.

Signal reset	Click the  button, or select the [Edit] menu >> [Signal Input] >> [Reset]. This returns the current signal input line to the beginning. If signal reset was performed during signal input, input continues from the beginning.
--------------	--

**Remark** The signal data input to the selected pin can be controlled by selecting the [Edit] menu >> [Pin Status] >> [Valid]/[Invalid].

#### (6) Operation at CPU reset


When CPU reset occurs, the current signal input line returns to the beginning.

If a CPU reset occurs during signal input, input continues from the beginning (same operation as the  button).

### Loop dialog box

This dialog box is used to perform detailed settings (loop start/stop and loop count) related to the loop information in the [Signal Data Editor window](#).

**Figure A-97. Loop Dialog Box**



This section describes the following.

- [\[How to open\]](#)
- [\[Description of each area\]](#)
- [\[Function buttons\]](#)

#### [How to open]

On the [Signal Data Editor window](#), any one of the following:

- Double-click the Mark area.
- Select the Mark area, then select [Mark] >> [Loop Dialog...] from the [Edit] menu.

#### [Description of each area]

##### (1) Loop information setting area

Start of Loop	Select this check box to set the Start of Loop.	
	Endless loop    Select this option button to set the Endless Loop.	
	Loop count    Select this option button to set the Loop Count. Sets the count value by spin button.	
	0	Skip loop
	1 to 99	Perform loop the specified count.
End of Loop	Select this check box to set the End of Loop.	


#### [Function buttons]

Button	Function
OK	Validates the settings and closes this dialog box.
Cancel	Cancels the settings and closes this dialog box.

### Select Pin dialog box

This dialog box is used when selecting pins displayed in the [Signal Data Editor window](#) and the [Timing Chart window](#). The pin information set in this dialog box can be saved as a pin information file (\*.pin) by clicking the [Save] button. Moreover, the saved file contents can be restored by clicking the [Load] button.

**Figure A-98. Select Pin Dialog Box**



This section describes the following.

- [\[How to open\]](#)
- [\[Description of each area\]](#)
- [\[Function buttons\]](#)

#### [How to open]

On the [Signal Data Editor window](#)/[Timing Chart window](#), any one of the following:

- Click the  button.
- Select [Select Pin...] from the [Edit] menu.

#### [Description of each area]

##### (1) Connection pins setting area

Up to 256 pins can be selected by using the scrollbar located on the right side of the pin name setting area.

Pin Name	This area is used to specify the pin name to be connected. The connection pins can be specified either via direct input or through selection from the drop-down list.
Analog	Select this check box to use the specified pin as an analog pin.
Function Name	This area is used to set a function name for the pin name. When a character string is input in this area, this character string is displayed as a function name in the pin name part. If nothing is specified, the pin name is displayed.

**Remark** For the pin names that can be specified, see the user's manual of the microcontroller that is used.

**[Function buttons]**

Button	Function
OK	Validates the settings and closes this dialog box. The pin name (or display name) is applied in the Pin field of the window from where this dialog box was called up.
Save	Saves the display contents to the pin information file (*.pin).
Load	Loads the pin setting information of the specified file (*.pin).
Clear	Deletes the settings.
Cancel	Cancels the settings and closes this dialog box.

### Timing Chart window

This window is used to display the output signals and input signals for pins in the form of a timing chart.


This window allows time measurement in main clock units.

The browsed signal data can be saved to the timing chart file (\*.wvo) by selecting the [File] menu >> [Save]/[Save As...]. Moreover, the saved file contents can be restored by selecting [File] menu >> [Open...].

If the project file is saved, signal data is not saved but information of the set pins is saved. (Solely saving the project file is sufficient if saving of the measurement result is unnecessary.)

- Cautions 1.**
1. If the saved timing chart file is opened or the project file is opened while Simulator GUI is running with a microcontroller different from the one used when the timing chart file was created, the settings of pins that are not provided in the microcontroller will not be restored.
  2. The main clock and sub clock waveforms cannot be displayed in this window. In addition, when using the external bus interface function, the waveforms of pins used for the external bus interface function cannot be displayed.

Figure A-99. Timing Chart Window



This section describes the following.

- [\[How to open\]](#)
- [\[Description of each area\]](#)
- [\[Dedicated menu \(Timing Chart window\)\]](#)
- [\[Timing Chart toolbar\]](#)
- [\[Context menu\]](#)
- [\[Operation\]](#)

#### [How to open]

- Click the  button.
- Select [Timing Chart] from the [Simulator] menu.

**[Description of each area]**


**(1) Information bar**

It can be specified whether this area is displayed or not, by selecting the [View] menu >> [Information Bar].

5553364.00	Clock/time count from simulation start until marker A location.
5554860.00	Clock/time count from simulation start until marker B location.
1496.00	Clock/time count between markers A and B. (Displayed as absolute value.)
Unit MainClk	Select from the drop-down list the time unit for the location information of markers A and B. This item can also be set by using [Time unit] in the [Edit] menu or [Time unit] from the context menu.
x1/2	Selects the waveform data display magnification ratio from the drop-down list. If a part of waveform data may be lost as a result of changing the display magnification ratio, the confirmation dialog box is displayed.

- Remarks 1.** Up to 4,294,967,262 clocks can be counted from the simulation start up to the marker position. When the count reaches the maximum value, the counter is cleared to 0 and starts counting again.
- 2.** The menu for setting the magnify ratio appears dimmed during program execution, so changing the ratio is unavailable.

**(2) Client area**



Pin Name area	Displays the names of the pins for which timing chart display is performed. Pin selection is performed by selecting the [Edit] menu >> [Select Pin...] to open the <a href="#">Select Pin dialog box</a> .
Marker area	Displays the 2 marker headers. These markers can be moved by dragging them with the mouse over this area.
	Marker A
	Marker B

Waveform area	Performs timing chart display for the data of the pins specified in the Pin area. The following color distinctions are used according to the signal by default.	
	Green	The HIGH and LOW signals of the pins
	Red	High-impedance signals
	Blue	Unsampled signals

- Remarks 1.** When the buffer is full, the data will be overwritten by the latest data starting from the oldest data because the buffer storing the pin data is in a ring buffer format.  
The upper limit of the buffer size is one of the following.
- The number of pin change points: 4,096
  - The number of clocks: 2,147,483,631
  - Horizontal draw width: 134,217,711 pixels
2. The colors and fonts can be changed via the [Customize dialog box](#) opened by selecting the [Option] menu >> [Customize...].

#### [Dedicated menu (Timing Chart window)]

##### (1) [Edit] menu

Clear	Deletes all the waveform data.
Find...	Opens the <a href="#">Search Data dialog box</a> . Waveform data search is performed in this dialog box.
Search backward	Searches for the change point of the selected pin in the backward direction (toward the left).
Search forward	Searches for the change point of the selected pin in the forward direction (toward the right).
Select Pin...	Opens the <a href="#">Select Pin dialog box</a> . The pin for which the waveform data is to be displayed is selected in this dialog box.
Time unit	Selects the time unit.
main clock	Main clock (default)
usec	Microsecond
msec	Millisecond

##### (2) [View] menu

Waveform	Switches on/off display of the Maker area and Waveform area.
Information Bar	Switches on/off display of the information bar.

Zoom	Selects the waveform data display magnification ratio from a cascade menu. If a part of waveform data may be lost as a result of changing the display magnification ratio, the confirmation dialog box is displayed.
x 1/32	Sets the magnification ratio to 1/32.
x 1/16	Sets the magnification ratio to 1/16.
x 1/8	Sets the magnification ratio to 1/8.
x 1/4	Sets the magnification ratio to 1/4.
x 1/2	Sets the magnification ratio to 1/2.
x 1	Sets the magnification ratio to 1.
x 2	Sets the magnification ratio to 2.
x 4	Sets the magnification ratio to 4.
x 8	Sets the magnification ratio to 8.
x 16	Sets the magnification ratio to 16.
x 32	Sets the magnification ratio to 32.

**(3) [Option] menu**

Customize...	Opens the <a href="#">Customize dialog box</a> .
--------------	--

**[Timing Chart toolbar]**

	Deletes all the waveform data.
	Searches for the change point of the selected pin in the backward direction (toward the left).
	Searches for the change point of the selected pin in the forward direction (toward the right).
	Opens the <a href="#">Select Pin dialog box</a> . The pin for which the waveform data is to be displayed is selected in this dialog box.
	Selects the waveform data display magnification ratio from the drop-down list. If a part of waveform data may be lost as a result of changing the display magnification ratio, the confirmation dialog box is displayed.

**[Context menu]**

The following context menus are available in the [Client area](#).

Clear	Deletes all the waveform data.
Find...	Opens the <a href="#">Search Data dialog box</a> . Waveform data search is performed in this dialog box.
Search backward	Searches for the change point of the selected pin in the backward direction (toward the left).
Search forward	Searches for the change point of the selected pin in the forward direction (toward the right).
Select Pin...	Opens the <a href="#">Select Pin dialog box</a> . The pin for which the waveform data is to be displayed is selected in this dialog box.
Waveform	Switches on/off display of the Maker area and Waveform area.
Time unit	Selects the time unit.

Zoom	Selects the waveform data display magnification ratio. If a part of waveform data may be lost as a result of changing the display magnification ratio, the confirmation dialog box is displayed.
Move MarkerA	Moves marker A to the cursor location. The same action can be accomplished by pressing the [Shift] key + left-clicking.
Move MarkerB	Moves marker B to the cursor location. The same action can be accomplished by pressing the [Ctrl] key + left-clicking.

**[Operation]**

- (1) Pin selection
- (2) Display of timing chart
- (3) Clearing of timing chart
- (4) Timing measurement for timing chart
- (5) Data search function
- (6) Operation at reset

**(1) Pin selection**

To display the timing chart, it is first necessary to select the pin to be displayed.

Open the [Select Pin dialog box](#) by selecting the [Edit] menu >> [Select Pin...] and select the pin to be edited. Once a pin is selected, its name is displayed in the [Pin Name area](#).

**(2) Display of timing chart**

The waveforms of the selected pins are displayed in timing chart form through execution of the program.

**Remark** The simulation speed can be increased by hiding the timing chart.

To hide the timing chart, select the [View] menu >> [Waveform] (deselect this item).

When the timing chart is hidden, the Maker area and Waveform area appear dimmed and "Display OFF" is displayed in the center.

**(3) Clearing of timing chart**

Timing chart display is cleared by selecting the [Edit] menu >> [Clear].

**(4) Timing measurement for timing chart**


The timing between two points can be measured by marking 2 locations using markers A and B.

The time of each marker and the time between markers are displayed in the information bar.

Each marker can be placed at the target position by dragging the marker head. Moreover, it can also be placed at the position of the current mouse cursor by selecting [Move MarkerA]/[Move MarkerB] from the context menu.

The marker that is clicked last becomes the selected marker and can be subjected to the [Data search function](#).

**Figure A-100. Marker A And Marker B**

**(5) Data search function**

There are two data search functions for timing charts.

**(a) Simple search**

Simple search is a function used to search change points for one pin.

Select the name of the pin for which the search is to be performed in the Pin area and then select the [Edit] menu >> [Search backward] or [Search forward].

As a result, the selected marker moves to the data position at which the change point was detected.

**(b) Detailed search**

In the case of detailed search, search using a combination of data of multiple pins can be executed.

The search data is set in the [Search Data dialog box](#) displayed by selecting the [Edit] menu >> [Find...].

The selected marker moves to the data position that was hit, similarly to simple search results.

**(6) Operation at reset**

If CPU reset or Simulator GUI reset occurs, the displayed waveforms of the timing chart are all cleared.

### Search Data dialog box

This dialog box is used to search the signal data displayed in the [Timing Chart window](#) in detail.

- Cautions 1.** **Analog I/O signals cannot be searched.**
2. **This dialog box cannot be opened during program execution.**

**Figure A-101. Search Data Dialog Box**



This section describes the following.

- [\[How to open\]](#)
- [\[Description of each area\]](#)
- [\[Function buttons\]](#)

#### [How to open]

On the [Timing Chart window](#), any one of the following:

- Click the  button.
- Select [Find...] from the [Edit] menu.

#### [Description of each area]

##### (1) Search pin setting area

When multiple search conditions have been specified, the signal data that meets all these search conditions is searched.

Up to 48 search conditions can be specified by using the scrollbar located on the right side.

Pin Name	This area is used to specify the pin name to be searched. The pins can be specified either via direct input or through selection from the drop-down list. Inputting noting makes an area off-limit to data search and input in the corresponding [Search Data] is disabled.
----------	---

Search Data	Selects the data from drop-down list. The data is searched for the pin to be specified.	
	-----	Don't care
	Rising Edge	Searches the rising edge of signal data.
	Falling Edge	Searches the falling edge of signal data.
	Rise/Fall Edge	Searches the rising/falling edge of the signal data.
	High	Searches the signal data that is HIGH.
	Low	Searches the signal data that is LOW.
	Hi Z	Searches the signal data that is high impedance.
Direction	Selects the data search direction by selecting one of the exclusive option buttons. When the [Next] button is clicked, the search is performed in the direction specified in this area.	
	Backward	Searches the data backward (data older than the current location).
	Forward	Searches the data forward (data newer than the current location). (default)

**[Function buttons]**

Button	Function
Next	Searches in the direction specified. When this button is clicked again following search completion, the next data is searched.
Cancel	Stops the data search and closes the dialog box.

### I/O Panel window

This window is used to configure a dummy target system, and manipulate created connected parts.

A dummy target system can be constructed by creating and setting connected parts (figure objects and part objects) in this window. The connected parts for which settings have been performed can be moved to any location within the window, and you can manipulate them during simulation to control signal processing.


Information about parts that are placed in the window can be saved to the I/O panel file (\*.pnl) by selecting the [File] menu >> [Save]/[Save As...] or by saving the project file.

The saved file contents can be restored by selecting the [File] menu >> [Open...] or by loading the project file.

- Cautions 1.** If the saved I/O panel file is opened while Simulator GUI is running with a microcontroller different from the one used when the file was created, information of the parts connected to the pins that are not provided in the microcontroller will not be restored (the [Pin Name] item in the property dialog boxes for parts remains blank).
2. If inputting of signals is started (by an event such as clicking a button) during program break, the signal level will change in actuality when the program is resumed from the break.

**Remark** On the titlebar of this window, "Project file name + Serial number (from 0).pnl" is displayed when the project file has been loaded. However, after having loaded a project file of PM+, then if you save a file as the project file of CubeSuite+, "Project file name + CS+ Serial number (from 0).pnl" is displayed on the titlebar.

Figure A-102. I/O Panel Window



This section describes the following.

- [\[How to open\]](#)
- [\[Description of each area\]](#)
- [\[Dedicated menu/toolbar \(I/O Panel window\)\]](#)
- [\[Context menu\]](#)
- [\[Operation\]](#)

#### [How to open]

- Click the  button.
- Select [I/O Panel...] from the [Simulator] menu.

**[Description of each area]****(1) Client area**

This area is used to create and set connected parts (figure objects and part objects) in order to construct a dummy target system (see "[\[Operation\]](#)").

**[Dedicated menu/toolbar (I/O Panel window)]**

The menu items and buttons on the toolbar, which are used to perform operations related to this window, are described below.

**(1) [Edit] menu**

Select this menu to perform basic editing actions on created objects.

Undo	Undoes the immediately preceding operation, such as object move. Undo can restore up to 5 previous changes.
Redo	Restores the status undone by the [Undo] command.
Cut	Cuts the selected range and saves it to the clipboard.
Copy	Pastes the contents of the clipboard.
Paste	Pastes the contents of the clipboard.
Delete	Deletes the selected range.
Select All	Selects all the objects in the window.
Group	Groups the selected objects.
UnGroup	Ungroups the selected objects.
Bring to Front	Brings the selected object to the front.
Send to Back	Sends the selected object to the back.
Bring Forward	Brings the selected object one panel forward.
Send Backward	Sends the selected object one panel backward.

**(2) [View] menu**

Select this menu to switch the toolbar/status bar display status in this window, or to show/hide various types of information in this window.

ToolBar	Switches on and off the display of two toolbars (Figure/Object).
StatusBar	Switches on and off display of the status bar.
Parts List...	Opens the <a href="#">Parts List dialog box</a> . A list of all the figure/part objects in this window is displayed.
Grid	Shows/hides the window grid.
Properties	Opens the property dialog box of the selected figure/part object.

**(3) [Parts] menu/[Parts] toolbar**

This menu and toolbar are used to select connected parts (part objects) provided by Simulator GUI when newly creating or placing parts (see "[\(3\) Creating part objects](#)").

In this menus, similar operations can be performed using the buttons on the [Parts] toolbar.


Menu Item	Button	Function
Button		Digital input switch
e.g.)		A button can be connected to any pin. A digital input value can be given to the connected pin by clicking the displayed button.
Analog Button		Analog input switches
e.g.)		A button can be connected to any pin. An analog input value can be given to the connected pin by clicking the displayed button.
Key Matrix		A key matrix consists of multiple pins connected in a matrix array, wherein each contact represents a key, and clicking a key results in a specific state.
e.g.)		A key matrix can be connected to any pin, and data can be input using multiple keys.
Level Gauge		Used for inputting analog data such as power supply voltage. Any data within a given range can be set.
e.g.)		Any value within a specified range can be assigned to a pin connected to an A/D converter.
LED		Light Emitting Diode
e.g.)		An LED can be connected to any pin, and the output from the pin can be indicated by switching the LED on or off.
7-Segment LED		A product that consists of 7 LEDs configured to represent a numeric figure.
e.g.)		When the output from the pin assigned to the digit signal is active, the corresponding 7-segment LED switches on or off.
14-Segment LED		A product that consists of 14 LEDs configured to represent an alphabetic character.
e.g.)		When the output from the pin assigned to the digit signal is active, the corresponding 14-segment LED switches on or off.
Matrix LED		A product that consists of multiple LEDs arranged in a matrix array.
e.g.)		When the output from an assigned pin is active, the corresponding 14-segment LED switches on or off.
Buzzer		A buzzer connected to a pin indicates the output information from the connected pin with a bitmap.
e.g.)		
Pull up / Pull down...		Opens the <a href="#">Pull up/Pull down dialog box</a> .
		Whether a pin is connected to a pull-up/down resistor can be specified via this dialog box.

## (4) [Figure] menu/[Figure] toolbar

This menu and toolbar are used to set the operation mode of this window, and select connected parts (figure objects) when newly creating or placing parts (see "(2) Creating figure objects").

In this menus, similar operations can be performed using the buttons on the [Figure] toolbar.

Menu Item	Button	Function
Select		Changes this window's operation mode to the <a href="#">Edit mode</a> . The cursor shape changes into an arrow, enabling the edit of objects.
Simulation Mode		Changes this window's operation mode to the <a href="#">Simulation mode</a> . The cursor shape changes into a hand, enabling simulation of input to connected parts (part objects).
Line		Changes the cursor shape into a cross (+), enabling the drawing of lines.
Rectangle		Changes the cursor shape into a cross (+), enabling the drawing of rectangles.
Rounded Rectangle		Changes the cursor shape into a cross (+), enabling the drawing of rectangles with rounded corners.
Ellipse		Changes the cursor shape into a cross (+), enabling the drawing of ellipses.
Polygon		Changes the cursor shape into a cross (+), enabling the drawing of polygons.
Fan-shaped		Changes the cursor shape into a cross (+), enabling the drawing of fan shapes.
Text		Changes the cursor shape into a cross (+), enabling the drawing of text.
Paste Bitmap...	-	Pastes the selected bitmap file in this window
Color of Line...		Opens the Color dialog box below. The color of the lines of the selected object can be changed to the selected color in this dialog box.  
Color of Fill...		Opens the Color dialog box. The color used for the selected object can be changed to the selected color in this dialog box.

Menu Item	Button	Function
Font...	-	<p>Opens the Font dialog box below</p> <p>The font of the selected object can be changed to the selected font in this dialog box.</p> 
Style of Line		Selects the line style from a cascade menu. The lines of the selected object are changed.
16pt		Sets the line thickness to 16 pt.
12pt		Sets the line thickness to 12 pt.
8pt		Sets the line thickness to 8 pt.
4pt		Sets the line thickness to 4 pt.
2pt		Sets the line thickness to 2 pt.
1pt		Sets the line thickness to 1 pt.
No line		Does not draw lines.
Dotted Line Style		Selects the dotted line style from a cascade menu. The lines of the selected object are changed.
Solid Line		Draw solid lines.
Dash Line		Draw dashed lines.
Dotted Line		Draw dotted lines.
DashDot Line		Draw DashDot lines.
DashDotDot Line		Draw DashDotDot lines.

### [Context menu]

In the [Edit mode](#), the following context menus are available.

Copy	Copies the selected objects.
Paste	Pastes the contents of the clipboard.
Delete	Deletes the selected objects.
Group	Selects from a cascade menu.
Group	Groups the selected objects.
Ungroup	Ungroups the selected objects.
Order	Selects from a cascade menu.
Bring to Front	Brings the selected object to the front.
Send to Back	Sends the selected object to the back.
Bring Forward	Brings the selected object one panel forward.
Send Backward	Sends the selected object one panel backward.
Properties	Opens the property dialog box of the selected figure/part object.

### [Operation]

How to create objects (figure objects and part objects) to construct a dummy target system, and manipulate them is as follows:

- (1) [Edit mode](#)
- (2) [Creating figure objects](#)
- (3) [Creating part objects](#)
- (4) [Placing objects](#)
- (5) [Inputting text](#)
- (6) [List display of objects](#)
- (7) [The detailed setting for objects](#)
- (8) [Simulation mode](#)

#### (1) Edit mode

Change the operation mode of this window to "edit mode" to create objects.

The edit mode can be set by any one of the following methods.

- Select the [Figure] menu >> [Select].
- Click the  button on the toolbar.
- Select the [Edit] menu >> [Select All].

#### (2) Creating figure objects

##### (a) Line

Select the [Figure] menu >> [Line] or click the  button on the toolbar.

-> The mouse cursor changes to a cross (+) shape and line drawing becomes possible.

Drag the cursor from the line start position to the end position.

-> The line start position and the line end position are connected by a straight line. (The line thickness and shape are the default settings.)

**(b) Rectangle/Rounded rectangle/Fan shape**

Select the [Figure] menu >> [Rectangle]/[Rounded Rectangle]/[Ellipse]/[Fan-shaped] or click the  button on the toolbar.

-> The mouse cursor changes to a cross (+) shape and each drawings becomes possible.

Drag the mouse cursor from the top left corner to the bottom right corner of the drawing area (rectangular area).

-> The corresponding figure is displayed in the drawing area, with the mouse position forming the lower right corner.

Drop the figure to fix its size.

-> Rectangles are drawn in the same size as the rectangular area, and other figure shapes are drawn in a size that fits in the rectangular area. (The line thickness and shape are the default settings.)

**(c) Polygon**

Select the [Figure] menu >> [Polygon] or click the  button on the toolbar.

-> The mouse cursor changes to a cross (+) shape and polygon drawing becomes possible.

Click at each position marking an apex of the polygon.

-> The apexes are linked by a straight line in the order in which they were clicked.

Drawing of the polygon is completed by double-clicking.

-> The line thickness and shape are the default settings.

**(d) Pasting a bitmap**

You can use an arbitrary bitmap file as a figure object.

Select the [Figure] menu >> [Paste Bitmap], and then select the bitmap file (\*.bmp) to be pasted.

-> The corresponding bitmap file is pasted in the default position in this window.

**(e) Changing the figure object style**

The color or line style of the created figure object can be changed by any one of the following methods.

- Specify with the [Style] tab of the [Object Properties dialog box](#) opened by double-clicking the figure object.
- Select the [Figure] menu >> [Color of Line]/[Color of Fill]/[Style of Line]/[Dotted Line Style] or click the  button on the toolbar.

**(3) Creating part objects**

You can create part objects by using connected parts provided by Simulator GUI.

**(a) Selecting a part object**

Select the part object to be created from the [Parts] menu or the toolbar.

-> The mouse cursor changes to a cross (+) shape.

Click any location.

-> The corresponding part object is created and placed with the clicked location as the top left corner (default size).

**(b) Changing the part object style**

The style of the created part object can be changed via the [Style] tab of the corresponding property dialog box opened by double-clicking the part object.

For details on the modifiable items, see the section of the property dialog box which is corresponding to the part object (the items differ depending on the part object).

**(4) Placing objects****(a) Grid display**

A grid is displayed by selecting the [View] menu >> [Grid].

**(b) Selecting objects**

The selected types and methods are indicated below.

The selected object(s) is displayed surrounded by a tracker indicating its selected status.

- Single selection

- Click the object to be selected.

- Multiple selections

- Click the objects to be selected while pressing the [Shift] key.

- Range selection

- Drag from the top left corner of the area including the object to be selected, and drop at the lower right corner.

- Select all


- Select [Edit] menu>> [Select All].

**(c) Moving objects**

After selecting the object to be moved (multiple selections possible), then drag and drop it at the move destination.

**Remark** Objects can be moved using the arrow keys on the keyboard.

If more than half of the part bitmap is hidden when the window size is reduced, however, the selected part cannot be moved by using the arrow keys.

**(d) Changing object size**

After selecting the object whose size is to be changed, then drag the tracker displayed.

**(e) Cut/Copy/Paste/Delete/Group/UnGroup an object**

After selecting the object, select the corresponding item from the [Edit] menu.

**(f) Changing object sequence (Bring to Front/Send to Back/Bring Forward/Send Backward)**

After selecting the object, select the corresponding item from the [Edit] menu.

**(5) Inputting text**

Select [Figure] menu >> [Text] or click the  button on the toolbar.

-> The mouse cursor changes to a cross (+) shape.

Drag the mouse cursor from the top left corner of the character drawing area (rectangular area) to the lower right corner.

-> This rectangular area serves as the character drawing area.

Click in the character drawing area.

-> The cursor is displayed and character input becomes possible.

#### (6) List display of objects

Figure objects and part objects created in this window can be displayed as a list by selecting the [View] menu >> [Parts List], in addition to display in this window.

#### (7) The detailed setting for objects

Each created object requires the detailed setting (pin connection information, etc.) in accordance with the target system to be used.

##### (a) Figure objects

The detailed setting can be performed via the [Object Connection] tab of the [Object Properties dialog box](#) opened by double-clicking the target figure object.

By connecting a object to an output pin, show/hide of the object can be switched depending on the output status of the connected pin.

##### (b) Part objects

The detailed setting can be performed via the [xxx Connection] tab of the property dialog box opened by double-clicking the target part object.

For details on the setable items, see the section of the property dialog box which is corresponding to the part object (the items differ depending on the part object).

#### (8) Simulation mode

The part objects whose settings have been completed can be manipulated during simulation (input values can be fed to the simulator). Accordingly you can check the I/O results from these displayed part objects in this window. Change the operation mode of this window to "simulation mode" to manipulate part objects.

The simulation mode can be set by any one of the following methods (the mouse cursor changes to a hand shape).

- Select the [Figure] menu >> [Simulation Mode].
- Click the  button on the toolbar.

**Remark** For details on input operation, see the section of the property dialog box which is corresponding to the part object

### Parts Button Properties dialog box

This property dialog box is used to set or change the pin connection information of buttons, which are one of the connection parts in the [I/O Panel window](#).


Input to the simulator can be done from pin-connected buttons in the [Simulation mode](#).

There are two types of button display styles, figure and bitmap. These styles can be changed on the [\[Style\] tab](#).

**Figure A-103. Parts Button Properties Dialog Box: [Button Connection] Tab**



**Figure A-104. Parts Button Properties Dialog Box: [Style] Tab**



This section describes the following.

- [\[How to open\]](#)
- [\[\[Button Connection\] tab\]](#)
- [\[\[Style\] tab\]](#)
- [\[Function buttons\]](#)
- [\[Operation\]](#)

### **[How to open]**

On the [I/O Panel window](#), any one of the following:

- Double-click a part object "Button".
- Select [Properties...] form the context menu on a part object "Button".
- Select a part object "Button", and then select [Properties...] form the [View] menu.

### **[[Button Connection] tab]**


#### **(1) Pin connection information setting area**

Label	This area is used to specify the part name. The part name input here is displayed on the button. Moreover, it is also displayed in the <a href="#">Parts List dialog box</a> as the label.	
Pin Name	This area is used to specify the pin name to be connected. The connection pins can be specified either via direct input or through selection from the drop-down list.	
Active Level	The active state is selected with a option button, as follows:	
	LOW	Sets the active level to LOW.
	HIGH	Sets the active level to HIGH (default).
Type	Button types are selected using option buttons, as follows:	
	Push	Makes the button a <a href="#">Push button</a> (default). The [Hold Time] item must be specified.
	Toggle	Makes the button a <a href="#">Toggle button</a> .
	Group	Makes the button a <a href="#">Group button</a> . The [Group Name] item must be specified.
Group Name	This area is used to input the button's group name. Input to this area is possible only when [Group] has been selected in [Type].	
Hold Time	Specify the time (hold time) for which the input value is to be held (default: 0.5msec). The settable range is from 0.001 to 999 (msec). Input to this area is possible only when [Push] has been selected in [Type].	
default	Specify the button status after CPU reset.	
	Not change at reset.	Maintains the button status after CPU reset.
	inactive	Buttons are non-depressed after CPU reset (default).
	active	Buttons are depressed after CPU reset.

**Remark** For the pin names that can be specified, see the user's manual of the microcontroller that is used.

## [[Style] tab]

## (1) Style information setting area

Figure	Select this option button to display the button with the following specified figure.	
	Shape	Select the figure shape. Two shapes can be selected: rectangle and ellipse.
	shadow	Cannot be selected.
	Line	Specify and change the figure line, as follows. You can change the color of figure line by clicking the pull-down button.
		Thickness      Specifies the line thickness. Specification is made either using a spin button or through direct input. A value from 1 to 100 can be specified.
		Active      Specifies the color of the line during active display.
		Inactive      Specifies the color of the line during inactive display.
		Fill up      Specify and change the figure filling, as follows. You can change the color of figure filling by clicking the pull-down button.
		Active      Specifies the fill color during active display.
		Inactive      Specifies the fill color during inactive display.
Bitmap	Select this option button to display the button with the following specified bitmap (default).	
	Selection list	Select a bitmap to be used from the selection list. The selectable bitmaps appear in the selection list.
	[Add] button	Opens the Entry Bitmap dialog box below to add a new bitmap to the selection list. The bitmap file to be added can be specified either through file selection using the [...] button, or through direct input.
		
	[Delete] button	Deletes the currently selected bitmap from the selection list. Note that only the bitmap that have been added by user can be deleted.

## (2) Preview area

This area displays the style of the button currently being specified.

**[Function buttons]**

Button	Function
OK	Validates the settings and closes this dialog box.
Cancel	Cancels the settings and closes this dialog box.
Apply	Cannot be selected.
Help	Displays the help for this dialog box.

**[Operation]**

In the [Simulation mode](#), by clicking the displayed button, data can be input to the pin connected to the button. The input format differs depending on the button type (push, toggle, group).

**Figure A-105. Connected Parts Display Example (Button)**



Push button	Clicking this button causes the active value to be loaded to the connected pin. The active value is held during the hold time, after which it changes to the original value.
Toggle button	Clicking this button loads the active value to the connected pin. The active value is held during the hold time, after which it changes to the original value.
Group button	Clicking this button loads the active value to the connected pin. The value of the Group button having the same group name returns to the original value.


### Analog Button Properties dialog box

This property dialog box is used to set or change the pin connection information of analog buttons, which are one of the connection parts in the [I/O Panel window](#).


Input to the simulator can be done from pin-connected analog buttons in the [Simulation mode](#).

There are two types of analog button display styles, figure and bitmap. These styles can be changed on the [\[Style\] tab](#).

**Figure A-106. Analog Button Properties Dialog Box: [Analog Button Connection] Tab**



**Figure A-107. Analog Button Properties Dialog Box: [Style] Tab**



This section describes the following.

- [\[How to open\]](#)
- [\[\[Analog Button Connection\] tab\]](#)
- [\[\[Style\] tab\]](#)
- [\[Function buttons\]](#)
- [\[Operation\]](#)

### **[How to open]**

On the [I/O Panel window](#), any one of the following:

- Double-click a part object "Analog Button".
- Select [Properties...] form the context menu on a part object "Analog Button".
- Select a part object "Analog Button", and then select [Properties...] form the [View] menu.

### **[[Analog Button Connection] tab]**


#### **(1) Pin connection information setting area**

Label	This area is used to specify the part name. The part name input here is displayed on the button. Moreover, it is also displayed in the <a href="#">Parts List dialog box</a> as the label.	
Pin Name	This area is used to specify the pin name to be connected. The connection pins can be specified either via direct input or through selection from the drop-down list.	
Active	Specify the active state.	
	Check box	Analog buttons are created by the number of selected check boxes.
	Label	Directly input the name to be displayed on each analog button.
	Voltage(mV)	Directly input the voltage to be input when each analog button is clicked, in mV units.
Arrange	Specify the button arrangement using the option button. This setting is available if two or more analog buttons have been created in the Active area. This setting is ignored if there is only one analog button or no analog buttons have been created.	
	Row	Analog buttons will be arranged horizontally (default).
	Column	Analog buttons will be arranged vertically.
default	Maintains the analog button operation after CPU reset.	
	Not change at reset.	Maintains the analog button status immediately before CPU reset, after CPU reset.
	inactive	All of the analog buttons are non-depressed after CPU reset (default).
	Active is 'xxx'yyy(mV)	The analog button specified with "xxx'(yyy)mV" is depressed after CPU reset.
Inactive	Specify the input level when no analog buttons are depressed.	

**Remark** For the pin names that can be specified, see the user's manual of the microcontroller that is used.

## [[Style] tab]

## (1) Style information setting area

Figure	Select this option button to display the analog button with the following specified figure.	
	Shape	Select the figure shape. Two shapes can be selected: rectangle and ellipse.
	shadow	Cannot be selected.
	Line	Specify and change the figure line, as follows. You can change the color of figure line by clicking the pull-down button.
		Thickness      Specifies the line thickness. Specification is made either using a spin button or through direct input. A value from 1 to 100 can be specified.
		Active      Specifies the color of the line during active display.
		Inactive      Specifies the color of the line during inactive display.
	Fill up	Specify and change the figure filling, as follows. You can change the color of figure filling by clicking the pull-down button.
		Active      Specifies the fill color during active display.
		Inactive      Specifies the fill color during inactive display.
Bitmap	Select this option button to display the analog button with the following specified bitmap (default).	
	Selection list	Select a bitmap to be used from the selection list. The selectable bitmaps appear in the selection list.
	[Add] button	Opens the Entry Bitmap dialog box below to add a new bitmap to the selection list. The bitmap file to be added can be specified either through file selection using the [...] button, or through direct input.
		
	[Delete] button	Deletes the currently selected bitmap from the selection list. Note that only the bitmap that have been added by user can be deleted.

## (2) Preview area

This area displays the style of the analog button currently being specified.

**[Function buttons]**


Button	Function
OK	Validates the settings and closes this dialog box.
Cancel	Cancels the settings and closes this dialog box.
Apply	Cannot be selected.
Help	Displays the help for this dialog box.

**[Operation]**

In the [Simulation mode](#), while an analog button is depressed, the specified analog voltage value is input to the specified pin.

Clicking the depressed analog button again restores the button to its original state.

**Figure A-108. Connected Parts Display Example (Analog Button)**



### Parts Key Properties dialog box

This property dialog box is used to set or change the pin connection information of a key matrix, which is one of the connection parts in the [I/O Panel window](#).

Input to the simulator can be done from pin-connected keys in the [Simulation mode](#).

A key matrix consisting of input pins and output pins of up to 16 x 16 can be set.

Either figure or bitmap can be selected as the key matrix display style. These styles can be changed on the [\[\[Style\] tab\]](#).

**Caution** When connecting a key matrix to pins, also perform the Pull up/Pull down settings for the connection pins. When a key is pressed, the output value of the output pin connected to that key is input to the input pin connected to that key. The value when the key is not pressed is the value specified in the [Pull up/Pull down dialog box](#).

If the Pull up/Pull down settings are not performed, the input pin becomes the high-impedance state. Consequently, the operation of the function that is connected to the input pin becomes undefined.

Figure A-109. Parts Key Properties Dialog Box: [Key Matrix Connection] Tab





Figure A-110. Parts Key Properties Dialog Box: [Style] Tab



This section describes the following.

- [\[How to open\]](#)
- [\[\[Key Matrix Connection\] tab\]](#)
- [\[\[Style\] tab\]](#)
- [\[Function buttons\]](#)
- [\[Operation\]](#)

#### **[How to open]**

On the [I/O Panel window](#), any one of the following:

- Double-click a part object "Key matrix".
- Select [Properties...] from the context menu on a part object "Key matrix".
- Select a part object "Key matrix", and then select [Properties...] from the [View] menu.

#### **[[Key Matrix Connection] tab]**

##### **(1) Pin connection information setting area**

Label	This area is used to specify the part name. The part name input here is also displayed in the <a href="#">Parts List dialog box</a> as the label.
-------	---


Pin Name	This area is used to specify the pin name to be connected (input pins and output pins). The connection pins can be specified either via direct input or through selection from the dropdown list.	
	This area can be used to set 16 x 16 pins using the scrollbar.	
	In0 - In15	Specify input pins.
	Out0 - Out15	Specify output pins.
N00 - Nff		This area is where the text strings displayed on the keys of the key matrix are specified. Text strings of any length can be specified. The default description string (N number) is not displayed on the keys.
Hold Time	Specify the time (hold time) for which the input value is to be held (default: 0.5msec). The settable range is from 0.001 to 999 (msec). Moreover, when multiple keys for input to the same input pin are pressed during the hold time, only the key that was clicked last is valid.	
default	Specify the key matrix operation after CPU reset.	
	Not change at reset.	The key matrix status does not change after CPU reset.
	inactive	No key matrix buttons are depressed after CPU reset (default).

**Remark** For the pin names that can be specified, see the user's manual of the microcontroller that is used.

### [[Style] tab]

#### (1) Style information setting area

Figure	Select this option button to display the key matrix with the following specified figure.	
	Shape	Select the figure shape. Two shapes can be selected: rectangle and ellipse.
	shadow	Cannot be selected.
	Line	Specify and change the figure line, as follows. You can change the color of figure line by clicking the pull-down button.
	Thickness	Specifies the line thickness. Specification is made either using a spin button or through direct input. A value from 1 to 100 can be specified.
	Active	Specifies the color of the line during active display.
	Inactive	Specifies the color of the line during inactive display.
	Fill up	Specify and change the figure filling, as follows. You can change the color of figure filling by clicking the pull-down button.
	Active	Specifies the fill color during active display.
	Inactive	Specifies the fill color during inactive display.

Bitmap	Select this option button to display the key matrix with the following specified bitmap (default).
	Selection list Select a bitmap to be used from the selection list. The selectable bitmaps appear in the selection list.
	[Add] button Opens the Entry Bitmap dialog box below to add a new bitmap to the selection list. The bitmap file to be added can be specified either through file selection using the [...] button, or through direct input.
	
	[Delete] button Deletes the currently selected bitmap from the selection list. Note that only the bitmap that have been added by user can be deleted.

## (2) Preview area

This area displays the style of the key matrix currently being specified.

## [Function buttons]

Button	Function
OK	Validates the settings and closes this dialog box.
Cancel	Cancels the settings and closes this dialog box.
Apply	Cannot be selected.
Help	Displays the help for this dialog box.

## [Operation]

In the [Simulation mode](#), the following operation can be done.

- (1) Inputting multiple keys simultaneously
- (2) Locking the key input value

### (1) Inputting multiple keys simultaneously

To enter two keys, simultaneously press the key to be input and right-click the mouse to enter the wait status.

Then, click the other key. This releases the wait status and enables simultaneous input of both keys. Multiple keys can be simultaneously input by setting the wait status for multiple keys, but if input is to be performed to the same input pin, the key that was input last is valid.

### (2) Locking the key input value

To enter two keys, simultaneously press the key to be input and right-click the mouse to enter the wait status.

Then, click the other key. This releases the wait status and enables simultaneous input of both keys. Multiple keys can be simultaneously input by setting the wait status for multiple keys, but if input is to be performed to the same input pin, the key that was input last is valid

Figure A-111. Connected Parts Display Example (Key Matrix)

1	2	3
4	5	6
7	8	9
10	11	12

### Parts Level Gauge Properties dialog box


This property dialog box is used to set or change the pin connection information of level gauge, which are one of the connection parts in the [I/O Panel window](#).

Input to the simulator can be done from pin-connected level gauge in the [Simulation mode](#).


Note that the connection pin must be an analog input pin.

There are two types of level gauge display styles, slide and dial. These styles can be changed on the [\[Style\] tab](#).

**Figure A-112. Parts Level Gauge Properties Dialog Box: [Level Gauge Connection] Tab**



**Figure A-113. Parts Level Gauge Properties Dialog Box: [Style] Tab**



This section describes the following.

- [\[How to open\]](#)
- [\[Level Gauge Connection\] tab\]](#)
- [\[\[Style\] tab\]](#)
- [\[Function buttons\]](#)
- [\[Operation\]](#)

### [How to open]

On the [I/O Panel window](#), any one of the following:

- Double-click a part object "Level Gauge".
- Select [Properties...] from the context menu on a part object "Level Gauge".
- Select a part object "Level Gauge", and then select [Properties...] from the [View] menu.

### [Level Gauge Connection] tab]

#### (1) Pin connection information setting area


Label	This area is used to specify the part name. The part name input here is also displayed in the <a href="#">Parts List dialog box</a> as the label.	
Pin Name	This area is used to specify the pin name to be connected. The connection pins can be specified either via direct input or through selection from the drop-down list.	
Maximum input	This area is used to set the maximum level gauge input value (default: 5000mV). The settable range is from 0 to 65535. The operation range of the level gauge displayed in the <a href="#">I/O Panel window</a> is determined by this specified value.	
When CPU reset	Specify the level gauge operation after CPU reset.	
	before CPU Reset	Maintains the level gauge status of immediately before CPU reset, after CPU reset.
	Set default voltage	The level gauge is set to the specified value after CPU reset (default). Specify the value in mV units. Input a value from 0 to "Maximum input:". (default: 0 mV)

**Remark** For the pin names that can be specified, see the user's manual of the microcontroller that is used.

### [[Style] tab]

#### (1) Style information setting area

Slide	Select this option button to display the level gauge with the side-type.	
	Select the slide direction (vertical or horizontal) from the drop-down list.	
	This area is used to specify or change the slide color. You can change the color by clicking the pull-down button.	

Dial	Select this option button to display the level gauge with the dial-type (default).
Color of Mark	This area is used to specify or change the color of the mark indicating the operating point. You can change the color by clicking the pull-down button.
Selection list	Select a bitmap to be used from the selection list. The selectable bitmaps appear in the selection list.
[Add] button	Opens the Entry Bitmap dialog box below to add a new bitmap to the selection list. The bitmap file to be added can be specified either through file selection using the [...] button, or through direct input.
	
[Delete] button	Deletes the currently selected bitmap from the selection list. Note that only the bitmap that have been added by user can be deleted.

## (2) Preview area

This area displays the style of the level gauge currently being specified.

### [Function buttons]

Button	Function
OK	Validates the settings and closes this dialog box.
Cancel	Cancels the settings and closes this dialog box.
Apply	Cannot be selected.
Help	Displays the help for this dialog box.


### [Operation]

In the [Simulation mode](#), analog input from the level gauge is performed through manipulation of the displayed slider or dial.

The value specified in [Maximum input] is the maximum value that can be input.

Input is enabled by selecting the [Figure] menu >> [Simulation Mode].

Figure A-114. Connected Parts Display Example (Level Gauge)



Dial-type level gauge	The displayed analog value changes as the operating point (red circle) on the dial is moved by dragging it with the mouse. When this analog value has become the value that is to be input, release the operating point. As a result, the displayed analog value is input. The operating point can also be moved by clicking the desired location on the dial.
Slide-type level gauge	The displayed analog value changes as the slider button is moved by dragging it with the mouse. When this analog value has become the value that is to be input, release the button. As a result, the displayed analog value is input. The button can also be moved by clicking the desired location on the slider.

**Caution** If you drag and drop the dial's operation point (red circle) or the slider's knob away from the level gauge, then the voltage displayed in the level gauge will change, but the voltage actually output by the level gauge will not change. Make sure to always drag and drop over the level gauge.


### Parts Led Properties dialog box

This property dialog box is used to set or change the pin connection information of LED, which are one of the connection parts in the [I/O Panel window](#).


A pin-connected LED displays the information output from the simulator through lit/unlit display in the [Simulation mode](#).

There are two types of LED display styles, figure and bitmap. These styles can be changed on the [\[Style\] tab](#).

**Figure A-115. Parts Led Properties Dialog Box: [LED Connection] Tab**



**Figure A-116. Parts Led Properties Dialog Box: [Style] Tab**



This section describes the following.

- [\[How to open\]](#)
- [\[\[LED Connection\] tab\]](#)
- [\[\[Style\] tab\]](#)
- [\[Function buttons\]](#)
- [\[Operation\]](#)

### **[How to open]**

On the [I/O Panel window](#), any one of the following:

- Double-click a part object "LED".
- Select [Properties...] form the context menu on a part object "LED".
- Select a part object "LED", and then select [Properties...] form the [View] menu.

### **[[LED Connection] tab]**

#### **(1) Pin connection information setting area**

Label	This area is used to specify the part name. The part name input here is also displayed in the <a href="#">Parts List dialog box</a> as the label.	
Pin Name	This area is used to specify the pin name to be connected (output pin). The connection pins can be specified either via direct input or through selection from the drop-down list.	
Active Level	The active state is selected with a option button, as follows:	
LOW	Sets the active level to LOW.	
HIGH	Sets the active level to HIGH (default).	

**Remark** For the pin names that can be specified, see the user's manual of the microcontroller that is used.

### **[[Style] tab]**

#### **(1) Style information setting area**

Figure	Select this option button to display the LED with the following specified figure.	
	Shape	Select the figure shape. Two shapes can be selected: rectangle and ellipse.
	shadow	Cannot be selected.
	Line	Specify and change the figure line, as follows. You can change the color of figure line by clicking the pull-down button.
	Thickness	Specifies the line thickness. Specification is made either using a spin button or through direct input. A value from 1 to 100 can be specified.
	Active	Specifies the color of the line during active display.
	Inactive	Specifies the color of the line during inactive display.
	Fill up	Specify and change the figure filling, as follows. You can change the color of figure filling by clicking the pull-down button.
	Active	Specifies the fill color during active display.
	Inactive	Specifies the fill color during inactive display.

Bitmap	Select this option button to display the LED with the following specified bitmap (default).
	Selection list Select a bitmap to be used from the selection list. The selectable bitmaps appear in the selection list.
	[Add] button Opens the Entry Bitmap dialog box below to add a new bitmap to the selection list. The bitmap file to be added can be specified either through file selection using the [...] button, or through direct input.
	
	[Delete] button Deletes the currently selected bitmap from the selection list. Note that only the bitmap that have been added by user can be deleted.

## (2) Preview area

This area displays the style of the LED currently being specified.

### [Function buttons]

Button	Function
OK	Validates the settings and closes this dialog box.
Cancel	Cancels the settings and closes this dialog box.
Apply	Cannot be selected.
Help	Displays the help for this dialog box.

### [Operation]

In the [Simulation mode](#), the output status (active/inactive) of the connected pins is displayed in real-time using two types of bitmaps or figures.

**Figure A-117. Connected Parts Display Example (LED)**




### Parts Segment LED Properties dialog box

This property dialog box is used to set or change the pin connection information of 7-segment LED and 14-segment LED, which are one of the connection parts in the [I/O Panel window](#).


A LED connected to pins displays the information output from the simulator in the [Simulation mode](#).

The segment LED display styles can be changed on the [\[Style\] tab](#).

**Figure A-118. Parts Segment LED Properties Dialog Box: [SegmentLED Connection] Tab**



**Figure A-119. Parts Segment LED Properties Dialog Box: [Style] Tab**



This section describes the following.

- [\[How to open\]](#)
- [\[\[SegmentLED Connection\] tab\]](#)
- [\[\[Style\] tab\]](#)
- [\[Function buttons\]](#)
- [\[Operation\]](#)

### **[How to open]**

On the [I/O Panel window](#), any one of the following:

- Double-click a part object "7-segment LED"/"14-segment LED".
- Select [Properties...] from the context menu on a part object "7-segment LED"/"14-segment LED".
- Select a part object "7-segment LED"/"14-segment LED", and then select [Properties...] from the [View] menu.

### **[[SegmentLED Connection] tab]**

#### **(1) Pin connection information setting area**

Label	This area is used to specify the part name. The part name input here is also displayed in the <a href="#">Parts List dialog box</a> as the label.	
Grid type	Select the grid signal allocation method from the following. As a result of the selection, the setting in the <a href="#">Digit signal setting area</a> changes.	
	Digit	Connects each segment LED to 1 grid pin. Digit signal settings are performed in the <a href="#">Digit signal setting area</a> (default). 16 digits can be specified for the digit signal. A segment LED of up to 16 digits can be created with 1 segment LED part.
	Customize	Cannot be selected.

#### **(2) Segment signal setting area**

Segment Signal	This area is used to specify the pins (output pins) to be connected to the segment signals of the 7-segment LED/14-segment LED, as well as their active level.	
	Figure	This area displays the bitmap of the 7-segment LED/14-segment LED at the top left. When "Pin Name:" is input, the corresponding location is indicated.
	Pin Name	The connection pins can be specified either via direct input or through selection from the drop-down list. The number of segment pins to be connected is 8 in the case of a 7-segment LED, and 15 in the case of a 14-segment LED. Connection to all the segment pins is possible by using the scroll bar on the right side.
	Active Level	The active status can be selected with a option button, as follows:
	LOW	Sets the active level to LOW.
	HIGH	Sets the active level to HIGH (default).

**Remark** For the pin names that can be specified, see the user's manual of the microcontroller that is used.

**(3) Digit signal setting area**

Digit Signal	This area is used to specify 7-segment LED/14-segment LED digits, grid signal connection pins (output pins), and their active level. The connection method changes as follows according to what is specified for [Grid type].	
	- When [Digit] selected	Perform digit signal setting. The maximum number of digit pins that can be connected is 16. Connection to all the digit pins can be done by using the scroll bar on the right side of the area.
	- When [Customize] selected	Cannot be selected.
	Pin Name	The connection pins can be specified either via direct input or through selection from the drop-down list. As the setting signal, specify the connection pins in a series from the lowermost digit.
Active Level	The active status can be selected with a option button, as follows:	
	LOW	Sets the active level to LOW.
	HIGH	Sets the active level to HIGH (default).

**Remark** For the pin names that can be specified, see the user's manual of the microcontroller that is used.

**[[Style] tab]****(1) Style information setting area**

Full up LED	This area is used to set and change related to the filling of each cell of the object are performed. You can change the color by clicking the pull-down button.	
	Active Color	Specifies the fill color during active display.
	Inactive Color	Specifies the fill color during inactive display.
Frame Line of LED	This area is used to set and change related to the frame of each cell of the object are performed.	
	Color of Line	Specifies and changes the line color. You can change the color by clicking the pull-down button.
	Dotted/Solid Line	Specifies and changes the line shape (dotted/solid). The desired line shape can be selected from the drop-down list. The line shape can be specified only when the line thickness is "1" in [Thickness of Line].
	Thickness of Line	Specifies and changes the line thickness. The desired line thickness can be specified either via direct input or through selection from the spin button. A value in the range of 1 to 100 (decimal) can be specified.


**[Function buttons]**

Button	Function
OK	Validates the settings and closes this dialog box.
Cancel	Cancels the settings and closes this dialog box.
Apply	Cannot be selected.
Help	Displays the help for this dialog box.

**[Operation]**

In the [Simulation mode](#), as the results of 1 simulation, the output information of the connection pins is received and display is performed accordingly. When both the digit/grid signals and segment signals are active output, the segment LED of the corresponding digit/grid light.

**Figure A-120. Connected Parts Display Example (7-segment LED)**




### Parts Matrix Led Properties dialog box

This property dialog box is used to set or change the pin connection information of matrix LED, which are one of the connection parts in the [I/O Panel window](#).


A pin-connected matrix LED displays the information output from the simulator through lit/unlit display in the [Simulation mode](#).

There are two types of matrix LED display styles, figure and bitmap. These styles can be changed on the [\[Style\] tab](#).

**Figure A-121. Parts Matrix Led Properties Dialog Box: [Matrix LED Connection] Tab**



**Figure A-122. Parts Matrix Led Properties Dialog Box: [Style] Tab**



This section describes the following.

- [\[How to open\]](#)
- [\[\[Matrix LED Connection\] tab\]](#)
- [\[\[Style\] tab\]](#)
- [\[Function buttons\]](#)
- [\[Operation\]](#)

### **[How to open]**

On the [I/O Panel window](#), any one of the following:

- Double-click a part object "Matrix LED".
- Select [Properties...] form the context menu on a part object "Matrix LED".
- Select a part object "Matrix LED", and then select [Properties...] form the [View] menu.

### **[[Matrix LED Connection] tab]**

#### **(1) [Label]**

Label	This area is used to specify the part name. The part name input here is also displayed in the <a href="#">Parts List dialog box</a> as the label.
-------	---

#### **(2) Row direction signals setting area**

Row Signal	This area is used to specify the output pins connected to the matrix LED row direction signals and their active level.	
	Pin Name	A maximum of 16 pins can be connected. Connection to all the row direction signals can be done by using the scrollbar located on the right side of the pin name input area.
	Active Level	The active status can be selected with a option button, as follows:
	LOW	Sets the active level to LOW.

**Remark** For the pin names that can be specified, see the user's manual of the microcontroller that is used.

#### **(3) Column direction signals setting area**

Column Signal	This area is used to specify the output pins connected to the matrix LED column direction signals and their active level.	
	Pin Name	The connection pins can be specified either via direct input or through selection from the drop-down list.A maximum of 16 pins can be connected. Connection to all the column direction signals can be done by using the scrollbar located on the right side of the pin name input area.
	Active Level	The active status can be selected with a option button, as follows:
	LOW	Sets the active level to LOW.

**Remark** For the pin names that can be specified, see the user's manual of the microcontroller that is used.

## [[Style] tab]

## (1) Style information setting area

Figure	Select this option button to display the matrix LED with the following specified figure.
	Shape Select the figure shape. Two shapes can be selected: rectangle and ellipse.
	shadow Cannot be selected.
	Line Specify and change the figure line, as follows. You can change the color of figure line by clicking the pull-down button.
	Thickness Specifies the line thickness. Specification is made either using a spin button or through direct input. A value from 1 to 100 can be specified.
	Active Specifies the color of the line during active display.
	Inactive Specifies the color of the line during inactive display.
	Fill up Specifiy and change the figure filling, as follows. You can change the color of figure filling by clicking the pull-down button.
	Active Specifies the fill color during active display.
	Inactive Specifies the fill color during inactive display.
Bitmap	Select this option button to display the matrix LED with the following specified bitmap (default)
	Selection list Select a bitmap to be used from the selection list. The selectable bitmaps appear in the selection list.
	[Add] button Opens the Entry Bitmap dialog box below to add a new bitmap to the selection list. The bitmap file to be added can be specified either through file selection using the [...] button, or through direct input.
	
	[Delete] button Deletes the currently selected bitmap from the selection list. Note that only the bitmap that have been added by user can be deleted.

## (2) Preview area

This area displays the style of the matrix LED currently being specified.


**[Function buttons]**

Button	Function
OK	Validates the settings and closes this dialog box.
Cancel	Cancels the settings and closes this dialog box.
Apply	Cannot be selected.
Help	Displays the help for this dialog box.

**[Operation]**

In the [Simulation mode](#), as the results of 1 simulation, the output information of the connection pins is received and display is performed accordingly. When the matrix intersection of a row pin and column pin is active, the corresponding LED lights.

**Figure A-123. Connected Parts Display Example (Matrix LED)**



### Parts Buzzer Properties dialog box


This property dialog box is used to set or change the pin connection information of a buzzer, which is one of the connection parts in the I/O Panel window.

The pin-connected buzzer displays the information output from the connected pins as a bitmap in the [Simulation mode](#).

The buzzer output can be checked as "display".

There are two types of buzzer display styles, figure and bitmap. These styles can be changed on the [\[\[Style\] tab\]](#).

**Figure A-124. Parts Buzzer Properties Dialog Box: [Buzzer Connection] Tab**



**Figure A-125. Parts Buzzer Properties Dialog Box: [Style] Tab**



This section describes the following.

- [\[How to open\]](#)
- [\[\[Buzzer Connection\] tab\]](#)
- [\[\[Style\] tab\]](#)
- [\[Function buttons\]](#)
- [\[Operation\]](#)

### **[How to open]**

On the [I/O Panel window](#), any one of the following:

- Double-click a part object "Buzzer".
- Select [Properties...] form the context menu on a part object "Buzzer".
- Select a part object "Buzzer", and then select [Properties...] form the [View] menu.

### **[[Buzzer Connection] tab]**


#### **(1) Pin connection information setting area**

Label	This area is used to specify the part name. The part name input here is also displayed in the <a href="#">Parts List dialog box</a> as the label.	
Pin Name	This area is used to specify the pin name to be connected (output pin). The connection pins can be specified either via direct input or through selection from the drop-down list.	
Active Level	The active state is selected with a option button, as follows:	
	LOW	Sets the active level to LOW.
	HIGH	Sets the active level to HIGH (default).
Output Form	This item is not allowed to change.	

**Remark** For the pin names that can be specified, see the user's manual of the microcontroller that is used.

## [[Style] tab]

## (1) Style information setting area

Figure	Select this option button to display the buzzer with the following specified figure.	
	Shape	Select the figure shape. Two shapes can be selected: rectangle and ellipse.
	shadow	Cannot be selected.
	Line	Specify and change the figure line, as follows. You can change the color of figure line by clicking the pull-down button.
		Thickness      Specifies the line thickness. Specification is made either using a spin button or through direct input. A value from 1 to 100 can be specified.
		Active      Specifies the color of the line during active display.
		Inactive      Specifies the color of the line during inactive display.
		Fill up      Specify and change the figure filling, as follows. You can change the color of figure filling by clicking the pull-down button.
		Active      Specifies the fill color during active display.
		Inactive      Specifies the fill color during inactive display.
Bitmap	Select this option button to display the buzzer with the following specified bitmap (default).	
	Selection list	Select a bitmap to be used from the selection list. The selectable bitmaps appear in the selection list.
	[Add] button	Opens the Entry Bitmap dialog box below to add a new bitmap to the selection list. The bitmap file to be added can be specified either through file selection using the [...] button, or through direct input.
		
	[Delete] button	Deletes the currently selected bitmap from the selection list. Note that only the bitmap that have been added by user can be deleted.

## (2) Preview area

This area displays the style of the buzzer currently being specified.

**[Function buttons]**


Button	Function
OK	Validates the settings and closes this dialog box.
Cancel	Cancels the settings and closes this dialog box.
Apply	Cannot be selected.
Help	Displays the help for this dialog box.

**[Operation]**

In the [Simulation mode](#), the active level output of the connected pins can be expressed as a bitmap.

The following bitmaps are displayed according to the pin's output value (active/inactive).

**Figure A-126. Connected Parts Display Example (Buzzer)**




### Pull up/Pull down dialog box

This dialog box is used to set or change the pin connection information of the pull-up/pull-down resistors, which are one of the connection parts of the [I/O Panel window](#).

The setting method for these connection parts differs from those for other parts. The connection information of all the pins is managed as a group in this dialog box.

**Figure A-127. Pull up/Pull down Dialog Box**



This section describes the following.

- [\[How to open\]](#)
- [\[Description of each area\]](#)
- [\[Function buttons\]](#)

#### [How to open]

- With the [I/O Panel window](#) in focus, click the  button or select [Pull up/Pull down...] from the [Parts] menu.

**[Description of each area]****(1) Connection information display area**

Pin name	Displays the names of the pins that can be connected to pull-up/pull-down resistors.	
Pull Up/Pull Down	Displays the connected status of the pins.	
	Pull Up	Indicates pull-up resistor is connected.
	Pull Down	Indicates pull-down resistor connected.
	-	Indicates no pull-up/pull-down resistor connected.
Buttons	Changes the pin connection information of the pull-up/pull-down resistors.	
	[Pull Up]	Connects the pins selected to pull-up resistors. When connection is completed, "Pull Up" is displayed.
	[Pull Down]	Connects the pins selected to pull-down resistors. When connection is completed, "Pull Down" is displayed.
	[Disconnect]	Cancels the connected status of the pins selected. When connection is completed, "-" is displayed.

**[Function buttons]**

Button	Function
OK	Validates the settings and closes this dialog box.
Cancel	Cancels the settings and closes this dialog box.


### Object Properties dialog box

This property dialog box is used to set or change the connection information fed to the pins of figure object (including text and bitmap) of the [I/O Panel window](#).


Show/hide can be switched for each pin-connected object by the output status of the connected pins in the [Simulation mode](#).

The default status of each signal is active HIGH. Display styles can be changed on the [\[Style\] tab](#).

**Figure A-128. Object Properties Dialog Box: [Object Connection] Tab**



**Figure A-129. Object Properties Dialog Box: [Style] Tab**



This section describes the following.

- [\[How to open\]](#)
- [\[\[Object Connection\] tab\]](#)
- [\[\[Style\] tab\]](#)
- [\[Function buttons\]](#)

### [How to open]

On the [I/O Panel window](#), any one of the following:

- Double-click a figure object.
- Select [Properties...] from the context menu on a figure object.
- Select a figure object, and then select [Properties...] from the [View] menu.

### [[Object Connection] tab]

#### (1) Pin connection information setting area

Pin Connect	Select the method for connecting objects and output pins by clicking the corresponding option buttons, and specify the output pin name. As a result of the connection, figure display is switched by the ON/OFF status of the connected output pin.	
	No Connection	The object and pin are not connected (default). Objects not connected to pins are always in the displayed status.
	Static Connection	Connects the figure to 1 output pin. The connection pin can be specified in [Pin Name] either via direct input or through selection from the drop-down list. During simulation, the object is displayed when the specified output signal data is active.
	Dynamic Connection	Connects the figure to 2 output pins. The connection pin can be specified in [Pin Name1] and [Pin Name2] either via direct input or through selection from the drop-down list. During simulation, the object is displayed when the specified output signal 1 data and the specified output signal 2 data are both active.
Active Level	The common active status of each output signal can be selected from the option buttons.	
	LOW	Sets the active level to LOW.
	HIGH	Sets the active level to HIGH (default).

**Remark** For the pin names that can be specified, see the user's manual of the microcontroller that is used.

## [[Style] tab]

## (1) Style information setting area

Fill up	Specifies and changes settings related to each object filling <sup>Note</sup> , as follows: The area to be filled differs according to the object. <ul style="list-style-type: none"><li>- Line Not applicable</li><li>- Rectangle, Ellipse, Rounded Rectangle Inside area enclosed by contour lines</li><li>- Polygon Inside area enclosed by lines linking apexes</li><li>- Text Inside text box</li><li>- Bitmap Inside figure drawing area</li></ul>	
	Color      Specifies and changes settings of color You can change the color by clicking the pull-down button.	
Line	<p>This area is used to perform settings and changes related to the lines of objects. The definition of line for each type of object is provided below.</p> <ul style="list-style-type: none"><li>- Line All areas of the object</li><li>- Rectangle, Ellipse, Rounded Rectangle Contour line of the figure</li><li>- Polygon Lines that link the apexes of the polygon</li><li>- Text Contour lines of the text box</li><li>- Bitmap Contour lines of figure drawing area</li></ul>	
	Color	Specifies and changes the line color. You can change the color by clicking the pull-down button.
	Dotted/ Solid	Specifies and changes line shapes (dotted line/solid line). The desired line shape can be selected from the drop-down list. Note that this item can be changed only when [Thickness] is set to "1".
	Thickness	Specifies and changes the line thickness. The desired line thickness can be specified either via direct input or through selection from the spin button. A value in the range of 1 to 100 (decimal) can be specified.

**Note** At this time, if the object that have been pasted from a bitmap file, it becomes invisible.

**[Function buttons]**


Button	Function
OK	Validates the settings and closes this dialog box.
Cancel	Cancels the settings and closes this dialog box.
Apply	Cannot be selected.
Help	Displays the help for this dialog box.

**Parts List dialog box**

This dialog box displays all the figure objects created in the [I/O Panel window](#) as well as the pin connection status of part objects.

The pin connection settings for each object can be changed in the property dialog box, which can be opened by double-clicking the relevant object listed in this dialog box, or selecting the relevant object listed in this dialog box and then selecting the [View] menu >> [Properties...].

**Figure A-130. Parts List Dialog Box**



This section describes the following.

- [\[How to open\]](#)
- [\[Description of each area\]](#)
- [\[Function buttons\]](#)

**[How to open]**

- With the [I/O Panel window](#) in focus, select [Parts List...] from the [View] menu.

**[Description of each area]****(1) Pin connection status display area**

Label	Displays the label (name) attached to the object. Nothing is displayed for objects that do not have a label.	
Parts	Displays the part category.	
rectangle	rectangle	Straight line, rectangle, ellipse, rounded rectangle, fan shape
polygon	polygon	Polygon
text	text	Text
bitmap	bitmap	Bitmap
button	button	Push button, pull button, group button
analog button	analog button	Analog button
key	key	Key matrix
level gauge	level gauge	Level gauge
led	led	LED
7segment led	7segment led	7-segment LED
14segment led	14segment led	14-segment LED
matrix led	matrix led	Matrix LED
buzzer	buzzer	Buzzer
groups	groups	Grouped part
Pin Name	Displays the pins connected to parts. "-" is displayed for parts that are connected to multiple pins, and a blank is displayed for parts that are unconnected.	
Active Level	Displays the active value set for the part. "-" is displayed for parts that are connected to multiple pins, and a blank is displayed for parts that are unconnected.	

**[Function buttons]**

Button	Function
Close	Closes the this dialog box.

### Serial window

This window is used to communicate with the serial interface provided in the CPU.

Since this window operates as the serial interface of the remote node of the CPU, transmission data from CPU turns into reception data in this window, and transmission data from this window turns into reception data in the CPU.

The following two types of files can be handled in this window.


The transmission/reception data displayed in the top area in this window can be saved to the serial log data file (\*.log) (CSV format) by selecting the [File] menu >> [Save]/[Save As...].

Moreover, the transmission data created in the lower part of this window can be saved to the serial transmission data file (\*.ser) (CSV format) by clicking the [Save] button (the contents can be restored by clicking the [Load] button).

Saving/restoring the created data can also be performed by saving/loading the project file. In this case, however, data is not saved as a CSV format text file but saved into the project file.

- Cautions 1.** If the saved serial transmission data file is opened or the project file is opened while Simulator GUI is running with a microcontroller different from the one used when the file was created, the settings of the serial interface that are not provided in the microcontroller will not be restored.
- 2.** Multiple instances of this window can be opened. After opening this window, select the serial interface to be verified in the **Serial selection area**.

Figure A-131. Serial Window



This section describes the following.

- [\[How to open\]](#)
- [\[Description of each area\]](#)
- [\[Dedicated menu \(Serial window\)\]](#)
- [\[Context menu\]](#)

### [How to open]

- Click the  button.
- Select [Serial] from the [Simulator] menu.

### [Description of each area]

#### (1) Serial selection area

Select the serial interface to be used.

	Select the serial interface to be used from the list of provided serial interfaces (drop-down list) <small>Note</small> .
	Select from the drop-down list the time information unit applied to [Wait] in the <a href="#">Serial editor area</a> . The time information unit can be changed by selecting the [Edit] menu >> [Time unit].

**Note** Once selected, the serial interface cannot be changed.

If you wish to change the serial interface, open the another Serial window newly.

#### (2) Log display area

Displays the transmission/reception data.

The display timing is when all the bits constituting the data have been received or sent.

Only data from which the start bit, stop bit, and parity bit have been deleted is displayed in this area.

The notation of data can be changed by selecting the [View] menu>> [Numeric Representation] >> [Binary]/[Hexadecimal].

Log display is cleared upon debugger or simulator reset.

Time	Displays the time from the completion of reception/transmission of the previous data until completion of reception/transmission of the current data. The time information unit is specified by selecting the [Edit] menu >> [Time unit].
Send Data	Displays the data sent by this window (data received by the CPU).
Receive Data	Displays the data received by this window (data sent by the CPU).
Status	Displays the status during data reception. When an error occurs, one of the following marks is displayed. When everything is normal, nothing is displayed.
	P      Parity error (mismatching parity bit)
	F      Framing error (stop bit not detected)

**(3) Serial editor area**

This area is where the transmission data is created.

This area can be shown or hidden by selecting the [View] menu >> [Serial Editor].

No.	This is a number assigned sequentially from the beginning. It cannot be directly written. The maximum number is 9,999 lines.	
Wait	Specifies the time from the completion of transmission of the immediately previous data until the start of transmission of next data. Valid during transmission using the [Auto send] button. The time information unit is the unit selected by selecting the [Edit] menu >> [Time unit]. The wait value is input by placing the cursor in the Wait field to be edited and double-clicking. One wait value can be written per operation.	
Data	This area is used to edit transmission data. Data can be directly input by placing the cursor in the data field and double-clicking. Data suffixed by "0x" is treated as hexadecimal data, and data suffixed by "0b" is treated as binary data. The default code is the hexadecimal code. If a bit length different from that specified in the <a href="#">Format (UART) dialog box</a> or <a href="#">Format (CSI) dialog box</a> is specified, data from the lower bit is valid. One data can be written per operation.	
Button	Format	Opens the <a href="#">Format (UART) dialog box</a> or <a href="#">Format (CSI) dialog box</a> .
	All Clear	Clears all <a href="#">Serial editor area</a> .
	Load	Loads the contents of the previously saved serial transmission data file (*.ser) and restores them in the <a href="#">Serial editor area</a> . A file created for UART cannot be loaded as a file for CSI and vice versa.
	Save	Saves the contents of the <a href="#">Serial editor area</a> to the specified serial transmission data file (*.ser).
	Send	Sends one of the data selected in the <a href="#">Serial editor area</a> . The next data becomes selected upon completion of transmission. If no data is selected, the first data is sent.
	Auto Send	Makes the data selected in the <a href="#">Serial editor area</a> the first data, and automatically transfers from the data to the bottom of the area. The data transmission time interval is the time specified for Wait.

**Caution** The help for this window will not be displayed even if the [F1] key on the keyboard is pressed while the cursor is placed in this area.

**Remark** When the CSI selected in this window is set to master mode, the clock must be supplied for reception. To perform reception, transmission of dummy data is therefore required.

**[Dedicated menu (Serial window)]****(1) [Edit] menu**

Insert	Inserts a new line immediately before the selected line.
Cut	Cuts the selected range and saves it to the clipboard.
Copy	Copies the selected range and copies it to the clipboard.
Paste	Pastes the contents of the clipboard to the selected location.
Delete	Deletes the selected range.
Time unit	Selects the time unit.
main clock	Main clock (default)
usec	Microsecond
msec	Millisecond
Format...	Opens the <a href="#">Format (UART) dialog box</a> or <a href="#">Format (CSI) dialog box</a> .

**(2) [View] menu**

Serial Editor	Selects whether <a href="#">Serial editor area</a> is displayed or not.
Numeric Representation	Changes the notation of the <a href="#">Log display area</a> display method.
Binary	Displays binary numbers.
Hexadecimal	Displays hexadecimal numbers.

**(3) [Option] menu**

Customize...	Opens the <a href="#">Customize dialog box</a> .
--------------	--

**[Context menu]**


The following context menus are available in the [Serial editor area](#).

Insert	Inserts a new line immediately before the selected line.
Cut	Cuts the selected range and saves it to the clipboard.
Copy	Copies the selected range and copies it to the clipboard.
Paste	Pastes the contents of the clipboard to the selected location.
Delete	Deletes the selected range.

### Format (UART) dialog box

This dialog box is used to set the serial format for the asynchronous serial interface (UART).

**Figure A-132. Format (UART) Dialog Box**



This section describes the following.

- [How to open]
- [Description of each area]
- [Function buttons]

#### [How to open]

On the [Serial window](#) with the UART serial interface, any one of the following:

- Click the [Format] button.
- Select [Format...] from the [Edit] menu

#### [Description of each area]

##### (1) Serial format setting area

Baudrate	Directly input the serial baud rate value as an integer. (Unit: bps)
Transfer Direction	Select the transfer direction.
	MSB first      Sets MSB first as the transfer direction.
	LSB first      Sets LSB first as the transfer direction (default).
Data bit length	Select the bit length of the transmission data from the drop-down list, or specify it through direct input (default:7).
Stop bit length	Select the stop bit length from the drop-down list (default:1).
Parity	Select the parity information (none parity (default) /odd parity/even parity/0 parity).

Repeat	Select this item to repeat data transfer when the [Auto Send] button in the <a href="#">Serial window</a> has been clicked.	
	<input checked="" type="checkbox"/>	Following transmission of the last data during automatic transmission, returns to the beginning of the data and performs automatic transmission.
	<input type="checkbox"/>	Following transmission of the last data during automatic transmission, stops transmission (default).

**Remark** For the selectable range, see the user's manual of the microcontroller that is used.

#### [Function buttons]

Button	Function
OK	Validates the settings and closes this dialog box.
Cancel	Cancels the settings and closes this dialog box.

### Format (CSI) dialog box

This dialog box is used to specify the serial format for the 3-wire serial interface (CSI).

Figure A-133. Format (CSI) Dialog Box



This section describes the following.

- [\[How to open\]](#)
- [\[Description of each area\]](#)
- [\[Function buttons\]](#)
- [\[Transmission/reception when 3-wire serial interface \(CSI\) is selected\]](#)

#### [How to open]

On the [Serial window](#) with the CSI serial interface, any one of the following:

- Click the [Format] button.
- Select [Format...] from the [Edit] menu

#### [Description of each area]

##### (1) Serial format setting area



Master, Slave	Select the transfer mode.	
	Master	Operates this window as a master. Setting of [Transfer Clock] is required for generating the clock during communication.
Slave		Operates this window as a slave (default). Communication is performed using the clock of the serial interface provided in the CPU.
Transfer Clock	Directly input the transfer clock value (unit: kHz). Values with decimals can also be set. This item must be set when master is selected.	

Transfer Direction		Select the transfer direction.	
MSB first		Sets MSB first as the transfer direction (default).	
LSB first		Sets LSB first as the transfer direction.	
Data bit length		Select the bit length of the transmission data from the drop-down list, or specify it through direct input (default: 8).	
Data Phase		Select the transmission/reception timing to set the data phase. The data clock phase is set in combination with "Clock Phase" as shown in " <a href="#">Table A-23. Data Clock Phase Settings</a> ".	
		Normal	Transmits/receives data at the normal 3-wire serial transmission/reception timing (default).
		Precede	Transmits/receives data at a timing half a clock of the operation clock earlier than the normal 3-wire serial transmission/reception timing.
Clock Phase		Select the transmission/reception clock waveform to set the clock phase. The data clock phase is set in combination with "Data Phase" as shown in " <a href="#">Table A-23. Data Clock Phase Settings</a> ".	
		Normal	Operates on the normal 3-wire serial clock. Transfer starts at the falling edge of the clock (default).
		Reverse	Operates on the reverse clock of the normal 3-wire serial clock. Transfer starts at the rising edge of the clock.
Repeat		Select this item to repeat data transfer when the [Auto Send] button in the <a href="#">Serial window</a> has been clicked.	
		<input checked="" type="checkbox"/>	Following transmission of the last data during automatic transmission, returns to the beginning of the data and performs automatic transmission.
		<input type="checkbox"/>	Following transmission of the last data during automatic transmission, stops transmission.

**Remark** For the selectable range, see the user's manual of the microcontroller that is used.

**Table A-23. Data Clock Phase Settings**

Data Phase Setting	Clock Phase Setting	Data Clock Phase		
Normal	Normal	SCK		SO 
Precede	Normal	SCK		SO 
		SI input Timing		

Data Phase Setting	Clock Phase Setting	Data Clock Phase	
Normal	Reverse	SCK	
Precede	Reverse	SCK	

#### [Function buttons]

Button	Function
OK	Validates the settings and closes this dialog box.
Cancel	Cancels the settings and closes this dialog box.

#### [Transmission/reception when 3-wire serial interface (CSI) is selected]


The [Serial window](#) when CSI serial interface is selected always operates in the transmission/reception mode regardless of whether [Master] or [Slave] is selected in this dialog box.

When [Master] is selected	Data is transmitted or received immediately after clicking the [Send] button or the [Auto Send] button in the <a href="#">Serial editor area</a> .
When [Slave] is selected	Data becomes ready to be transmitted or received after clicking the [Send] button or the [Auto Send] button in the <a href="#">Serial editor area</a> .  Data starts to be transmitted or received when the CSI clock signal is received in the data transmission/reception ready status. This ready status is released when data transmission or reception is completed. (Even if the CSI clock is received, data is not transmitted or received in other than the data transmission/reception ready status.)


Accordingly, when only wanting to reception data in the [Serial window](#) when "Slave" is selected, execute as follows (Reception setting when CSI serial slave is selected):

##### (1) Set [Repeat]

Set the [Repeat] check box in the [Format (CSI)] dialog box.

**(2) Set Wait time**

Set the Wait time to 0 as a dummy setting in the [Serial window](#).

**(3) Click the [Auto Send] button**

**APPENDIX B USER OPEN INTERFACE**

Appendix B provides detailed explanations of the user open interface that is one of the functions provided by Simulator GUI.


### B.1 Overview

Simulator GUI provides two ways of creating an environment where a target system, as well as a CPU (CPU core + internal peripherals), can be simulated.

One is the [I/O Panel window](#), via which a user-friendly simulation environment can be organized through GUI manipulation, by supplying standard components for connection and their manipulation environment.

The other is to create the simulation environment of the target system that uses the user open interface to be explained in this appendix. In this environment, functions that cannot be realized on the [I/O Panel window](#) can be used if the user programs an external user model.

**Figure B-1. Programming Image of User Model**



### B.1.1 Types of interface functions

Simulator GUI's user open interface supplies the following types of interface functions (see "[B.4 Supplied Interface Functions](#)").

**Table B-1. Types of Functions Supplied by User Open Interface**

Type	Description
Basic interface functions	Basic function of simulation - Initialization notification - Reset notification, etc.
Time interface functions	Cyclic timer function for time-series processing of the user model - Setting of timer - Clearing of timer - Notification of timer time, etc.
Pin interface functions	Pin I/O function - Signal output to pin - Notification of signal input to pin
External bus interface functions <sup>Note</sup>	Slave function of external bus - External bus read access notification - External bus write access notification, etc.
Serial interface functions	Serial transmission/reception function - Transmission of serial data - Notification of reception of serial data, etc.
Signal output unit interface functions	Function to output signals in accordance with signal data file - Signal output in accordance with signal data file, etc.

**Note** When using the external bus interface function, the external memory area to use must be set to [Target memory area] with the [Memory Type] area of the [Memory Mapping dialog box](#).

### B.1.2 Interface methods

Simulator GUI's user open interface has the following interface methods.

#### (1) C language interface

The user open interface consists of a C language API (Application Program Interface) function set. Therefore, program the user model in C language.

#### (2) Callback function method

The user open interface uses the callback function method as a means to call a program from the system. The callback function method is that a program (user model) is called by the system (CPU) when it is necessary. This method uses the pointer to the function which is defined on the program (user model). The system (CPU) calls the user program (user model) by using this pointer. While the provided API functions call the system from the program, the callback function is used to call the program from the system, such as when inputting a signal to a pin.

**(3) Event-driven method**

The user open interface uses an event-driven method in which processing is described in accordance with occurrence of events.

Therefore, a callback function prepared on the user model side is called if an event such as initialization of simulation, resetting the CPU, signal output to a pin, or access to the external bus occurs on the Simulator GUI side. In addition, a time interface (= timer function) provided to perform time-series processing of a user model also calls a callback function prepared on the user model side when the specified time has elapsed.

**B.1.3 Development environment**

Use the following development tools to perform programming with the Simulator GUI's user open interface and create a DLL file.

- Microsoft Visual C++ (Ver. 6.00 or later)


## B.2 Creating User Model

This section describes how to create a user model.

### B.2.1 Program configuration

The following figure shows the program configuration when the Simulator GUI's user open interface is used to expand a system.

**Figure B-2. Program Configuration**



To expand a system, a user model must be created first.

Because the user model operates in conjunction with the simulation system, it interfaces with the user open interface processing module. This interface is the user open interface.

The user model generates resources such as pins and external bus slaves via the user open interface during configuration (processing to configure the simulator that is performed when Simulator GUI is started). By connecting the pins and external bus slaves to the pins and external bus masters of the CPU simulation block, signals can be input to or output from the pins of the CPU simulation block and the external bus can be accessed from the CPU simulation block.


The generated pins and external bus slaves can also be connected to the expansion simulation block (other user models), as well as to the CPU simulation block.

### B.2.2 Outline of programming

The user model is programmed in the dynamic link library (DLL) format of WIN32.

The template of a program file is shown below.

**Figure B-3. Template of Program File**



**Notes 1.** "Configuration" means simulator configuration processing that is executed when Simulator GUI is started.

**2.** An initialization notification is reported only once, immediately after Simulator GUI is started when simulator configuration processing has been completed.

#### (1) File name

Indicates the file name of the user model to be created.

The file name can be determined freely (the suffix for a C language file is ".c").

#### (2) Include file

Indicates a include file.

To use the user open interface, the system header file "suo.h" must be included.

#### (3) Make UserModel function

Indicates the `Make UserModel` function that is called from the system during configuration of Simulator GUI.

Note that the name of this function must be "Make UserModel".

#### [Syntax]

```
SuoUserEntry void Make UserModel (const char *option);
```

The following two types of processing are described in this function.

**(a) Interface generation**

Because Simulator GUI connects pins and buses during configuration processing when it is started, resources such as pins and buses that are to be connected during configuration must be generated.

To do this, call a function that generates an interface in the [MakeUserModel](#) function and generate an interface (see "[B.4 Supplied Interface Functions](#)"). The necessary resources will be also generated.

**(b) Registering callback function**

Callback functions can be registered as necessary.

**Caution** When describing a callback function for initialization, be sure to register it at this time; otherwise callback will not function. This is because initialization notification is reported immediately after the [MakeUserModel](#) function is called.

**(4) Callback function**

Indicates a callback function.

Two or more callback functions, such as those for initialization notification, reset notification, time notification, pin input, and external bus access, can be created. Describe processing in accordance with the callback contents in the callback function (see "[B.5 User-Defined Functions](#)").

A callback function that has been created must be registered in advance so that it can be called from the system (see "[B.4 Supplied Interface Functions](#)"). The name of a callback function can be determined freely, and the format of the function differs depending on the type of callback.

**B.2.3 Example of program file (*UserModel.c*)**

```
#include "suo.h"
#include <memory.h>

void Init(void);
void InputP00(SuoHandle handle, int pinValue);
void ReadBUS1(SuoHandle handle, unsigned long addr, int accessSize, unsigned char data[]);
void WriteBUS1(SuoHandle handle, unsigned long addr, int accessSize, const unsigned char data[]);

SuoHandle p00;
SuoHandle p01;
SuoHandle bus1;
unsigned char mem[0x100];

/* MakeUserModel */
SuoUserEntry void MakeUserModel(const char *option)
{
    SuoCreatePin("P00", &p00);
    SuoCreatePin("P01", &p01);
    SuoCreateExtbus("BUS1", 0x200000, 0x100, &bus1);

    SuoSetInitCallback(Init);
    SuoSetInputDigitalPinCallback(p00, InputP00);
    SuoSetReadExtbusCallback(bus1, ReadBUS1);
    SuoSetWriteExtbusCallback(bus1, WriteBUS1);
}

/* callbacks */
void Init(void)
{
    memset(mem, 0, 0x100);
}

void InputP00(SuoHandle handle, int pinValue)
{
    SuoOutputDigitalPin(p01, pinValue);
}


void ReadBUS1(SuoHandle handle, unsigned long addr, int accessSize, unsigned char data[])
{
    memcpy(data, &mem[addr-0x200000], accessSize);
}

void WriteBUS1(SuoHandle handle, unsigned long addr, int accessSize, const unsigned char data[])
{
    memcpy(&mem[addr-0x200000], data, accessSize);
}
```

#### B.2.4 Compilation and linking

Create a *UserModel.dll* by compiling and linking the created *UserModel.c* and *suolink.cpp*.

**Figure B-4. Flow of Compilation and Linking**



File Name	Description
suo.h	<p>This is a system header file for the user open interface.</p> <p>This file is included by the program (<i>UserModel.c</i>) but is not compiled.</p> <p>Note that "suo.h" is stored in the following folder by default.</p> <p><b>[V850E1][V850ES]</b> - <i>Install-folder</i> \CubeSuite+\DebugTools\DebugTool\V850Simulator\useropen\sys</p> <p><b>[V850E2]</b> - <i>Install-folder</i> \CubeSuite+\DebugTools\DebugTool\V850ERSimulator\useropen\sys</p>
suolink.cpp	<p>This is a file that performs dynamic link processing with the user open interface processing module of the system.</p> <p>Note that "suolink.cpp" is stored in the following folder by default.</p> <p><b>[V850E1][V850ES]</b> - <i>Install-folder</i> \CubeSuite+\DebugTools\DebugTool\V850Simulator\useropen\sys</p> <p><b>[V850E2]</b> - <i>Install-folder</i> \CubeSuite+\DebugTools\DebugTool\V850ERSimulator\useropen\sys</p>
<i>UserModel.c</i>	<p>This is the source file of the user model to be created.</p> <p>The file name can be determined freely.</p>
<i>UserModel.dll</i>	<p>This is a binary file of the user model (DLL file).</p> <p>The file name can be determined freely.</p>

**Caution To execute a DLL file in an environment in which Microsoft Visual C++ is not installed, the DLL file must be created using the release version.**

### B.3 Embedding User Model

This section describes how to embed the created user model (*UserModel.dll*) in Simulator GUI.

To embed the user model in Simulator GUI, use a simulator configuration file (\*.cfg).

Therefore, when using Simulator GUI embedding the created user model, you need to specify [Yes] with the [Use simulator configuration file] property in the [Configuration] category on the [\[Connect Settings\]](#) tab of the [Property panel](#), and then specify the configuration file to be used with the [Simulator configuration file] property in the category same as above.

#### B.3.1 Description in simulator configuration file

Describe the user model generation processing, processing to connect pins and an external buses and so on in the simulator configuration file.

- (1) User model generation processing
- (2) Pin connection
- (3) External bus connection
- (4) Other processing

##### (1) User model generation processing

```
UserModel1 = Device("USEROPEN", "UserModel1.dll UserOption1");
```

###### (a) UserModel1

*UserModel1* is a variable that indicates the generated user model. The variable name can be determined freely by user.

###### (b) Device function

The Device function is used to create a user model.

###### (c) "USEROPEN"

"USEROPEN" is a user open interface processing module (system module).

###### (d) UserModel1.dll

*UserModel1.dll* is the binary file (DLL format) of the user model to be created in ["B.2 Creating User Model"](#).

The file name can be determined freely by user.

Specify a absolute path or relative path from the folder where the simulator configuration file exists as the file path.

**Caution** Do not use single-byte spaces for specifying the path name; otherwise, the user model will not be created.

###### (e) UserOption1

*UserOption1* is an option character string for *UserModel1.dll*. This character string is passed to the "option" parameter of the [MakeUserModel](#) function as is.

**(2) Pin connection**

```

wire1 = Wire(1);                                     --- (a)
wire1 += cpu.Port("PinName1");                      --- (b)
wire1 += UserModel1.Port("UserPinName1");           --- (c)

```

**(a) Generation of a wire**

Generate a wire (= line that connects pins) by using the Wire function.

Be sure to specify "1" for the argument of the Wire function.

*wire1* is a variable that indicates the generated wire. The variable name can be determined freely.

**(b) Connection of the wire and CPU**

Connect one end of the wire to a pin of the CPU.

Specify the name of the external CPU pin to be connected by using uppercase characters, as "*PinName1*" (note that lowercase characters cannot be used). Enclose the pin name between double quotation marks ("").

**(c) Connection of the wire and user model**

Connect the other end of the wire to a pin of the user model.

Specify the name of the user model pin to be connected as "*UserPinName1*" (pin name generated in the [Make UserModel](#) function). Enclose the pin name between double quotation marks ("").

Add this line to connect two or more user model pins to the same wire.

**(3) External bus connection**

```

extbus1 = BUS(n);                                     --- (a)
extbus1 += cpu.BusMasterIF("EXTBUS");                 --- (b)
extbus1 += UserModel1.BusSlaveIF("UserExtbusName1"); --- (c)

```

**(a) Generation of a bus**

Generate a bus by using the BUS function.

Argument *n* of the BUS function is the data bus bit width. This may be 8, 16, or 32.

*extbus1* is a variable that indicates the generated bus. The variable name can be determined freely.

**(b) Connection of the bus and CPU**

Connect one end of the bus to the external bus master of the CPU.

Specify the external bus master "EXTBUS" for the argument.

**(c) Connection of the bus and user model**

Connect the other end of the bus to the external bus of the user model.

Specify the name of the external bus of the user model to be connected as "*UserExtbusName1*" (the external bus name generated in the [Make UserModel](#) function). Enclose the external bus name between double quotation marks ("").

Add this line to connect two or more user model external buses.

**(4) Other processing**

In addition to the above, the formulaic connections for the main clock notification pin and the reset notification pin shown below is required to operate the user open interface.

```

clock1 = Wire(1);                                     --- (a)
clock1 += cpu.DebuggerPseudoPort("debugger_pseudo_pin_main_clkout"); --- (b)
clock1 += UserModel1.Port("gui_pseudo_pin_clock_notice"); --- (c)
reset1 = Wire(1);                                     --- (d)
reset1 += cpu.DebuggerPseudoPort("debugger_pseudo_pin_reset_notice"); --- (e)
reset1 += UserModel1.Port("gui_pseudo_pin_reset_notice"); --- (f)

```

**(a) Generation of a wire**

Generate a wire (= line that connects pins) by using the Wire function.

Be sure to specify "1" for the argument of the Wire function.

*clock1* is a variable that indicates the generated wire. The variable name can be determined freely.

**(b) Connection of the wire and main clock notification pin**

Connect one end of the wire to Simulator GUI's main clock notification pin.

Specify "debugger\_pseudo\_pin\_main\_clkout" for the argument.

**(c) Connection of the wire and user model**

Connect the other end of the wire to a pin of the user model.

Specify "gui\_pseudo\_pin\_clock\_notice" for the argument.

**(d) Generation of a wire**

Generate a wire (= line that connects pins) by using the Wire function.

Be sure to specify "1" for the argument of the Wire function.

*reset1* is a variable that indicates the generated wire. The variable name can be determined freely.

**(e) Connection of the wire and reset notification pin**

Connect one end of the wire to Simulator GUI's reset notification pin.

Specify "debugger\_pseudo\_pin\_reset\_notice" for the argument.

**(f) Connection of the wire and user model**

Connect the other end of the wire to a pin of the user model.

Specify "gui\_pseudo\_pin\_reset\_notice" for the argument.

**B.3.2 Example of simulator configuration file**

An example of the simulator configuration file is shown below.

In this example, the following connection processing is performed.

Type of Connection	CPU		User Model (SampleModel.dll)	
Pin	"P00/INTP0"	P00 pin	"P00"	Pin manipulating P00
	"P30/TXD1"	Serial output pin	"RXD"	Serial input pin
	"P31/RXD1"	Serial input pin	"TXD"	Serial output pin
External bus	"EXTBUS"	External bus master	"EXTBUS1"	External bus slave 1
	"EXTBUS"	External bus master	"EXTBUS2"	External bus slave 2

```
cpu = CPU('a');

# -----
# SampleModel description
# -----


# Generate SampleModel.dll
model = Device("USEROPEN", "SampleModel.dll -a -b");

# Connect PIN (CPU.P00-MODEL.P00)
wire_P00 = Wire(1);
wire_P00 += cpu.Port("P00/INTP0");
wire_P00 += model.Port("P00");

# Connect PIN (CPU.TXD1-MODEL.RXD)
wire_RXD = Wire(1);
wire_RXD += cpu.Port("P30/TXD1");
wire_RXD += model.Port("RXD");

# Connect PIN (CPU.RXD1-MODEL.TXD)
wire_TXD = Wire(1);
wire_TXD += cpu.Port("P31/RXD1");
wire_TXD += model.Port("TXD");

# Connect BUS (CPU.EXTBUS-MODEL.EXTBUS1)
extbus = BUS(32);
extbus += cpu.BusMasterIF("EXTBUS");
extbus += model.BusSlaveIF("EXTBUS1");
extbus += model.BusSlaveIF("EXTBUS2");

# Connect Pseudo PIN
wire_clock = Wire(1);
wire_clock += cpu.DebuggerPseudoPort("debugger_pseudo_pin_main_clkout");
wire_clock += model.Port("gui_pseudo_pin_clock_notice");
wire_reset = Wire(1);
wire_reset += cpu.DebuggerPseudoPort("debugger_pseudo_pin_reset_notice");
wire_reset += model.Port("gui_pseudo_pin_reset_notice");
```

## B.4 Supplied Interface Functions

This section describes the interface functions supplied by Simulator GUI as the user open interface.

### B.4.1 Overview

The supplied interface functions are listed below.

**Table B-2. List of Supplied Interface Functions**

Type	Function Name	Outline of Function
Basic interface functions	SuoSetInitCallback	Registers initialization callback.
	SuoSetResetCallback	Registers reset callback.
	SuoGetMainClock	Acquires the cycle of the main clock for simulation.
Time interface functions	SuoCreateTimer	Generates timer interface.
	SuoGetTimerHandle	Acquires timer handle.
	SuoSetTimer	Sets cyclic timer.
	SuoKillTimer	Stops cyclic timer.
	SuoSetNotifyTimerCallback	Registers timer time notification callback.
Pin interface functions	SuoCreatePin	Generates pin interface.
	SuoGetPinHandle	Acquires pin interface handle.
	SuoOutputDigitalPin	Outputs digital pin value.
	SuoOutputAnalogPin	Outputs analog pin value.
	SuoOutputHighImpedance	Outputs high-impedance for the pin.
	SuoSetInputDigitalPinCallback	Registers digital pin value input callback.
	SuoSetInputAnalogPinCallback	Registers analog pin value input callback.
	SuoSetInputHighImpedanceCallback	Registers pin high-impedance state report callback.
External bus interface functions <sup>Note</sup>	SuoCreateExtbus	Generates external bus interface.
	SuoGetExtbusHandle	Acquires external bus interface handle.
	SuoSetReadExtbusCallback	Registers external bus read access callback.
	SuoSetWriteExtbusCallback	Registers external bus write access callback.

Type	Function Name	Outline of Function
Serial interface functions	SuoCreateSerialUART	Generates serial interface (UART type).
	SuoCreateSerialCSI	Generates serial interface (CSI type).
	SuoGetSerialHandle	Acquires serial interface handle.
	SuoSetSerialParameterUART	Sets serial parameter (UART type).
	SuoSetSerialParameterCSI	Sets serial parameter (CSI type).
	SuoGetSerialParameterUART	Acquires serial parameter (UART type).
	SuoGetSerialParameterCSI	Acquires serial parameter (CSI type).
	SuoSendSerialData	Performs serial transmission (1 data).
	SuoSendSerialDataList	Performs serial transmission (more than one data).
	SuoSendSerialFile	Performs serial transmission (serial transmission data file).
	SuoSetNotifySentSerialCallback	Registers serial transmission end notification callback.
	SuoSetReceiveSerialCallback	Registers serial reception callback.
Signal output unit interface functions	SuoCreateWave	Generates signal output unit interface.
	SuoGetWaveHandle	Acquires signal output unit interface handle.
	SuoSendWaveFile	Performs transmission via signal output unit.
	SuoSetNotifySentWaveCallback	Registers signal output unit transmission end notification callback.

**Note** When using the external bus interface function, the external memory area to use must be set to [Target memory area] with the [Memory Type] area of the [Memory Mapping dialog box](#).

#### B.4.2 Basic interface functions

The basic interface functions that are supplied by Simulator GUI are as follows:

Function Name	Outline of Function
<a href="#">SuoSetInitCallback</a>	Registers initialization callback.
<a href="#">SuoSetResetCallback</a>	Registers reset callback.
<a href="#">SuoGetMainClock</a>	Acquires the cycle of the main clock for simulation.

## SuoSetInitCallback

Registers initialization callback.

**Caution** A callback function is not executed unless this function is called in the [MakeUserModel](#) function.

### [Syntax]

```
#include    "suo.h"  
void      SuoSetInitCallback(SuoInitCallback func);
```

### [Argument(s)]

Argument	Description
<i>func</i>	Pointer to the user-defined function that performs initialization processing (see " <a href="#">InitFunc</a> ")

### [Return value]

None

### [Description]

- This function registers the user-defined function that performs initialization processing.
- The function registered by this function is called only once, when Simulator GUI is started.
- If NULL is specified for *func*, registration is canceled.

### [Example]

```
#include    "suo.h"  
void InitFunc(void);  
  
/* MakeUserModel */  
SuoUserEntry void MakeUserModel(const char *option)  
{  
    .....  
    SuoSetInitCallback(InitFunc);           /* Set initialize function */  
}  
  
/* Initialize function */  
void InitFunc(void){  
    .....  
}
```

## SuoSetResetCallback

Registers reset callback.

### [Syntax]

```
#include    "suo.h"  
void     SuoSetResetCallback(SuoResetCallback func);
```

### [Argument(s)]

Argument	Description
<i>func</i>	Pointer to the user-defined function that performs reset processing (see " <a href="#">ResetFunc</a> ")

### [Return value]

None

### [Description]

- This function registers the user-defined function that performs reset processing.
- The registered function is called when the CPU is reset.
- If NULL is specified for *func*, registration is canceled.

### [Example]

```
#include    "suo.h"  
  
void ResetFunc(void);  
  
void func1(void)  
{  
    .....  
    SuoSetResetCallback(ResetFunc);           /* Set reset function */  
}  
  
/* Reset function */  
void ResetFunc(void){  
    .....  
}
```

## SuoGetMainClock

Acquires the cycle of the main clock for simulation.

**Caution** This function cannot be called in the [MakeUserModel](#) function. It can only be called in a callback function.

### [Syntax]

```
#include    "suo.h"  
int       SuoGetMainClock(unsigned long* time);
```

### [Argument(s)]

Argument	Description
<i>time</i>	Location where the main clock cycle value (unit: pS) is to be stored.

### [Return value]

Macro	Description
SUO_NOERROR	Normal completionNormal completion
<i>Error number</i>	Exit with error (abend) (see " <a href="#">B.4.8 Error numbers</a> ")

### [Description]

- This function is used to acquire the cycle of the main clock for the simulation environment currently being executed.

### [Example]

```
#include    "suo.h"  
  
unsigned long time;  
  
void func1(void)  
{  
    .....  
    SuoGetMainClock(&time);           /* Get main clock */  
}
```

#### B.4.3 Time interface functions

The time interface functions that are supplied by Simulator GUI are as follows:

Function Name	Outline of Function
SuoCreateTimer	Generates timer interface.
SuoGetTimerHandle	Acquires timer handle.
SuoSetTimer	Sets cyclic timer.
SuoKillTimer	Stops cyclic timer.
SuoSetNotifyTimerCallback	Registers timer time notification callback.

## SuoCreateTimer

Generates timer interface.

**Caution** This function can only be called in the [MakeUserModel](#) function. An error occurs if it is called at any other timing.

### [Syntax]

```
#include    "suo.h"
int       SuoCreateTimer(const char* timerName, SuoHandle* handle);
```

### [Argument(s)]

Argument	Description
<i>timerName</i>	Name of the timer
<i>handle</i>	Location where the handle of the timer interface is to be stored

### [Return value]

Macro	Description
SUO_NOERROR	Normal completion
<i>Error number</i>	Exit with error (abend) (see " <a href="#">B.4.8 Error numbers</a> ")

### [Description]

- This function generates a timer interface.
- The generated timer interface is associated with the name specified for *timerName*.
- If this function is successful, the handle of the generated timer interface can be obtained. The timer interface can then be controlled by specifying this handle.
- The handle can also be obtained by using the [SuoGetTimerHandle](#) function.

### [Example]

```
#include    "suo.h"
SuoHandle hTim1;

SuoUserEntry void MakeUserModel(const char *option)
{
    .....
    SuoCreateTimer("TIM1", &hTim1);           /* Create "TIM1" */
}
```

## SuoGetTimerHandle

Acquires timer handle.

### [Syntax]

```
#include    "suo.h"
SuoHandle  SueGetTimerHandle(const char* timerName);
```

### [Argument(s)]

Argument	Description
<i>timerName</i>	Name of the timer

### [Return value]

Macro	Description
<i>Handle of the specified timer interface</i>	Normal completion
NULL	Exit with error (abend)

### [Description]

- This function is used to obtain the handle of the specified timer interface.
- Specify the name specified by the [SuoCreateTimer](#) function as *timerName* (if a different name is specified, NULL is returned).

### [Example]

```
#include    "suo.h"
SuoHandle hTim1;

void func1(void)
{
    .....
    hTim1 = SueGetTimerHandle("TIM1");           /* Get handle of "TIM1" */
}
```

## SuoSetTimer

Sets cyclic timer.

**Caution** This function cannot be called in the [MakeUserModel](#) function. It can only be called in a callback function.

### [Syntax]

```
#include "suo.h"
int SuoSetTimer(SuoHandle handle, int timeUnit, unsigned long timeValue);
```

### [Argument(s)]

Argument	Description
<i>handle</i>	Handle of the timer interface
<i>timeUnit</i>	Time unit (specify any of the following) <ul style="list-style-type: none"> <li>- SUO_MAINCLK : Main clock cycle units</li> <li>- SUO_USEC : Microsecond units</li> </ul>
<i>timeValue</i>	Timer cycle time

### [Return value]

Macro	Description
SUO_NOERROR	Normal completion
<i>Error number</i>	Exit with error (abend) (see " <a href="#">B.4.8 Error numbers</a> ")

### [Description]

- This function sets a cyclic timer for the specified timer interface.
- The cycle time is specified by the value of *timeValue* in units of *timeUnit* ("0" cannot be specified for *timeValue*).
- The timer starts operating immediately after this function is called. The timer continues operating until it is stopped by the [SuoKillTimer](#) function.
- If a timer notification function has been registered by the [SuoSetNotifyTimerCallback](#) function, the timer notification function is called in each cycle.
- If this function is called for the timer that is currently operating, the timer is reset and starts operating with the specified cycle time.

**[Example]**

```
#include    "suo.h"
SuoHandle hTim1;

void func1(void)
{
.....
    SuoSetTimer(hTim1, SUO_USEC, 20);      /* Invoke 20us cyclic timer */
}
```

## SuoKillTimer

Stops cyclic timer.

**Caution** This function cannot be called in the [MakeUserModel](#) function. It can only be called in a callback function.

### [Syntax]

```
#include    "suo.h"
int       SuoKillTimer(SuoHandle handle);
```

### [Argument(s)]

Argument	Description
<i>handle</i>	Handle of the timer interface

### [Return value]

Macro	Description
SUO_NOERROR	Normal completion
<i>Error number</i>	Exit with error (abend) (see " <a href="#">B.4.8 Error numbers</a> ")

### [Description]

- This function stops the cyclic timer of the specified timer interface.
- If the timer is operating, the timer is stopped. If the timer is stopped, nothing is done (in this case, an error does not occur).

### [Example]

```
#include    "suo.h"
SuoHandle hTim1;

void func1(void)
{
    .....
    SuoKillTimer(hTim1);      /* Stop timer */
}
```

## SuoSetNotifyTimerCallback

Registers timer time notification callback.

### [Syntax]

```
#include "suo.h"
int SuoSetNotifyTimerCallback(SuoHandle handle, SuoNotifyTimerCallback func);
```

### [Argument(s)]

Argument	Description
<i>handle</i>	Handle of the timer interface
<i>func</i>	Pointer to the user-defined function that reports the time of the timer (see " <a href="#">NotifyTimerFunc</a> ")

### [Return value]

Macro	Description
SUO_NOERROR	Normal completion
<i>Error number</i>	Exit with error (abend) (see " <a href="#">B.4.8 Error numbers</a> ")

### [Description]

- This function registers a user-defined function that performs processing when the time of the timer is reported.
- The registered function is called in every timer cycle of the specified timer interface.
- If NULL is specified for *func*, registration is canceled.

### [Example]

```
#include "suo.h"
void NotifyTimerFunc(SuoHandle handle);
SuoHandle hTim1;
void func1(void)
{
    .....
    SuoSetNotifyTimerCallback(hTim1, NotifyTimerFunc); /* Set notify-timer function */
}

/* Notify-timer function */
void NotifyTimerFunc(SuoHandle handle)
{
    .....
}
```

**B.4.4 Pin interface functions**

The pin interface functions that are supplied by Simulator GUI are as follows:

Function Name	Outline of Function
SuoCreatePin	Generates pin interface.
SuoGetPinHandle	Acquires pin interface handle.
SuoOutputDigitalPin	Outputs digital pin value.
SuoOutputAnalogPin	Outputs analog pin value.
SuoOutputHighImpedance	Outputs high-impedance for the pin.
SuoSetInputDigitalPinCallback	Registers digital pin value input callback.
SuoSetInputAnalogPinCallback	Registers analog pin value input callback.
SuoSetInputHighImpedanceCallback	Registers pin high-impedance state report callback.

## SuoCreatePin

Generates pin interface.

**Caution** This function can only be called in the [MakeUserModel](#) function. An error occurs if it is called at any other timing.

### [Syntax]

```
#include "suo.h"
int SuoCreatePin(const char* pinName, SuoHandle* handle);
```

### [Argument(s)]

Argument	Description
<i>pinName</i>	Name of the pin
<i>handle</i>	Location where the handle of the pin interface is to be stored

### [Return value]

Macro	Description
SUO_NOERROR	Normal completion
<i>Error number</i>	Exit with error (abend) (see " <a href="#">B.4.8 Error numbers</a> ")

### [Description]

- This function generates a pin interface.
- The generated pin interface is associated with the name specified for *pinName*. Also, the pin specified as *pinName* is generated.
- If this function is successful, the handle of the generated pin interface can be obtained. The pin interface can then be controlled by specifying this handle.

The handle can also be obtained by using the [SuoGetPinHandle](#) function.

### [Example]

```
#include "suo.h"
SuoHandle hPinP00;
SuoHandle hPinABC;

SuoUserEntry void MakeUserModel(const char *option)
{
    .....
    SuoCreatePin("P00", &hPinP00);           /* Create "P00" */
    SuoCreatePin("ABC", &hPinABC);          /* Create "ABC" */
}
```

## SuoGetPinHandle

Acquires pin interface handle.

### [Syntax]

```
#include    "suo.h"
SuoHandle  SueGetPinHandle(const char* pinName);
```

### [Argument(s)]

Argument	Description
<i>pinName</i>	Name of the pin

### [Return value]

Macro	Description
<i>Handle of the specified pin interface</i>	Normal completion
NULL	Exit with error (abend)

### [Description]

- This function is used to obtain the handle of the specified pin interface.
- Specify the name of a function specified by the [SuoCreatePin](#) function as *pinName* (if a different name is specified, NULL is returned).

### [Example]

```
#include    "suo.h"
SuoHandle hPinP00;

void func1(void)
{
    .....
    hPinP00 = SueGetPinHandle("P00");           /* Get handle of "P00" */
}
```

## SuoOutputDigitalPin

Outputs digital pin value.

**Caution** This function cannot be called in the [MakeUserModel](#) function. It can only be called in a callback function.

### [Syntax]

```
#include    "suo.h"
int       SuoOutputDigitalPin(SuoHandle handle, int pinValue);
```

### [Argument(s)]

Argument	Description
<i>handle</i>	Handle of the pin interface
<i>pinValue</i>	Digital output value (specify any of the following) - SUO_HIGH (=1): HIGH value - SUO_LOW (=0): LOW value

### [Return value]

Macro	Description
SUO_NOERROR	Normal completion
<i>Error number</i>	Exit with error (abend) (see " <a href="#">B.4.8 Error numbers</a> ")

### [Description]

- This function outputs a digital data signal specified with *pinValue* to the specified pin interface.
- To output an analog data signal, use the [SuoOutputAnalogPin](#) function.

### [Example]

```
#include    "suo.h"
SuoHandle hPinP00;

void func1(void)
{
    .....
    SuoOutputDigitalPin(hPinP00, SUO_HIGH);      /* Output HIGH */
}
```

## SuoOutputAnalogPin

Outputs analog pin value.

**Caution** This function cannot be called in the [MakeUserModel](#) function. It can only be called in a callback function.

### [Syntax]

```
#include "suo.h"
int SuoOutputAnalogPin(SuoHandle handle, double pinValue);
```

### [Argument(s)]

Argument	Description
<i>handle</i>	Handle of the pin interface
<i>pinValue</i>	Analog output value (unit: V)

### [Return value]

Macro	Description
SUO_NOERROR	Normal completion
<i>Error number</i>	Exit with error (abend) (see " <a href="#">B.4.8 Error numbers</a> ")

### [Description]

- This function outputs an analog data signal specified with *pinValue* to the specified pin interface.
- Specify *pinValue* in V (volts), as floating-point data.
- To output a digital data signal, use the [SuoOutputDigitalPin](#) function.

### [Example]

```
#include "suo.h"
SuoHandle hPinP00;

void func1(void)
{
    .....
    SuoOutputAnalogPin(hPinP00, 3.5); /* Output 3.5V */
}
```

## SuoOutputHighImpedance

Outputs high-impedance for the pin.

**Caution** This function cannot be called in the [MakeUserModel](#) function. It can only be called in a callback function.

### [Syntax]

```
#include    "suo.h"
int       SuoOutputHighImpedance(SuoHandle handle);
```

### [Argument(s)]

Argument	Description
<i>handle</i>	Handle of the pin interface

### [Return value]

Macro	Description
SUO_NOERROR	Normal completion
<i>Error number</i>	Exit with error (abend) (see " <a href="#">B.4.8 Error numbers</a> ")

### [Description]

- This function is used to output high-impedance for the specified digital/analog pin interface.

### [Example]

```
#include    "suo.h"
SuoHandle hPinP00;

void func1(void)
{
    .....
    SuoOutputHighImpedance(hPinP00);      /* Output High Impedance */
}
```

## SuoSetInputDigitalPinCallback

Registers digital pin value input callback.

### [Syntax]

```
#include "suo.h"
int SuoSetInputDigitalPinCallback(SuoHandle handle, SuoInputDigitalPinCallback func);
```

### [Argument(s)]

Argument	Description
<i>handle</i>	Handle of the pin interface
<i>func</i>	Pointer to a user-defined function that performs digital pin input processing (see " <a href="#">InputDigitalPinFunc</a> ")

### [Return value]

Macro	Description
SUO_NOERROR	Normal completion
<i>Error number</i>	Exit with error (abend) (see " <a href="#">B.4.8 Error numbers</a> ")

### [Description]

- This function is used to register a user-defined function that performs digital pin input processing.
- The registered function is called when a signal is input to the specified pin.
- If NULL is specified for *func*, registration is canceled.

### [Example]

```
#include "suo.h"

void InputDigitalPinFunc(SuoHandle handle, int pinValue);
SuoHandle hPinP00;

void func1(void)
{
    .....
    SuoSetInputDigitalPinCallback(hPinP00, InputDigitalPinFunc); /* Set input-digital-pin function */
}

/* Input-digital-pin function */
void InputDigitalPinFunc(SuoHandle handle, int pinValue)
{
    .....
}
```

## SuoSetInputAnalogPinCallback

Registers analog pin value input callback.

### [Syntax]

```
#include    "suo.h"
int      SuoSetInputAnalogPinCallback(SuoHandle handle, SuoInputAnalogPinCallback func);
```

### [Argument(s)]

Argument	Description
<i>handle</i>	Handle of the pin interface
<i>func</i>	Pointer to a user-defined function that performs analog pin input processing (see " <a href="#">InputAnalogPinFunc</a> ")

### [Return value]

Macro	Description
SUO_NOERROR	Normal completion
<i>Error number</i>	Exit with error (abend) (see " <a href="#">B.4.8 Error numbers</a> ")

### [Description]

- This function is used to register a user-defined function that performs analog pin input processing.
- The registered function is called when a signal is input to the specified pin.
- If NULL is specified for *func*, registration is canceled.

### [Example]

```
#include    "suo.h"
void InputAnalogPinFunc(SuoHandle handle, double pinValue);
SuoHandle hPinP00;

void func1(void)
{
    .....
    SuoSetInputAnalogPinCallback(hPinP00, InputAnalogPinFunc); /* Set input-analog-pin function */
}

/* Input-analog-pin function */
void InputAnalogPinFunc(SuoHandle handle, double pinValue)
{
    .....
}
```

## SuoSetInputHighImpedanceCallback

Registers pin high-impedance state report callback.

### [Syntax]

```
#include "suo.h"
int SuoSetInputHighImpedanceCallback(SuoHandle handle, SuoInputHighImpedanceCallback func);
```

### [Argument(s)]

Argument	Description
<i>handle</i>	Handle of the pin interface
<i>func</i>	Pointer to a user-defined function that performs processing when all the connected pins enter the high-impedance state (see " <a href="#">InputHighImpedanceFunc</a> ")

### [Return value]

Macro	Description
SUO_NOERROR	Normal completion
<i>Error number</i>	Exit with error (abend) (see " <a href="#">B.4.8 Error numbers</a> ")

### [Description]

- This function is used to register the user-defined function that performs processing when all the pins connected to digital/analog pins enter the high-impedance state.
- If NULL is specified for *func*, registration is canceled.

### [Example]

```
#include "suo.h"
void InputHighImpedanceFunc(SuoHandle handle);
SuoHandle hPinP00;

void func1(void)
{
    .....
    SuoSetInputHighImpedanceCallback(hPinP00, InputHighImpedanceFunc);
    /* Set input-high-impedance function */
}

/* Input-high-impedance function */
void InputHighImpedanceFunc(SuoHandle handle)
{
    .....
}
```

#### B.4.5 External bus interface functions

The external bus interface functions that are supplied by Simulator GUI are as follows:

Function Name	Outline of Function
SuoCreateExtbus	Generates external bus interface.
SuoGetExtbusHandle	Acquires external bus interface handle.
SuoSetReadExtbusCallback	Registers external bus read access callback.
SuoSetWriteExtbusCallback	Registers external bus write access callback.

**Caution** When using the external bus interface function, the external memory area to use must be set to [Target memory area] with the [Memory Type] area of the [Memory Mapping dialog box](#).

## SuoCreateExbus

Generates external bus interface.

- Cautions**
1. This function can only be called in the [MakeUserModel](#) function. An error occurs if it is called at any other timing.
  2. When using the external bus interface function, the external memory area to use must be set to [Target memory area] with the [Memory Type] area of the [Memory Mapping dialog box](#).

### [Syntax]

```
#include "suo.h"

int SuoCreateExbus(const char* extbusName, unsigned long addr, unsigned long size,
SuoHandle* handle);
```

### [Argument(s)]

Argument	Description
<i>extbusName</i>	Name of the external bus
<i>addr</i>	The first address of the external memory area
<i>size</i>	Size of the external memory area
<i>handle</i>	Location where the handle of the external bus interface is to be stored

### [Return value]

Macro	Description
SUO_NOERROR	Normal completion
<i>Error number</i>	Exit with error (abend) (see " <a href="#">B.4.8 Error numbers</a> ")

### [Description]

- This function is used to generate an external bus interface.
- The generated external bus interface is associated with the name specified for *extbusName*.
- If this function is successful, the handle of the generated external bus interface can be obtained. The external bus interface can then be controlled by specifying this handle.

The handle can also be obtained by using the [SuoGetExbusHandle](#) function.

**[Example]**

```
#include    "suo.h"
SuoHandle hExtbus1;

SuoUserEntry void MakeUserModel(const char *option)
{
    .....
    SuoCreateExtbus("EXTBUS1", 0x200000, 0x1000, &hExtbus1); /* Create "EXTBUS1" */
}
```

## SuoGetExtbusHandle

Acquires external bus interface handle.

### [Syntax]

```
#include    "suo.h"
SuoHandle  SueGetExtbusHandle(const char* extbusName);
```

### [Argument(s)]

Argument	Description
<i>extbusName</i>	Name of the external bus

### [Return value]

Macro	Description
<i>Handle of the specified external bus interface</i>	Normal completion
NULL	Exit with error (abend)

### [Description]

- This function is used to obtain the handle of the specified external bus interface.
- Specify the name specified by the [SuoCreateExtbus](#) function as *extbusName* (if a different name is specified, NULL is returned).

### [Example]

```
#include    "suo.h"
SuoHandle hExtbus1;

void func1(void)
{
    .....
    hExtbus1 = SueGetExtbusHandle("EXTBUS1"); /* Get handle of "EXTBUS1" */
}
```

## SuoSetReadExtbusCallback

Registers external bus read access callback.

### [Syntax]

```
#include "suo.h"
int SuoSetReadExtbusCallback(SuoHandle handle, SuoReadExtbusCallback func);
```

### [Argument(s)]

Argument	Description
<i>handle</i>	Handle of the external bus interface
<i>func</i>	Pointer to a user-defined function that performs read access processing of an external bus (see " <a href="#">ReadExtbusFunc</a> ")

### [Return value]

Macro	Description
SUO_NOERROR	Normal completion
<i>Error number</i>	Exit with error (abend) (see " <a href="#">B.4.8 Error numbers</a> ")

### [Description]

- This function is used to register a user-defined function that performs read access processing of an external bus.
- The registered function is called if a read request is issued to the specified external bus (in the registered address range).
- If NULL is specified for *func*, registration is canceled.

### [Example]

```
#include "suo.h"

void ReadExtbusFunc(SuoHandle handle, unsigned long addr, int accessSize, unsigned char data[]) ;
SuoHandle hExtbus1;

void func1(void)
{
    .....
    SuoSetReadExtbusCallback(hExtbus1, ReadExtbusFunc); /* Set read-external-bus function */
}

/* Read-external-bus function */
void ReadExtbusFunc(SuoHandle handle, unsigned long addr, int accessSize, unsigned char data[])
{
    .....
}
```

## SuoSetWriteExtbusCallback

Registers external bus write access callback.

### [Syntax]

```
#include "suo.h"
int SuoSetWriteExtbusCallback(SuoHandle handle, SuoWriteExtbusCallback func);
```

### [Argument(s)]

Argument	Description
<i>handle</i>	Handle of the external bus interface
<i>func</i>	Pointer to a user-defined function that performs write access processing of an external bus (see " <a href="#">WriteExtbusFunc</a> ")

### [Return value]

Macro	Description
SUO_NOERROR	Normal completion
<i>Error number</i>	Exit with error (abend) (see " <a href="#">B.4.8 Error numbers</a> ")

### [Description]

- This function is used to register a user-defined function that performs write access processing of an external bus.
- The registered function is called when a write request is issued to the specified external bus (in the registered address range).
- If NULL is specified for *func*, registration is canceled.

**[Example]**

```
#include    "suo.h"

void WriteExtbusFunc(SuoHandle handle, unsigned long addr, int accessSize, const unsigned char data[]);

SuoHandle hExtbus1;

void func1(void)
{
    .....
    SuoSetWriteExtbusCallback(hExtbus1, WriteExtbusFunc); /* Set write-external-bus function */
}

/* Write-external-bus function */
void WriteExtbusFunc(SuoHandle handle, unsigned long addr, int accessSize, const unsigned char data[])
{
    .....
}
```

#### B.4.6 Serial interface functions

The serial interface functions that are supplied by Simulator GUI are as follows:

Function Name	Outline of Function
SuoCreateSerialUART	Generates serial interface (UART type).
SuoCreateSerialCSI	Generates serial interface (CSI type).
SuoGetSerialHandle	Acquires serial interface handle.
SuoSetSerialParameterUART	Sets serial parameter (UART type).
SuoSetSerialParameterCSI	Sets serial parameter (CSI type).
SuoGetSerialParameterUART	Acquires serial parameter (UART type).
SuoGetSerialParameterCSI	Acquires serial parameter (CSI type).
SuoSendSerialData	Performs serial transmission (1 data).
SuoSendSerialDataList	Performs serial transmission (more than one data).
SuoSendSerialFile	Performs serial transmission (serial transmission data file).
SuoSetNotifySentSerialCallback	Registers serial transmission end notification callback.
SuoSetReceiveSerialCallback	Registers serial reception callback.

## SuoCreateSerialUART

Generates serial interface (UART type).

**Caution** This function can only be called in the [MakeUserModel](#) function. An error occurs if it is called at any other timing.

### [Syntax]

```
#include "suo.h"
int SuoCreateSerialUART(const char* serialName, const char* pinNameTXD, const char*
pinNameRXD, SuHandle* handle);
```

### [Argument(s)]

Argument	Description
<i>serialName</i>	Name of the serial
<i>pinNameTXD</i>	Name of the transmit data pin used by the serial
<i>pinNameRXD</i>	Name of the receive data pin used by the serial
<i>handle</i>	Location where the handle of the serial interface is to be stored

### [Return value]

Macro	Description
SUO_NOERROR	Normal completion
<i>Error number</i>	Exit with error (abend) (see " <a href="#">B.4.8 Error numbers</a> ")

### [Description]

- This function is used to generate a serial interface (UART type).
- The generated serial interface is associated with the name specified for *serialName*. In addition, pins specified as *pinNameTXD* and *pinNameRXD* are also generated.
- If this function is successful, the handle of the generated serial interface can be obtained. The serial interface can then be controlled by specifying this handle.

The handle can also be obtained by using the [SuoGetSerialHandle](#) function.

**[Example]**

```
#include    "suo.h"
SuoHandle hUart1;

SuoUserEntry void Make UserModel(const char *option)
{
    .....
    SuoCreateSerialUART("UART1", "TXD1", "RXD1", &hUart1); /* Create "UART1" */
}
```

## SuoCreateSerialCSI

Generates serial interface (CSI type).

**Caution** This function can only be called in the [MakeUserModel](#) function. An error occurs if it is called at any other timing.

### [Syntax]

```
#include "suo.h"
int SuoCreateSerialCSI(const char* serialName, const char* pinNameSO, const char*
pinNameSI, const char* pinNameSCK, SuoHandle* handle);
```

### [Argument(s)]

Argument	Description
<i>serialName</i>	Name of the serial
<i>pinNameSO</i>	Name of the transmit data pin used by the serial
<i>pinNameSI</i>	Name of the receive data pin used by the serial
<i>pinNameSCK</i>	Name of the clock pin used by the serial
<i>handle</i>	Location where the handle of the serial interface is to be stored

### [Return value]

Macro	Description
SUO_NOERROR	Normal completion
<i>Error number</i>	Exit with error (abend) (see " <a href="#">B.4.8 Error numbers</a> ")

### [Description]

- This function is used to generate a serial interface (CSI type).
  - The generated serial interface is associated with the name specified for *serialName*. In addition, the pins specified as *pinNameSO*, *pinNameSI*, and *pinNameSCK* are also generated.
  - If this function is successful, the handle of the generated serial interface can be obtained. The serial interface can then be controlled by specifying this handle.
- The handle can also be obtained by using the [SuoGetSerialHandle](#) function.

**[Example]**

```
#include    "suo.h"
SuoHandle hCsil;

SuoUserEntry void MakeUserModel(const char *option)
{
    .....
    SuoCreateSerialCSI("CSI1", "SO1", "SI1", "SCK1", &hCsil); /* Create "CSI1" */
}
```

## SuoGetSerialHandle

Acquires serial interface handle.

### [Syntax]

```
#include    "suo.h"
SuoHandle  SueGetSerialHandle(const char* serialName);
```

### [Argument(s)]

Argument	Description
serialName	Name of the serial

### [Return value]

Macro	Description
<i>Handle of the specified serial interface</i>	Normal completion
NULL	Exit with error (abend)

### [Description]

- This function is used to obtain the handle of the specified serial interface.
- Specify the name specified by the [SuoCreateSerialUART](#) or [SuoCreateSerialCSI](#) function as *serialName* (if a different name is specified, NULL is returned).

### [Example]

```
#include    "suo.h"
SuoHandle hSerial1;

void func1(void)
{
    .....
    hSerial1 = SueGetSerialHandle("SERIAL1");    /* Get handle of "SERIAL1" */
}
```

## SuoSetSerialParameterUART

Sets serial parameter (UART type).

**Caution** This function cannot be called in the [MakeUserModel](#) function. It can only be called in a callback function.

### [Syntax]

```
#include "suo.h"
int SuoSetSerialParameterUART(SuoHandle handle, const SuoSerialParameterUART* param);
```

### [Argument(s)]

Argument	Description
<i>handle</i>	Handle of the serial interface
<i>param</i>	Location where the parameters of the serial interface (UART type) are to be stored Specify a pointer to SuoSerialParameterUART structure <sup>Note</sup> .

**Note** The configuration of SuoSerialParameterUART structure is as follows:

```
typedef struct {
    unsigned long    baudrate;          /* Baud rate */
    int              direction;         /* Transfer direction */
    int              dataLength;        /* Data bit length */
    int              stopLength;        /* Stop bit length */
    int              parity;            /* Parity */
} SuoSerialParameterUART;
```

Parameter (UART Type)	Value	Description
Baud rate	<i>Baud rate value</i>	Unit: bps
Transfer direction	SUO_MSBFIRST	MSB first
	SUO_LSBFIRST	LSB first
Data bit length	1 to 32	-
Stop bit length	1 or 2	-
Parity	SUO_NONEPARITY	No parity
	SUO_ZEROPARITY	0 parity (During transmission: parity 0, During reception: no parity check)
	SUO_ODDPARITY	Odd parity
	SUO_EVENPARITY	Even parity

**[Return value]**

Macro	Description
SUO_NOERROR	Normal completion
<i>Error number</i>	Exit with error (abend) (see " <a href="#">B.4.8 Error numbers</a> ")

**[Description]**

- This function is used to set parameters (UART type) related to the serial operation of the specified serial interface.

The default values of the parameters are as follows:

- Baud rate: 9600 bps
- Transfer direction: LSB first
- Data bit length: 7 bits
- Stop bit length: 1 bit
- Parity: None

**[Example]**

```
#include    "suo.h"
SuoHandle hUart1;

void func1(void)
{
    SuoSerialParameterUART param;
    .....
    param.baudrate    = 19200;           /* 19200 bps */
    param.direction   = SUO_LSBFIRST;    /* LSB First */
    param.dataLength  = 8;              /* databit 8 bit */
    param.stopLength  = 1;              /* stopbit 1 bit */
    param.parity      = SUO_EVENPARITY; /* even parity */
    SuoSetSerialParameterUART(hUart1, &param); /* Set parameter of UART1 */
}
```

## SuoSetSerialParameterCSI

Sets serial parameter (CSI type).

**Caution** This function cannot be called in the [MakeUserModel](#) function. It can only be called in a callback function.

### [Syntax]

```
#include "suo.h"
int SuoSetSerialParameterCSI(SuoHandle handle, const SuoSerialParameterCSI* param);
```

### [Argument(s)]

Argument	Description
<i>handle</i>	Handle of the serial interface
<i>param</i>	Location where the parameters of the serial interface (CSI type) are to be stored Specify a pointer to SuoSerialParameterCSI structure <sup>Note</sup> .

**Note** The configuration of SuoSerialParameterCSI structure is as follows:

```
typedef struct {
    int          mode;           /* Operation mode */
    unsigned long frequency;    /* Frequency of transfer clock */
    int          phase;          /* Phase */
    int          direction;      /* Transfer direction */
    int          datalength;     /* Data bit length */
} SuoSerialParameterCSI;
```

Parameter (CSI Type)	Value	Description	
Operation mode	SUO_MASTER	Master operation	See " <a href="#">Table B-3</a> ."
	SUO_SLAVE	Slave operation	
Frequency of transfer clock	<i>Frequency</i>	Unit: Hz Note that "0" cannot be specified if master operation.	
Phase	0	Normal phase	
	SUO_PRECEDEDATA	Data output first	
	SUO_REVERSECLOCK	Clock reversal	
	SUO_PRECEDEDATA   SUO_REVERSECLOCK	Specifies both data output first and clock reversal.	
Transfer direction	SUO_MSBFIRST	MSB first	
	SUO_LSBFIRST	LSB first	
Data bit length	1 to 32	-	

**Table B-3. CSI Phase Types (SuoSetSerialParameterCSI Function)**

Value of Phase	Phase
0	<p>SCK</p> <p>SO</p> <p>SI input timing</p>
SUO_PRECEDEDATA	<p>SCK</p> <p>SO</p> <p>SI input timing</p>
SUO_REVERSECLOCK	<p>SCK</p> <p>SO</p> <p>SI input timing</p>
SUO_PRECEDEDATA SUO_REVERSECLOCK	<p>SCK</p> <p>SO</p> <p>SI input timing</p>

**[Return value]**

Macro	Description
SUO_NOERROR	Normal completion
<i>Error number</i>	Exit with error (abend) (see "B.4.8 Error numbers")

**[Description]**

- This function is used to set parameters (CSI type) related to the serial operation of the specified serial interface.

The default values of the parameters are as follows:

- Operation mode : Slave
- Frequency of transfer clock : 0
- Phase : Normal phase
- Transfer direction : MSB first
- Data bit length : 8 bits

- When operating as the master for CSI communication, transmission of dummy data is required for reception because the CSI is the communication mode that performs transmission/reception in response to the clock output from the master.

**Remark** If the CSI pin waveform is checked in the [Timing Chart window](#) while CSI communication is not performed, an unexpected level will be monitored.

The expected level will be output after communication starts, so this issue does not affect the actual operation.

- SCK pin (in slave mode) : High level is output (which should be high impedance).
- SO pin : High level is output (which should be low level).

### [Example]

```
#include    "suo.h"

SuoHandle hCsil;
void func1(void)
{
    SuoSerialParameterCSI param;
    .....
    param.mode      = SUO_SLAVE;           /* slave */
    param.frequency = 1000000;            /* 1MHz */
    param.phase     = 0;                 /* normal */
    param.direction = SUO_LSBFIRST;      /* LSB First */
    param.dataLength = 8;                /* databit 8bit */
    SuoSetSerialParameterCSI(hCsil, &param); /* Set parameter of CSII */
}
```

## SuoGetSerialParameterUART

Acquires serial parameter (UART type).

**Caution** This function cannot be called in the [MakeUserModel](#) function. It can only be called in a callback function.

### [Syntax]

```
#include    "suo.h"
int       SuoGetSerialParameterUART(SuoHandle handle, SuoSerialParameterUART* param);
```

### [Argument(s)]

Argument	Description
<i>handle</i>	Handle of the serial interface
<i>param</i>	Location where the parameters of the serial interface (UART type) are to be stored Specify a pointer to SuoSerialParameterUART structure <sup>Note</sup> .

**Note** For details on SuoSerialParameterUART structure, see the [SuoSetSerialParameterUART](#) function.

### [Return value]

Macro	Description
SUO_NOERROR	Normal completion
<i>Error number</i>	Exit with error (abend) (see " <a href="#">B.4.8 Error numbers</a> ")

### [Description]

- This function is used to obtain the parameters (UART type) related to serial operation of the specified serial interface.

### [Example]

```
#include    "suo.h"
SuoHandle hUart1;

void func1(void)
{
    SuoSerialParameterUART param;
    .....
    SuoGetSerialParameterUART(hUart1, &param); /* Get parameter of UART1 */
    .....
}
```

## SuoGetSerialParameterCSI

Acquires serial parameter (CSI type).

**Caution** This function cannot be called in the [MakeUserModel](#) function. It can only be called in a callback function.

### [Syntax]

```
#include "suo.h"
int SuoGetSerialParameterCSI(SuoHandle handle, SuoSerialParameterCSI* param);
```

### [Argument(s)]

Argument	Description
<i>handle</i>	Handle of the serial interface
<i>param</i>	Location where the parameters of the serial interface (UART type) are to be stored Specify a pointer to SuoSerialParameterCSI structure <sup>Note</sup> .

**Note** For details on SuoSerialParameterCSI structure, see the [SuoSetSerialParameterCSI](#) function.

### [Return value]

Macro	Description
SUO_NOERROR	Normal completion
<i>Error number</i>	Exit with error (abend) (see " <a href="#">B.4.8 Error numbers</a> ")

### [Description]

- This function is used to obtain the parameters (CSI type) related to serial operation of the specified serial interface.

### [Example]

```
#include "suo.h"
SuoHandle hCs1;

void func1(void)
{
    SuoSerialParameterCSI param;
    .....
    SuoGetSerialParameterCSI(hCs1, &param); /* Get parameter of CSI1 */
    .....
}
```

## SuoSendSerialData

Performs serial transmission (1 data).

- Cautions**

  1. Be sure to use the [SuoSendSerialDataList](#) function (for serial transmission of multiple data units) when executing continuous UART transmission.
  2. If this function is called using [NotifySentSerialFunc](#) function (serial transmission completion report callback function), transmission start is delayed for half the baud rate cycle of UART.
  3. This function cannot be called in the [MakeUserModel](#) function. It can only be called in a callback function.

### [Syntax]

```
#include    "suo.h"
int      SuoSendSerialData(SuoHandle handle, unsigned long data);
```

### [Argument(s)]

Argument	Description
<i>handle</i>	Handle of the serial interface
<i>data</i>	Transmit data (1 data)

### [Return value]

Macro	Description
SUO_NOERROR	Normal completion
<i>Error number</i>	Exit with error (abend) (see " <a href="#">B.4.8 Error numbers</a> ")

### [Description]

- This function is used to start transmitting one serial data.
- It takes time to complete transmitting the serial data. If you want to know the timing of transmission completion, set the transmission end notification function by using the [SuoSetNotifySentSerialCallback](#) function.
- If this function is called for a serial interface that is currently transmitting data, an error occurs.

### [Example]

```
#include    "suo.h"
SuoHandle hSerial1;

void func1(void)
{
    .....
    SuoSendSerialData(hSerial1, 0x80); /* Send 0x80 */
}
```

## SuoSendSerialDataList

Performs serial transmission (more than one data).

**Caution** This function cannot be called in the [MakeUserModel](#) function. It can only be called in a callback function.

### [Syntax]

```
#include    "suo.h"
int       SuoSendSerialDataList(SuoHandle handle, long count, unsigned long dataList[]);
```

### [Argument(s)]

Argument	Description
<i>handle</i>	Handle of the serial interface
<i>count</i>	Number of data to be transmitted (1 to 32767)
<i>dataList[]</i>	Transmit data Specify an array consisting of the number of data to be transmitted.

### [Return value]

Macro	Description
SUO_NOERROR	Normal completion
<i>Error number</i>	Exit with error (abend) (see " <a href="#">B.4.8 Error numbers</a> ")

### [Description]

- This function is used to start transmitting two or more serial data.
- It takes time to complete transmission of the serial data. If you want to know the timing of transmission completion, set the transmission end notification function by using the [SuoSetNotifySentSerialCallback](#) function.
- If this function is called for a serial interface that is currently transmitting data, an error occurs.

### [Example]

```
#include    "suo.h"
SuoHandle hSerial1;

void func1(void)
{
    unsigned long dataList[6] = { 0x73, 0x65, 0x72, 0x69, 0x61, 0x6c };
    .....
    SuoSendSerialDataList(hSerial1, 6, dataList);           /* Send dataList */
}
```

## SuoSendSerialFile

Performs serial transmission (serial transmission data file).

**Caution** This function cannot be called in the [MakeUserModel](#) function. It can only be called in a callback function.

### [Syntax]

```
#include "suo.h"
int SuoSendSerialFile(SucHandle handle, const char* serialFile);
```

### [Argument(s)]

Argument	Description
<i>handle</i>	Handle of the serial interface
<i>serialFile</i>	Name of the serial transmission data file that has been saved after being edited on the <a href="#">Serial window</a>  Note that if <i>serialFile</i> is specified by a relative path, it is treated as relative to the path of the user model ( <i>UserModel.dll</i> ).

### [Return value]

Macro	Description
SUO_NOERROR	Normal completion
<i>Error number</i>	Exit with error (abend) (see <a href="#">B.4.8 Error numbers</a> )

### [Description]

- This function is used to start transmitting serial data described in a serial transmission data file (\*.ser) that has been saved after being edited on the [Serial window](#).
- It takes time to complete transmission of the serial data. If you want to know the timing of transmission completion, set the transmission end notification function by using the [SuoSetNotifySentSerialCallback](#) function.
- If this function is called for a serial interface that is currently transmitting data, an error occurs.

### [Example]

```
#include "suo.h"
SuoHandle hSerial1;

void func1(void)
{
    .....
    SuoSendSerialFile(hSerial1, "foo.ser"); /* Send serial data on "foo.ser" */
}
```

## SuoSetNotifySentSerialCallback

Registers serial transmission end notification callback.

### [Syntax]

```
#include "suo.h"
int SuoSetNotifySentSerialCallback(SuoHandle handle, SuoNotifySentSerialCallback func);
```

### [Argument(s)]

Argument	Description
<i>handle</i>	Handle of the serial interface
<i>func</i>	Pointer to a user-defined function that performs processing when serial transmission is completed (see " <a href="#">NotifySentSerialFunc</a> ")

### [Return value]

Macro	Description
SUO_NOERROR	Normal completion
<i>Error number</i>	Exit with error (abend) (see " <a href="#">B.4.8 Error numbers</a> ")

### [Description]

- This function is used to register a user-defined function that performs processing when serial transmission is completed.
- The registered function is called when one or more serial data specified to be transmitted have been completely transmitted.
- If NULL is specified for *func*, registration is canceled.

**[Example]**

```
#include    "suo.h"
void NotifySentSerialFunc(SuoHandle handle);
SuoHandle hSerial1;

void func1(void)
{
    .....
    SuoSetNotifySentSerialCallback(hSerial1, NotifySentSerialFunc);
    /* Set notify-sent-serial function */
}

/* Notify-sent-serial function */
void NotifySentSerialFunc(SuoHandle handle)
{
    .....
}
```

## SuoSetReceiveSerialCallback

Registers serial reception callback.

### [Syntax]

```
#include "suo.h"
int SuoSetReceiveSerialCallback(SuoHandle handle, SuoReceiveSerialCallback func);
```

### [Argument(s)]

Argument	Description
<i>handle</i>	Handle of the serial interface
<i>func</i>	Pointer to a user-defined function that performs processing when serial data is received (see " <a href="#">ReceiveSerialFunc</a> ")

### [Return value]

Macro	Description
SUO_NOERROR	Normal completion
<i>Error number</i>	Exit with error (abend) (see " <a href="#">B.4.8 Error numbers</a> ")

### [Description]

- This function is used to register a user-defined function that performs processing when serial data is received.
- The registered function is called when one serial data has been received.
- If NULL is specified for *func*, registration is canceled.

### [Example]

```
#include "suo.h"
void ReceiveSerialFunc(SuoHandle handle, unsigned long data, int status);
SuoHandle hSerial1;

void func1(void)
{
    .....
    SuoSetReceiveSerialCallback(hSerial1, ReceiveSerialFunc);
    /* Set receive-serial function */
}

/* Receive-serial function */
void ReceiveSerialFunc(SuoHandle handle, unsigned long data, int status)
{
    .....
}
```

**B.4.7 Signal output unit interface functions**

The signal output unit interface functions that are supplied by Simulator GUI are as follows:

Function Name	Outline of Function
SuoCreateWave	Generates signal output unit interface.
SuoGetWaveHandle	Acquires signal output unit interface handle.
SuoSendWaveFile	Performs transmission via signal output unit.
SuoSetNotifySentWaveCallback	Registers signal output unit transmission end notification callback.

## SuoCreateWave

Generates signal output unit interface.

**Caution** This function can only be called in the [MakeUserModel](#) function. An error occurs if it is called at any other timing.

### [Syntax]

```
#include "suo.h"
int SuoCreateWave(const char* waveName, int count, const char* pinNameList[], SuHandle* handle);
```

### [Argument(s)]

Argument	Description
<i>waveName</i>	Name of the signal output unit
<i>count</i>	Number of pins used by the signal output unit
<i>pinNameList[]</i>	Names of the pins used by the signal output unit Specify names in an array equivalent to the number of pins.
<i>handle</i>	Location where the handle of the signal output unit interface is to be stored

### [Return value]

Macro	Description
SUO_NOERROR	Normal completion
<i>Error number</i>	Exit with error (abend) (see " <a href="#">B.4.8 Error numbers</a> ")

### [Description]

- This function is used to generate a signal output unit interface.
  - The generated signal output unit interface is associated with the name specified for *waveName*. In addition, the pins specified by *count* and *pinNameList* are also generated.
  - If this function is successful, the handle of the generated signal output unit interface can be obtained. The signal output unit interface can then be controlled by specifying this handle.
- The handle can also be obtained by using the [SuoGetWaveHandle](#) function.

**[Example]**

```
#include    "suo.h"
SuoHandle hWave1;

SuoUserEntry void MakeUserModel(const char *option)
{
    .....
    char* pinNameList[4] = {"P00", "P01", "P02", "P03"};
    SuoCreateWave("WAVE1", 4, pinNameList, &hWave1);           /* Create "WAVE1" */
}
```

## SuoGetWaveHandle

Acquires signal output unit interface handle.

### [Syntax]

```
#include    "suo.h"
SuoHandle  SueGetWaveHandle(const char* waveName);
```

### [Argument(s)]

Argument	Description
waveName	Name of the signal output unit

### [Return value]

Macro	Description
<i>Handle of the signal output unit interface</i>	Normal completion
NULL	Exit with error (abend)

### [Description]

- This function is used to obtain the handle of the specified signal output unit interface.
- Specify the name specified by the [SuoCreateWave](#) function as *waveName* (if a different name is specified, NULL is returned).

### [Example]

```
#include    "suo.h"
SuoHandle hWave1;

void func1(void)
{
    .....
    hWave1 = SueGetWaveHandle("WAVE1");           /* Get handle of "WAVE1" */
}
```

## SuoSendWaveFile

Performs transmission via signal output unit.

**Caution** This function cannot be called in the [MakeUserModel](#) function. It can only be called in a callback function.

### [Syntax]

```
#include "suo.h"
int SuoSendWaveFile(SuoHandle handle, const char* waveFile);
```

### [Argument(s)]

Argument	Description
<i>handle</i>	Handle of the signal output unit interface
<i>waveFile</i>	Name of the signal data file that has been saved after being edited on the <a href="#">Signal Data Editor window</a>  Note that if <i>waveFile</i> is specified by a relative path, it is treated as relative to the path of the user model ( <i>UserModel.dll</i> ).

### [Return value]

Macro	Description
SUO_NOERROR	Normal completion
<i>Error number</i>	Exit with error (abend) (see " <a href="#">B.4.8 Error numbers</a> ")

### [Description]

- This function is used to start transmitting a signal value whose timing is described in a signal data file (\*.wvi) that has been saved after being edited on the [Signal Data Editor window](#).
- It takes time to complete transmitting the signal data file. If you want to know the timing of transmission completion, set the transmission end notification function by using the [SuoSetNotifySentWaveCallback](#) function.
- If this function is called for a signal output unit interface that is currently transmitting data, the data being transmitted is canceled and the newly specified data is transmitted.

### [Example]

```
#include "suo.h"
SuoHandle hWave1;

void func1(void)
{
    .....
    SuoSendWaveFile(hSerial1, "foo.wvi"); /* Send pin data on "foo.wvi" */
}
```

## SuoSetNotifySentWaveCallback

Registers signal output unit transmission end notification callback.

### [Syntax]

```
#include "suo.h"
int SuoSetNotifySentWaveCallback(SuoHandle handle, SuoNotifySentWaveCallback func);
```

### [Argument(s)]

Argument	Description
<i>handle</i>	Handle of the signal output unit interface
<i>func</i>	Pointer to a user-defined function that performs processing when transmission by the signal output unit is completed (see " <a href="#">NotifySentWaveFunc</a> ")

### [Return value]

Macro	Description
SUO_NOERROR	Normal completion
<i>Error number</i>	Exit with error (abend) (see " <a href="#">B.4.8 Error numbers</a> ")

### [Description]

- This function is used to register a user function that performs processing when transmission by the signal output unit is completed.
- The registered function is called when all signal data specified to be transmitted have been completely transmitted.
- If NULL is specified for *func*, registration is canceled.

### [Example]

```
#include "suo.h"

void NotifySentWaveFunc(SuoHandle handle);
SuoHandle hWave1;

void func1(void)
{
    .....
    SuoSetNotifySentWaveCallback(hWave1, NotifySentWaveFunc);
        /* Set notify-sent-wave function */
}
/* Notify-sent-wave function */
void NotifySentWaveFunc(SuoHandle handle)
{
    .....
}
```

#### B.4.8 Error numbers

The meanings of error numbers (macro names) that are returned from the supplied interface function as return values are as follows:

Note that an error number is indicated by a macro name defined by the supplied header file (suo.h).

**Table B-4. List of Error Numbers (Macro Names)**

Error number (Macro Name)	Description
SUO_NOERROR	Normal completion
SUO_CANTALLOC	Memory cannot be allocated.
SUO_ILLIFNAME	The interface name is not correct. NULL or "" is specified for the interface name. Or, an interface name that has not been generated is specified for a handle acquisition function.
SUO_ILLHANDLE	The handle is not correct. A handle other than that of the generated interface is specified.
SUO_ILLPARAM	The argument (parameter) is not correct. A value other than those that can be specified is specified as a argument (parameter).
SUO_CANTCALL	The function cannot be called. A function that can be called only by the <a href="#">MakeUserModel</a> function is called by another function. Or, a function that can be called by a function other than the <a href="#">MakeUserModel</a> function is called by the <a href="#">MakeUserModel</a> function.
SUO_CONFLICTRES	The resources to be generated conflict. Two or more names that are the same as an interface name or pin name generated in the <a href="#">MakeUserModel</a> function exist.
SUO_ILLFILENAME	The file name is not correct. NULL or a name including an invalid character is specified for a file name.
SUO_CANTOPENFILE	The signal data file cannot be opened. The signal data file does not exist, or is not permitted to be read.
SUO_ILLFILEFMT	[Serial transmission data file] The file cannot be opened. The file does not exist, is not permitted to be read, or the file name is not correct. [Signal data file] The file format is not correct. NULL or a name including an invalid character is specified for a file name.
SUO_ILLFILECONT	The file contents are not correct. The contents of data described in the file include a contradiction, or no data exists in the file.
SUO_ILLPINNAME	The pin name is not correct. NULL or "" is specified for the pin name.
SUO_ILLADDR RANGE	The address range is not correct. The address range is not valid.
SUO_UNDERSENDING	Already being transmitted. New transmission cannot be started because transmission is in progress.

## B.5 User-Defined Functions

This section describes the user-defined functions that user creates.

The user-defined functions are listed below.

**Table B-5. List of User-Defined Functions**

Function Name	Outline of Function
MakeUserModel	MakeUserModel entry function
InitFunc	Initialization callback function
ResetFunc	Reset callback function
NotifyTimerFunc	Timer time notification callback function
InputDigitalPinFunc	Digital pin input value callback function
InputAnalogPinFunc	Analog pin input value callback function
InputHighImpedanceFunc	Pin high-impedance state report callback function
ReadExtbusFunc	External bus read access callback function
WriteExtbusFunc	External bus write access callback function
NotifySentSerialFunc	Serial interface transmission end notification callback function
ReceiveSerialFunc	Serial interface reception callback function
NotifySentWaveFunc	Serial interface reception callback function

## MakeUserModel

Creates the resources to be used as the entry function of the user model.

**Caution Because MakeUserModel is a static entry function of the user model, this function name must be used.**

### [Syntax]

```
#include    "suo.h"
SuoUserEntry    void MakeUserModel(const char *option);
```

### [Argument(s)]

Argument	Description
<i>option</i>	Option character string specified in the simulator configuration file Note that if no option is specified in the simulator configuration file, NULL character (" ") is assumed.

### [Return value]

None

### [Description]

- This function must be used to generate the resources to be used with the user model. Any function other than this function cannot generate the resources.
- This function must be used to register a callback function as necessary. In particular, an initialization callback function must be registered by this function (because the initialization timing has passed even if a function is registered by a function other than this function).

**[Example]**

```
#include    "suo.h"
SuoHandle hTim1;
SuoHandle hPinP00;
SuoHandle hExtbus1;

void InitFunc(void);
void ResetFunc(void);

SuoUserEntry void MakeUserModel(const char *option)
{
    /* Create source */
    SuoCreateTimer("TIM1", &hTim1);                      /* Create "TIM1" */
    SuoCreatePin("P00", &hPinP00);                        /* Create "P00" */
    SuoCreateExtbus("EXTBUS1", 0x200000, 0x1000, &hExtbus1); /* Create "EXTBUS1" */

    /* Set callbacks */
    SuoSetInitCallback(InitFunc);                         /* Set initialize function */
    SuoSetResetCallback(ResetFunc);                       /* Set reset function */
}
```

## InitFunc

Performs the initialization processing as a callback function.

**Caution** **InitFunc is a place holder for a user-defined function name, so this function name does not have to be used.**

### [Syntax]

```
#include    "suo.h"  
void      InitFunc (void);
```

### [Argument(s)]

None

### [Return value]

None

### [Description]

- InitFunc describes initialization processing.
- Use the [SuoSetInitCallback](#) function to register InitFunc as a callback function.

## ResetFunc

Performs the reset processing as a callback function.

**Caution** **ResetFunc is a place holder for a user-defined function name, so this function name does not have to be used.**

### [Syntax]

```
#include    "suo.h"  
void      ResetFunc (void);
```

### [Argument(s)]

None

### [Return value]

None

### [Description]

- ResetFunc describes the reset processing.
- Use the [SuoSetResetCallback](#) function to register ResetFunc as a callback function.

## NotifyTimerFunc

Performs the processing when the timer time is reported, as a callback function.

**Caution** **NotifyTimerFunc is a place holder for a user-defined function name, so this function name does not have to be used.**

### [Syntax]

```
#include    "suo.h"  
void     NotifyTimerFunc (SuoHandle handle);
```

### [Argument(s)]

Argument	Description
<i>handle</i>	Handle of the timer interface

### [Return value]

None

### [Description]

- NotifyTimerFunc describes the processing when the timer time is reported.
- Use the [SuoSetNotifyTimerCallback](#) function to register NotifyTimerFunc as a callback function.

## InputDigitalPinFunc

Performs the digital pin input processing, as a callback function.

**Caution** **InputDigitalPinFunc is a place holder for a user-defined function name, so this function name does not have to be used.**

### [Syntax]

```
#include "suo.h"
void InputDigitalPinFunc (SuoHandle handle, int pinValue);
```

### [Argument(s)]

Argument	Description
<i>handle</i>	Handle of the pin interface
<i>pinValue</i>	Digital input value (specify any of the following) - SUO_HIGH (=1): HIGH value - SUO_LOW (=0): LOW value

### [Return value]

None

### [Description]

- InputDigitalPinFunc describes the digital pin input processing.
- Use the [SuoSetInputDigitalPinCallback](#) function to register InputDigitalPinFunc as a callback function.

## InputAnalogPinFunc

Performs the analog pin input processing, as a callback function.

**Caution** **InputAnalogPinFunc is a place holder for a user-defined function name, so this function name does not have to be used.**

### [Syntax]

```
#include "suo.h"  
void InputAnalogPinFunc (SuoHandle handle, double pinValue);
```

### [Argument(s)]

Argument	Description
<i>handle</i>	Handle of the pin interface
<i>pinValue</i>	Value (analog value) input to the pin (unit: V)

### [Return value]

None

### [Description]

- InputAnalogPinFunc describes the analog pin input processing.
- Use the [SuoSetInputAnalogPinCallback](#) function to register InputAnalogPinFunc as a callback function.

## InputHighImpedanceFunc

Performs the processing when all the pins connected to digital/analog pins enter the high-impedance state, as a callback function.

**Caution** InputHighImpedanceFunc is a place holder for a user-defined function name, so this function name does not have to be used.

### [Syntax]

```
#include "suo.h"  
void InputHighImpedanceFunc (SuoHandle handle);
```

### [Argument(s)]

Argument	Description
<i>handle</i>	Handle of the pin interface

### [Return value]

None

### [Description]

- InputHighImpedanceFunc is used to describe the processing when all the pins connected to digital/analog pins enter the high-impedance state.
- Use the [SuoSetInputHighImpedanceCallback](#) function to register InputHighImpedanceFunc as a callback function.

## ReadExtbusFunc

Performs the read access processing of an external bus, as a callback function.

**Caution** **ReadExtbusFunc is a place holder for a user-defined function name, so this function name does not have to be used.**

### [Syntax]

```
#include "suo.h"  
void ReadExtbusFunc (SuoHandle handle, unsigned long addr, int accessSize, unsigned char data[]);
```

### [Argument(s)]

Argument	Description
<i>handle</i>	Handle of the external bus interface
<i>addr</i>	Address
<i>accessSize</i>	Access size
<i>data[]</i>	Data storage area As many data as the access size must be stored.

### [Return value]

None

### [Description]

- ReadExtbusFunc describes the read access processing of an external bus.
- Data must be stored in *data[]*.
- Use the [SuoSetReadExtbusCallback](#) function to register ReadExtbusFunc as a callback function.

## WriteExtbusFunc

Performs the write access processing of an external bus, as a callback function.

**Caution** WriteExtbusFunc is a place holder for a user-defined function name, so this function name does not have to be used.

### [Syntax]

```
#include "suo.h"  
void WriteExtbusFunc (SuoHandle handle, unsigned long addr, int accessSize, const unsigned char  
data[]);
```

### [Argument(s)]

Argument	Description
<i>handle</i>	Handle of the external bus interface
<i>addr</i>	Address
<i>accessSize</i>	Access size
<i>data[]</i>	Data storage area As many data as the access size must be stored.

### [Return value]

None

### [Description]

- WriteExtbusFunc describes the write access processing of an external bus.
- Use the [SuoSetWriteExtbusCallback](#) function to register WriteExtbusFunc as a callback function.

## NotifySentSerialFunc

Performs the processing when transmission by a serial interface has been completed, as a callback function.

**Caution** **NotifySentSerialFunc is a place holder for a user-defined function name, so this function name does not have to be used.**

### [Syntax]

```
#include "suo.h"  
void NotifySentSerialFunc (SuoHandle handle);
```

### [Argument(s)]

Argument	Description
<i>handle</i>	Handle of the serial interface

### [Return value]

None

### [Description]

- NotifySentSerialFunc describes the processing when transmission by a serial interface has been completed.
- Use the [SuoSetNotifySentSerialCallback](#) function to register NotifySentSerialFunc as a callback function.

## ReceiveSerialFunc

Performs the processing during reception by a serial interface, as a callback function.

**Caution** **ReceiveSerialFunc is a place holder for a user-defined function name, so this function name does not have to be used.**

### [Syntax]

```
#include "suo.h"  
void ReceiveSerialFunc (SuoHandle handle, unsigned long data, int status);
```

### [Argument(s)]

Argument	Description
<i>handle</i>	Handle of the serial interface
<i>data</i>	Received serial data
<i>status</i>	Receive status (specify any of the following) - 0 : Normal reception - SUO_PARITYERR : Parity error (if parity bit does not match) - SUO_FRAMINGERR : Framing error (if stop bit is not detected)

### [Return value]

None

### [Description]

- ReceiveSerialFunc describes the processing during reception by a serial interface.
- Use the [SuoSetReceiveSerialCallback](#) function to register ReceiveSerialFunc as a callback function.

## NotifySentWaveFunc

Performs the processing to be performed when transmission by a signal output unit has been completed, as a callback function.

**Caution** **NotifySentWaveFunc is a place holder for a user-defined function name, so this function name does not have to be used.**

### [Syntax]

```
#include    "suo.h"  
void     NotifySentWaveFunc (SuoHandle handle);
```

### [Argument(s)]

Argument	Description
<i>handle</i>	Handle of the signal output unit interface

### [Return value]

None

### [Description]

- NotifySentWaveFunc describes the processing to be performed when transmission by a signal output unit has been completed.
- Use the [SuoSetNotifySentWaveCallback](#) function to register NotifySentWaveFunc as a callback function.

## B.6 Sample Program (Timer Model)

This section describes a sample program (timer model) of a user model created by using the Simulator GUI's user open interface.

### B.6.1 Overview

Timer model is a sample program using a timer interface.


It outputs a value to a pin at fixed time intervals.

### B.6.2 Configuration

The timer model generates the PIN pin and TIM timer.

The generated PIN pin is connected to the PDH pin of the CPU.

**Figure B-5. Timer Model Configuration**




### B.6.3 Operation

The timer model calculates a predetermined time by using the timer interface, and alternately outputs a low level and a high level to the PDH pin.

The output value and output time are as shown below.

**Figure B-6. Timer Model Operation**



### B.6.4 Project file

The following table shows the setting information of the Visual C++ project file of the Timer model.

**Table B-6. Setting Information of Timer Model**

Information	Description
Project type	Win32 Dynamic-Link Library
Source file	suolink.c, uo_timer.c
Path of include file	Folder storing suo.h

### B.6.5 Details of program

The following shows the sample programs of the timer model.

- (1)Source file of timer model (uo\_timer.c)
- (2)Simulator configuration file (smplus.cfg)
- (3)Source file of target program (lm\_timer.c)

#### (1) Source file of timer model (uo\_timer.c)

```
#include <windows.h>
#include "suo.h"

/* Handle */
SuoHandle hTIM;
SuoHandle hPIN;

/* Wave-Table */
#define MAXWAVE 8
struct _WaveTable {
    unsigned longtime;           /* Wait Time [usec] */
    int pinValue;                /* Pin Value (SUO_HIGH or SUO_LOW) */
} waveTable[MAXWAVE] = {
    1000, SUO_HIGH,
    4000, SUO_LOW,
    2000, SUO_HIGH,
    2000, SUO_LOW,
    4000, SUO_HIGH,
    1000, SUO_LOW,
    2000, SUO_HIGH,
    2000, SUO_LOW
};
int waveIndex;

/* Declare */
void Reset(void);
void NotifyTimer(SuoHandle handle);
void puterr(int error);

/* MakeUserModel */
void SuoUserEntry MakeUserModel(const char *option)
{
    int error;
    /* Create interface */
    if((error = SuoCreateTimer("TIM", &hTIM)) != SUO_NOERROR) {
        puterr(error);
        return;
    }
}
```

```
if((error = SuoCreatePin("PIN", &hPIN)) != SUO_NOERROR) {
    puterr(error);
    return;
}

/* Set callback */
SuoSetResetCallback(Reset);
SuoSetNotifyTimerCallback(hTIM, NotifyTimer);
}

/* Reset callback */
void Reset(void)
{
    int error;

    /* Initialize Wave-Tabel index */
    waveIndex = 0;

    /* Output LOW(initial value) to PIN */
    if((error = SuoOutputDigitalPin(hPIN, SUO_LOW)) != SUO_NOERROR) {
        puterr(error);
        return;
    }

    /* Set wait time */
    if((error = SuoSetTimer(hTIM, SUO_USEC, waveTable[waveIndex].time)) != SUO_NOERROR) {
        puterr(error);
        return;
    }
}

/* NotifyTimer callback */
void NotifyTimer(SuoHandle handle)
{
    int error;

    /* Output value to PIN */
    if((error = SuoOutputDigitalPin(hPIN, waveTable[waveIndex].pinValue)) != SUO_NOERROR) {
        puterr(error);
        return;
    }

    /* Set next Wave-Tabel index */
    waveIndex++;
    if(waveIndex >= MAXWAVE) {
        waveIndex = 0;
    }
}
```

```

/* Set wait time */

if((error = SuoSetTimer(hTIM, SUO_USEC, waveTable[waveIndex].time)) != SUO_NOERROR) {
    puterr(error);
    return;
}

/* Report error */
void puterr(int error)
{
    char message[80];
    wsprintf(message, "The user open interface error (0x%04x) occurred.", error);
    MessageBox(NULL, message, "ERROR", MB_OK|MB_ICONERROR);
}

```

## (2) Simulator configuration file (smplus.cfg)

```

cpu = CPU('a');

#=====
# UO_TIMER description (CPU=uPD70F3261Y)
=====

#---- Create UserOpen -----
uo_timer = Device("USEROPEN", "Release\uo_timer.dll");

#---- Pseudo Pin connection -----
wire_clock = Wire(1);
wire_clock += cpu.DebuggerPseudoPort("debugger_pseudo_pin_main_clkout");
wire_clock += uo_timer.Port("gui_pseudo_pin_clock_notice");
wire_reset = Wire(1);
wire_reset += cpu.DebuggerPseudoPort("debugger_pseudo_pin_reset_notice");
wire_reset += uo_timer.Port("gui_pseudo_pin_reset_notice");

#---- PIN connection -----
# UO_TIMER.PIN <--> CPU.PDH0
wire_PIN = Wire(1);
wire_PIN += uo_timer.Port("PIN");
wire_PIN += cpu.Port("PDH0");

```

## (3) Source file of target program (lm\_timer.c)

```
/* Target Program for UO_TIMER */

#pragma ioreg

void main( )
{
    unsigned char value;

    PMDH.0 = 1;           /* set port-input mode */
    PMDH.1 = 0;           /* set port-output mode */

    while( 1 ){
        value = PDH.0;      /* input signal from "PDH0" */
        PDH.1 = value;      /* output signal to "PDH1" */
    }
}
```

## APPENDIX C INDEX

**A**

Access to variables ... 130  
 Action event ... 195, 366, 370, 371  
 Action Events dialog box ... 394  
   [Printf event] tab ... 396  
 Address Offset Settings dialog box ... 405  
 Address range ... 377  
 Analog Button Properties dialog box ... 495  
 Array ... 335, 341  
 Auto variables ... 335

**B**

Basic interface functions ... 555  
   SuoGetMainClock ... 558  
   SuoSetInitCallback ... 556  
   SuoSetResetCallback ... 557  
 Bookmarks dialog box ... 402  
 Boot block cluster ... 31  
 Boot swap ... 30, 262  
 Break ... 45, 58, 70, 79, 87  
 Break cause ... 358  
 Break event ... 128  
 Breakpoint ... 125  
 Built-in event ... 370, 371

**C**

Call stack information ... 352  
 Call Stack panel ... 352  
 Callback function ... 542  
 Clock ... 20, 38, 51, 64, 83  
 Code ... 313  
 Collect execution history of programs ... 164  
   Clear the trace memory ... 178  
   Collect execution history from the start to stop of the  
     execution ... 171  
   Collect execution history in the arbitrary section  
     ... 171

Collect execution history when the condition is met

... 173

Configure the trace operation ... 164

Display collected execution history ... 176

Save the contents of execution history ... 183

Search the trace data ... 178

Column Number Settings dialog box ... 404

Configuration ... 84

Configure the trace operation ... 164

Connect to/disconnect from debug tool ... 89

Control register ... 148, 320

Coverage Measurement ... 190

  Configure the coverage measurement ... 190

  Display the coverage measurement result ... 193

CPU Register panel ... 320

Current PC mark ... 312

Current PC position ... 283, 312

Customize dialog box ... 462

**D**

Data flash emulation function ... 32  
 Data flash memory ... 20, 37, 50, 63, 75, 235, 300  
 Data Save dialog box ... 427  
 DCU ... 237  
 Debug information ... 273  
 Debug Manager panel ... 224  
 Debug toolbar ... 219  
 Delete a break event ... 130  
 Disassemble display mode ... 177, 359  
 Disassemble panel ... 310  
 Disassembled text ... 113, 310  
 Display and change programs ... 105  
   Display source files ... 105  
   Display the result of disassembling ... 113  
   Perform line assembly ... 117  
 Display format of watch-expression ... 344  
 Display information on function call from stack ... 162  
   Display call stack information ... 162

Save the contents of call stack information ... 163  
 Display/change the memory, register and variable ... 135  
   Display/change global variables/static variables  
   ... 153  
   Display/change local variables ... 153  
   Display/change the CPU register ... 148  
   Display/change the I/O register ... 150  
   Display/change the memory ... 135  
   Display/change watch-expression ... 155  
 DMA ... 360  
 DMM function ... 142  
 Download ... 33, 92, 271  
 Download condition ... 97, 381, 384  
 Download Files dialog box ... 381

**E**

Editor panel ... 277  
 EEPROM Library ... 32  
 Encoding dialog box ... 399  
 Event area ... 282, 312  
 Event mark ... 365  
 Event type ... 365  
 Events panel ... 363  
 Execute programs ... 120  
   Execute programs ... 121  
   Execute programs in steps ... 122  
   Reset microcontroller (CPU) ... 121  
 External bus interface functions ... 575  
   SuoCreateExtbus ... 576  
   SuoGetExtbusHandle ... 578  
   SuoSetReadExtbusCallback ... 579  
   SuoSetWriteExtbusCallback ... 580  
 External flash memory ... 100  
 External Flash Memory Download dialog box ... 384  
 External flash memory information file ... 100, 384

**F**

Fail-safe break function ... 26, 133  
 Features ... 8  
 File monitor ... 286  
 Flash ... 40, 54, 66, 77

Flash macro service ... 260  
 Flash Options Setting dialog box ... 387  
 Flash self programming emulation function ... 28, 259  
 Font ... 432  
 Format (CSI) dialog box ... 537  
 Format (UART) dialog box ... 535

**G**

Global variable ... 153  
 Go to Here ... 122  
 Go to Line dialog box ... 425  
 Go to the Location dialog box ... 426

**H**

HALT mode ... 247  
 Hardware Break ... 126, 365  
 Hook transaction ... 275  
 Hot plug-in ... 90  
 Hot plug-in function ... 218  
 How to connect to debug tool ... 89  
 How to disconnect from debug tool ... 89

**I**

I/O Panel window ... 482  
 I/O protection area ... 377  
 InitFunc ... 611  
 Initial value ... 407  
 Input format of watch-expression ... 342  
 InputAnalogPinFunc ... 615  
 InputDigitalPinFunc ... 614  
 InputHighImpedanceFunc ... 616  
 Instruction level debugging ... 105  
 Instrunction level debugging ... 105, 277  
 Interface functions ... 553  
   Basic interface functions ... 555  
   External bus interface functions ... 575  
   Pin interface functions ... 566  
   Serial interface functions ... 582  
   Signal output unit interface functions ... 601  
   Time interface functions ... 559  
 Internal Static variables ... 335  
 IOR panel ... 328

**L**

Label ... 358  
 Label name ... 313  
 Line assembly ... 117, 314  
 Load module file ... 92  
 Local variable ... 153  
 Local Variables panel ... 334  
 Loop dialog box ... 471

**M**

Macro service error ... 29  
 Main window ... 216  
 MakeUserModel ... 609  
 Manage events ... 198  
     Change the setting state of the event ... 198  
     Delete events ... 200  
     Delete the set events ... 200  
     Display only particular event types ... 199  
     Event types that can be set and deleted during execution ... 202  
     Jump to the event address ... 199  
     Maximum number of enabled events ... 200  
 Mask for input signal ... 27, 28, 45, 46, 59, 60, 71, 72, 80, 100  
 Maximum number of enabled events ... 200  
 Measure Execution Time of the Program ... 185  
     Measurable time ranges ... 188  
     Measure execution time from the start to stop of the execution ... 185  
     Measure execution time in the arbitrary section ... 186  
 Measurement of the execution time of the program ... 185  
 Memory access ... 24, 43, 56, 69, 79, 86  
 Memory Initialize dialog box ... 407  
 Memory mapping ... 23, 42, 56, 68, 78, 86  
 Memory Mapping dialog box ... 375  
 Memory Search dialog box ... 409  
 Memory settings ... 23, 86  
 Memory type ... 376  
 Menubar ... 217

Mixed display mode ... 106, 177, 359  
 Move to ... 110  
 Move to the specified address ... 114  
 Move to the symbol defined location ... 115

**N**

NotifySentSerialFunc ... 619  
 NotifySentWaveFunc ... 621  
 NotifyTimerFunc ... 613

**O**

Offset value ... 313, 358  
 On-chip debug unit ... 39, 65, 237  
 Open break function ... 249  
 Open File dialog box ... 446  
 Open Option Setting File dialog box ... 452  
 Open Watch Expression Data File dialog box ... 442  
 Operating environment ... 17  
 Option bytes ... 389  
 Option dialog box ... 430  
     [General - Build/Debug] category ... 437  
     [General - Font and Color] category ... 432  
 Output panel ... 372

**P**

Parts Button Properties dialog box ... 491  
 Parts Buzzer Properties dialog box ... 519  
 Parts Key Properties dialog box ... 499  
 Parts Led Properties dialog box ... 508  
 Parts Level Gauge Properties dialog box ... 504  
 Parts List dialog box ... 529  
 Parts Matrix Led Properties dialog box ... 515  
 Parts Segment LED Properties dialog box ... 511  
 PE ... 224  
 Pin interface functions ... 566  
     SuoCreatePin ... 567  
     SuoGetPinHandle ... 568  
     SuoOutputAnalogPin ... 570  
     SuoOutputDigitalPin ... 569  
     SuoOutputHighImpedance ... 571  
     SuoSetInputAnalogPinCallback ... 573  
     SuoSetInputDigitalPinCallback ... 572

- SuoSetInputHighImpedanceCallback ... 574
- Point Trace ... 365, 366
- Pointer type variable ... 341
- Pointer variables ... 335
- Print Address Range Settings dialog box ... 411
- Print Preview window ... 413
- Printf ... 365, 366
- Printf event ... 195, 396
- Processor element ... 224
- Program register ... 148, 320
- Programmable I/O area ... 22, 41, 55, 67, 77, 85, 240
- Progress Status dialog box ... 429
- Project Tree panel ... 226
- Property panel ... 228
- [Flash Options Settings] tab ... 274
  - [Connect Settings] tab ... 230
  - [Data Flash Emulation Settings] tab ... 268
  - [Debug Tool Settings] tab ... 242
  - [Download File Settings] tab ... 271
  - [Flash Self Emulation Eettings] tab ... 259
  - [Hook Transaction Settings] tab ... 275
- Pseudo RRM function ... 140
- Pull up/Pull down dialog box ... 523
- R**
- Rapid build function ... 116
- ReadExtbusFunc ... 617
- Read-protected object ... 330
- Real-time display update function ... 139
- ReceiveSerialFunc ... 620
- Recycle mode ... 108
- Register variables ... 335
- Registering a watch-expression ... 156
- Reset ... 121
- Reset vector ... 262, 30
- ResetFunc ... 612
- Return out execution ... 124, 219, 220
- RRM function ... 139
- Run-Break time ... 185
- Run-Break Timer ... 365, 366
- Run-Break Timer event ... 185
- S**
- Sample program ... 622
- Save As dialog box ... 448
- Save Option Setting File dialog box ... 454
- Save Settings dialog box ... 400
- Scope specification ... 153
- Scroll Range Settings dialog box ... 423
- Search Data dialog box ... 480
- Security flag emulation ... 30, 261
- Security ID ... 239, 389
- Select Data Save File dialog box ... 450
- Select Download File dialog box ... 440
- Select Flash Memory Information File dialog box ... 444
- Select Pin dialog box ... 472
- Select Simulator Configuration File dialog box. ... 456
- Serial interface functions ... 582
- SuoCreateSerialCSI ... 585
  - SuoCreateSerialUART ... 583
  - SuoGetSerialHandle ... 587
  - SuoGetSerialParameterCSI ... 594
  - SuoGetSerialParameterUART ... 593
  - SuoSendSerialData ... 595
  - SuoSendSerialDataList ... 596
  - SuoSendSerialFile ... 597
  - SuoSetNotifySentSerialCallback ... 598
  - SuoSetReceiveSerialCallback ... 600
  - SuoSetSerialParameterCSI ... 590
  - SuoSetSerialParameterUART ... 588
- Serial transmission data file ... 531
- Serial window ... 531
- Set action into the program ... 195
- Inset printf ... 195
- Set PC to Here ... 122
- Settable mapping attribute ... 377
- Setting state of the event ... 199
- Signal Data Editor window ... 464
- Signal data file ... 464
- Signal output unit interface functions ... 601
- SuoCreateWave ... 602
  - SuoGetWaveHandle ... 604
  - SuoSendWaveFile ... 605

- SuoSetNotifySentWaveCallback ... 606  
 Simulator GUI window ... 458  
 Smart edit function ... 286  
 Software Break ... 126, 365  
 Source display mode ... 177, 359  
 Source level debugging ... 277  
 Start Tracing ... 365  
 Statusbar ... 221  
 Step execution ... 122  
 Step in execution ... 123, 219, 220  
 Step over execution ... 123, 219, 220  
 Stop programs ... 125  
   Access to variables ... 130  
   Manually stop the execution ... 125  
   Stop at the arbitrary position ... 125  
 Structure ... 335, 341  
 Summary ... 8  
 SuoCreateExtbus ... 576  
 SuoCreatePin ... 567  
 SuoCreateSerialCSI ... 585  
 SuoCreateSerialUART ... 583  
 SuoCreateTimer ... 560  
 SuoCreateWave ... 602  
 SuoGetExtbusHandle ... 578  
 SuoGetMainClock ... 558  
 SuoGetPinHandle ... 568  
 SuoGetSerialHandle ... 587  
 SuoGetSerialParameterCSI ... 594  
 SuoGetSerialParameterUART ... 593  
 SuoGetTimerHandle ... 561  
 SuoGetWaveHandle ... 604  
 SuoKillTimer ... 564  
 SuoOutputAnalogPin ... 570  
 SuoOutputDigitalPin ... 569  
 SuoOutputHighImpedance ... 571  
 SuoSendSerialData ... 595  
 SuoSendSerialDataList ... 596  
 SuoSendSerialFile ... 597  
 SuoSendWaveFile ... 605  
 SuoSetInitCallback ... 556  
 SuoSetInputAnalogPinCallback ... 573  
 SuoSetInputDigitalPinCallback ... 572  
 SuoSetInputHighImpedanceCallback ... 574  
 SuoSetNotifySentSerialCallback ... 598  
 SuoSetNotifySentWaveCallback ... 606  
 SuoSetNotifyTimerCallback ... 565  
 SuoSetReadExtbusCallback ... 579  
 SuoSetReceiveSerialCallback ... 600  
 SuoSetResetCallback ... 557  
 SuoSetSerialParameterCSI ... 590  
 SuoSetSerialParameterUART ... 588  
 SuoSetTimer ... 562  
 SuoSetWriteExtbusCallback ... 580  
 System register ... 148
- T**
- Tag jump ... 112, 285, 373  
 Target board ... 22  
 Targets that can be registered as watch-expressions ... 156  
 Text Edit dialog box ... 393  
 Time interface functions ... 559  
   SuoCreateTimer ... 560  
   SuoGetTimerHandle ... 561  
   SuoKillTimer ... 564  
   SuoSetNotifyTimerCallback ... 565  
   SuoSetTimer ... 562  
 Timer ... 87  
 Timer end ... 365  
 Timer end event ... 186  
 Timer Result ... 365, 366  
 Timer Result event ... 186  
 Timer start ... 365  
 Timer start event ... 186  
 Timing chart file ... 474  
 Timing Chart window ... 474  
 Trace end event ... 171  
 Trace event ... 171  
 Trace frame ... 170  
 Trace memory ... 166, 169, 252  
 Trace number ... 357  
 Trace panel ... 356

Trace Search dialog box ... 415

[Instruction Level] tab ... 417

[Source Level] tab ... 420

Trace start ... 365

Trace start event ... 171

Trace time tag ... 253

Type of breakpoint ... 248

## U

Unconditional Trace ... 365, 366

Unconditional Trace event ... 171, 199

Union ... 335, 341

Upload ... 92, 103, 104

Use hook function ... 206

User model ... 544

User open interface ... 541

User-defined functions ... 608

InitFunc ... 611

InputAnalogPinFunc ... 615

InputDigitalPinFunc ... 614

InputHighImpedanceFunc ... 616

MakeUserModel ... 609

NotifySentSerialFunc ... 619

NotifySentWaveFunc ... 621

NotifyTimerFunc ... 613

ReadExtbusFunc ... 617

ReceiveSerialFunc ... 620

ResetFunc ... 612

WriteExtbusFunc ... 618

## W

Watch panel ... 339

Watch-expression ... 155, 339

Window reference ... 213

WriteExtbusFunc ... 618

## Revision Record

Rev.	Date	Description	
		Page	Summary
1.00	Feb 01, 2013	-	First Edition issued

---

CubeSuite+ V2.00.00 User's Manual:  
V850 Debug

Publication Date: Rev.1.00      Feb 01, 2013

Published by:      Renesas Electronics Corporation

---

**SALES OFFICES****Renesas Electronics Corporation**<http://www.renesas.com>

Refer to "<http://www.renesas.com/>" for the latest and detailed information.

**Renesas Electronics America Inc.**

2880 Scott Boulevard Santa Clara, CA 95050-2554, U.S.A.  
Tel: +1-408-588-6000, Fax: +1-408-588-6130

**Renesas Electronics Canada Limited**

1101 Nicholson Road, Newmarket, Ontario L3Y 9C3, Canada  
Tel: +1-905-898-5441, Fax: +1-905-898-3220

**Renesas Electronics Europe Limited**

Dukes Meadow, Millboard Road, Bourne End, Buckinghamshire, SL8 5FH, U.K.  
Tel: +44-1628-651-700, Fax: +44-1628-651-804

**Renesas Electronics Europe GmbH**

Arcadiastrasse 10, 40472 Düsseldorf, Germany  
Tel: +49-211-65030, Fax: +49-211-6503-1327

**Renesas Electronics (China) Co., Ltd.**

7th Floor, Quantum Plaza, No.27 ZhiChunLu Haidian District, Beijing 100083, P.R.China  
Tel: +86-10-8235-1155, Fax: +86-10-8235-7679

**Renesas Electronics (Shanghai) Co., Ltd.**

Unit 204, 205, AZIA Center, No.1233 Lujiazui Ring Rd., Pudong District, Shanghai 200120, China  
Tel: +86-21-5877-1818, Fax: +86-21-6887-7858 / -7898

**Renesas Electronics Hong Kong Limited**

Unit 1601-1613, 16/F., Tower 2, Grand Century Place, 193 Prince Edward Road West, Mongkok, Kowloon, Hong Kong  
Tel: +852-2886-9318, Fax: +852 2886-9022/9044

**Renesas Electronics Taiwan Co., Ltd.**

13F, No. 363, Fu Shing North Road, Taipei, Taiwan  
Tel: +886 2-8175-9600, Fax: +886 2-8175-9670

**Renesas Electronics Singapore Pte. Ltd.**

80 Bendemeer Road, Unit #06-02 Hyflux Innovation Centre Singapore 339949  
Tel: +65-6213-0200, Fax: +65-6213-0300

**Renesas Electronics Malaysia Sdn.Bhd.**

Unit 906, Block B, Menara Amcorp, Amcorp Trade Centre, No. 18, Jln Persiaran Barat, 46050 Petaling Jaya, Selangor Darul Ehsan, Malaysia  
Tel: +60-3-7955-9390, Fax: +60-3-7955-9510

**Renesas Electronics Korea Co., Ltd.**

11F., Samik Lavied' or Bldg., 720-2 Yeoksam-Dong, Kangnam-Ku, Seoul 135-080, Korea  
Tel: +82-2-558-3737, Fax: +82-2-558-5141

CubeSuite+ V2.00.00



Renesas Electronics Corporation

R20UT2446EJ0100