

To our customers,

---

## Old Company Name in Catalogs and Other Documents

---

On April 1<sup>st</sup>, 2010, NEC Electronics Corporation merged with Renesas Technology Corporation, and Renesas Electronics Corporation took over all the business of both companies. Therefore, although the old company name remains in this document, it is a valid Renesas Electronics document. We appreciate your understanding.

Renesas Electronics website: <http://www.renesas.com>

April 1<sup>st</sup>, 2010  
Renesas Electronics Corporation

Issued by: Renesas Electronics Corporation (<http://www.renesas.com>)

Send any inquiries to <http://www.renesas.com/inquiry>.

## Notice

1. All information included in this document is current as of the date this document is issued. Such information, however, is subject to change without any prior notice. Before purchasing or using any Renesas Electronics products listed herein, please confirm the latest product information with a Renesas Electronics sales office. Also, please pay regular and careful attention to additional and different information to be disclosed by Renesas Electronics such as that disclosed through our website.
2. Renesas Electronics does not assume any liability for infringement of patents, copyrights, or other intellectual property rights of third parties by or arising from the use of Renesas Electronics products or technical information described in this document. No license, express, implied or otherwise, is granted hereby under any patents, copyrights or other intellectual property rights of Renesas Electronics or others.
3. You should not alter, modify, copy, or otherwise misappropriate any Renesas Electronics product, whether in whole or in part.
4. Descriptions of circuits, software and other related information in this document are provided only to illustrate the operation of semiconductor products and application examples. You are fully responsible for the incorporation of these circuits, software, and information in the design of your equipment. Renesas Electronics assumes no responsibility for any losses incurred by you or third parties arising from the use of these circuits, software, or information.
5. When exporting the products or technology described in this document, you should comply with the applicable export control laws and regulations and follow the procedures required by such laws and regulations. You should not use Renesas Electronics products or the technology described in this document for any purpose relating to military applications or use by the military, including but not limited to the development of weapons of mass destruction. Renesas Electronics products and technology may not be used for or incorporated into any products or systems whose manufacture, use, or sale is prohibited under any applicable domestic or foreign laws or regulations.
6. Renesas Electronics has used reasonable care in preparing the information included in this document, but Renesas Electronics does not warrant that such information is error free. Renesas Electronics assumes no liability whatsoever for any damages incurred by you resulting from errors in or omissions from the information included herein.
7. Renesas Electronics products are classified according to the following three quality grades: “Standard”, “High Quality”, and “Specific”. The recommended applications for each Renesas Electronics product depends on the product’s quality grade, as indicated below. You must check the quality grade of each Renesas Electronics product before using it in a particular application. You may not use any Renesas Electronics product for any application categorized as “Specific” without the prior written consent of Renesas Electronics. Further, you may not use any Renesas Electronics product for any application for which it is not intended without the prior written consent of Renesas Electronics. Renesas Electronics shall not be in any way liable for any damages or losses incurred by you or third parties arising from the use of any Renesas Electronics product for an application categorized as “Specific” or for which the product is not intended where you have failed to obtain the prior written consent of Renesas Electronics. The quality grade of each Renesas Electronics product is “Standard” unless otherwise expressly specified in a Renesas Electronics data sheets or data books, etc.
  - “Standard”: Computers; office equipment; communications equipment; test and measurement equipment; audio and visual equipment; home electronic appliances; machine tools; personal electronic equipment; and industrial robots.
  - “High Quality”: Transportation equipment (automobiles, trains, ships, etc.); traffic control systems; anti-disaster systems; anti-crime systems; safety equipment; and medical equipment not specifically designed for life support.
  - “Specific”: Aircraft; aerospace equipment; submersible repeaters; nuclear reactor control systems; medical equipment or systems for life support (e.g. artificial life support devices or systems), surgical implantations, or healthcare intervention (e.g. excision, etc.), and any other applications or purposes that pose a direct threat to human life.
8. You should use the Renesas Electronics products described in this document within the range specified by Renesas Electronics, especially with respect to the maximum rating, operating supply voltage range, movement power voltage range, heat radiation characteristics, installation and other product characteristics. Renesas Electronics shall have no liability for malfunctions or damages arising out of the use of Renesas Electronics products beyond such specified ranges.
9. Although Renesas Electronics endeavors to improve the quality and reliability of its products, semiconductor products have specific characteristics such as the occurrence of failure at a certain rate and malfunctions under certain use conditions. Further, Renesas Electronics products are not subject to radiation resistance design. Please be sure to implement safety measures to guard them against the possibility of physical injury, and injury or damage caused by fire in the event of the failure of a Renesas Electronics product, such as safety design for hardware and software including but not limited to redundancy, fire control and malfunction prevention, appropriate treatment for aging degradation or any other appropriate measures. Because the evaluation of microcomputer software alone is very difficult, please evaluate the safety of the final products or system manufactured by you.
10. Please contact a Renesas Electronics sales office for details as to environmental matters such as the environmental compatibility of each Renesas Electronics product. Please use Renesas Electronics products in compliance with all applicable laws and regulations that regulate the inclusion or use of controlled substances, including without limitation, the EU RoHS Directive. Renesas Electronics assumes no liability for damages or losses occurring as a result of your noncompliance with applicable laws and regulations.
11. This document may not be reproduced or duplicated, in any form, in whole or in part, without prior written consent of Renesas Electronics.
12. Please contact a Renesas Electronics sales office if you have any questions regarding the information contained in this document or Renesas Electronics products, or if you have any other inquiries.

(Note 1) “Renesas Electronics” as used in this document means Renesas Electronics Corporation and also includes its majority-owned subsidiaries.

(Note 2) “Renesas Electronics product(s)” means any product developed or manufactured by or for Renesas Electronics.

8

# CPUBD-38004F

H8S Super Low Power CPU Board

Microcomputer Development Environment System

# User's Manual

2004.01



## **CPUBD-38004F – CPU Board for H8/300L Super Low Power Series Microcomputer User's Manual**

Published by : Renesas System Solutions Asia Pte. Ltd.

Date : January 6<sup>th</sup>, 2004, Version 2.0

Copyright(C) Renesas System Solutions Asia Pte. Ltd. All rights reserved.

### **Trademarks**

#### a) General

All brand or product names used in this manual are trademarks or registered trademarks of their respective companies or organizations.

#### b) Specific

Microsoft, MS and MS-DOS is registered trademark.

Windows and Windows NT are trademarks of Microsoft Corporation.

Pentium is a registered trademark of Intel.

## IMPORTANT INFORMATION

- **READ this user's manual before using this emulator product.**
- **KEEP the user's manual handy for future reference.**

**Do not attempt to use the product until you fully understand its mechanism.**

### **CPUBD:**

Throughout this document, the term "CPUBD" shall be defined as the H8S Super Low Power Series Low-cost CPU Board, CPUBD-38004F produced only by Renesas System Solutions Asia Pte. Ltd. excludes all subsidiary products. The user system or a host computer is not included in this definition.

### **Purpose of the Product:**

This product is a development-supporting unit for use as training and evaluation tool. The product must only be used for the above purpose.

### **Improvement Policy:**

Renesas System Solutions Asia Pte. Ltd. (hereafter collectively referred to as Renesas) pursues a policy of continuing improvement in design, performance, and safety of the emulator product. Renesas reserves the right to change, wholly or partially, the specifications, design, user's manual, and other documentation at any time without notice.

### **Target User of the Product:**

This product should only be used by those who have carefully read and thoroughly understood the information as well as restrictions contained in the user's manual. Do not attempt to use the product until you fully understand its mechanism.

It is highly recommended that first-time user be instructed by users that are well versed in the operation of emulator product.

## LIMITED WARRANTY

RENESAS warrants its products to be manufactured in accordance with published specifications and free from defects in material and/or workmanship. The foregoing warranty does not cover damage caused by fair wear and tear, abnormal store condition, incorrect use, accidental misuse, abuse, neglect, corruption, misapplication, addition or modification or by the use with other hardware or software, as the case may be, with which the product is incompatible. No warranty of fitness for a particular purpose is offered. The user assumes the entire risk of using the product. Any liability of RENESAS is limited exclusively to the replacement of defective materials or workmanship.

## DISCLAIMER

RENESAS MAKES NO WARRANTIES, EITHER EXPRESS OR IMPLIED, ORAL OR WRITTEN, EXCEPT AS PROVIDED HEREIN, INCLUDING WITHOUT LIMITATION THEREOF, WARRANTIES AS TO MARKETABILITY, MECHRCHANTABILITY, FITNESS FOR ANY PARTICULAR PURPOSE OR USE, OR AGAINST INFRINGEMENT OF ANY PATENT. IN NO EVENT SHALL RENESAS BE LIABLE FOR ANY DIRECT, INCIDENTAL OR CONSEQUENTIAL DAMAGES OF ANY NATURE, OR LOSSES OR EXPENSES RESULTING FROM ANY DEFECTIVE EMULATOR PRODUCT, THE USE OF ANY EMULATOR PRODUCT OR ITS DOCUMENTATION, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGES. EXCEPT AS EXPRESSLY STATED OTHERWISE IN THIS WARRANTY, THIS EMULATOR PRODUCT IS SOLD "AS IS". AND YOU MUST ASSUME ALL RISK FOR THE USE AND RESULTS OBTAINED FROM THE EMULATOR PRODUCT.

**State Law:**

Some states do not allow the exclusion or limitation of implied warranty or liability for incidental or consequential damages, so the above limitation or exclusion may not apply to you. This warranty gives you specific legal rights, and you may have other rights which may vary from state to state.

**The Warranty is Void in the Following Cases:**

Renesas shall have no liability or legal responsibility for any problems caused by misuse, abuse, misapplication, neglect, improper handling, installation, repair or modifications of the emulator product without Renesas's prior written consent or any problems caused by the user system.

**Restrictions:**

1. Earthing (applies only to manual for Renesas hardware products)  
This hardware is designed for use with equipment that is fully earthed.  
Ensure that all equipments used are appropriately earthed.  
Failure to do so could lead to danger for the operator or damaged to equipments.
2. Electrostatic Discharge Precautions (applies only to manuals for Renesas hardware products)  
This hardware contains devices that are sensitive to electrostatic discharge.  
Ensure appropriate precautions are observed during handling and accessing connections.  
Failure to do so could result in damage to the equipment.

**All Right Reserved:**

This user's manual and emulator product are copyrighted and all rights are reserved by Renesas. No part of this user's manual, all or part, may be reproduced or duplicated in any form, in hardcopy or machine-readable form, by any means available without Renesas's prior written consent.

**Other Important Things to Keep in Mind:**

1. Circuitry and other examples described herein are meant merely to indicate the characteristics and performance of Renesas Technology's semiconductor products. Renesas assumes no responsibility for any intellectual property claims or other problems that may result from applications based on the examples described herein.
2. No license is granted by implication or otherwise under any patents or other rights of any third party or Renesas.
3. MEDICAL APPLICATIONS: Renesas Technology's products are not authorized for use in MEDICAL APPLICATIONS without the written consent of the appropriate officer of Renesas Technology (Asia Sales company). Such use includes, but is not limited to, use in life support systems. Buyers of Renesas Technology's products are requested to notify the relevant Renesas Technology (Asia Sales offices) when planning to use the products in MEDICAL APPLICATIONS.

**Figures:**

Some figures in this user's manual may show items different from your actual system.

**Limited Anticipation of Danger:**

Renesas cannot anticipate every possible circumstance that might involve a potential hazard. The warnings in this user's manual and on the emulator product are therefore not all inclusive. Therefore, you must use the emulator product safely at your own risk.



# PREFACE

## **About this manual**

This manual explains how to install and setup the H8/38004F CPU board for evaluating the performance of the H8/38004F microcomputer. Hereafter, the H8/38004F CPU board shall term as 'CPUBD'.

Operation using the HEW pure debugger is also detailed in the manual.

### **1. Introduction**

Gives an introduction about the CPU board, package, specification and functions.

### **2. Installation**

Explains how to install the hardware and accompanied software to a host computer.

### **3. Setup of HEW (Pure Debugger) for CPU Board**

Describes the setup steps before embarking on a new project development.

### **4. Performing Emulation**

Describes the various functions available in HEW

### **5. Usage Constraints**

Highlights the various constraints that may encounter by user when operating the CPU board.

### **6. Hardware**

Explains the various hardware blocks in the CPU board.

### **7. Monitor software**

Explains the purpose of the monitor software, the implementation requirements and how to use the monitor software.

### **8. Flash Programming**

Explains the difference between two programming modes and how CPU board operates in these modes.

### **9. Tutorial**

Provides a step-by-step guide in using the CPU board to perform debugging.

### **10. Demonstration Program**

Provides two demonstration programs for user to have hands-on experience with the CPU board.

## 11. Trouble-Shooting

Advises on some basic fault finding methods and commonly make mistakes.

Appendix A - CPUBD-38004F Board Layout

Appendix B – H8/38004F Memory Map

Appendix C – Pin Assignment for JP1 ~ JP4

Appendix D - Pin assignment for CON1 & CON2

Appendix E – Schematic drawings

Appendix G – Bill of Materials

### **Technical Support**

The CPUBD is a product for evaluation purposes only. We do NOT supply the same level of support as for the development tools, however, you may contact the sales offices for downloads and documents.

### **Related Manuals:**

H8S, H8/300 series C/C++ Compiler, Assembler, Optimizing Linkage Editor User's Manual

H8/38004 Series, H8/38004F-ZTAT™ Series Hardware Manual

# Table of Contents

<b>SECTION 1. INTRODUCTION.....</b>	<b>1</b>
1.1. SPECIFICATION.....	2
1.1.1. General.....	2
1.1.2. Serial Communication .....	2
1.1.3. Power Input.....	2
1.1.4. Memory Map.....	2
1.1.5. Interface with Application Board.....	2
1.1.6. Interface with E10T/ E7 emulator.....	2
1.1.7. Monitor software.....	2
1.2. CPUBD FUNCTIONAL BLOCKS.....	3
1.3. PACKAGE .....	5
1.3.1. Hardware Components .....	5
1.3.2. Software Components .....	5
1.4. SUMMARY OF CPUBD-38004F FUNCTIONS .....	6
<b>SECTION 2. INSTALLATION.....</b>	<b>7</b>
2.1. LABEL OF PARTS ON CPU BOARD .....	7
2.2. INSTALLING THE CPU BOARD .....	8
2.3. COMMUNICATION PORT BAUD RATE .....	8
2.4. POWER SUPPLY FOR CPU BOARD.....	9
2.5. JUMPERS OPTIONS.....	9
2.5.1. Operating Voltage Selection Jumpers for MCU.....	10
2.5.2. Power Supply Selection Jumpers for MCU.....	10
2.5.3. Boot Mode Selection Jumpers.....	10
2.5.4. User Mode [Standalone] Selection Jumpers [Default] .....	11
2.5.5. User Mode – Interface with Application Board Selection Jumpers.....	11
2.5.6. Serial Communication Enable Jumpers.....	12
2.5.7. E10T/ E7 Emulation Selection Jumpers.....	12
2.5.8. Optional Jumpers.....	12
2.6. INSTALLATION OF HEW (PURE DEBUGGER) FOR CPU BOARD .....	13
<b>SECTION 3. SETUP OF HEW (PURE DEBUGGER) FOR CPU BOARD.....</b>	<b>18</b>
3.1. RUNNING HEW (PURE DEBUGGER) FOR CPU BOARD .....	18
3.2. CREATING A NEW WORKSPACE .....	19
3.3. SELECTING THE TARGET (DEBUG SETTINGS).....	22
<b>SECTION 4. PERFORMING EMULATION.....</b>	<b>23</b>
4.1. HIGH-PERFORMANCE EMBEDDED WORKSHOP .....	23
4.2. COMPILER CONFIGURATION & DEBUGGER SESSION.....	25
4.3. DEBUG SETTINGS .....	27
4.4. CONNECTING & DISCONNECTING WITH THE EMULATOR .....	27
4.5. EMULATOR SETTING .....	28
4.5.1. Configure Platform .....	28
4.5.1.1. Standalone Flash .....	29
4.5.2. Memory Mapping.....	31
4.6. VIEWING OF PROGRAM .....	33
4.6.1. Source Code level.....	33
4.6.2. Disassembly level.....	34

4.7.	MCU RELATED INFORMATION .....	35
4.7.1.	<i>Registers</i> .....	35
4.7.2.	<i>Memory</i> .....	36
4.7.3.	<i>I/O</i> .....	36
4.7.4.	<i>Status</i> .....	37
4.7.4.1.	<i>Status - Memory</i> .....	37
4.7.4.2.	<i>Status - Platform</i> .....	38
4.7.4.3.	<i>Status - Events</i> .....	38
4.7.5.	<i>Symbol</i> .....	39
4.7.5.1.	<i>Label</i> .....	39
4.7.5.2.	<i>Watch</i> .....	40
4.7.5.3.	<i>Local</i> .....	41
4.7.6.	<i>Break Functions</i> .....	42
4.7.7.	<i>Stack Trace</i> .....	43
4.8.	MCU MEMORY MANIPULATION .....	44
4.9.	EXECUTION OF MCU CODE .....	45
4.9.1.	<i>Reset CPU</i> .....	45
4.9.2.	<i>Go, Reset Go, Goto Cursor, Set PC to Cursor, Run</i> .....	46
4.9.3.	<i>Step Functions</i> .....	47
4.10.	C-SOURCE LEVEL DEBUGGING .....	49
<b>SECTION 5. USAGE PRECAUTIONS .....</b>		<b>50</b>
5.1.	CORRUPTION OF MONITOR SOFTWARE .....	50
5.2.	INTERRUPT .....	50
5.3.	WATCHDOG TIMER .....	50
5.4.	TIMING ISSUES .....	51
5.5.	SOFTWARE BREAKPOINT .....	51
5.6.	STEP .....	51
5.7.	POWER-DOWN MODES .....	52
5.8.	SCI3 .....	52
5.9.	E10T/ E7 INTERFACE .....	52
5.10.	OTHER CONSTRAINTS .....	52
<b>SECTION 6. HARDWARE .....</b>		<b>53</b>
6.1.	H8/38004F MICROCOMPUTER .....	53
6.2.	POWER SUPPLY CIRCUITRY .....	53
6.3.	RESET CIRCUITRY .....	53
6.4.	CLOCK CIRCUITRY .....	54
6.5.	SERIAL COMMUNICATION BLOCK [VIA SCI3] .....	54
6.6.	FLASH ROM & RAM .....	54
6.7.	LEDs .....	54
6.8.	BOOT MODE ENABLE .....	54
6.9.	E10T/ E7 INTERFACE .....	55
6.10.	EXTERNAL USER INTERFACE .....	55
<b>SECTION 7. MONITOR SOFTWARE .....</b>		<b>56</b>
7.1.	INTRODUCTION TO MONITOR SOFTWARE .....	56
7.2.	PROGRAM DEVELOPMENT .....	56
7.3.	MONITOR SOFTWARE REQUIREMENTS .....	56
7.4.	MODE TRANSITION .....	57
7.5.	USING MONITOR SOFTWARE .....	58
7.6.	INTERRUPTS USED BY THE MONITOR .....	58

7.7.	BREAKPOINTS .....	59
<b>SECTION 8.</b>	<b>FLASH PROGRAMMING.....</b>	<b>60</b>
8.1.	FLASH PROGRAMMING THE CPUBD .....	60
8.1.1.	<i>Boot Mode:</i> .....	60
8.1.2.	<i>User Mode:</i> .....	61
8.2.	OPERATION DURING PROGRAMMING KERNEL EXECUTION .....	61
<b>SECTION 9.</b>	<b>TUTORIAL (300L_TUT).....</b>	<b>63</b>
9.1.	INTRODUCTION .....	63
9.2.	OVERVIEW .....	63
9.3.	TUTORIAL SETUP .....	66
9.3.1.	<i>Downloading the tutorial Program</i> .....	66
9.3.2.	<i>Displaying the Program Listing</i> .....	69
9.4.	USING BREAKPOINTS .....	71
9.4.1.	<i>Setting a Program Count (PC) Breakpoint</i> .....	71
9.4.2.	<i>Executing the Program</i> .....	72
9.4.3.	<i>Reviewing the Breakpoints</i> .....	74
9.4.4.	<i>Examining MCU Registers</i> .....	75
9.5.	EXAMINING MEMORY AND VARIABLES .....	76
9.5.1.	<i>Viewing Memory</i> .....	76
9.5.2.	<i>Watching Variables</i> .....	77
9.6.	STEPPING THROUGH A PROGRAM.....	79
9.7.	WATCHING LOCAL VARIABLES.....	80
9.8.	SAVES THE SESSION .....	81
9.9.	WHAT NEXT?.....	81
<b>SECTION 10.</b>	<b>DEMONSTRATION PROGRAM .....</b>	<b>82</b>
10.1.	BLINKING LEDES .....	82
10.2.	RUNNING LEDES .....	83
<b>SECTION 11.</b>	<b>TROUBLE-SHOOTING .....</b>	<b>84</b>
<b>APPENDIX A</b>	<b>CPUBD-38004F BOARD LAYOUT .....</b>	<b>85</b>
<b>APPENDIX B</b>	<b>H8/38004F MEMORY MAP.....</b>	<b>87</b>
<b>APPENDIX C</b>	<b>PIN ASSIGNMENT FOR JP1~JP4 .....</b>	<b>88</b>
<b>APPENDIX D</b>	<b>PIN ASSIGNMENT FOR CON1 &amp; CON2 .....</b>	<b>89</b>
<b>APPENDIX E</b>	<b>CPUBD-38004F SCHEMATIC DRAWINGS.....</b>	<b>91</b>
<b>APPENDIX F</b>	<b>BILL OF MATERIALS .....</b>	<b>92</b>
<b>RENESAS TECHNOLOGY (ASIA SALES OFFICES)</b>	<b>.....</b>	<b>93</b>

## Figures & Tables

FIGURE 1.1	H8/38004F CPU BOARD [CPUBD-38004F].....	1
FIGURE 1.2	CPU BOARD FUNCTIONAL BLOCKS.....	3
FIGURE 1.3	CPUBD-38004F PACKAGE.....	5
FIGURE 2.1	NAMES OF PARTS ON CPU BOARD.....	7
FIGURE 2.2	SERIAL COMMUNICATION CONNECTIONS.....	8
FIGURE 2.3	POWER CONNECTOR & DC PLUG.....	9
FIGURE 2.4	RUN DIALOGUE BOX.....	13
FIGURE 2.5	HEW FOR CPUBD INSTALLER WELCOME! SCREEN.....	13
FIGURE 2.6	UPDATE INFORMATION (README) DIALOGUE BOX.....	14
FIGURE 2.7	SELECT DESTINATION DIRECTORY SCREEN.....	14
FIGURE 2.8	SELECT COMPONENTS.....	15
FIGURE 2.9	DIRECTORY CONFIRMATION SCREEN.....	16
FIGURE 2.10	INSTALLING SCREEN.....	16
FIGURE 2.11	COMPLETION SCREEN.....	17
FIGURE 3.1	HEW (PURE DEBUGGER) FOR CPUBD ICON.....	18
FIGURE 3.2	SELECT PLATFORM DIALOGUE BOX.....	19
FIGURE 3.3	HEW START-UP WINDOW (WITHOUT TOOLCHAIN).....	19
FIGURE 3.4	SELECT TARGET.....	20
FIGURE 3.5	DEBUGGER SETTING SUMMARY WINDOW.....	21
FIGURE 3.6	SELECT PLATFORM DIALOGUE BOX.....	22
FIGURE 4.1	HIGH-PERFORMANCE EMBEDDED WORKSHOP WINDOW.....	23
FIGURE 4.2	TOOLBAR SHOWING THE SESSION AND CONFIGURATION.....	25
FIGURE 4.3	TOOLBAR SHOWING THE SESSIONS AND CONFIGURATIONS AVAILABLE.....	25
FIGURE 4.4	OPTION - EMULATOR.....	28
FIGURE 4.5	TARGET CONFIGURATION DIALOGUE BOX.....	28
FIGURE 4.6	ENABLING STANDALONE FLASH OPTION.....	29
FIGURE 4.7	DIALOGUE BOX FOR DOWNLOADING USER TARGET PROGRAM.....	29
FIGURE 4.8	DIALOGUE BOX FOR RUNNING USER TARGET PROGRAM.....	30
FIGURE 4.9	MEMORY MAPPING DIALOGUE BOX.....	31
FIGURE 4.10	TARGET MEMORY CONFIGURATION DIALOGUE.....	32
FIGURE 4.11	SOURCE LEVEL.....	33
FIGURE 4.12	DISASSEMBLY WINDOW.....	34
FIGURE 4.13	VIEW - CPU.....	35
FIGURE 4.14	REGISTER.....	35
FIGURE 4.15	SET MEMORY.....	36
FIGURE 4.16	INPUT AND OUTPUT REGISTER.....	36
FIGURE 4.17	STATUS – MEMORY WINDOW.....	37
FIGURE 4.18	STATUS – PLATFORM WINDOW.....	38
FIGURE 4.19	STATUS – EVENTS WINDOW.....	38
FIGURE 4.20	VIEW - SYMBOL.....	39
FIGURE 4.21	LABEL.....	39
FIGURE 4.22	WATCH.....	40
FIGURE 4.23	LOCALS.....	41
FIGURE 4.24	TOOLTIP.....	41
FIGURE 4.25	VIEW CODE.....	42
FIGURE 4.26	STACK TRACE.....	43
FIGURE 4.27	MEMORY FUNCTIONS.....	44
FIGURE 4.28	DEBUG FUNCTIONS.....	45

FIGURE 4.29	STEP PROGRAM .....	47
FIGURE 4.30	STEP MODE .....	48
FIGURE 5.1	TIMING DIAGRAM OF HEW .....	51
FIGURE 7.1	MODE TRANSITION DIAGRAM.....	57
FIGURE 8.1	OVERVIEW OF BOOT MODE .....	61
FIGURE 8.2	OVERVIEW OF USER MODE .....	62
FIGURE 9.1	DEBUG SETTINGS WITH LOAD OBJECT FILE DIALOGUE .....	67
FIGURE 9.2	CONFIGURE LOAD OBJECT FILE DIALOGUE .....	67
FIGURE 9.3	DOWNLOAD THE SELECTED OBJECT FILE .....	68
FIGURE 9.4	SOURCE-WINDOW “RESETPRG.C” .....	69
FIGURE 9.5	SOURCE-WINDOW “300L_TUT.C” .....	70
FIGURE 9.6	SETTING A BREAKPOINT .....	71
FIGURE 9.7	PROGRAM BREAK .....	72
FIGURE 9.8	SYSTEM STATUS WINDOW .....	73
FIGURE 9.9	BREAKPOINTS WINDOW .....	74
FIGURE 9.10	POPUP IN BREAKPOINTS WINDOW.....	74
FIGURE 9.11	CPU REGISTERS WINDOW .....	75
FIGURE 9.12	CHANGING REGISTER VALUE.....	75
FIGURE 9.13	OPEN MEMORY-WINDOW .....	76
FIGURE 9.14	MEMORY-WINDOW .....	76
FIGURE 9.15	INSTANT WATCH DIALOGUE BOX.....	77
FIGURE 9.16	WATCH WINDOW .....	77
FIGURE 9.17	ADD WATCH DIALOGUE BOX .....	78
FIGURE 9.18	WATCH WINDOW .....	78
FIGURE 9.19	DISPLAYING INDIVIDUAL ELEMENTS IN AN ARRAY .....	78
FIGURE 9.20	EXECUTING UP TO A FUNCTION CALL .....	79
FIGURE 9.21	LOCALS WINDOW .....	80
FIGURE 9.22	DISPLAYING INDIVIDUAL ELEMENTS IN AN ARRAY .....	80
TABLE 2.1	LIST OF JUMPERS.....	9
TABLE 2.2	OPERATING VOLTAGE SELECTION JUMPERS FOR MCU .....	10
TABLE 2.3	POWER SUPPLY SELECTION JUMPERS FOR MCU .....	10
TABLE 2.4	BOOT MODE SELECTION JUMPERS .....	10
TABLE 2.5	USER MODE [STANDALONE] SELECTION JUMPERS [DEFAULT].....	11
TABLE 2.6	USER MODE - INTERFACE WITH APPLICATION BOARD SELECTION JUMPERS .....	11
TABLE 2.7	BOOT MODE SELECTION JUMPERS .....	12
TABLE 2.8	E10T/ E7 EMULATION SELECTION JUMPERS .....	12
TABLE 2.9	BOOT MODE SELECTION JUMPERS .....	12
TABLE 4.1	TYPES OF BREAKS ENCOUNTERED DURING EMULATION .....	42
TABLE 7.1	INTERRUPTS USED BY MONITOR PROGRAM .....	58

## Section 1. Introduction

H8/38004F CPU board (CPUBD-38004F) is a low cost training and MCU performance evaluation tool for the H8/300L Super Low Power family series of microcomputers.

It is also implemented with flash programming feature for the H8/38004 F-ZTAT microcomputer. It contains a QFP-64A package H8/38004F microcomputer on the board.

The H8/38004F CPU board adopts the common HEW that also contains a pure debugger as the user interface.

The diagram below shows the H8/38004F CPU Board:




Figure 1.1 H8/38004F CPU Board [CPUBD-38004F]

## 1.1. Specification

### 1.1.1. General

- H8/38004F microcomputer (using HD64F38004H FP-64A device)
- 32Kbytes of FLASH memory (Monitor software uses approx. 6Kbytes)
- 1Kbytes of on-chip RAM (Monitor software work area uses 1Kbytes)
- Two user LED indicators
- One push button for reset control
- One boot mode LED indicator
- One Power LED indicator
- All Input/Output signals are being pulled out for user connection via CON1 & CON2

### 1.1.2. Serial Communication

- Utilizes Serial Communication Interface 3 via RS-232 DB-9F socket and RS-232 transceiver chip.
- Supports communication at a baud rate of 38,400bps [non-configurable during debugging].

### 1.1.3. Power Input

- Accept dual DC power supply at +7.5 volt. ~ +9.0 volt only. [Ripple Rejection ratio more than 60dbm]

### 1.1.4. Memory Map

- If the CPUBD is to be used with debugger, a section in the memory area is reserved for monitor software. See Appendix B for memory map diagrams.

### 1.1.5. Interface with Application Board

- It is designed to interface with any application board via two 30x2pin connector sockets.
- It can be interfaced with the H8/3800 application board (APPBD – 3800) for immediate evaluation. [For information about H8/3800 application board (APPBD – 3800), please contact the sales office.]

### 1.1.6. Interface with E10T/ E7 emulator

- Supports E10T and E7 emulator.

### 1.1.7. Monitor software

- A FLASH-resident debugging monitor software hosted on the CPUBD for performing debugging operations.

## 1.2. CPUBD Functional Blocks

The CPUBD comprises of a H8/38004F microcomputer, serial port, and boot mode control and user interface.




Figure 1.2 CPU Board Functional Blocks

The boot mode circuitry is necessary to place the CPUBD into Boot mode for programming the FLASH. To enter into Boot mode, respective jumper headers on the CPUBD must be shorted. SCI3 is used to program the board's on-chip flash memory, using the flash programming software built-into the HEW with pure debugger. If the user is not using the serial port for flash programming the CPUBD or debugging, this serial port is available to user by switching jumpers J4 and J5.

The HEW with pure debugger software combined with the monitor software programmed into the device provides high level debugging via SCI3.

When connecting external analogue signals, it is important that CPUBD is configured properly with respect to analogue voltage supply and reference. There are two user LEDs on board that can be used by user for their evaluation and are driven directly by the MCU.

All the I/O signals are being tracked out to four 2x10-way straight header connectors for user access as well as to two 2x30-way sockets to allow connection to a target board. These I/O signals are available to user if either flash programming or debugging is not used.

### 1.3. Package

The CPUBD is supplied in a package containing the following components:



Figure 1.3 CPUBD-38004F Package

#### 1.3.1. Hardware Components

The hardware components included in the package are listed below.

- 1 x H8/38004F CPU Board
- 1 x RS-232 Serial cable
- 1 x DC Power Input Jack free-end cable
- 1 x 7x2pin connector [not assembled]
- 2 x 30x2pin connectors [not assembled]
- 

#### 1.3.2. Software Components

1 x CD ROM containing HEW installer, User's Manual, Tutorial program Source code, Schematic drawings

Before proceeding, user has to check that all the items listed in the packing list. Please contact the relevant Renesas Technology sales office in Asia if any item is missing.

## 1.4. Summary of CPUBD-38004F functions

Items	Specifications
Supported Microcomputers	<ul style="list-style-type: none"> <li>▪ H8/38004F</li> </ul>
Operating Frequency	<ul style="list-style-type: none"> <li>▪ 9.8304MHz (System clock)</li> <li>▪ 32.768KHz (Sub clock)</li> </ul>
Supported Operating Voltage	3.3 Volt. and 5 Volt. Only*1
Host Machine	<ul style="list-style-type: none"> <li>▪ Recommended Pentium™ III or equivalent processor PC</li> <li>▪ Recommended 128Mbytes RAM and 100Mbytes hard disk space</li> <li>▪ Microsoft Windows 98, Windows Me, Windows NT 4.0, Windows 2000 or Windows XP</li> <li>▪ One Serial port</li> </ul>
Host Interface	<ul style="list-style-type: none"> <li>▪ RS-232 Serial Interface</li> <li>▪ Baud rate @ 38,400 bps</li> </ul>
Supported File Format	<ul style="list-style-type: none"> <li>▪ Motorola S-type, ELF/Dwarf2</li> </ul>
Interface Software	<ul style="list-style-type: none"> <li>▪ HEW with pure debugger</li> </ul>
Emulation Functions	<ul style="list-style-type: none"> <li>▪ C – source level debugging (e.g. instant watch....)</li> <li>▪ Modify and display MCU registers</li> <li>▪ Perform real-time emulation of a target program</li> </ul>
Memory Functions	<ul style="list-style-type: none"> <li>▪ Copy, Search, Fill, Load and Save memory functions</li> <li>▪ Modifies and displays memory content</li> </ul>
Break Functions	<ul style="list-style-type: none"> <li>▪ PC breakpoints (max. 255)</li> <li>▪ Forced break by ESC key</li> </ul>
Step Functions	<ul style="list-style-type: none"> <li>▪ Step In/ Step Out/ Step Over</li> </ul>
On-board Programming	<ul style="list-style-type: none"> <li>▪ Support on-board programming - Boot mode and User mode</li> </ul>
User LEDs	<ul style="list-style-type: none"> <li>▪ Supports two user's LEDs</li> </ul>
Interface with E10T and E7 Emulators	<ul style="list-style-type: none"> <li>▪ Supports E10T and E7emulator</li> </ul>
Interface with Target system	<ul style="list-style-type: none"> <li>▪ Supports emulation on a target system.</li> </ul>
Power Supply for CPU board	<ul style="list-style-type: none"> <li>▪ DC +7.5 Volt. to +9.0 Volt. supplied from external input*2</li> </ul>
Environmental	<ul style="list-style-type: none"> <li>▪ Operating Temperature: 10 °C to 35 °C</li> <li>▪ Humidity: 30% to 85% RH</li> <li>▪ No condensation and corrosive gas</li> </ul>

**NOTE:**

1. 5 Volt. device would be in production in the 1<sup>st</sup> Quarter of 2004
2. For 3.3 Volt. device, a DC supply of 4.5 Volts. would be sufficient to operate the MCU

## Section 2. Installation

### 2.1. Label of Parts on CPU Board

Figure 2.1 shows the name of each part of the CPUBD.





Figure 2.1 Names of Parts on CPU Board

## 2.2. Installing the CPU Board

Installing the CPUBD requires power and serial connection to a host computer. The serial communication cable for connecting the CPUBD to a host computer is supplied. The serial connection cable uses a 1:1 connectivity.

The diagram below shows how to connect the CPUBD to a host machine or notebook computer equipped with a DB-9P connector.



**Figure 2.2 Serial Communication connections**

## 2.3. Communication Port Baud Rate

The baud rate utilized by the CPUBD is FIXED at 38,400bps.

## 2.4. Power Supply for CPU Board

The CPUBD requires a D.C. power supply from +7.5 VDC ~ +9 VDC\*<sup>1</sup> at approximately 100mA supplied to the J1 connector. Prepare the D.C. power supply separately. The power cable is included with this product. Since total power consumption can vary widely due to external connections, use a power supply capable of providing at least 250mA at +7.5 VDC  $\pm$  5%.

When power is supplied to the CPUBD, a PWR LED, D1 is lit; otherwise, check the power connection for polarity reversal.

Figure 2.3 and Figure 2.4 show the specification of the power connector and the DC plug respectively.




Figure 2.3 Power Connector & DC Plug

## 2.5. Jumpers Options

The CPUBD has several jumpers to allow various settings for the user:

Designator	Jumper Name	Jumper Descriptions
J2	3.3 / 5V SEL	Select either +3.3V or +5.0V depending on operating voltage of MCU
J3	VCC SEL	Select source of power supply
J4	TXD & RXD SEL	Select to use either SCI3 receive or P41
J5		Select to use either SCI3 transmit or P42
J6	AVCC SEL	Select internal or external AVCC
J7	AVSS SEL	Select internal or external AVSS
J8	LED SEL	Select either to use D3 or P93
J9		Select either to use D2 or P92
J10	E10T/ E7 SEL	Select either to use E10T/ E7 or P33
J11		Select either to use E10T/ E7 or P35
J12		Select either to use E10T/ E7 or P34
J13	BOOT MODE SEL	Select either BOOT or USER mode

Table 2.1 List of Jumpers

### 2.5.1. Operating Voltage Selection Jumpers for MCU

There are 2 devices for 38004F MCU. The only difference is their operating voltages, which are +3.3V and +5.0V. In order to cater to both devices, the CPUBD has 2 regulators. However, only the +3.3V regulator is mounted, as the MCU on the CPUBD is a +3.3V device.

Table 2.1 shows the jumper switch to select either +3.3V or +5.0V operating voltage.

Jumper Name	Jumper Designator	Jumper Selection	Descriptions
3.3 / 5V SEL	J2	Short Pin 2 to Pin 3 [Default] [Do not short Pin 1 to Pin 2]	Operating Voltage of +3.3V is selected
		Short Pin 1 to Pin 2 [Do not short Pin 2 to Pin 3]	Operating Voltage of +5V is selected

**Table 2.2 Operating Voltage Selection Jumpers for MCU**

### 2.5.2. Power Supply Selection Jumpers for MCU

This is the jumper switch to select the power supply to the MCU. As shown in Table 2.2 below, any setting not listed in Table 2.2 is not allowed.

Connect to Application Board	Jumper Name	Jumper Designator	Jumper Selection	Descriptions
Not Connected	VCC SEL	J3	Short Pin 2 to Pin 3 [Default] [Do not short Pin 1 to Pin 2]	Power of MCU is supplied from the CPUBD. Verify the operating voltage selected in Table 2.1
Connected			Short Pin 1 to Pin 2 [Do not short Pin 2 to Pin 3]	Power of MCU is supplied from an application board

**Table 2.3 Power Supply Selection Jumpers for MCU**

### 2.5.3. Boot Mode Selection Jumpers

This is the jumper switch to place the CPUBD into the boot mode. This is necessary for flashing the kernel software and monitor software into the FLASH ROM of the H8/38004F microcomputer.

Jumper Name	Jumper Designator	Jumper Selection	Descriptions
BOOT MODE SEL	J12	Short Pin 2 to Pin 3 [Default]	To place CPUBD into Boot mode.
	J13	Short Pin 1 to Pin 2	

**Table 2.4 Boot Mode Selection Jumpers**

#### 2.5.4. User Mode [Standalone] Selection Jumpers [Default]

This is the jumper switch to place the CPUBD into the user mode for standalone operation. This is necessary for flashing of the user software into the FLASH ROM of the H8/38004F.

Jumper Name	Jumper Designator	Jumper Selection	Descriptions
E10T/ E7 SEL	J10	Short Pin 2 to Pin 3 [Default]	To place CPUBD into User mode [Normal mode]
	J11	Short Pin 2 to Pin 3 [Default]	
BOOT MODE SEL	J12	Short Pin 2 to Pin 3	
	J13	Short Pin 2 to Pin 3	

**Table 2.5 User Mode [Standalone] Selection Jumpers [Default]**

#### 2.5.5. User Mode – Interface with Application Board Selection Jumpers

This is the jumper switch to place the CPUBD into the user mode and allow debugging operation with Application board.

Jumper Name	Jumper Designator	Jumper Selection	Descriptions
LED SEL	J8	Short Pin 1 to Pin 2	To enable debugging with Application board in User Mode.
	J9	Short Pin 1 to Pin 2	
TXD & RXD SEL	J4	Short Pin 1 to Pin 2	
	J5	Short Pin 1 to Pin 2	
E10T/ E7 SEL	J10	Short Pin 1 to Pin 2	
	J11	Short Pin 1 to Pin 2	
BOOT MODE SEL	J12	Short Pin 1 to Pin 2	
	J13	Short Pin 2 to Pin 3	

**Table 2.6 User Mode - Interface with Application Board Selection Jumpers**

### 2.5.6. Serial Communication Enable Jumpers

This is the jumper switch to enable the use of SCI3 during debugging. It is also necessary for flashing the kernel software and monitor software into the FLASH ROM of the H8/38004F microcomputer.

When debugging is not required, user can switch the jumper (Short Pin 1 to Pin 2) to enable the use P41 and P42.

Jumper Name	Jumper Designator	Jumper Selection	Descriptions
Serial Comm Enable	J4	Short Pin 2 to Pin 3 [Default]	Enable the use of SCI3
	J5	Short Pin 2 to Pin 3 [Default]	

**Table 2.7 Boot Mode Selection Jumpers**

### 2.5.7. E10T/ E7 Emulation Selection Jumpers

This is the jumper switch to allow CPUBD to debug with an E10T/ E7 emulator.

Jumper Name	Jumper Designator	Jumper Selection	Descriptions
LED SEL	J8	Don't Care	To support RENESAS TECHNOLOGY CORP. E10T/ E7 emulator
	J9	Don't Care	
TXD & RXD SEL	J4	Don't Care	
	J5	Don't Care	
E10T/ E7 SEL	J10	Short Pin 2 to Pin 3	
	J11	Short Pin 2 to Pin 3	
BOOT MODE SEL	J12	Short Pin 2 to Pin 3	
	J13	Short Pin 2 to Pin 3	

**Table 2.8 E10T/ E7 Emulation Selection Jumpers**

### 2.5.8. Optional Jumpers

Jumpers J6 and J7 are not mounted and have been shorted via tracks at the bottom layer of the CPUBD. These tracks have to be cut if the user needs to use the A/D converter function of the MCU.

When A/D converter function is no longer required, these jumpers have to be shorted. The user can do so by mounting a pair of 1X2 Header pins.


Jumper Name	Jumper Designator	Jumper Selection	Descriptions
A/D Converter SEL	J6	Short Pin 1 to Pin 2	When A/D Converter not in use
	J7	Short Pin 1 to Pin 2	

**Table 2.9 Boot Mode Selection Jumpers**

## 2.6. Installation of HEW (Pure Debugger) for CPU Board


To install the HEW (Pure Debugger) for CPUBD from the installation disk, proceed as follows:

- Insert the HEW (Pure Debugger) for CPUBD installation CD.
- Run Windows if it is not already running.
- Close all other applications that are running.
- Choose *Run* from the Program Manager File menu.
- Type *Setup* and click OK:



**Figure 2.4** Run Dialogue Box


This runs the HEW (Pure Debugger) for CPUBD installer, and the following Welcome! Screen is displayed:



**Figure 2.5** HEW for CPUBD Installer Welcome! Screen


- Click *Next* to proceed with the installation.

- ❑ Check the *License Agreement* concerning installation and then click *Yes* to proceed.



**Figure 2.6 Update Information (Readme) Dialogue Box**

The following dialogue box enables the selection of directory in which user can install the HEW (Pure Debugger) for CPUBD.




**Figure 2.7 Select Destination Directory Screen**

- ❑ Click *Next* to install into the default directory *C:\HEW3*, or specify an alternative directory by clicking on *Browse*-button.

**NOTE:**


1. User may install this HEW debugger in the same directory as the previously setup HEW toolchain (Make sure both are in the same version).
2. User may install the debugger into another directory, and register this component into the other HEW tool administration menu.
3. Do not install a HEW toolchain over (in the same directory) the HEW debugger
4. A new Toolchain can be installed if it is installed to another directory (different from the toolchain directory) and register either component to the respective HEW tool administration menu.



**Figure 2.8 Select Components**

- ❑ Select the components to be installed.
- ❑ Ensure each selection is selected in turn to confirm the correct directory it is installing into.


If user chooses *Next*, the following dialogue box will confirm each installation directory you selected. Ensure that all components are installed in the same required directory.



**Figure 2.9 Directory Confirmation Screen**


- Click *Next* to begin installation.

The installer then copies the HEW (Pure Debugger) for CPUBD files to the specified directory:



**Figure 2.10 Installing Screen**

The installation will complete with the Completion screen:



**Figure 2.11 Completion Screen**

At the end of the installation, icons for HEW (Pure Debugger) CPUBD will be created into the *Start Menu* and ready for execution.

## Section 3. Setup of HEW (Pure Debugger) for CPU Board

In this section, the focus is to highlight the basic steps for any initial setup for a project. On subsequent HEW activation, user will just be required to select the desired workspace/session, and the setup will be done automatically.

Ensure that the CPUBD is linked up i.e. the serial cable is linked between the CPUBD and PC, and the CPUBD is powered up.

### 3.1. Running HEW (Pure Debugger) for CPU Board

- Execute HEW (Pure Debugger) for CPUBD by selecting HEW.





Figure 3.1 HEW (Pure Debugger) for CPUBD Icon

### 3.2. Creating a New Workspace


This step is to create a workspace, to inform the HEW environment, what type of tool is to be used. This will enable user to have the same setup (workspace) at the following activation of the tool.

- ❑ Click on [Create a new project workspace]




**Figure 3.2 Select Platform Dialogue Box**

- ❑ Select a directory and key the workspace name as required




**Figure 3.3 HEW Start-Up Window (without toolchain)**

- ❑ Select 38004F CPU Board as the target by selecting
  - CPU Series: SLP(Super Low Power)
  - CPU Type: 38004F



**Figure 3.4 Select Target**

- ❑ Complete the workspace setup by clicking on [Finish] button




**Figure 3.5 Debugger Setting Summary Window**

- ❑ A summary window shows the project files that will be generated
- ❑ Click OK to proceed

### 3.3. Selecting the Target (Debug Settings)

HEW (Pure Debugger) for CPUBD can be extended to support multiple target emulators or platforms (if the system is setup for more than one platform), user will have to choose a platform for the session from *Debug Settings...* in the *Options* menu.



**Figure 3.6 Select Platform Dialogue Box**

- Select '38004F CPU Board' and click OK to continue
- A warning message will pop up. Click "OK" to proceed


**NOTE:** User can change the target platform at any time by choosing *Debug Settings...* from the *Options* menu. Under the *Download Modules*, User can also define the Download Module/s for Debugging.

When the emulator has been successfully setup, the HEW (Pure Debugger) for CPUBD desktop window will be displayed. A message *Connected* is displayed in the Output Window.

## Section 4. Performing Emulation

### 4.1. High-performance Embedded Workshop

The following shows a snap shot of the HEW Pure Debugger desktop Window:



**Figure 4.1 High-Performance Embedded Workshop Window**

The key features of HEW (Pure Debugger) for CPUBD are described in the following sections:

- Title Bar** : Displays the name of the currently open workspace, project and file.
- Menu Bar** : Give you access to the HEW (Pure Debugger) for CPUBD debugging commands for controlling CPUBD.
- Toolbars** : Provides convenient buttons as shortcuts for the most frequently used menu commands. The tool bar can be docked or floated. It can be created, modified and removed.
- Program Window** : Displays the source code of the program being debugged as well as the source address.

- Workspace** : Display the detail of current workspace, and provide a quick & easy mean of navigation.
- Output Window** : Displays the various outputs from HEW. For example, build details, results of find files.
- Status Bar** : Displays the status of the CPUBD. For example, progress information about downloads.
- Help Button** : Activates context sensitive help about any feature of the HEW (Pure Debugger) for CPUBD software.
- Memory Flash Button** : Flash contents of the memory window for on-chip ROM area into the MCU. User is required to press this button when he/she manually updates the contents of the memory window for on-chip ROM\* area. This is not required for RAM\* area.

**NOTE:** \* Please refer to the *Appendix B – H8/38004F Memory Map for the on-chip ROM and RAM areas.*

The major topics are highlighted as follows.

	Menu	General Description	Sub Menu	Usage
1	Option	Emulation Setting	Debug Settings	Target Selection
			Emulator	View memory mapping and Configure Platform
2	View	MCU related information	Disassembly	View disassembly window
			CPU	Register, memory, Status, I/O
			Symbol	Label
			Code	Breakpoints
3	Memory	MCU memeory manipulation	Fill	
			Refresh	
4	Debug	Execution of MCU Code	Reset CPU	
			Go/Reset Go /Go to Cursor/ Set PC to Cursor /Run	
			Step In/ Over/ Out/ ... Step mode	
			Initialize	

## 4.2. Compiler Configuration & Debugger Session

In HEW compiler, every setting is stored in a configuration.

Session is not directly related to a configuration. This means that multiple sessions can share the same download module and avoid unnecessary program rebuilds.


Users can create new configuration & session under the [Options\Build Configuration...] and [Options\Debug Session...] pull down menu respectively.



**Figure 4.2** Toolbar Showing the Session and Configuration

At the HEW (Pure Debugger) environment with a toolchain, a default debugger **Session**, [Debug] is created to store information of

- Target platform
- Downloadable program
- Window positioning
- Registers value settings



**Figure 4.3** Toolbar Showing the Sessions and Configurations Available

Generally, the HEW organized the configuration & session of a workspace as follows

<u>Root Directory</u>	<u>Workspace directory Files</u>	<u>Configuration directory Files</u>
(xxx.hws)	Debug (DIR)	Configuration Information & Output (abs,lst...)
	Release (DIR)	Configuration Information & Output (abs,lst...)
	Default Session (hsf)	
	Release Session (hsf)	
	C & header files	

**Example of usage:**

User may use [Debug Session] to link to CPUBD, & [Debug] configuration setting to debug on the project output file (xxx.abs) store in the Debug sub directory. User may switch the configuration to [Release] and debug on the new setting (e.g optimization on...).

On the other hand, user may add sessions and may switch the configuration from [Release] to [Debug], so as to debug on the generated output (xxx.abs) in the simulator environment.

**NOTE: The path name defined in the [Options\Debug Setting..] must be relative [\$(CONFIGDIR)\\$(PROJECTNAME).abs]. Otherwise, when the session is switch, the download module will not be able to switch correctly.**

### 4.3. Debug Settings

The Debug Settings in [Options\Debug Settings...] is to set the environment for a session.

In HEW Pure Debugger with a toolchain, users have been provided with two sessions

- Debug Session
- Release Session

In each session, users are to set

- Target (38004F, Simulator...)
- Default Debug Format (Elf\Dwaf2, S-record, IntelHex...)
- Download module (\$(CONFIGDIR)\\$(PROJECTNAME).abs)

In each session, users can set a list of command chain to be executed at the [option] tab.

- At connecting the emulator
- Immediately before downloading
- Immediately after downloading

### 4.4. Connecting & Disconnecting with the Emulator

The open (activation) or close (exit) of the HEW and/or workspace will determine the emulator and HEW connectivity.

The alternative method is to use the “session” control:

In HEW (Pure Debugger) environment with a toolchain, user is provided with two sessions

- Debug Session (linking with emulator)
- Release Session (no target)

Thus by switching between the sessions, the emulator can be connected & disconnected from the HEW.

## 4.5. Emulator Setting

The emulator setting, which consists of the system configuration & memory mapping, has to be done before any emulation.




Figure 4.4 Option - Emulator

### 4.5.1. Configure Platform

The configure platform enables the user to set their target device and mode at startup.

To setup the system configuration:

- ❑ From the *Options* menu, choose *Emulator*, *System...* or click on the following icon on the Toolbar:



- ❑ The following Configure Platform dialogue will appear:





Figure 4.5 Target Configuration Dialogue Box

The user has the option of using standalone flashing by enabling the Standalone Flash in the Control option.

#### 4.5.1.1. Standalone Flash


Standalone Flashing downloads the user target program directly into the memory. Monitor program would not reside in the memory and hence no debugging is available if this option is used. This option should only be used when the user has finalized his/her user target program and wants to run it on the CPU Board.



**Figure 4.6 Enabling Standalone Flash option**

- ❑ Click on the check box and click OK to enable standalone flashing.

When user downloads the selected object file, the following dialogue box would appear, prompting the user to switch to Boot Mode to download the user target program.



**Figure 4.7 Dialogue box for downloading user target program**

After downloading the user target program, the dialog box would prompt the user to switch to User Program Mode to run the user target program. The user can either click YES to exit HEW or click NO to re-download the user target program or Flash monitor Program.




Figure 4.8 Dialogue box for running user target program

**NOTE: By pressing the reset switch when jumper J13 is in the User Mode position, the user target program will run in standalone mode, that is, no connection to HEW is required to run the user target program and therefore, no debugging is available to user.**

#### 4.5.2. Memory Mapping


Once the device and operating mode are selected, the default memory mapping will be set. The main objective of memory mapping is to ensure that the emulator has the correct internal memory (Internal ROM, RAM, IO) access.

To display the current memory mapping:

- ❑ From the *Options* menu, choose *Emulator, Memory resource...* or click the Open memory mapping button in the toolbar:



The memory mapping is shown in the following figure:



**Figure 4.9 Memory Mapping Dialogue Box**

Alternatively, the CPU memory map can be viewed from the status window:

- ❑ From the View menu, choose CPU then Status, or click the View Status button in the toolbar:



- ❑ Select the Memory tab in Status window to show the Memory Mapping configured:




Figure 4.10 Target Memory Configuration Dialogue

**NOTE: CPUBD Memory Map is for display and information purpose, user cannot configure it.**

The following explains the target memory configuration dialogue:

- CPU Memory Map : Display the memory configuration of the specific target device selected.
- Program Name : Display the Downloaded Module's name (User Target Program) and the memory space that it has occupied

## 4.6. Viewing of Program

Programs can be viewed as

- Source Code level (C or assembly-language)
- Disassembly level (assembly-language)

### 4.6.1. Source Code level

Users may double-click on the file located in the workspace window to open and view the source code. However this is merely in “editor” point of view. Users have to download the code to the emulator. Once the code is downloaded, user can observe that “address values” have appeared in the source address column of the source file.

#### NOTE:

When a break condition occurred during a running program, HEW will open up the source code or disassembly window.

1. If the source code information is not available, the disassembly window will be opened.
2. If the downloaded project is a Elf/Dwarf2-based file, and the project has been moved from its original path, the source file may not be automatically found. In this case, HEW will open a source file browser dialogue box to allow user to manually locate the file.




Figure 4.11 Source Level

Information available:

- Corresponding address for source file
- PC location
- Bookmark
- Breakpoint

#### 4.6.2. Disassembly level

User can open the disassembly window:

- ❑ Choose *Disassembly* from the *View* Menu, or right click on the source window, and select *Goto Disassembly*




Figure 4.12 Disassembly Window

## 4.7. MCU related information

User can be monitor & control the MCU information under the view menu.




Figure 4.13 View - CPU

### 4.7.1. Registers

User can access these registers directly through the Register windows during break mode only.




Figure 4.14 Register

### 4.7.2. Memory

Users will have to set a pre-defined address range to be monitored, before user can access the memory through the memory windows. The memory window will not refresh constantly by itself. The access methodology is different when emulation is in different mode (Run or Break). More memory functions are explained in Memory manipulation.




Figure 4.15 Set Memory

### 4.7.3. I/O

The IO window provides an easy access to MCU IO registers. The Address & Data values of respective peripherals & MCU control registers are displayed in the IO window.




Figure 4.16 Input and Output Register

#### 4.7.4. Status

The status window uses three different tabs to monitor the emulator setting.

##### 4.7.4.1. Status - Memory

The memory tab display

- the available memory setting for the selected target device & mode.
- the address range where the User Target Program is loaded




Figure 4.17 Status – memory window

#### 4.7.4.2. Status - Platform

This platform tab shows the current emulation condition

- Target device
- CPU
- Run Status
- Break Cause




Figure 4.18 Status – Platform window

#### 4.7.4.3. Status - Events

The events tab shows the usage of

- PC Breakpoints




Figure 4.19 Status – Events window

#### 4.7.5. Symbol

This enables easy monitoring of declared variables in the assembly or C files. If debug information is not included, the Watch and Locals sub menus will not appeared.




Figure 4.20 View - Symbol

##### 4.7.5.1. Label

When debug information is included, detail of all labels will be displayed in the Label window. User can add new label into the window for simple reference too.




Figure 4.21 Label

**NOTE:** When a label value matches an operand, the corresponding instruction's operand is replaced by the label. If two or more labels have the same value, the earlier label (alphabetical order) will be displayed.

#### 4.7.5.2. Watch

User will have to add the variables into the watch window.




Figure 4.22 Watch


**NOTE:** The variables can be displayed only if debug information is included in the absolute file (abs)

- The variables have not been excluded after the compiler optimization
- The variables are not cleared as macro.



#### 4.7.6. Break Functions

Various breakpoints setting are discussed as follows.



**Figure 4.25 View Code**

Breaks are events used to intercept the normal program execution when a specific condition is matched. There are two types of break in the CPUBD, hardware and software break.

For Hardware Event break, the preset break condition will cause the break event to occur after an instruction is executed. For Software PC break, the break condition causes the break event to occur before the break condition.

	Types of Break	Description
1	PC Break (Software Break)	A break occurs at the program address specified by PC Break window. The instruction at this address is replaced with a system instruction before the execution of code. If a PC breakpoint is detected, the emulation stops at the specified address before executing the subsequent instruction.
2	User Break (Hardware Break)	There are 3 scenarios when a hardware break occurs: Pressing the ESC key of the host PC Pressing STOP button of HEW Pressing reset switch of CPUBD

**Table 4.1 Types of Breaks Encountered During Emulation**

### 4.7.7. Stack Trace

The Stack Trace window can be selected if only debug information has been supplied.

Stack Trace window shows the function call history.




Figure 4.26 Stack Trace

The following items can be displayed:

Kind Indicate the symbol type

F: Function

P: Function parameter

L: Local variable

Name Indicate the symbol name

Value Indicate the value, address and symbol type

At default, the function parameter and local variable are not displayed.

To enable all the items, right click in the Stack Trace window and select *View Setting...*

## 4.8. MCU memory manipulation

General supported functions are


- fill
- refresh

Memory Data display format can be in

- Byte (x1)
- Word (x2)
- Long (x4)
- Double (x8)

Memory value display format can be in


- ANSI character
- unsigned char
- signed char



**Figure 4.27 Memory Functions**

## 4.9. Execution of MCU Code

The MCU executes the user code either in “RUN” or “STEP” modes.



**Figure 4.28 Debug Functions**

### 4.9.1. Reset CPU

When *RESET CPU* command is activated, the following actions will take place,

PC	=	Power on Reset vector value
ER7	=	H'FF7E
ER0-6	=	H'00000000
CCR	=	H'00

The microcomputer is reset.

i.e all internal peripherals registers will be at default state.

#### 4.9.2. Go, Reset Go, Goto Cursor, Set PC to Cursor, Run...

Near Real-time execution [Debug] by the MCU based on the user setting. These commands will cause the HEW Debugger to steal a cycle from the running chip, in order to probe a response from the MCU to verify that the communication link between the PC and CPUBD is still active.

**NOTE: [Go To Cursor] will not halt if the running program never executes the code at the cursor. Stopping of the execution is possible via [ESC] key, pressing the RESET switch on the CPUBD or STOP button of HEW.**

### 4.9.3. Step Functions

There are four types of Step Functions:

- Step-In,
- Step-Out &
- Step-Over.
- Step...
- Step Mode (Auto, Assembly and Source)

**Single Step** executes the instruction at the current program counter. If an interrupt is asserted, the interrupt service routine will not be serviced unless a “Go” command is issued.

**Step-In** will execute a single instruction only. For C source file, a single step will execute a “single C source code”; whereas for an assembly file, a single step will execute a single assembly instruction code.

**Step-Out** executes till it has branched out of the current routine. It is used to perform stepping to exit from the subroutine. Instructions in the subroutine function will be executed and PC will be set to the line of code after the subroutine return instruction RTS.

**Step-Over** executes a function call (and any function call called by the function) and halt at the next instruction.

**Step...** will execute multiple Step-in as specified by the user. The delay enable a visual view of the code running sequence.





Figure 4.29 Step program

**Step Mode** setting configures how the step instruction operates.



**Figure 4.30 Step Mode**

- *Auto*: The execution mode will depend on the active window. i.e. when step instruction is activated in a C Source window, a C-source level step will be invoked.
- *Source*: When Step instruction is executed, user will see a C-source level step. i.e. a series of assembly code is run in the background.
- *Assembly*: When step is executed, the current assembly code located at current PC will be executed. The disassembly window will pop up if the current window is a C source window.

## 4.10. C-source Level Debugging

If user compiles and links the code (when a toolchain is used) with the Debug option enabled, the ELF/DWARF2 (.abs) file with the debugging information is generated.

This enables user to debug the code in C-source level i.e. ,

- Display code in C source level,
- Step in, out & over code in C source level,
- View label,
- Go To label (address),
- View local
- Instant/add watches (local and user defined)
- Stack Trace

In other words, C-source Level debugging is only available when a ELF/DWARF2 (.abs) file is downloaded. User would not be able to perform debugging if other file formats like S-Record, Intel Hex and Binary are used.

## Section 5. Usage Precautions

Users may need to observe several precautions while operating the CPUBD. They are described as below:

### 5.1. Corruption of Monitor Software

If a Renesas Standard Toolchain is used, go to *Options* menu and select the toolchain used. View the *Section* of the program by selecting *Section* in the *Link/Library* tab.

Please refer to the *Appendix B – H8/38004F Memory Map* to take note of the area occupied by the monitor code.

- User target program must not reside in H'6A00 to H'7FFF of the on-chip ROM as this memory space contains the Monitor Program.
- User must not use H'F780 to H'FB7F of the RAM as this area is reserved for Monitor RAM.

### 5.2. Interrupt

- Users, who want to perform debugging operation on the CPUBD, must enable the interrupt.
- The example provided below, would result in a loss of communication between HEW and CPUBD:

Referring to the following code, after single stepping the line, *set\_imask\_ccr(1);*, I bit is set to '1', disabling interrupts.

Therefore, if another single step is performed, SCI3 interrupt would not occur and HEW will timeout and a dialogue box "Error in communication" will be displayed as follow:-

```
set_imask_ccr(1);
light_LED();
```


### 5.3. Watchdog timer

Watchdog timer must not be used to generate an internal reset when performing debugging operation. This is because when counter in watchdog timer overflows, a signal is generated, resetting the MCU. At this instance, if HEW performs a debug operation, the operation will not be completed as the MCU has been reset, resulting in a loss in synchronization. This will result in a timeout in HEW.

## 5.4. Timing Issues

- ❑ Execution time to complete an interrupt subroutine must not be longer than 3sec, else HEW will timeout and a dialogue box “Error in communication” will be displayed.
- ❑ If the frequency of interrupts generated is less than 300msec, MCU will not be able to respond to the SCI0 interrupt sent by HEW. This will also cause HEW to timeout.

The following shows the timing diagram when using HEW.



**Figure 5.1** Timing diagram of HEW

## 5.5. Software Breakpoint

- ❑ User shall not set a software breakpoint in the following address:
  - An area other than the flash memory or RAM
  - An area of address H'6A00 to H'7FFF [Monitor code resident]
  - An area of address H'F780 to H'FB7F [Monitor work area]
- ❑ User shall not set any breakpoints in the interrupt service routines.
- ❑ When execution resumes from the breakpoint address, single-step execution is performed before execution resumes.

## 5.6. Step

- ❑ Step function (step in, step out and step over) is a simulated operation in the CPBD. It is not implemented by the conventional hardware break mechanism.
- ❑ No interrupts will be serviced during stepping.
- ❑ Do not step into interrupt service routines as interrupts will be masked and HEW cannot communicate with the CPUBD.
- ❑ Stepping of SLEEP instructions are not allowed in HEW. User needs to use “Go to cursor” in order to proceed to the next instruction.

## 5.7. Power-Down Modes

User must not place the MCU in any of the following power-down modes when performing debugging operation:

- Watch Mode
- Sub-active Mode
- Subsleep Mode
- Software Standby Mode

Serial Communication function is disabled/ reset in these modes, hence HEW is unable to communicate with the CPUBD.

## 5.8. SCI3

If debugging operation is required, user is not allowed to make use of SCI3 in his/her program because SCI3 is used by HEW to communicate with the CPUBD.

## 5.9. E10T/ E7 Interface

When interfacing with E10T/ E7, the following limitations have to be observed:

- The Port 9 pin 5 is not available for use because it is dedicated to E10T/ E7
- The Port 3 pin3, Port 3 pin 4, and Port3 pin 5 are also not available for use. To use these pins, additional hardware is required on the user's board.
- When E10T/ E7 emulator is used, the Port 9 pin 5 is designated as I/O, the Port 3 pin 3 and Port 3 pin 4 pins are designated as input, and the Port 3 pin 5 is designated as output.
- User is prohibited from accessing the address regions, H'7000 to H'7FFF because E10T/ E7 emulator uses them.
- Access to address regions, H'F780 to H'FB7F is prohibited.

## 5.10. Other Constraints

- When viewing memory content in HEW, user may access to memory area above the available memory area on H8/38004F MCU. This is because the H8/38004F MCU has only 64K address space so the top bits of any address above 16 bits are ignored. This results in address error if data is written to these wrong addresses.
- User must be aware that they are not allowed to place the MCU into hardware standby mode as this condition is exited by reset interrupt only. This would restart the monitor software, and DESTROYS the current context of the user target program. Sleep mode and software standby mode may be entered, but may not be exited by the use of the reset interrupt for the same reason mentioned.
- When SLEEP instruction is executed, the MCU is unable to stay in SLEEP mode as HEW will send data via SCI3 and wake up the MCU.

## Section 6. Hardware

The CPUBD comprises of the following blocks:

- H8/38004F Microcomputer
- Power Supply circuitry
- Reset circuitry
- Clock circuitry
- Serial Communication block [via SCI3]
- LEDs
- Flash ROM and RAM
- Boot Mode Enable
- E10T/ E7 Emulator Interface
- External User Interface

### 6.1. H8/38004F Microcomputer

The H8/38004F series has a system-on-chip architecture that includes peripheral functions and can be used as embedded microcomputer in application systems. Its on-chip ROM offers flexibility as it can be reprogrammed in no time to cope with all situations from early stages of mass production to full-scale mass production. Users reconfiguring processor I/O ports are cautioned that pull-up resistors may be needed for proper operation in some configurations.

### 6.2. Power Supply Circuitry

The power supply circuitry supplies the DC power to the CPUBD from an external power supply. This is also known as the system DC power. The CPUBD either accepts +7.5V DC to +9V DC voltage. This power input is further stepped down to +3.3V and +5.0V DC that is acceptable by the MCU. In addition, user can select the source of power supply to the MCU via a jumper selection between the system power supply or from a target system.

When power is supplied to the MCU, the green LED, D3 lights up.

### 6.3. Reset Circuitry

The reset circuitry comprises of RC circuit and a push button, S1 also known as the RST SW. During power-on, the RC circuit asserts a reset signal to MCU to reset the MCU. If the RST SW, S1, is pressed, a reset signal of approximately 20msec. duration is generated to allow proper reset to be performed. The reset switch allows user to manually reset the CPU board when abnormal situation occurs and during flash programming control.

## 6.4. Clock Circuitry

The clock circuitry comprises of a quartz crystal of 9.8304MHz, system clock oscillator and a system clock divider. The system clock divider halved the input clock from the quartz crystal [via OSC1 & OSC2]. A sub clock is also provided by a quartz crystal of 32.768KHz on the CPUBD.

## 6.5. Serial Communication Block [via SCI3]

The CPUBD supports a three-wire serial channel using the on-chip serial communication channel [SCI3] on the H8/38004F. SCI3 is used, both to flash the device using a flash programming software and to connect to HEW. If neither flashing nor debugging with HEW is required, then the serial channel is available to user. The SCI3 port provides transmit and receive signals to the RS3232 transceiver device on the board. The transmit and receive signals from the transceiver device is then connected to the 9-pin D-type connector, P1 on the CPUBD. The RS3232 transceiver device translates the RS232 signals to logic levels and vice versa.

## 6.6. FLASH ROM & RAM

The H8/38004F does not have any interface to external memory; it could only be used in single chip mode. The chip has 32Kbytes of FLASH ROM and 1Kbytes of RAM for user. If debugging by user is necessary, a monitor software would be downloaded together with the user target program. A total of 6Kbytes of FLASH ROM and 1Kbytes of RAM must be reserved for the monitor software.

## 6.7. LEDs

There are two red LEDs on the CPUBD available to user. LED D2 can be driven by port 9 bit 2 of the H8/38004F. This can be selected by a jumper selection of J9 header.

The second LED D3 can be driven by port 9 bit 3 of the H8/38004F. This can be selected by a jumper selection of the J8 header.

A LOW output level from H8/38004F will set the LED ON and a HIGH output level would set the LED OFF.

## 6.8. Boot Mode Enable

Boot Mode is necessary to flash the FLASH kernel software and monitor software or user target program if required into the FLASH ROM when the CPUBD is placed into Boot mode. This is done via the Boot Mode Enable jumper selection, J13. Boot mode is required at the Power-On stage only. For the jumper selection, see section 2.5.3.

A red LED, D4, lights up when Boot Mode is selected.

## 6.9. E10T/ E7 Interface

Interface the CPUBD to E10T/ E7 emulator is only allowed when the E10T/ E7 Enable jumper selection, J10 - J13 on the CPUBD are set. See section 2.5.7.

This interface allows user to extend the debugging function of the CPUBD if an E10T/ E7 emulator is available.

## 6.10. External User Interface

The external user interface makes all H8/38004F signals available to user. These signals are connected to the following connectors.

- Four 2x10-pin connector [JP1 ~ JP4]
- Two 2x30-pin socket connector [CON1, CON2]

The four 2x10-pin connectors [JP1~JP4] are placed closed to the H8/38004F QFP-64A on the CPUBD.

The two 2x30-pin socket connector [CON1, CON2] is placed to the edge of the CPUBD for ease of connection to an external system. These connectors should be mounted on the solder side.

Both connector types use commonly available 2.54mm[0.100inch] pitch male header and female socket with 0.635mm[0.025inch] square posts.

These connectors are all connected to the H8/38004F QFP-64A, and can be used to access the pins of the chip and labeled with reference to the actual chip QFP-64A pin-out.

In addition, jumper selection must also be made, see section 2.5.5.

See appendix C, appendix D for the pin assignment for JP1~JP4 and CON1, CON2.

**NOTE: External interface should be powered by an independent power supply.**

## Section 7. Monitor Software

### 7.1. Introduction to Monitor software

The Monitor Software is a FLASH-resident debugging program hosted on the CPUBD. Monitor software may be used to download, run, and debug programs developed on a PC. The monitor software provides all the necessary control and communications to operate under the HEW. This allows users to perform high-level C debugging on the CPUBD.

Using the powerful debugging features of HEW, user may explore features of the H8/38004F microcomputer and the CPUBD by directly running sample programs.

The CPUBD comprises of limited RAM and is also a single chip MCU. To debug the user target program, both the user code and the monitor software must be programmed into the FLASH ROM. The monitor software is built separately from the user target program into S-record format. Without the monitor software flashed into the FLASH ROM of the MCU, no debug can be performed with the HEW software.

### 7.2. Program Development

The tutorial program which accompanied the CPUBD contain examples you may use as a basic reference code to explore and evaluate the architecture of the MCU.

When you install the High-Performance Embedded Workshop [HEW] with free Tiny/SLP tool-chain, user obtains faster turn-around-time for a complete design cycle from 'Code Entry' → 'Compile' → 'Linkage' → 'Download S-record file to MCU' → 'Execute User target program' → 'Debug User target program' within an integrated environment (*HEW with 38004F pure debugger*).

### 7.3. Monitor software Requirements

The monitor software makes use of the following peripheral function and input/output pins of H8/38004F MCU, which cannot be used by user target program during debugging. These are:

- SCI3 Port for communication to the PC running HEW
- IO Port 3 Pin 4
- IO Port 9 Pin 5

Refer to Section 5 on usage precautions and limitations for more information.

## 7.4. Mode Transition

The CPUBRD operates in two modes: Boot Mode and User Mode.

In Boot Mode, user can either download the monitor program or user target program (for Stand-alone flash operation).


In User Mode, monitor program is being executed. User target program can be downloaded for debugging purposes in User Mode.

The MCU loops in the Break Mode of the monitor program while waiting for commands from HEW.

To execute the downloaded user target program, user can either *Run at current program counter*, *Reset Go* or perform Step functions (*Step-In*, *Step-Over* and *Step-Out*). This will cause it to operate in the User Target Mode.

To terminate the User Run state, a break condition has to be asserted to bring the MCU to the Break Mode. This can either be a preset condition (eg. PC Break, Event Break) or a force break condition (Hit ESC key or press STOP button). The MCU also returns to Break Mode automatically after completing Step functions.

Figure 7.1 illustrates the mode transition diagram.



**Figure 7.1 Mode Transition Diagram**

## 7.5. Using Monitor software

The monitor software is used with the CPUBD. All monitor software functions are accessed through the HEW graphical user interface and they are not accessible by user commands via the serial interface.

The following functions are supported by monitor software:

- Program Download
  - Supported file formats are:
    - Elf/Dwarf2
    - Motorola S-Record
    - SYSROF format
- Breakpoint
  - Maximum of 256 breakpoints is allowed at a time when executing with the monitor software
- Types of Execution
  - Three execution modes:
    - RUN
    - STOP
    - Step
- Memory Read/Write
  - - Memory Write
    - Memory Read
    - Fill Memory
- Register Read/Write
  - - Read CPU Register
    - Write CPU Register
- Others
  - - Mapping
    - Read or Write I/O registers [I/O windows]

## 7.6. Interrupts used by the Monitor

The monitor uses several interrupts to communicate with the host PC and control user target program execution. The user is not allowed to use these interrupts if HEW is used for debugging.

The following lists the interrupts reserved by the monitor and their vector addresses:

<i>Exception Source</i>	<i>Vector Number</i>	<i>Vector address</i>
Reset	0	H'0000 to H'0001
Reserve	1	H'0002 to H'0003
SCI channel 3	18	H'0024 to H'0025

**Table 7.1 Interrupts Used by Monitor Program**

## 7.7. Breakpoints

The CPUBD only allows a maximum of 256 breakpoints to be assigned at a time when executing with the monitor software.

The breakpoint is controlled through software means, the line of code where the breakpoint is placed is NOT executed and the program stops at the same instruction where the breakpoint is set.

**NOTE:**

- When user inserts breakpoints, it is recommended to use the 'Disassembly window'.
- Beware of instruction pre-fetches after branch instructions.

**A breakpoint inserted on a branch instruction, will halt on the line of code where the instruction branches. A breakpoint inserted on a line of code after a conditional branch such as *BNE* may never be triggered because the line of code may always be pre-fetched and thus not seen by the break control.**

## Section 8. FLASH Programming

For programming of the FLASH ROM, FLASH Kernel software is developed. This FLASH Kernel is downloaded together with the monitor software to the FLASH ROM at power on. It performs Write or Erase control program operation in Boot mode and User mode.

The MCU's serial communication port, SCI3 is used for flash.

Please refer to specific device manual to enter boot mode.

### 8.1. FLASH Programming the CPUBD

There are several methods to flash the CPUBD

- 38004F HEW (pure debugger)
- FDT version 2.1
- E10T/ E7 emulator for H8/38004F

HEW is discussed in this user manual. As for the other methods, please refer to their respective user manuals for detailed operations.

Flash programming is performed in the HEW under the following modes:

- Boot mode – the writing or erasing is performed in batches,
- User mode - the range of writing or erasing can be defined independently for each program block.

#### 8.1.1. Boot Mode:

Boot Mode is necessary under the following operation:

- Upgrade or Recovery of monitor software
- Stand-alone flash operation of user target program.

Hardware jumpers are required to be set accordingly to trigger MCU to enter boot mode. For jumper settings, please refer to section 2.5.3“Boot Mode Selection Jumpers”.

The sequence to trigger MCU into boot mode is described below:

- Short J12 [2-3 default] and short J13 [1-2]
- Power-on the CPU Board
- Press RST SW to put MCU in the boot mode.

The boot program then start to transfers the write control program received from the host machine to the MCU internal ram. When the write control program has been received, the entire internal flash memory area is erased.

After entire flash memory has been erased, the execution is transferred from the boot program to the write control program, and the application program (Monitor program or user program) received from the host machine is written to the flash memory.

### 8.1.2. User Mode:

User mode is used only when the monitor program is resident in the flash memory.

Most of the time, user mode is used to download user target program and modify Flash memory content.

The advantage of using user mode is no jumper setting is needed and the range of writing or erasing can be defined independently for each program block (reduce programming time).

When monitor program is started, host machine sends flash memory command to MCU. The monitor program copies the write / erase control program into internal RAM, this is followed by having execution transferred to the write / erase control program.

HEW sends address that needs to be programmed and the entire flash memory block is erased. The MCU starts receiving program data from HEW and write to the flash memory. After completing the flash programming, write / erase control program returns the execution control to the monitor program waiting for debugging command from HEW.

## 8.2. Operation during Programming Kernel Execution




Figure 8.1 Overview of Boot Mode




Figure 8.2 Overview of User Mode

## Section 9. Tutorial (300l\_tut)

The following describes a simple debugging session, designed to introduce the main features of the CPUBD used in conjunction with the HEW (Pure Debugger) for CPUBD software.

The tutorial is designed to run in the CPUBD's Flash memory so that it can be used without connecting the CPUBD to any external user system.

User has to setup the CPUBD as stated in section 2 before the tutorial can begin.

### 9.1. Introduction

The 300l\_tut is based on a simple Assembler / C program located in your installed directory "... \Tools \Renesas \DebugComp \Platform \Emulator \Evb38004F \300l\_tut".

Before reading this chapter, ensure the followings would certainly ease the learning process:

- Setup the CPUBD and verify that it is working correctly with the HEW software (Pure Debugger) for CPUBD.
- User has to be familiar with the architecture and instruction set of the H8/300L Series MCU.

For more information please refer to the H8/300L Series Programming Manual and H8/38004F Series Hardware Manual.

Refer to H8S, H8/300 Series High-Performance Embedded Workshop 3 in your installed directory (install directory/Manuals/Renesas/PDFS/EH8HTU36.pdf) for more detailed information on using HEW.

### 9.2. Overview

This program is an infinite loop that sort elements based on NAME in the alphabetical order, and AGE and ID in the numerical ascending order.

The 300l\_tut workspace is provided on the installation CD. A compiled version of the 300l\_tut is provided in Motorola S-Record in the file *300l\_tut.mot*.

□ How the 300l\_tut Program Works:

The first part of the program includes a series of header files:

```
#include "machine.h"
#include "string.h"
```

The program then gives prototypes for the constants, structures, and function initial values:

```
#define NAME      (short)0
#define AGE       (short)1
#define ID        (short)2
#define LENGTH    8

struct namelist {
    char    name[LENGTH];
    short   age;
    long    idcode;
};

struct namelist section1[] = {
    "Naoko", 17, 1234,
    "Midori", 22, 8888,
    "Rie",   19, 7777,
    "Eri",   20, 9999,
    "Kyoko", 26, 3333,
    "",      0,   0
};

int count;

void sort();
```

Followed by the main program below.

```
main( )
{
    count = 0;
    for ( ; ; ){
        sort(section1, NAME);
        count++;
        sort(section1, AGE);
        count++;
        sort(section1, ID);
        count++;
    }
}
```

The remainder of the program defines the functions called from main:

```

void sort(list, key)
struct namelist list[];
short key;
{
    short i,j,k;
    long min;
    char *name;
    struct namelist worklist;

    switch(key){
        case NAME :
            for (i = 0 ; *list[i].name != 0 ; i++){
                name = list[i].name;
                k = i;
                for (j = i+1 ; *list[j].name != 0 ; j++){
                    if (strcmp(list[j].name , name) < 0){
                        name = list[j].name;
                        k = j;
                    }
                }
                worklist = list[i];
                list[i] = list[k];
                list[k] = worklist;
            }
            break;

        case AGE :
            for (i = 0 ; list[i].age != 0 ; i++){
                min = list[i].age;
                k = i;
                for (j = i+1 ; list[j].age != 0 ; j++){
                    if (list[j].age < min){
                        min = list[j].age;
                        k = j;
                    }
                }
                worklist = list[i];
                list[i] = list[k];
                list[k] = worklist;
            }
            break;

        case ID :
            for (i = 0 ; list[i].idcode != 0 ; i++){
                min = list[i].idcode;
                k = i;
                for (j = i+1 ; list[j].idcode != 0 ; j++){
                    if (list[j].idcode < min){
                        min = list[j].idcode;
                        k = j;
                    }
                }
                worklist = list[i];
                list[i] = list[k];
                list[k] = worklist;
            }
            break;
    }
}

```

## 9.3. Tutorial Setup

Open tutorial workspace in:

*“install directory\Tools\Renesas\DebugComp\Platform\Emulator\Evb38004F\300l\_tut”.*

**NOTE: On a first time loading of the tutorial, a dialogue box prompting the move of workspace from previous installed directory is displayed. Please click [YES] and the workspace would be configured to the current installed directory permanently.**

The setup of HEW is detailed in section 3.

Thus these steps will not be fully illustrated in this section.

Before downloading a program to the CPUBD, check the following items and user target program (Download Module) to be debugged:


- Device type
- Memory map

**NOTE: Refer to Section 4.5 for these emulation settings.**

### 9.3.1. Downloading the tutorial Program


Once the emulation settings of the CPUBD have been setup, user can download the object program for debugging.

- First load the object file, as follows:
- Open the Debug Settings window by choosing *Options* menu and *Debug Settings...*
- Select Elf/Dwarf2 for the Default Debug Format.



**Figure 9.1 Debug Settings with Load Object File Dialogue**

- Click on the Add... button.
- Select the download Format to be the ELF/DWARF2.
- Click the Browse button and select the file '300l\_tut.abs'.
- Click OK to exit from Download Module window and click OK again to exit the Debug Settings window.




**Figure 9.2 Configure Load Object File Dialogue**

A new folder, Download Modules, with the '300l\_tut.abs' file is created in the workspace window.

Download the file into the memory as follows:

- ❑ Right click on the '300l\_tut.abs' in the workspace window and select Download module.



**Figure 9.3 Download the Selected Object File**

When the file has been downloaded, the Status-window Memory Tab will show the downloaded Memory Address.


**NOTE: All the code should lie within the on-chip ROM.**

### 9.3.2. Displaying the Program Listing

HEW (Pure Debugger) for CPUBD allows user to debug a program at source level, so that a listing of the program can be seen alongside the disassembled code. To do this, user needs to read in a copy of the source program from which the object file is compiled.

- ❑ Choose *Reset CPU* from the *Debug* menu.

User will be prompted for the '*Resetprg.c*' source file corresponding to the loaded object file if HEW could not automatically locate the required file.



**Figure 9.4** Source-window "Resetprg.c"

- ❑ Run the program until Address H'0000040c (Set breakpoint at H'0000040c and select Reset Go, see section 9.4).
- ❑ Single step (see section 9.6 for Single Step) again to Jump into the 300l\_tut.c main program window

```

300l_tut.c
    "Naoko", 17, 1234,
    "Midori", 22, 8888,
    "Rie", 19, 7777,
    "Eri", 20, 9999,
    "Kyoko", 26, 3333,
    "", 0, 0
};

int count=0;
const int Dumb= 1;

void sort();

main()
0x00000800 →|
0x00000804     count = 0;
0x00000836     for ( ; ; ){
0x00000808         sort(section1, NAME);
0x00000810         count++;
0x00000816         sort(section1, AGE);
0x00000820         count++;
0x00000826         sort(section1, ID);
0x00000830         count++;
0x00000838     }
}

void sort(list, key)
struct namelist list[]:

```

Figure 9.5 Source-window "300l\_tut.c"

- ❑ If necessary, choose *Format Views...* from the *Tools* menu to select a font and size suitable for your computer.

The above source-window has its font changed to Courier New, 8-point font.

**NOTE: If change of font or size did not take place in the window, close the window and re-open the file again.**

## 9.4. Using Breakpoints

The simplest debugging aid is the program breakpoint (or PC breakpoint), it causes execution to stop when a particular point in the program is reached. You can then examine the state of the MCU and memory at that point in the program.

### 9.4.1. Setting a Program Count (PC) Breakpoint

The program window provides a very simple way of setting a program breakpoint.

For example, set a breakpoint at address H'00000808 as follows:

- Click once on the line containing address H'00000808 and right-click for the pop-up menu and select *Toggle Breakpoint* OR
- Click once on the line containing address H'00000808 and press F9.

A red dot will be displayed there to indicate that a program breakpoint is set at that address.




Figure 9.6 Setting a Breakpoint

### 9.4.2. Executing the Program

To run the program from reset:

- ❑ Choose *Reset Go* from the *Debug* menu, or click the Reset Go button in the toolbar icon.



The yellow arrow will appear on the read dot, indicating that the program is executed up to the breakpoint you have inserted.





Figure 9.7 Program Break

The message *Break = PC Break* is displayed in the status bar to show the cause of the break.

This can be viewed under Break Cause of the last break in the System Status window.

- ❑ From the View menu, choose CPU then Status, or click the Status Window button in the toolbar:




**Figure 9.8 System Status Window**

The cause of last break line shows that the break was a User PC Break.

### 9.4.3. Reviewing the Breakpoints

The list of all the breakpoints set in the program can be viewed in the Breakpoints window.

- ❑ Choose *Source Breakpoints* from the *Edit* menu, or click the Breakpoint Window button in the toolbar:




**Figure 9.9 Breakpoints Window**

The Breakpoints window also allows user to perform the following:

- Define new breakpoints
- Delete existing breakpoints
- Disable existing breakpoints

- ❑ Right-mouse click on a breakpoint in the Breakpoint-window to show the following pop-up:




**Figure 9.10 Popup in Breakpoints Window**

### 9.4.4. Examining MCU Registers

While the program is halted, you can examine the contents of the MCU registers. These are displayed in the Registers Window.

- ❑ Choose CPU: Registers from the View menu, or click the Registers Window button in the toolbar:




**Figure 9.11 CPU Registers Window**

As expected, the value of the program counter (PC) is the same as the position of the yellow arrow, H'0000808.

The registers' values can be changed from the Registers window by double-clicking on respective registers in the Registers window.

The Register-PC dialogue box allows you to edit the value.



**Figure 9.12 Changing Register Value**

## 9.5. Examining Memory and Variables

The behavior of a program can be monitored by examining the contents of an area of memory, or by displaying the values of variables used in the program.

### 9.5.1. Viewing Memory

The contents of a block of memory can be viewed in the Memory Window.

For example, to view the memory corresponding to the array section1 in ASCII:

- ❑ Choose CPU: Memory... from the View menu, or click the Memory Window button in the toolbar:



- ❑ Enter “\_section1” (a label valid only after downloading of Download Module- .abs file) in the Begin Address field and “ffff” in the End field, and keep the Format as Byte (x1).




Figure 9.13 Open Memory-window

- ❑ Click OK to open the Memory window showing the specified memory area.

Address	+0	+1	+2	+3	+4	+5	+6	+7	+8	+9	+A	+B	+C
0x0000FC00	4E	61	6F	6B	6F	00	00	00	00	11	00	00	04
0x0000FC10	64	6F	72	69	00	00	00	16	00	00	22	B8	52
0x0000FC20	00	00	00	00	00	13	00	00	1E	61	45	72	69
0x0000FC30	00	00	00	14	00	00	27	0F	4B	79	6F	6B	6F
0x0000FC40	00	1A	00	00	0D	05	00	00	00	00	00	00	00
0x0000FC50	00	00	00	00	00	00	FB	80	FF	FF	FF	FF	FF
0x0000FC60	FF												
0x0000FC70	FF												

Figure 9.14 Memory-window

Leave the Memory window open so that you can monitor the contents of the array label “\_section1”.

## 9.5.2. Watching Variables

It is useful to be able to watch the values of variables as the program is being stepped.

For example, set a watch on the structure (STRUCT) variable section1, which is declared at the beginning of the program, using the following procedure:

- ❑ Scroll up in the program window until you see the line:  
`sort(section1, ID);`
- ❑ In the Program windows, position the cursor on the word section1 and perform a right mouse button click to display a pop-up menu.
- ❑ Choose Instant Watch.

The Instant Watch dialogue box will be displayed:




Figure 9.15 Instant Watch Dialogue Box

- ❑ Click Add button to add the variable to the Watch Window.




Figure 9.16 Watch Window

A variable watch can be added to the Watch Window by specifying its name. Use this method to add a Watch on the variable 'count' as follows:

- ❑ Click with the right mouse button within the Watch window and choose Add Watch... from the pop-up menu.

The Add Watch... dialogue box appears.




Figure 9.17 Add Watch Dialogue Box

- ❑ Type the variable 'count' and click OK.

The Watch Window will show the content of the variable label 'count'.

**NOTE: You might be getting different result of 'count'.**




Figure 9.18 Watch Window

You can double-click on the '+' symbol to the left of any symbol in the Watch window to expand it and display the individual elements in the array.




Figure 9.19 Displaying Individual Elements in an Array



## 9.7. Watching Local Variables

The localised variables within a function can be viewed using the Locals Window.

For example, in order to examine the local variables in the function `sort()`, performs the following:

- ❑ Open the Locals window by choosing *Symbol: Local...* from the *View* menu or clicking the Locals Window button in the toolbar.



**NOTE: The Local Window will be empty if there is no local variable declared or local variables have not yet been entered. In another words, user target program execution should halt within a function with local variables to show any variables within Locals Window.**

In this 300l\_tut, once when the execution halts within the function `sort()`, the local variables within function `sort()` will be shown in Locals Window:

Name	Value	Type
list	0xfc00 { R0 }	{struct namelist*}
key	H'0000 { R1 }	(short)
i	Not available now.	
j	Not available now.	
k	Not available now.	
min	Not available now.	
name	0x0000 { R2 }	(char*)
worklist	{ 0xff5a }	{struct namelist}

Figure 9.21 Locals Window

- ❑ Double-click on the '+' symbol in front of the variable 'list' in the Locals window to display the individual elements of the array 'list'.

Name	Value	Type
list	0xfc00 { R0 }	{struct namelist*}
*	{ 0xfc00 }	{struct namelist}
name	"Naoko" { 0xfc00 }	(char[8])
age	H'0011 { 0xfc08 }	(short)
idcode	H'000004d2 { 0xfc0a }	(long)
key	H'0000 { R1 }	(short)
i	Not available now.	
j	Not available now.	
k	Not available now.	
min	Not available now.	

Figure 9.22 Displaying Individual Elements in an Array

## 9.8. Saves the Session

Before exiting, it is good practice to save the session so that debugging work can be resumed instantly with the same configuration at the next debugging session.

- ❑ Choose *Save Session* from the *File* menu.
- ❑ Choose *Exit* from the *File* menu to exit from HEW (Pure Debugger) for CPUBD.

## 9.9. What Next?

This 3001\_tut has introduced the key features of the CPUBD, and their use in conjunction with the HEW (Pure Debugger) for CPUBD. By combining the debugging tools provided in the CPUBD, user can perform basic debugging to trace for any hardware and software problems by identifying the conditions under which they occur.


## Section 10. Demonstration Program

There are two demonstration programs provided for user to have hands-on experience with the CPUBD in the installed directory:


- ❑ “install directory \ Tools \ Renesas \ DebugComp \ Platform \ Emulator \ Evb38004 \ Sample \ Blinking\_LED” and
- ❑ “install directory \ Tools \ Renesas \ DebugComp \ Platform \ Emulator \ Evb38004 \ Sample \ Running\_LED”

You may select to change the ON/OFF speed of the LEDs by changing the value in the delay routine.

### 10.1. Blinking LEDs




## 10.2. Running LEDs



## Section 11. Trouble-Shooting

Common Failures	Actions	Remarks
1. Wrong Settings of Jumpers and Switches	<ul style="list-style-type: none"> <li><input type="checkbox"/> Check the manual and set them accordingly.</li> </ul>	
2. Power LED off	<ul style="list-style-type: none"> <li><input type="checkbox"/> Check DC input voltage (+7.5V /+9.0V)</li> <li><input type="checkbox"/> Check output voltage of voltage-regulators (<math>\approx 3.3V</math>)</li> <li><input type="checkbox"/> Check PWR LED D1</li> </ul>	<ul style="list-style-type: none"> <li><input type="checkbox"/> If Power supply failure: measure TP1 <math>\approx 3.3V</math> (<math>\approx 5V</math> for 5V device)</li> <li><input type="checkbox"/> Regulator working?</li> <li><input type="checkbox"/> PWR LED broken?</li> </ul>
3. Unable to detect CPUBD in "USER MODE"	<ul style="list-style-type: none"> <li><input type="checkbox"/> Check J3 2-3 short?</li> <li><input type="checkbox"/> Check J13 2-3 short?</li> <li><input type="checkbox"/> No monitor program at Flash Memory</li> <li><input type="checkbox"/> Check other software using communication port?</li> <li><input type="checkbox"/> Serial cable connected to P1?</li> <li><input type="checkbox"/> Check U2 pin 12 for serial data</li> <li><input type="checkbox"/> Check Y2 (9.8304MHz) for clock oscillation?</li> </ul>	
4. Unable detect CPUBD in "BOOT MODE"	<ul style="list-style-type: none"> <li><input type="checkbox"/> Check J3 2-3 short?</li> <li><input type="checkbox"/> Check J13 1-2 short?</li> <li><input type="checkbox"/> Check other software using communication port?</li> <li><input type="checkbox"/> Serial cable connected to P1?</li> <li><input type="checkbox"/> Check U2 pin 12 for serial data</li> <li><input type="checkbox"/> Check Y2 (9.8304MHz) for clock oscillation?</li> </ul>	
5. Flashing Memory failure	<ul style="list-style-type: none"> <li><input type="checkbox"/> Time to change a new IC U1 (H8/38004F)</li> </ul>	Typical number of write cycle = 10,000 times
6. Current Overdrawn [Current draws more than 0.05 A]	<ul style="list-style-type: none"> <li><input type="checkbox"/> Identify short traces and then rework as accordingly.</li> </ul>	Measure low resistance between Vcc with respect to the ground.

Appendix A CPUBD-38004F Board layout





## Appendix B H8/38004F Memory Map

Memory Map - Monitor Code		Memory Map - H8/38004F	
H'0029	Interrupt Vector Area	H'0029	Interrupt Vector Area
H'002A	Free FLASH for User code 26Kbytes	H'002A	Free FLASH for User code 32Kbytes
H'69FF			
H'6A00			
H'7FFF	Monitor Code 6Kbytes	H'7FFF	
	Not Used		Not Used
	Internal I/O Register		Internal I/O Register
	Not Used		Not Used
	LCD RAM		LCD RAM
	Not Used		Not Used
H'F780	Internal RAM for Monitor Work Area 1 Kbytes	H'F780	Internal RAM for FLASH Programming Work Area 1Kbytes
H'FB7F		H'FB7F	
H'FB80	Internal RAM for User Code 1 Kbytes	H'FB80	Internal RAM for User code 1 Kbytes
H'FF7F		H'FF7F	
	Internal I/O Registers		Internal I/O Registers

## Appendix C Pin Assignment for JP1~JP4

OFP-64A	Descriptions	IP1		Descriptions	OFP-64A
	N.C	1	2	N.C	
	N.C	3	4	N.C	
1	PB3/IRO1*/AN3	5	6	X1	2
3	X2	7	8	AVSS	4
5	OSC2	9	10	OSC1	6
7	TEST	11	12	RES*	8
	N.C	13	14	P31/TMOFL	9
10	P32/TMOFH	15	16	P33	11
12	P34	17	18	P35	13
14	P36/AEVH	19	20	P37/AEVL	15

QFP-64A	Descriptions	JP2		Descriptions	QFP-64A
	N.C	1	2	N.C	
	N.C	3	4	N.C	
23	PA0/COM1	5	6	PA1/COM2	22
21	PA2/COM3	7	8	PA3/COM4	20
32	P70/SEG17	9	10	P71/SEG18	31
30	P72/SEG19	11	12	P73/SEG20	29
28	P74/SEG21	13	14	P75/SEG22	27
26	P76/SEG23	15	16	P77/SEG24	25
24	P80/SEG25	17	18	V3	19
17	V1	19	20	V2	18

OFP-64A	Descriptions	IP3		Descriptions	OFP-64A
34	P66/SEG15	1	2	P67/SEG16	33
36	P64/SEG13	3	4	P65/SEG14	35
38	P62/SEG11	5	6	P63/SEG12	37
40	P60/SEG9	7	8	P61/SEG10	39
42	P56/WKP6*/SEG7	9	10	P57/WKP7*/SEG8	41
44	P54/WKP4*/SEG5	11	12	P55/WKP5*/SEG6	43
46	P52/WKP2*/SEG3	13	14	P53/WKP3*/SEG4	45
48	P50/WKP0*/SEG1	15	16	P51/WKP1*/SEG2	47
	N.C	17	18	N.C	
	N.C	19	20	N.C	








OFP-64A	Descriptions	IP4		Descriptions	OFP-64A
49	P90/PWM1	1	2	P91/PWM2	50
51	P92	3	4	P93	52
53	P94	5	6	P95	54
55	VSS	7	8	IROAEC	56
57	P40/SCK32	9	10	P41/RXD32	58
59	P42/TXD32	11	12	P43/IRO0*	60
62	PB0/AN0	13	14	PB1/AN1	63
64	PB2/AN2	15	16	N.C	
61	AVCC	17	18	N.C	
	N.C	19	20	N.C	

## Appendix D Pin Assignment for CON1 & CON2

Signal Name	CON 1		Signal Name
OSC1	1	2	AVCC
GND	3	4	AVSS
X1	5	6	UVCC
GND	7	8	GND
NC	9	10	NC
NC	11	12	NC
NC	13	14	NC
NC	15	16	NC
NC	17	18	NC
NC	19	20	NC
NC	21	22	NC
NC	23	24	NC
P31/TM0FL	25	26	P30
P33	27	28	P32/TM0FH
P35	29	30	P34
P37/AEVL	31	32	P36/AEVH
RES_N	33	34	GND
IRQAEC	35	36	NC
NC	37	38	P80
NC	39	40	NC
NC	41	42	NC
NC	43	44	NC
P91/PWM2	45	46	P90/PWM1
P93	47	48	P92
P95	49	50	P94
NC	51	52	NC
PA1/COM2	53	54	PA0/COM1
PA3/COM4	55	56	PA2/COM3
NC	57	58	NC
NC	59	60	NC

Signal Name	CON 2		Signal Name
GND	1	2	GND
V1	3	4	NC
V3	5	6	V2
GND	7	8	UVCC
P41/RXD32	9	10	P40/SCK32
P43/IRQ_0	11	12	P42/TXD32
P51/SEG2	13	14	P50/SEG1
P53/SEG4	15	16	P52/SEG3
P55/SEG6	17	18	P54/SEG5
P57/SEG8	19	20	P56/SEG7
P61/SEG10	21	22	P60/SEG9
P63/SEG12	23	24	P62/SEG11
P65/SEG14	25	26	P64/SEG13
P67/SEG16	27	28	P66/SEG15
P71/SEG18	29	30	P70/SEG17
P73/SEG20	31	32	P72/SEG19
P75/SEG22	33	34	P74/SEG21
P77/SEG24	35	36	P76/SEG23
NC	37	38	NC
PB1/AN1	39	40	PB0/AN0
PB3/AN3	41	42	PB2/AN2
NC	43	44	NC
NC	45	46	NC
NC	47	48	NC
NC	49	50	NC
NC	51	52	NC
NC	53	54	NC
NC	55	56	NC
NC	57	58	NC
GND	59	60	GND

# Appendix E CPUBD-38004F Schematic Drawings



Caution! Do not change Mode when power is ON.

Hitachi Micro Systems Asia Pte Ltd - Singapore Design Centre		
Title 38004F CPU Board Version 1.1		
Size A3	Document Number <Doc>	Rev 1.1
Drawn By J.C. Kwok	Checked By	
Date: Tuesday, January 06, 2004	Sheet 1 of 1	

## Appendix F Bill of Materials

Items	Designator					P/N Code	Part Description	Qty	Package	Mfg
<b>A) Board H8/38024F</b>										
1						AA-02129-2	PCB CPU Board Ver 1.1	1		AVS
2	C10	C11				CA-70121-6	Capacitor SMD 0805 12pF / 50V	2	0805	Panasonic
3	C8	C9				CA-70151-6	Capacitor SMD 0805 15pF / 50V	2	0805	Panasonic
4	C2					CA-73101-3	Capacitor SMD 0805 10nF / 50V	1	0805	AVX /
5	C4	C6	C16	C17		CA-74101-3	Capacitor SMD 0805 100nF / 50V	4	0805	AVX /
6	C1	C5				CE-14105-1	Capacitor Ele GSS-R 10uF/50V	2	thru-hole	Rubycon / any
7	C7	C12	C13	C14	C15	CE-15105-1	Capacitor Ele GSS-R 1uF/50V	5	thru-hole	Rubycon / any
8	C3					CE-16105-1	Capacitor Ele GSS-R 10uF/50V	1	thru-hole	Rubycon / any
9	D2					DZ-45503-9	Diode Zener BZV55C3V9 1/2W	1	thru-hole	Philips Semi
10	J2					KH-20103-1	Header Pin 0.100" 1x3-Way	1	thru-hole	AUK
11	JP8	JP9	JP10			KH-20153-1	Header Pin 0.100" 2x3-Way	3	thru-hole	AUK
12	JP1	JP2	JP3	JP4		KH-20160-1	Header Pin 0.100" 2x10-Way	4	thru-hole	AUK
13	J2(2-3)	JP8(1-3)	JP8(2-4)	JP9(3-5)		KH-22004-0	0.100" Micro Shunt JH6	7	thru-hole	AUK
14	JP9(4-6)	JP10(3-5)	JP10(4-6)							
15	J1					KP-99501-0	Connector DC Jack 2.1mm PCB Mt	1	thru-hole	AUK
16	P1					KS-60309-0	Connector D-Sub Female 9-Way RA	1	thru-hole	AUK
17	D1					LE-03121-0	LED 3mm Green Diffused	1	thru-hole	MIC
18	D3	D4	D5			LE-03321-0	LED 3mm Red Diffused	3	thru-hole	MIC
19	Q1					QB-02847-1	Transistor BC847B	1	SOT23	Philips Semi
20	R2	R6	R7	R8		RA-63222-0	Resistor SMD 1206 1/4W 2% 220R	4	1206	any
21	R3					RA-66102-0	Resistor SMD 1206 1/4W 2% 100K	1	1206	any
22	R4					RA-67102-0	Resistor SMD 1206 1/4W 2% 1M	1	1206	any
23	R1					RA-73471-0	Resistor SMD 2010 1/2W 1% 470R	1	2010	any
24	R5					RL-00941-0	Resistor Netwk-A SIL 1/8W 5% 10Kx9-Pin	1	thru-hole	Toma Resistor
25	S1					SP-10011-0	Switch Tactile Round	1	thru-hole	KIE / any
26	U2					UF-53232-0	IC SP3232ECT RS232 Driver /Receiver	1	SO 150	Sipex
27	Y1					XC-05181-0	Crystal 32.7680 KHz Cylinder 2x6	1	thru-hole	TSC
28	Y2					XC-06709-0	Crystal 9.8304 MHZ HC49/U-S	1	thru-hole	TSC
29							Anti-Static Bag	1		any
30							Label for Serial Number	1		any
31						***	IC H8/38024 FZTAT, FP-	1	FP-80A	Hitachi
<b>B) Packaging</b>										
32						BA-61007-0	Rubber Foot Stick On SJ5008	4		3M
33						BZ-00053-0	Box RSC ST-04	1		
34	JP7					KH-20157-1	Header Pin 0.100" 2x7-Way	1		
35	CON1	CON2				KH-27180-0	Connector PCB Mt 0.100" 2x30-	2		
36							Anti-Static Bag for Accessories	6		
37							Bubble Foam	1		
38							Checking List Form	1		
39							Label for Carton Box	1		
40							Manual in CR-ROM format w/Label &	1		
<b>C) Optional Items</b>										
41						WL-64004-0	Supply Cable Assembly Rev 1.0	1		
42						WL-64004-1	Serial Cable M/M 9-Way	1		

# Renesas Technology (Asia Sales Offices)

URL: <http://www.renesas.com>

URL: <http://www.sg.renesas.com/sales>

<b>ASIA HEADQUARTERS &amp; TECHNICAL SUPPORT :</b>	
<p><b>South Asia Headquarters : Singapore</b>  <a href="#">Renesas Technology Singapore Pte. Ltd.</a>            1, HarbourFront Avenue,            #06-10, Keppel Bay Tower,            Singapore 098632.            Tel : (65)-6213-0200            Fax : (65)-6278-8001            Email : <a href="mailto:contact.singapore@renesas.com">contact.singapore@renesas.com</a></p>	<p><b>Technical Support</b>  <a href="#">Renesas System Solutions Asia Pte. Ltd.</a>            1, Harbourfront Avenue,            #06-06, Keppel Bay Tower,            Singapore 098632.            Tel : (65)-6213-0333 and 6387-2839            Fax : (65)-6278-1226</p>
<p><b>North Asia Headquarters : Hong Kong</b>  <a href="#">Renesas Technology Hong Kong Ltd.</a>            7/F., North Tower, World Finance Centre,            Harbour City, Canton Road,            Hong Kong.            Tel: (852) 2265-6688            Fax: (852) 2375-6836            Email : <a href="mailto:contact.hongkong@renesas.com">contact.hongkong@renesas.com</a></p>	
<b>ASIA SALES OFFICES :</b>	
<b>China</b>	
<p><b>Renesas Technology Hong Kong Ltd</b>            Shenzhen Representative Office            Unit 1511-12, Shun Hing Square Di Wang Commercial Centre,            5002 Shennan Road East, Shenzhen City 518008, China            Tel : (86) (755) 8246-1711            Fax : (86) (755) 8246-1728            Email : <a href="mailto:contact.china@renesas.com">contact.china@renesas.com</a>            URL : <a href="http://www.cn.renesas.com">http://www.cn.renesas.com</a></p>	
<p><b>Renesas Technology (Shanghai) Co., Ltd.</b>            26/F., Ruijin Building,            No. 205 Maoming Road (S),            Shanghai 200020, China            Tel : (86) (21) 6472-1001            Fax : (86) (21) 6415-2952            Email : <a href="mailto:contact.china@renesas.com">contact.china@renesas.com</a>            URL : <a href="http://www.cn.renesas.com">http://www.cn.renesas.com</a></p>	
<p><b>Renesas Technology (Shanghai) Co., Ltd. Beijing Office</b>            Room 1654, Office Building, New Century Hotel,            No. 6 Southern Rd. Capital GYM.,            Beijing 100044, China            Telex : 210509 HTCBJ CN            Tel : (86) (10) 6849-2430            Fax : (86) (10) 6849-2819            Email : <a href="mailto:contact.china@renesas.com">contact.china@renesas.com</a>            URL : <a href="http://www.cn.renesas.com">http://www.cn.renesas.com</a></p>	
<b>Taipei</b>	
<p>Renesas Technology Taiwan Co., Ltd.            (effective July 1, 2003)            FL. 10, #99, Fu-Hsing N. Rd., Taipei, Taiwan            Tel : (886)(2) 2715-2888            Fax : (886)(2) 2713-2999            Email : <a href="mailto:contact.taiwan@renesas.com">contact.taiwan@renesas.com</a>            URL : <a href="http://www.tw.renesas.com">http://www.tw.renesas.com</a></p>	



CPUBD-38004

