

To our customers,

---

## Old Company Name in Catalogs and Other Documents

---

On April 1<sup>st</sup>, 2010, NEC Electronics Corporation merged with Renesas Technology Corporation, and Renesas Electronics Corporation took over all the business of both companies. Therefore, although the old company name remains in this document, it is a valid Renesas Electronics document. We appreciate your understanding.

Renesas Electronics website: <http://www.renesas.com>

April 1<sup>st</sup>, 2010  
Renesas Electronics Corporation

Issued by: Renesas Electronics Corporation (<http://www.renesas.com>)

Send any inquiries to <http://www.renesas.com/inquiry>.

## Notice

1. All information included in this document is current as of the date this document is issued. Such information, however, is subject to change without any prior notice. Before purchasing or using any Renesas Electronics products listed herein, please confirm the latest product information with a Renesas Electronics sales office. Also, please pay regular and careful attention to additional and different information to be disclosed by Renesas Electronics such as that disclosed through our website.
2. Renesas Electronics does not assume any liability for infringement of patents, copyrights, or other intellectual property rights of third parties by or arising from the use of Renesas Electronics products or technical information described in this document. No license, express, implied or otherwise, is granted hereby under any patents, copyrights or other intellectual property rights of Renesas Electronics or others.
3. You should not alter, modify, copy, or otherwise misappropriate any Renesas Electronics product, whether in whole or in part.
4. Descriptions of circuits, software and other related information in this document are provided only to illustrate the operation of semiconductor products and application examples. You are fully responsible for the incorporation of these circuits, software, and information in the design of your equipment. Renesas Electronics assumes no responsibility for any losses incurred by you or third parties arising from the use of these circuits, software, or information.
5. When exporting the products or technology described in this document, you should comply with the applicable export control laws and regulations and follow the procedures required by such laws and regulations. You should not use Renesas Electronics products or the technology described in this document for any purpose relating to military applications or use by the military, including but not limited to the development of weapons of mass destruction. Renesas Electronics products and technology may not be used for or incorporated into any products or systems whose manufacture, use, or sale is prohibited under any applicable domestic or foreign laws or regulations.
6. Renesas Electronics has used reasonable care in preparing the information included in this document, but Renesas Electronics does not warrant that such information is error free. Renesas Electronics assumes no liability whatsoever for any damages incurred by you resulting from errors in or omissions from the information included herein.
7. Renesas Electronics products are classified according to the following three quality grades: “Standard”, “High Quality”, and “Specific”. The recommended applications for each Renesas Electronics product depends on the product’s quality grade, as indicated below. You must check the quality grade of each Renesas Electronics product before using it in a particular application. You may not use any Renesas Electronics product for any application categorized as “Specific” without the prior written consent of Renesas Electronics. Further, you may not use any Renesas Electronics product for any application for which it is not intended without the prior written consent of Renesas Electronics. Renesas Electronics shall not be in any way liable for any damages or losses incurred by you or third parties arising from the use of any Renesas Electronics product for an application categorized as “Specific” or for which the product is not intended where you have failed to obtain the prior written consent of Renesas Electronics. The quality grade of each Renesas Electronics product is “Standard” unless otherwise expressly specified in a Renesas Electronics data sheets or data books, etc.
  - “Standard”: Computers; office equipment; communications equipment; test and measurement equipment; audio and visual equipment; home electronic appliances; machine tools; personal electronic equipment; and industrial robots.
  - “High Quality”: Transportation equipment (automobiles, trains, ships, etc.); traffic control systems; anti-disaster systems; anti-crime systems; safety equipment; and medical equipment not specifically designed for life support.
  - “Specific”: Aircraft; aerospace equipment; submersible repeaters; nuclear reactor control systems; medical equipment or systems for life support (e.g. artificial life support devices or systems), surgical implantations, or healthcare intervention (e.g. excision, etc.), and any other applications or purposes that pose a direct threat to human life.
8. You should use the Renesas Electronics products described in this document within the range specified by Renesas Electronics, especially with respect to the maximum rating, operating supply voltage range, movement power voltage range, heat radiation characteristics, installation and other product characteristics. Renesas Electronics shall have no liability for malfunctions or damages arising out of the use of Renesas Electronics products beyond such specified ranges.
9. Although Renesas Electronics endeavors to improve the quality and reliability of its products, semiconductor products have specific characteristics such as the occurrence of failure at a certain rate and malfunctions under certain use conditions. Further, Renesas Electronics products are not subject to radiation resistance design. Please be sure to implement safety measures to guard them against the possibility of physical injury, and injury or damage caused by fire in the event of the failure of a Renesas Electronics product, such as safety design for hardware and software including but not limited to redundancy, fire control and malfunction prevention, appropriate treatment for aging degradation or any other appropriate measures. Because the evaluation of microcomputer software alone is very difficult, please evaluate the safety of the final products or system manufactured by you.
10. Please contact a Renesas Electronics sales office for details as to environmental matters such as the environmental compatibility of each Renesas Electronics product. Please use Renesas Electronics products in compliance with all applicable laws and regulations that regulate the inclusion or use of controlled substances, including without limitation, the EU RoHS Directive. Renesas Electronics assumes no liability for damages or losses occurring as a result of your noncompliance with applicable laws and regulations.
11. This document may not be reproduced or duplicated, in any form, in whole or in part, without prior written consent of Renesas Electronics.
12. Please contact a Renesas Electronics sales office if you have any questions regarding the information contained in this document or Renesas Electronics products, or if you have any other inquiries.

(Note 1) “Renesas Electronics” as used in this document means Renesas Electronics Corporation and also includes its majority-owned subsidiaries.

(Note 2) “Renesas Electronics product(s)” means any product developed or manufactured by or for Renesas Electronics.

---

## SH7080 Series

### Synchronous Serial Communication Unit Master Transmission (Writing to EEPROM)

---

#### Introduction

This application note describes master transmission using the SSU (Synchronous Serial communication Unit) module. It is intended as reference material to help in the design of user software.

#### Target Device

SH7086

#### Contents

1. Specifications .....	2
2. Applicable Conditions .....	3
3. Descriptions of Functions Used .....	4
4. Description of Operation .....	6
5. Description of Software .....	9
6. Flowcharts.....	16
7. Documents for Reference.....	22


### 1. Specifications

In this application note, the synchronous serial communication unit is used to write 10-bytes of data to a 4-wire serial-transmission type EEPROM (HN58X2564I, 64K bits, 8K words × 8bit).

- The SH7086 is used as the master device in a single-master configuration.
- PE12 (general input/output port) of the SH7086 is used as the chip select pin for the EEPROM\*.
- 10 bytes of data at the address of the EEPROM from H'0000 to H'0009 are written.
- The data transfer clock (synchronization clock) is set to 2.5MHz.
- For writing data into the EEPROM, the synchronous serial communication unit is set to transmission operation.

Figure 1 shows an example of connection between the SH7086 and the EEPROM. Table 1 shows the module settings of the synchronous serial communication unit. Table 2 lists the EEPROM instruction codes used in this sample application.

Note: \* The synchronous serial communication unit enables the SCS pin for each frame.  
When one or more frames is transmitted or received, the SCS pin is used as general output.



**Figure 1 Example of Connection between the SH7086 and EEPROM**

**Table 1 Synchronous Serial Communication Unit Settings**

Format	Settings
Operating mode	<ul style="list-style-type: none"> <li>• Select master mode.</li> <li>• Select synchronous serial communication mode.</li> </ul>
Data input/output pin	Normal (two data input/output pins used for communication)
Transfer clock	2.5 MHz (P <sub>φ</sub> = 40 MHz)
Number of data bits	8-bit data length
MSB/LSB first	MSB first
Timing for setting the TEND bit	The TEND bit is set after the final bit is transmitted.

**Table 2 EEPROM instruction codes**

Code Name	Operation	Code [B']
WREN	Sets the EEPROM as writable.	0000 0110
WRDI	Sets the EEPROM as non-writable.	0000 0100
RDSR	Reads the EEPROM Status Register.	0000 0101
WRSR	Writes the EEPROM Status Register.	0000 0001
READ	Reads stored data.	0000 0011
WRITE	Writes data.	0000 0010

## 2. Applicable Conditions

Table 3 shows the applicable conditions for this sample application.

**Table 3 Applicable Conditions**

Item	Setting
Device	SH7086 (R5F70865)
Operating frequency	Internal clock: $I\phi = 80$ MHz Bus clock: $B\phi = 40$ MHz Peripheral clock: $P\phi = 40$ MHz MTU2 clock: $MP\phi = 40$ MHz MTU2S clock: $MI\phi = 80$ MHz
Device operating mode	Single-chip mode
Development environment	High-performance Embedded Workshop Version 4.03.00.001 SuperH RISC engine Standard Toolchain (V.9.1.1.0) SuperH RISC engine C/C++ Compiler (V.9.01.01) (Manufactured by Renesas Technology)
C compiler option	High-performance Embedded Workshop default setting -cpu=sh2 -include="\$(WORKSPDIR)\inc" -debug -gbr=auto -chgincpath -errorpath -global_volatile=0 -opt_range=all -infinite_loop=0 -del_vacant_loop=0 -struct_alloc=1 -nologo

### 3. Descriptions of Functions Used

An overview of the SSU (Synchronous Serial communication Unit) functions used in this sample application is given below.

#### 3.1 Synchronous Serial Communication Unit

For synchronous serial communication, the SSU has a master mode in which this LSI outputs the clocks signal as the master device and a slave mode in which the clock signal is input from an external device. Synchronous serial communications between devices with different clock polarity and phase are possible.

Figure 2 shows a block diagram of the SSU module.




Figure 2 Block Diagram of the SSU Module

- SS Control Register H (SSCRH) selects the master or slave mode, selects the input/output pin mode, selects the SSO pin output value, and selects the SCS pin function.
- SS Control Register L (SSCRL) selects the operating mode, software reset, and the transmit/receive data length.
- The SS Mode Register (SSMR) selects MSB first or LSB first, the clock polarity, the clock phase, and the transfer clock rate.
- The SS Enable Register (SSER) enables and disables transmission, reception, and interrupts requests.
- The SS Status Register (SSSR) handles the status flags for various interrupts.
- SS Control Register 2 (SSCR2) is used to set open drain output for the SSO pin, SSI pin, SSCK pin, and SCS pin, the timing for assertion of the SCS signal, the timing for output of data from the SSO pin, and the timing for setting of the TEND bit.
- SS Transmit Data Registers 0 to 3 (SSTDR0 to 3) are 8-bit registers used to store data for transmission.
- SS Receive Data Registers 0 to 3 (SSRDR0 to 3) are 8-bit registers used to store received data.
- The SS Shift Register (SSTRSR) is used to transmit/receive serial data.

Note: For details on each register function, see the sections related to the synchronous serial communication unit in the SH7080 Group Hardware Manual.

## 4. Description of Operation

In this sample application, simultaneous transmission and reception operation in the SSU mode is applied to write data from the EEPROM.


### 4.1 Writing Data from an EEPROM

Data can be write from the EEPROM. According to the following procedure.

- Transmit the write-enable code (WREN) to the EEPROM
- Transmit the write code (WRITE) to the EEPROM
- Transmit the write start address to the EEPROM
- Transmit the write data to the EEPROM


Figure 3 shows the details of transfer to read data out from the EEPROM.

When data is written to the EEPROM, the WREN code must be transmitted to the EEPROM to set the WEN bit of the EEPROM status register to 1. After the write operation to the EEPROM, the WEN bit of the EEPROM status register is cleared to 0, and the data is stored in the EEPROM.



**Figure 3 Details of Transfer to Write Data from the EEPROM**

Figure 4 illustrates how data is write from the EEPROM. The software and hardware processing is described in table 4.



**Figure 4 Processing to Write Data**

**Table 4 Description of Software and Hardware Processing**

	<b>Software Processing</b>	<b>Hardware Processing</b>
Process (1)	<ul style="list-style-type: none"> <li>• Set PE12 low (output). (EEPROM selected).</li> <li>• Set data for transmission (instruction code) in SSTDR0 .</li> </ul>	<ul style="list-style-type: none"> <li>• Setting data for transmission in SSTDR0 clears the TDRE bit to 0.</li> </ul>
Process (2)	<ul style="list-style-type: none"> <li>• Confirm TDRE = 1, and set data for transmission in the SSTDR register.</li> </ul>	<ul style="list-style-type: none"> <li>• Transfer data from the SSTDR0 register to the SSTRSR register.</li> <li>• Transmit the data in the SSTRSR register SSTDR. then set the TDRE bit to 1.</li> <li>• Setting data for transmission in the SSTDR register clears the TDRE bit to 0.</li> </ul>
Process (3)	<ul style="list-style-type: none"> <li>• Set PE12 high (output); (EEPROM deselected)</li> <li>• Clear the TEND bit to 0.</li> <li>• Clear the TE bit to 0 to disable transmit operation.</li> </ul>	<ul style="list-style-type: none"> <li>• After the last bit is transmitted with TDRE = 1, set the TEND bit to 1.</li> </ul>

## 5. Description of Software

### 5.1 Description of Modules

The modules used in this sample applications are described in Table 5.

**Table 5 Description of Modules**

Module Name	Label Name	Description
Main function	main()	Sets the operating frequency, sets the address to start writing from, calls the SSU initialization function, and calls the EEPROM data-write function.
SSU initialization function	init_ssu()	Release the SSU from module standby mode, sets the pin function controller (PFC), and sets the SSU.
EEPROM-data writing function	write_EEPROM()	Writes data from the EEPROM.
Instruction code setting function	set_inst_code()	Sets an instruction code in the EEPROM Status Register.
EEPROM addressing function	set_addr_EEPROM()	Sets the write start address in the EEPROM.

### 5.2 Variables Used

The variables used in this sample application are described in Table 6.

**Table 6 Variables**

Variable, Label Name	Description	Used In
write_data[0-9]	Array for storing write data	Main function
address	EEPROM address where writing starts	Main function
addr	Copy of the EEPROM address where reading starts	EEPROM-data writing function EEPROM addressing function
*r_data	Pointer variable to the array where the write data are stored	EEPROM-data writing function
num	Number of data for transmission	EEPROM-data writing function
count	Transmitted-data counter	EEPROM-data writing function
code	Instruction code	Instruction code setting function

### 5.3 Settings of Registers

This section describes the settings of registers used in this sample application. Note that the settings presented below are for this sample application and are not the initial values.

#### 5.3.1 Register for Setting the Clock Pulse Generator (CPG)

##### 1. Frequency Control Register (FRQCR)

This register specifies the division ratio of the frequency.

Setting: H'0241

Bit	Bit Name	Value	Function
15	—	0	Reserved
14 to 12	IFC[2-0]	000	Internal Clock (I $\phi$ ) Frequency Division Ratio 000: $\times 1$ , 80 MHz when the input clock is 10 MHz
11 to 9	BFC[2-0]	001	Bus Clock (B $\phi$ ) Frequency Division Ratio 001: $\times 1/2$ , 40 MHz when the input clock is 10 MHz
8 to 6	PFC[2-0]	001	Peripheral Clock (P $\phi$ ) Frequency Division Ratio 001: $\times 1/2$ , 40 MHz when the input clock is 10 MHz
5 to 3	MIFC[2-0]	000	MTU2S Clock (MI $\phi$ ) Frequency Division Ratio 000: $\times 1$ , 80 MHz when the input clock is 10 MHz
2 to 0	MPFC[2-0]	001	MTU2 Clock (MP $\phi$ ) Frequency Division Ratio 001: $\times 1/2$ , 40 MHz when the input clock is 10 MHz

#### 5.3.2 Setting the Power-Down Mode

##### 1. Standby Control Register 3 (STBCR3)

This register controls the operation of individual modules in the power-down mode.

Setting: H'FB

Bit	Bit Name	Value	Function
7	MSTP15	1	1: Stops clock supply to I <sup>2</sup> C2.
6	MSTP14	1	1: Stops clock supply to SCIF.
5	MSTP13	1	1: Stops clock supply to SCI_2.
4	MSTP12	1	1: Stops clock supply to SCI_1.
3	MSTP11	1	1: Stops clock supply to SCI_0.
2	MSTP10	0	0: SSU is operational.
1 to 0	—	11	Reserved

### 5.3.3 Registers for Setting the Synchronous Serial Communication Unit

#### 1. SS Control Register H (SSCRH)

This register selects the master or slave mode and sets the SCS pin function.

Setting: H'8F

Bit	Bit Name	Value	Function
7	MSS	1	0: Master mode
6	BIDE	0	0: Normal mode (two input/output pins used for communication)
5	—	0	Reserved
4	SOL	0	0: Changes the serial data output to a low level.
3	SOLP	1	SOL write-protect When SOL bit is changed, the SOLP is set to 1.
2	—	1	Reserved
1 to 0	CSS[1-0]	11	11: The $\overline{\text{SCS}}$ pin is used with the automatic output function.

- SS Control Register L (SSCRL)

This register selects the operating mode, software reset, and data length.

Setting: H'80

Bit	Bit Name	Value	Function
7	FCLRM	1	1: Clears the interrupt flag when the register is accessed.
6	SSUMS	0	0: SSU mode
5	SRES	0	Setting 1 forcibly resets the SSU internally.
4 to 2	—	0	Reserved
1 to 0	DATS[1-0]	00	00: 8-bit data length

- SS Mode Register (SSMR)

This register selects MSB-first and the transfer clock rate.

Setting: H'83

Bit	Bit Name	Value	Function
7	MLS	1	1: MSB first
6	CPOS	0	0: Outputs high from the SSCK pin in the idle state and low in the active state.
5	CPHS	0	0: Changes the data at the first edge on the SSCK pin.
4 to 3	—	0	Reserved
2 to 0	CKS[2-0]	011	011: Transfer clock = $P\phi/16$ ( $P\phi = 40$ MHz)

- **SS Enable Register (SSER)**  
This register enables transmit/receive operation.  
Setting: H'CO

Bit	Bit Name	Value	Function
7	TE	1	1: Enables transmission operation
6	RE	1	1: Enables reception operation.
5 to 4	—	0	Reserved
3	TEIE	0	0: Disables SSTEI interrupts.
2	TIE	0	0: Disables SSTXI interrupts.
1	RIE	0	0: Disables SSRXI and SSOEI interrupts.
0	CEIE	0	0: Disables SSCEI interrupts.

- **SS Status Register (SSSR)**  
SSSR is a status flag register for interrupts.  
Setting: H'04

Bit	Bit Name	Value	Function
7	—	0	Reserved
6	ORER	0	Overrun error
5 to 4	—	0	Reserved
3	TEND	0	Transmission end
2	TDRE	1	Transmit data empty
1	RDRF	0	Receive data register full
0	CE	0	Conflict error/incomplete error

Note: For clearing conditions of the individual flags, see the hardware manual.

- **SS Control Register 2 (SSCR2)**  
This register selects the timing for setting the TEND bit.  
Setting: H'10

Bit	Bit Name	Value	Function
7 to 5	—	000	Reserved
4	TENDSTS	1	1: Sets the TEND bit after transmission of the last bit.
3	SCSATS	0	Selects the timing for asserting the SCS signal*.
2	SSODTS	0	Selects the timing for outputting data from the SSO pin*.
1 to 0	—	00	Reserved

Note: \* See the hardware manual for details.

- **SS Transmit Data Register 0 (SSTDR0)\***  
This register is an 8-bit register that stores data for transmission.  
Setting: H'00 (initial value)

Note: \* Since the data length is 8 bits, SSTDR1 to SSTDR3 are not used.

- SS Receive Data Register 0 (SSRDR0)\*  
This is an 8-bit register that stores received data.  
Setting: H'00 (initial value)

Note: \* Since the data length is 8 bits, SSRDR1 to 3 are not used.

### 5.3.4 Registers for Setting the Pin Function Controller (PFC)

#### 1. Port E Control Register L4 (PECRL4)

This register selects the functions of multiplexed pins of port E (PE15-PE12).

Setting: H'0000

Bit	Bit Name	Value	Function
15	—	0	Reserved
14 to 12	PE15MD[2-0]	000	000: Sets the pin function to PE15 (general input/output).
11	—	0	Reserved
10 to 8	PE14MD[2-0]	000	000: Sets the pin function to PE14 (general input/output).
7 to 6	—	00	Reserved
5 to 4	PE13MD[1-0]	00	00: Sets the pin function to PE13 (general input/output).
3	—	0	Reserved
2 to 0	PE12MD[2-0]	000	000: Sets the pin function to PE12 (general input/output).

#### • Port E Control Register L3 (PECRL3)

This register selects the functions of multiplexed pins of port E (PE11-PE8).

Setting: H'0505

Bit	Bit Name	Value	Function
15	—	0	Reserved
14 to 12	PE11MD[2-0]	000	000: Sets the pin function to PE11 (general input/output).
11	—	0	Reserved
10 to 8	PE10MD[2-0]	101	101: Sets the pin function to SSO (SSU data input/output).
7	—	0	Reserved
6 to 4	PE9MD[2-0]	000	000: Sets the pin function to PE10 (general input/output).
3	—	0	Reserved
2 to 0	PE8MD[2-0]	101	101: Sets the pin function to SSCK (SSU clock input/output).

- Port E Control Register L2 (PECRL2)

This register selects the functions of multiplexed pins of port E (PE7-PE4).

Setting: H'5000

Bit	Bit Name	Value	Function
15	—	0	Reserved
14 to 12	PE7MD[1-0]	101	101: Sets the pin function to SSI (SSU data input/output).
11	—	0	Reserved
10 to 8	PE6MD[3-0]	000	000: Sets the pin function to PE6 (general input/output).
7	—	0	Reserved
6 to 4	PE5MD[3-0]	000	000: Sets the pin function to PE5 (general input/output).
3	—	0	Reserved
2 to 0	PE4MD[3-0]	000	000: Sets the pin function to PE4 (general input/output).

- Port E I/O Register L (PEIORL)

This register selects the functions of multiplexed pins of port E (PE7-PE4).

Setting: H'5000

Bit	Bit Name	Value	Function
15	PE15IOR	0	0: Input
14	PE14IOR	0	0: Input
13	PE13IOR	0	0: Input
12	PE12IOR	1	1: Output ( $\overline{\text{SCS}}$ is used as a general input/output port)
11	PE11IOR	0	0: Input
10	PE10IOR	0	0: Input
9	PE9IOR	0	0: Input
8	PE8IOR	0	0: Input
7	PE7IOR	0	0: Input
6	PE6IOR	0	0: Input
5	PE5IOR	0	0: Input
4	PE4IOR	0	0: Input
3	PE3IOR	0	0: Input
2	PE2IOR	0	0: Input
1	PE1IOR	0	0: Input
0	PE0IOR	0	0: Input

### 5.3.5 Setting the I/O Port

#### 1. Port E Data Register L (PEDRL)

This register stores port E data.


Setting: H'1000

Bit	Bit Name	Value	Function
15	PE15DR	0	0: The port state is low level.
14	PE14DR	0	0: The port state is low level.
13	PE13DR	0	0: The port state is low level.
12	PE12DR	1	0: The EEPROM is selected. 1: The EEPROM is deselected.
11	PE11DR	0	0: The port state is low level.
10	PE10DR	0	0: The port state is low level.
9	PE9DR	0	0: The port state is low level.
8	PE8DR	0	0: The port state is low level.
7	PE7DR	0	0: The port state is low level.
6	PE6DR	0	0: The port state is low level.
5	PE5DR	0	0: The port state is low level.
4	PE4DR	0	0: The port state is low level.
3	PE3DR	0	0: The port state is low level.
2	PE2DR	0	0: The port state is low level.
1	PE1DR	0	0: The port state is low level.
0	PE0DR	0	0: The port state is low level.

## 6. Flowcharts

Figure 5 to figure 10 show flows of processing to read data from the EEPROM.

### 6.1 Main Function



**Figure 5 Main Function Processing**

### 6.2 SSU Initialization Function




Figure 6 SSU Initialization Processing

### 6.3 EEPROM-Data Writing Function





Figure 7 Processing for EEPROM-Data Reading (1)



**Figure 8 Processing for EEPROM-Data Reading (2)**

### 6.4 EEPROM Instruction Code Setting Function





Figure 9 Processing for EEPROM Instruction Code Setting

## 6.5 EEPROM Addressing Function



**Figure 10 Processing for EEPROM Addressing**

## 7. Documents for Reference

- Software Manual  
SH-1/SH-2/SH-DSP Software Manual  
The most up-to-date version of this document is available on the Renesas Technology Website.
- Hardware Manual  
SH7080 Group Hardware Manual  
The most up-to-date version of this document is available on the Renesas Technology Website.

## Website and Support

Renesas Technology Website

<http://www.renesas.com/>

Inquiries

<http://www.renesas.com/inquiry>

[csc@renesas.com](mailto:csc@renesas.com)

## Revision Record

Rev.	Date	Description	
		Page	Summary
1.00	Feb.18.08	—	First edition issued

All trademarks and registered trademarks are the property of their respective owners.

### Notes regarding these materials

1. This document is provided for reference purposes only so that Renesas customers may select the appropriate Renesas products for their use. Renesas neither makes warranties or representations with respect to the accuracy or completeness of the information contained in this document nor grants any license to any intellectual property rights or any other rights of Renesas or any third party with respect to the information in this document.
2. Renesas shall have no liability for damages or infringement of any intellectual property or other rights arising out of the use of any information in this document, including, but not limited to, product data, diagrams, charts, programs, algorithms, and application circuit examples.
3. You should not use the products or the technology described in this document for the purpose of military applications such as the development of weapons of mass destruction or for the purpose of any other military use. When exporting the products or technology described herein, you should follow the applicable export control laws and regulations, and procedures required by such laws and regulations.
4. All information included in this document such as product data, diagrams, charts, programs, algorithms, and application circuit examples, is current as of the date this document is issued. Such information, however, is subject to change without any prior notice. Before purchasing or using any Renesas products listed in this document, please confirm the latest product information with a Renesas sales office. Also, please pay regular and careful attention to additional and different information to be disclosed by Renesas such as that disclosed through our website. (<http://www.renesas.com>)
5. Renesas has used reasonable care in compiling the information included in this document, but Renesas assumes no liability whatsoever for any damages incurred as a result of errors or omissions in the information included in this document.
6. When using or otherwise relying on the information in this document, you should evaluate the information in light of the total system before deciding about the applicability of such information to the intended application. Renesas makes no representations, warranties or guaranties regarding the suitability of its products for any particular application and specifically disclaims any liability arising out of the application and use of the information in this document or Renesas products.
7. With the exception of products specified by Renesas as suitable for automobile applications, Renesas products are not designed, manufactured or tested for applications or otherwise in systems the failure or malfunction of which may cause a direct threat to human life or create a risk of human injury or which require especially high quality and reliability such as safety systems, or equipment or systems for transportation and traffic, healthcare, combustion control, aerospace and aeronautics, nuclear power, or undersea communication transmission. If you are considering the use of our products for such purposes, please contact a Renesas sales office beforehand. Renesas shall have no liability for damages arising out of the uses set forth above.
8. Notwithstanding the preceding paragraph, you should not use Renesas products for the purposes listed below:
  - (1) artificial life support devices or systems
  - (2) surgical implantations
  - (3) healthcare intervention (e.g., excision, administration of medication, etc.)
  - (4) any other purposes that pose a direct threat to human life
 Renesas shall have no liability for damages arising out of the uses set forth in the above and purchasers who elect to use Renesas products in any of the foregoing applications shall indemnify and hold harmless Renesas Technology Corp., its affiliated companies and their officers, directors, and employees against any and all damages arising out of such applications.
9. You should use the products described herein within the range specified by Renesas, especially with respect to the maximum rating, operating supply voltage range, movement power voltage range, heat radiation characteristics, installation and other product characteristics. Renesas shall have no liability for malfunctions or damages arising out of the use of Renesas products beyond such specified ranges.
10. Although Renesas endeavors to improve the quality and reliability of its products, IC products have specific characteristics such as the occurrence of failure at a certain rate and malfunctions under certain use conditions. Please be sure to implement safety measures to guard against the possibility of physical injury, and injury or damage caused by fire in the event of the failure of a Renesas product, such as safety design for hardware and software including but not limited to redundancy, fire control and malfunction prevention, appropriate treatment for aging degradation or any other applicable measures. Among others, since the evaluation of microcomputer software alone is very difficult, please evaluate the safety of the final products or system manufactured by you.
11. In case Renesas products listed in this document are detached from the products to which the Renesas products are attached or affixed, the risk of accident such as swallowing by infants and small children is very high. You should implement safety measures so that Renesas products may not be easily detached from your products. Renesas shall have no liability for damages arising out of such detachment.
12. This document may not be reproduced or duplicated, in any form, in whole or in part, without prior written approval from Renesas.
13. Please contact a Renesas sales office if you have any questions regarding the information contained in this document, Renesas semiconductor products, or if you have any other inquiries.