

RENESAS TOOL NEWS on January 16, 2014: 140116/tn8

Note on Using Emulator Software with E200F Emulator R0E0200F1EMU00

When using the Emulator Software with the E200F Emulator R0E0200F1EMU00, take note of the problem described below.

1. Product and Versions Concerned

Emulator Software for the E200F Emulator R0E0200F1EMU00
V.1.00 Release 00 through V.3.01 Release 00

2. Description

After acquisition of trace information is stopped on the Trace window during program execution, acquisition cannot be resumed.

3. Condition

This problem occurs when the Reset Go is selected (Shift + F5 keys are pressed) to start program execution through the product concerned.

4. Workaround

To resume trace acquisition after stopping it on the Trace window during program execution, do not use the Reset Go (Shift + F5 keys) to start program execution; reset the CPU and then select the Go (press F5 key).

5. Schedule for Fixing the Problem

We have no plan to fix this problem for the Emulator Software with the E200F Emulator R0E0200F1EMU00.

[Disclaimer]

The past news contents have been based on information at the time of publication. Now changed or invalid information may be included. The URLs in the Tool News also may be subject to change or become invalid without prior notice.

