

To our customers,

Old Company Name in Catalogs and Other Documents

On April 1st, 2010, NEC Electronics Corporation merged with Renesas Technology Corporation, and Renesas Electronics Corporation took over all the business of both companies. Therefore, although the old company name remains in this document, it is a valid Renesas Electronics document. We appreciate your understanding.

Renesas Electronics website: <http://www.renesas.com>

April 1st, 2010
Renesas Electronics Corporation

Issued by: Renesas Electronics Corporation (<http://www.renesas.com>)

Send any inquiries to <http://www.renesas.com/inquiry>.

Notice

1. All information included in this document is current as of the date this document is issued. Such information, however, is subject to change without any prior notice. Before purchasing or using any Renesas Electronics products listed herein, please confirm the latest product information with a Renesas Electronics sales office. Also, please pay regular and careful attention to additional and different information to be disclosed by Renesas Electronics such as that disclosed through our website.
2. Renesas Electronics does not assume any liability for infringement of patents, copyrights, or other intellectual property rights of third parties by or arising from the use of Renesas Electronics products or technical information described in this document. No license, express, implied or otherwise, is granted hereby under any patents, copyrights or other intellectual property rights of Renesas Electronics or others.
3. You should not alter, modify, copy, or otherwise misappropriate any Renesas Electronics product, whether in whole or in part.
4. Descriptions of circuits, software and other related information in this document are provided only to illustrate the operation of semiconductor products and application examples. You are fully responsible for the incorporation of these circuits, software, and information in the design of your equipment. Renesas Electronics assumes no responsibility for any losses incurred by you or third parties arising from the use of these circuits, software, or information.
5. When exporting the products or technology described in this document, you should comply with the applicable export control laws and regulations and follow the procedures required by such laws and regulations. You should not use Renesas Electronics products or the technology described in this document for any purpose relating to military applications or use by the military, including but not limited to the development of weapons of mass destruction. Renesas Electronics products and technology may not be used for or incorporated into any products or systems whose manufacture, use, or sale is prohibited under any applicable domestic or foreign laws or regulations.
6. Renesas Electronics has used reasonable care in preparing the information included in this document, but Renesas Electronics does not warrant that such information is error free. Renesas Electronics assumes no liability whatsoever for any damages incurred by you resulting from errors in or omissions from the information included herein.
7. Renesas Electronics products are classified according to the following three quality grades: “Standard”, “High Quality”, and “Specific”. The recommended applications for each Renesas Electronics product depends on the product’s quality grade, as indicated below. You must check the quality grade of each Renesas Electronics product before using it in a particular application. You may not use any Renesas Electronics product for any application categorized as “Specific” without the prior written consent of Renesas Electronics. Further, you may not use any Renesas Electronics product for any application for which it is not intended without the prior written consent of Renesas Electronics. Renesas Electronics shall not be in any way liable for any damages or losses incurred by you or third parties arising from the use of any Renesas Electronics product for an application categorized as “Specific” or for which the product is not intended where you have failed to obtain the prior written consent of Renesas Electronics. The quality grade of each Renesas Electronics product is “Standard” unless otherwise expressly specified in a Renesas Electronics data sheets or data books, etc.
 - “Standard”: Computers; office equipment; communications equipment; test and measurement equipment; audio and visual equipment; home electronic appliances; machine tools; personal electronic equipment; and industrial robots.
 - “High Quality”: Transportation equipment (automobiles, trains, ships, etc.); traffic control systems; anti-disaster systems; anti-crime systems; safety equipment; and medical equipment not specifically designed for life support.
 - “Specific”: Aircraft; aerospace equipment; submersible repeaters; nuclear reactor control systems; medical equipment or systems for life support (e.g. artificial life support devices or systems), surgical implantations, or healthcare intervention (e.g. excision, etc.), and any other applications or purposes that pose a direct threat to human life.
8. You should use the Renesas Electronics products described in this document within the range specified by Renesas Electronics, especially with respect to the maximum rating, operating supply voltage range, movement power voltage range, heat radiation characteristics, installation and other product characteristics. Renesas Electronics shall have no liability for malfunctions or damages arising out of the use of Renesas Electronics products beyond such specified ranges.
9. Although Renesas Electronics endeavors to improve the quality and reliability of its products, semiconductor products have specific characteristics such as the occurrence of failure at a certain rate and malfunctions under certain use conditions. Further, Renesas Electronics products are not subject to radiation resistance design. Please be sure to implement safety measures to guard them against the possibility of physical injury, and injury or damage caused by fire in the event of the failure of a Renesas Electronics product, such as safety design for hardware and software including but not limited to redundancy, fire control and malfunction prevention, appropriate treatment for aging degradation or any other appropriate measures. Because the evaluation of microcomputer software alone is very difficult, please evaluate the safety of the final products or system manufactured by you.
10. Please contact a Renesas Electronics sales office for details as to environmental matters such as the environmental compatibility of each Renesas Electronics product. Please use Renesas Electronics products in compliance with all applicable laws and regulations that regulate the inclusion or use of controlled substances, including without limitation, the EU RoHS Directive. Renesas Electronics assumes no liability for damages or losses occurring as a result of your noncompliance with applicable laws and regulations.
11. This document may not be reproduced or duplicated, in any form, in whole or in part, without prior written consent of Renesas Electronics.
12. Please contact a Renesas Electronics sales office if you have any questions regarding the information contained in this document or Renesas Electronics products, or if you have any other inquiries.

(Note 1) “Renesas Electronics” as used in this document means Renesas Electronics Corporation and also includes its majority-owned subsidiaries.

(Note 2) “Renesas Electronics product(s)” means any product developed or manufactured by or for Renesas Electronics.

∞

H8/300L Series User System Interface Cable
For H8/300L Series Low-Cost Emulator

Microcomputer Development Environment System

User's Manual

2003.4

H8/300L Series User System Interface Cable
QFP 80A-Pin
(SD01AC38024F80A)

H8/38024 series

ALE300L-H8/3800 Emulator

**H8/300L Series User System Interface Cable
User's Manual**

Published by : Renesas System Solutions Asia Pte. Ltd.

Date : April 1st, 2003, Version 1.0

Copyright (C) Renesas System Solutions Asia Pte. Ltd. All rights reserved.

Trademarks

(a) General

All brand or product names used in this manual are trademarks or registered trademarks of their respective companies or organizations.

IMPORTANT INFORMATION

- **READ this user's manual before using this emulator product.**
- **KEEP the user's manual handy for future reference.**

Do not attempt to use the emulator product until you fully understand its mechanism.

Emulator Product:

Throughout this document, the term 'emulator product' shall be defined as the following products produced only by Renesas System Solutions Asia Pte. Ltd.:

- Emulation system (SD00ALE3800)
- User system interface cable (SD01AC38024F80A)
- User system interface cable (SD01AC38024T80C)

The user system or a host computer is not included in this definition.

Purpose of the User System Interface Cable:

This user system interface cable is for connection between the emulator station and the user system. This user system interface cable must only be used for the above purpose.

Improvement Policy:

Renesas System Solutions Asia Pte. Ltd. (hereafter collectively referred to as Renesas) pursues a policy of continuing improvement in design, performance, and safety of the emulator product. Renesas reserves the right to change, wholly or partially, the specifications, design, user's manual, and other documentation at any time without notice.

Target User of the Emulator Product:

Those who have carefully read and thoroughly understood the information and restrictions contained in the user's manual should only use this emulator product. Do not attempt to use the emulator product until you fully understand its mechanism.

It is highly recommended that users that are well versed in the operation of emulator product instruct first-time users.

LIMITED WARRANTY

Renesas warrants its emulator products to be manufactured in accordance with published specifications and free from defects in material and/or workmanship. Renesas, at its option, will repair or replace any emulator products returned intact to the factory, transportation charges prepaid, which Renesas, upon inspection, shall determine to be defective in material and/or workmanship. The foregoing shall constitute the sole remedy for any breach of Renesas warranty. This warranty extends only to you, the original Purchaser. It is not transferable to anyone who subsequently purchases the emulator product from you. Renesas is not liable for any claim made by a third party or made by you for a third party.

DISCLAIMER

RENESAS MAKES NO WARRANTIES, EITHER EXPRESS OR IMPLIED, ORAL OR WRITTEN, EXCEPT AS PROVIDED HEREIN, INCLUDING WITHOUT LIMITATION THEREOF, WARRANTIES AS TO MARKETABILITY, MERCHANTABILITY, FITNESS FOR ANY PARTICULAR PURPOSE OR USE, OR AGAINST INFRINGEMENT OF ANY PATENT. IN NO EVENT SHALL RENESAS BE LIABLE FOR ANY DIRECT, INCIDENTAL OR CONSEQUENTIAL DAMAGES OF ANY NATURE, OR LOSSES OR EXPENSES RESULTING FROM ANY DEFECTIVE EMULATOR PRODUCT, THE USE OF ANY EMULATOR PRODUCT OR ITS DOCUMENTATION, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGES. EXCEPT AS EXPRESSLY STATED OTHERWISE IN THIS WARRANTY, THIS EMULATOR PRODUCT IS SOLD "AS IS". AND YOU MUST ASSUME ALL RISK FOR THE USE AND RESULTS OBTAINED FROM THE EMULATOR PRODUCT.

State Law:

Some states do not allow the exclusion or limitation of implied warranty or liability for incidental or consequential damages, so the above limitation or exclusion may not apply to you. This warranty gives you specific legal rights, and you may have other rights which may vary from state to state.

The Warranty is Void in the Following Cases:

Renesas shall have no liability or legal responsibility for any problems caused by misuse, abuse, misapplication, neglect, improper handling, installation, repair or modifications of the emulator product without Renesas's prior written consent or any problems caused by the user system.

All Right Reserved:

This user's manual and emulator product are copyrighted and Renesas reserves all rights. No part of this user's manual, all or part, may be reproduced or duplicated in any form, in hardcopy or machine-readable form, by any means available without Renesas's prior written consent.

Other Important Things to Keep in Mind:

1. Circuitry and other examples described herein are meant merely to indicate the characteristics and performance of Renesas Technology's semiconductor products. Renesas assumes no responsibility for any intellectual property claims or other problems that may result from applications based on the examples described herein.
2. No license is granted by implication or otherwise under any patents or other rights of any third party or Renesas.
3. **MEDICAL APPLICATIONS:** Renesas Technology's products are not authorized for use in **MEDICAL APPLICATIONS** without the written consent of the appropriate officer of Renesas Technology (Asia Sales company). Such use includes, but is not limited to, use in life support systems. Buyers of Renesas Technology's products are requested to notify the relevant Renesas Technology (Asia Sales offices) when planning to use the products in **MEDICAL APPLICATIONS**.

Figures:

Some figures in this user's manual may show items different from your actual system.

Limited Anticipation of Danger:

Renesas cannot anticipate every possible circumstance that might involve a potential hazard. The warnings in this user's manual and on the emulator product are therefore not all inclusive. Therefore, you must use the emulator product safely at your own risk.

! WARNING

Observe the precautions listed below. Failure to do so will result in a FIRE HAZARD and will damage the user system and the emulator product or will result in PERSONAL INJURY. The USER PROGRAM will be LOST.

- Always switch OFF the emulator product and the user system before connecting or disconnecting any cables, the user system interface cable connector, and the user system IC socket.
- When connecting the user system interface cable connector to the user system IC socket, ensure those pins 1 on both sides are correctly aligned.

Table of Contents

SECTION 1. INTRODUCTION.....	1-1
1.1 GENERAL DESCRIPTION	1-1
1.2 IC SOCKET TYPE	1-1
1.3 CONFIGURATION	1-1
1.4 COMPONENTS	1-2
SECTION 2. CONNECTION PROCEDURES.....	2-1
2.1 CONNECTING USER SYSTEM INTERFACE CABLE TO ALE300L EMULATOR.....	2-1
2.2 CONNECTING USER SYSTEM INTERFACE CABLE TO USER SYSTEM.....	2-2
2.2.1 <i>Soldering IC Socket</i>	2-2
2.2.2 <i>Connecting the MAIN BOARD AND SUB BOARD to user system</i>	2-2
SECTION 3. DIMENSIONS FOR USER SYSTEM CABLE HEAD.....	3-1
SECTION 4. INSTALLING MCU TO THE USER SYSTEM.....	4-1
SECTION 5. WARNINGS.....	5-1
RENESAS TECHNOLOGY (ASIA SALES OFFICES)	

List of Figures

Figure 1.0	Main Board and QFP 80 SUB Board.....	1-1
Figure 2.1	Connect User System Interface Cable to ALE300L Emulator.....	2-1
Figure 2.2	Connecting user system interface cable to user system	2-3
Figure 3.1	PCB footprint of YAMAICHI IC socket.....	3-1
Figure 3.2	User system interface cable head - Main board	3-2
Figure 3.3	User system interface cable head - QFP 80 SUB board	3-2
Figure 3.4	Connecting user system interface cable to user system	3-3
Figure 4.1	Installing MCU to user system.....	4-1

Section 1. Introduction

1.1 General description

The user system interface cable connects an 8-bit ALE Emulator (ALE300L-H8/3800) to the IC socket for a QFP 80A-pin package (Package code: QFP-80A) for the H8/38024 series MCU on the user system.

1.2 IC socket type

The IC socket used on the user system is manufactured by YAMAICHI ELECTRONICS Co., Ltd.). The part number for the QFP-80A pin package IC socket is given below:

- IC149-080-017-S5 [Tin-plated]
- IC149-080-017-B5 [Gold-plated]

1.3 Configuration




Figure 1.0 Main Board and QFP 80 SUB Board

1.4 Components

No.	Component	Quantity	Remarks
1	Main board	1	
2	QFP 80 SUB BOARD	1	With IC PCB Footprint
3	IC socket	1	For QFP 80-pin package (QFP-80A)
4	Socket cover	1	For installing the MCU
5	Screws (M2x4.5)	4	For fastening SUB board to the socket (with four flat washers)
6	Screws (M3x4.5)	1	For fastening SUB board to the main board

Section 2. Connection Procedures


WARNING: Always switch OFF the user system and the emulator product before the USER SYSTEM INTERFACE CABLE is connected to or removed from either of the boards. Before connecting, make sure that pin 1 on both sides is correctly aligned. Failure to do so will result in a FIRE HAZARD and will damage the user system and the emulator product or will result in PERSONAL INJURY. The USER PROGRAM will be lost.

2.1 Connecting User System Interface Cable to ALE300L Emulator

To connect the cable body to the emulator, follow the instructions below:

- Make sure the user system and emulator are powered off.
- Open the cover at the bottom of the emulator.
- Align the connectors of the cable body with those on the emulator according to the specified number.
- Insert the connectors of the cable body to those found on the emulator until they are locked. Refer to figure 2.1.

Figure 2.1 Connect User System Interface Cable to ALE300L Emulator



1. Align pin 1 indicated by a chamfered edge of the SUB board to IC socket on the user system.
2. Install SUB board to the socket with tightened screws.
3. Align the chamfered edge of the SUB board to the chamfered edge of the Main board
4. Install the SUB board to the Main board with tightened screws.
5. Connect the user cable header to the ALE300L Emulator using the cable provided.

2.2 Connecting User System Interface Cable to User System


2.2.1 Soldering IC Socket

- Apply epoxy resin adhesive to the corner guides and bottom face of an IC socket for the QFP-80A pin package and fasten it to the user system.

2.2.2 Connecting the MAIN BOARD AND SUB BOARD to user system


- Align pin 1 on the IC socket with pin 1 on the QFP80 SUB BOARD, and insert the QFP80 SUB BOARD into the IC socket on the user system as shown in figure 2.2.
- Fasten the QFP80 SUB BOARD to the IC socket on the user system with the four screws provided. Note... *Make sure to use the short screws supplied with the user cable and NOT the screws supplied with the YAMAICHI socket otherwise the target board may be damaged.* Each screw should be tightened a little at a time, alternating between screws on opposite corners. Use special care to prevent the soldered IC socket from being damaged by over-tightening the screws or twisting the components.
- Align the MAIN BOARD on top of the QFP 80 SUB BOARD by using the pin 1 arrow (and PCB chamfer) of the MAINBOARD to the pin 1 arrow of the QFP 80 SUB BOARD. Line up the hole in the center of the MAIN BOARD with the standoff on the QFP 80 SUB BOARD. There is only a single way whereby the boards can be connected together as the connectors are polarized.
- After they are aligned, gently push them together.
- Fix the whole assembly with the M3 screw. This provides good mechanical strength for the system.
- Attach the ribbon cables to the emulator ensuring they are oriented correctly. Pls. note the labeling for each connector and insert accordingly.
- Place the ribbon cables into the main board make sure they are seated in a secured manner.
- Note... The target cable assembly is relying on the integrity of the QFP solder joints, which could break or fracture if stressed. Therefore it is important to make sure the user cable header assembly and cable assembly is not twisted. It is also a good idea to support the cables to prevent the user cable header assembly from dipping.
- Orient the emulator and work area to allow a proper lay-out of the cables between the emulator and the target system.
- The system can now be powered up by conventional means.

Figure 2.2 Connecting user system interface cable to user system



Section 3. Dimensions for User System Cable Head

The dimensions for the recommended mount pad(footprint) for the user system shown in figure 3.1 for the IC socket used on a QFP-80A-pin package (manufactured by YAMAICHI ELECTRONICS Co., Ltd.



Dimension for IC Socket Adapter IC149-080-017-S5 / IC149-080-017-B5
(pitch size: 0.35 ± 0.10 or 0.05 mm) unit: mm

Figure 3.1 PCB footprint of YAMAICHI IC socket

The dimensions of the Main board of the user system interface cable head is shown in figure 3.2.




Figure 3.2 User system interface cable head - Main board

The dimensions of the QFP 80 SUB board of the user system interface cable head is shown in figure 3.3.




Figure 3.3 User system interface cable head - QFP 80 SUB board

Below shows the dimension after connecting to User System Interface Cable to the user system.




Figure 3.4 Connecting user system interface cable to user system

Section 4. Installing MCU to the User System

- Check the location of pin 1 before inserting the MCU into the IC socket on the user system as shown in figure 4.1.
- After inserting the MCU, fasten the socket cover with the four screws provided.
- Take special care, such as manually securing the IC socket soldered area, to prevent the soldered IC socket from being damaged by over-tightening the screws or twisting the component.




Figure 4.1 Installing MCU to user system


Section 5. Warnings

- Make sure that pin 1 on the IC socket is correctly aligned with pin 1 on the QFP 80 SUB board of the user cable header before inserting the QFP 80 SUB board into the IC socket on the user system.
- Do not apply excessive force to the user system interface cable while it is connected to the user system.
- This user system interface cable is specifically designed for the ALE300L-H8/3800 emulator. Do not use this cable with any other emulator.
- This user system interface cable can be operated with an external crystal oscillator installed onto the user system. The clock signal is buffered and with a propagation delay of 6nsec (max.)

Renesas Technology (Asia Sales Offices)

URL: <http://www.renesas.com>

H8/300L Series User System Interface Cable



Renesas System Solutions Asia Pte. Ltd.